


SERVICE MANUAL

<i>MODEL</i>	<i>DEST.</i>	<i>CHASSIS NO.</i>	<i>MODEL</i>	<i>DEST.</i>
VPH-G90U	US/CND	SCC-K81D-A	RM-PJ1001	World
VPH-G90E	AEP	SCC-K82E-A	PSS-90	World
VPH-G90M	E	SCC-N96A-A	IFB-G90E	AEP



MULTISCAN PROJECTOR

SONY

⚠ WARNING

This manual is intended for qualified service personnel only.

To reduce the risk of electric shock, fire or injury, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so. Refer all servicing to qualified service personnel.

WARNING!!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS.

THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK Δ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

ATTENTION!!

AFIN D'EVITER TOUT RISQUE D'ELECTROCUTION PROVENANT D'UN CHÂSSIS SOUS TENSION, UN TRANSFORMATEUR D'ISOLEMENT DOIT ETRE UTILISÉ LORS DE TOUT DÉPANNAGE. LE CHÂSSIS DE CE RÉCEPTEUR EST DIRECTEMENT RACCORDÉ À L'ALIMENTATION SECTEUR.

ATTENTION AUX COMPOSANTS RELATIFS À LA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET PAR UNE MARQUE Δ SUR LES SCHÉMAS DE PRINCIPE, LES VUES EXPLOSÉES ET LES LISTES DE PIÈCES CONT D'UNE IMPORTANCE CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT. NE LES REMPLACER QUE PAR DES COMPOSANTS SONY DONT LE NUMÉRO DE PIÈCE EST INDiqué DANS LE PRÉSENT MANUEL OU DANS DES SUPPLÉMENTS PUBLIÉS PAR SONY. LES RÉGLAGES DE CIRCUIT DONT L'IMPORTANCE EST CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT SONT IDENTIFIÉS DANS LE PRÉSENT MANUEL. SUIVRE CES PROCÉDURES LORS DE CHAQUE REMPLACEMENT DE COMPOSANTS CRITIQUES, OU LORSQU'UN MAUVAIS FONCTIONNEMENT EST SUSPECTÉ.

TABLE OF CONTENTS

1. OPERATING INSTRUCTIONS

Operation Instruction	1-1
Installation Manual for Dealers	1-33

2. SERVICE INFORMATION

2-1. CIRCUIT BOARDS LOCATION	2-1
2-1-1. Location 1	2-1
2-1-2. Location 2	2-1
2-1-3. Location 3	2-2
2-2. DISASSEMBLY	2-3
2-2-1. Hood Removal	2-3
2-2-2. Cover Removal	2-4
2-2-3. Opening ED Block	2-5
2-2-4. DC Board Removal	2-5
2-2-5. EC Board Removal	2-6
2-2-6. ED Board Removal	2-7
2-2-7. E Board Removal	2-7
2-2-8. Remote Commander Removal	2-8
2-2-9. CB, CG and CR Blocks Removal	2-9
2-2-10. DA, DB, DD, DE and DF Boards Removal	2-10
2-2-11. EBH and EBQ Boards Removal	2-10
2-2-12. HVB Block and High-voltage Cable Removal	2-11
2-2-13. DC Fan Removal	2-12
2-2-14. PA and PD Boards Removal	2-12
2-2-15. MD Board Removal	2-13
2-2-16. HVF Block Removal	2-14
2-2-17. BA and YA Boards Removal	2-15
2-2-18. BC, F and ME Boards Removal	2-16
2-2-19. EBB, EBG, EBR and PE Boards Removal	2-17
2-2-20. GA and GB Boards Removal	2-18
2-2-21. Lens Removal	2-18
2-2-22. (1) Picture Tube Removal	2-19
2-2-22. (2) Picture Tube Installation	2-20
2-2-23. MA, MB and MC Boards Removal	2-21
2-2-24. M Board Removal	2-23
2-2-25. Extension Board	2-24
2-3. ERROR CODE	2-25
2-3-1. Warning Code on 7-Segment LED	2-25
2-3-2. Protector Code on 7-Segment LED	2-26
2-3-3. Error Code on 7-Segment LED	2-27
2-4. MEMORY ACCESS SYSTEM	2-28
2-4-1. Memory Structure	2-28
2-4-2. Various Memory Data	2-29
2-5. MEMORY DATA RESET	2-50

3. SET-UP ADJUSTMENTS

3-1. PRECAUTIONS UPON ADJUSTMENT	3-1
3-2. ATTACHING THE NECK ASSEMBLY	3-1
3-3. ADJUSTING CONDITIONS	3-1
3-3-1. Projecting System	3-1
3-3-2. CRT Convergence Angle Check	3-2
3-4. FOCUS ADJUSTMENT	3-3
3-4-1. Preparations	3-3
3-4-2. Focus Rough Adjustment	3-3
3-4-3. DY Angle Adjustment	3-4
3-4-4. MG FOCUS Coil Angle Adjustment	3-5
3-4-5. 64 kHz Signal Registration Rough Adjustment	3-6
3-4-6. RED/GREEN/BLUE Focus Adjustment	3-7
3-4-7. Zenith Angle Adjustment	3-8
3-4-8. HWC (H Width Coil) Adjustment	3-9
3-4-9. Video Size Adjustment	3-9
3-4-10. MG FOCUS Adjustment for 31.5 kHz Signal	3-10
3-4-11. VIDEO Block MG FOCUS Adjustment	3-11
3-4-12. MG FOCUS Adjustment for 64 kHz and 106 kHz Signals	3-11
3-4-13. Adjustment of Other Frequencies	3-11
3-5. REGISTRATION ADJUSTMENT	3-12
3-5-1. INPUT MEMORY No. 0 Adjustment	3-12
3-5-2. INPUT MEMORY No. 3 Adjustment	3-13
3-5-3. INPUT MEMORY No. 5 Adjustment	3-13
3-5-4. INPUT MEMORY No. 8 Adjustment	3-14
3-5-5. Horizontal/Vertical Reverse Mode Centering Adjustment	3-14
3-6. WHITE BALANCE ADJUSTMENT	3-15
3-6-1. Preparations	3-15
3-6-2. Color Temperature Adjustment with a Test Signal Generator	3-16
3-6-3. Color Temperature Adjustment with No Test Signal Generator	3-18
3-7. SIZE/SHIFT BLKG ADJUSTMENT	3-18
3-7-1. SIZE/SHIFT/BLKG of Video/HDTV Adjustment	3-18
3-7-2. Video Memory SIZE/SHIFT/BLKG Adjustments	3-19
3-8. HIGH VOLTAGE SCREEN DISTORTION ADJUSTMENT	3-19
3-9. PROCEDURE AFTER COMPLETING ADJUSTMENTS	3-19

4. SAFETY RELATED ADJUSTMENT

4-1. PA BOARD HV REGULATOR/HV PROTECTOR ADJUSTMENT	4-1
4-2. CRT PROTECTOR ADJUSTMENT	4-2

5. CIRCUIT ADJUSTMENTS

5-1. POWER BLOCK	5-1
5-1-1. DC (+) Adjustment	5-1
5-1-2. +115 V Adjustment	5-1
5-1-3. +200 V Adjustment	5-1
5-1-4. Oscillating Frequency Adjustment	5-1
5-2. BA BOARD ADJUSTMENT	5-2
5-2-1. Picture Control Adjustment	5-2
5-2-2. Signal Level Adjustment	5-2
5-2-3. Analog Test Signal Amplitude Adjustment	5-3
5-2-4. ABL Adjustment	5-3
5-3. CAR/CAG/CAB BOARDS ADJUSTMENT	5-3
5-3-1. Preparation Before Adjustments	5-3
5-3-2. Pedestal Level Adjustment	5-3
5-3-3. CRT Protector Adjustment	5-3
5-3-4. Cathode Level Adjustment	5-4
5-3-5. G1 Level Adjustment	5-4
5-3-6. VPS Limiter Adjustment	5-5
5-4. DA/DB/DD BOARDS ADJUSTMENTS	5-5
5-4-1. F/V Voltage Adjustment (DA Board)	5-5
5-4-2. AFC Adjustment (DA Board)	5-5
5-4-3. V Hold Adjustment (DA Board)	5-5
5-4-4. H Parabola Waveform Adjustment (DA Board)	5-6
5-4-5. H SIN Adjustment (DA Board)	5-6
5-4-6. H SIN × VP Waveform Adjustment (DB Board)	5-6
5-4-7. H SIN × V SIN Waveform Adjustment (DB Board)	5-7
5-4-8. HS × VS Waveform Adjustment (DB Board)	5-7
5-4-9. HP × V SIN Waveform Adjustment (DB Board)	5-7
5-4-10. 1/2 SIN1 Waveform Adjustment (DB Board)	5-7
5-4-11. 1/2 SIN2 Waveform Adjustment (DB Board)	5-7
5-4-12. HS × VS Waveform Adjustment (DB Board)	5-8
5-4-13. HP × VS Waveform Adjustment (DB Board)	5-8
5-4-14. B KEY Waveform Adjustment (DB Board)	5-8
5-4-15. T KEY Waveform Adjustment (DB Board)	5-8
5-4-16. 1/2H Switching Waveform Adjustment (DA/DB Boards)	5-8
5-4-17. D/A Converter Offset Adjustment (DD Board)	5-8
5-5. VCO OFFSET/LIMITER ADJUSTMENT	5-9
5-6. YA BOARD REPLACEMENT	5-9
5-6-1. Replacement Procedure	5-9
5-6-2. Uploading Program (Emergency Mode)	5-10
5-6-3. Creating Factory Data	5-10
5-6-4. Creating Service Data	5-11

6. SEMICONDUCTORS

7. EXPLODED VIEWS

7-1. HOOD AND COVER BLOCK	7-2
7-2. ED BLOCK	7-4
7-3. HVF BLOCK	7-6
7-4. CHASSIS BLOCK 1	7-7
7-5. REAR BLOCK	7-8
7-6. PICTURE TUBE BLOCK	7-10
7-7. CHASSIS BLOCK 2	7-12
7-8. BASE BLOCK	7-18

8. ELECTRICAL PARTS LIST

Note:

IFB-G90E corresponds to the BD BOARD.

9. BLOCK DIAGRAMS

BA (1/3)	9-2
BA (2/3)	9-3
BD (Except VPH-G90E)	9-3
BA (3/3)	9-4
BB	9-5
BC	9-6
YA (1/4)	9-7
YA (2/4)	9-8
YA (3/4)	9-9
YB	9-9
YA (4/4)	9-10
DA	9-11
DB	9-12
DC	9-13
NA	9-13
DD (1/2)	9-14
DD (2/2)	9-15
DE (1/2)	9-16
DE (2/2)	9-17
DF	9-18
F	9-19
GA	9-19
GAA	9-19
GB	9-19
GBA	9-19
GBB	9-19
GC	9-19

L	9-19
ME	9-19
E	9-20
EA	9-20
ED	9-20
EBH	9-21
EBQ	9-21
EBR	9-22
EBG	9-22
EBB	9-22
PA	9-23
PB	9-23
MD	9-24
NB	9-24
PD	9-24
PE	9-25
CAR	9-26
CAG	9-26
CAB	9-26
CBR	9-26
CBG	9-26
CBB	9-26
CDR	9-26
CDG	9-26
CDB	9-26

10. DIAGRAMS

10-1. FRAME SCHEMATIC DIAGRAMS	10-2
10-2. SCHEMATIC DIAGRAMS/PRINTED WIRING BOARDS	10-13
SCHEMATIC DIAGRAMS	
BD	10-13
BA	10-19
BB	10-40
BC	10-47
YA	10-52
YB	10-63
DA	10-67
DB	10-73
NA	10-78
DC	10-79
DD	10-83
DE	10-89
DF	10-95
L	10-99
E	10-103
ED	10-105
EA	10-107
PA	10-110

PB	10-113
PD	10-115
NB	10-115
PE	10-117
EBA	10-119
EBC	10-119
EBB	10-121
EBG	10-123
EBR	10-125
EBH	10-127
EBQ	10-129
CAB	10-132
CBB	10-135
CDB	10-137
CAG	10-140
CBG	10-143
CDG	10-145
CAR	10-148
CBR	10-151
CDR	10-153
F	10-155
GA	10-158
GAA	10-159
GB	10-162
GBA	10-165
GBB	10-167
GC	10-169
M	10-172
MA	10-176
MB	10-178
MC	10-179
MD	10-180
EC	10-181
ME	10-182
PRINTED WIRING BOARDS	
BD	10-13
BA	10-14
BB	10-39
BC	10-46
YA	10-48
YB	10-63
DA	10-64
DB	10-70
DC	10-76
NA	10-78
DD	10-80
DE	10-86
DF	10-92
L	10-99
E	10-100

ED	10-104
EA	10-106
PA	10-108
PB	10-113
PD	10-114
NB	10-114
PE	10-116
EBA	10-118
EBC	10-118
EBB	10-120
EBG	10-122
EBR	10-124
EBH	10-126
EBQ	10-128
CAB	10-130
CBB	10-135
CDB	10-136
CAG	10-138
CBG	10-143
CDG	10-144
CAR	10-146
CBR	10-151
CDR	10-152
F	10-154
GA	10-156
GAA	10-159
GB	10-160
GBA	10-164
GBB	10-166
GC	10-168
M	10-170
MA	10-175
MB	10-178
MC	10-179
MD	10-180
EC	10-181
ME	10-182

SONY.

3-865-265-11 (2)

Multiscan Projector

Operating Instructions

SECTION 1 OPERATING INSTRUCTIONS

This section is extracted
from operating instructions.


**VPH-G90E
VPH-G90M
VPH-G90U**

© 1998 by Sony Corporation

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



For the customers in the USA

Note
This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Warning
You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

AVERTISSEMENT

Afin d'éviter tout risque d'incendie et d'électrocution, ne pas exposer l'appareil à la pluie ou à l'humidité.

Pour éviter tout risque de décharge électrique, ne pas ouvrir le boîtier. Confiez l'entretien uniquement à un personnel qualifié.

Pour les utilisateurs au Canada
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

La prise doit être près de l'appareil et facile d'accès.

ACHTUNG

Um Feuergefahr und die Gefahr eines elektrischen Schlagens zu vermeiden, darf das Gerät weder Regen noch Feuchtigkeit ausgesetzt werden.

Im Gerätinneren befinden sich Teile, die unter gefährlich hoher Spannung stehen. Das Gehäuse darf nicht geöffnet werden. Überlassen Sie die Wartung nur geschultem Fachpersonal.

Für Kunden in Deutschland
Dieses Produkt kann im kommerziellen und in begrenztem Maße auch im industriellen Bereich eingesetzt werden. Dies ist eine Einrichtung, welche die Funk-Entstörung nach Klasse B besitzt.

Die Steckdose muß nahe bei diesem Gerät angebracht und leicht zugänglich sein.

ADVERTENCIA

Para prevenir el riesgo de incendios o de electrocución, no exponga la unidad a la lluvia ni a la humedad.

Para evitar descargas eléctricas, no abra la unidad. En caso de avería, solicite el servicio de personal cualificado únicamente.

ATTENZIONE

Per evitare il pericolo di incendi o scosse elettriche, non esporre l'apparecchio alla pioggia o all'umidità e non aprirlo.

Per eventuali riparazioni, rivolgersi esclusivamente a personale qualificato.



STAATL. GEWERBEAUFSICHTSAMT STUTTGART
Zentrale Stelle für die Vollzugsüberwachung (ZSV)

Sony International (Europe) GmbH
Stuttgart Technology Center
Stuttgarter Straße 106
70736 Fellbach

Stuttgart, den 13.07.1998
Durchwahl: 1869-638
AktENZEICHEN: ZSV 4677.21 Bm
Bearbeiter: Herr Böhm

Zulassungsschein Nr. BW/505/98/Rö

Gemäß § 10 der Röntgenverordnung vom 08.01.1987 (HGBl. I S. 114) wird die Zulassung der Bauart durch den Bauartzulassungsbescheid vom 13.07.1998 für den nachfolgend aufgeführten Störstrahler bescheinigt:

Gegenstand : Multiscan Projector
Firmenbezeichnung : Sony Typ VPH-G90.
Projektionsröhren : Hersteller: Panasonic
Type: P19LQF60RJA
P19LQF60HKA
P19LQF60RMB

Betriebsbedingungen : Hochspannung max. 33,3 kV
Strahlstrom 3,6 mA

Hersteller (Produktionsstätte) : 1. Sony INC
Quality Control Department
Ichinomiya, Aichi-Prefecture, Japan
2. SDC-DSX (Display System Manufacturing)
Quality Assurance Department
San Diego, California, USA

Befristung : bis 13.07.2008



Für den Strahlenschutz wesentliche Merkmale:

1. Die Art und Qualität der Projektionsröhren,
2. die der Hochspannungserzeugung und -stabilisierung dienenden Bauelemente.

Kronenstr. 39, 70174 Stuttgart Postfach 101743, 70015 Stuttgart Telefon 0711/1869-0 Telefax 0711/1869-630

Blatt 2 zum Bescheid vom 13.07.1998
Zulassungsschein - Kennzeichen: BW/505/98/Rö

Auflagen:

1. Die Multiscan Projectoren sind einer Stückprüfung daraufhin zu unterziehen, ob sie bezüglich der für den Strahlenschutz wesentlichen Merkmale der Bauartzulassung entsprechen.

Die Prüfung muß umfassen:

- a) Kontrolle der Hochspannung an jedem einzelnen Gerät,
- b) Messung der Dosisleistung nach Festlegung im Bauartzulassungsbescheid.

2. Jedem Erwerber eines Multiscan Projectors ist ein Abdruck des Zulassungsscheins auszuhandigen, auf dem das Ergebnis der Stückprüfung (Maßgabe 1) bestätigt und die Hersteller Nummer angegeben sein muß.

3. Die Multiscan Projectoren sind deutlich sichtbar und dauerhaft mit dem Kennzeichen

BW/505/98/Rö

zu versehen, sowie mit einem Hinweis folgenden Mindestinhaltes:
"Die in diesem Gerät entstehende Röntgenstrahlung ist ausreichend abgeschirmt."


Beschleunigungsspannung maximal 33,3 kV".

4. Jedem Multiscan Projector ist eine Betriebsanleitung beizufügen, in der insbesondere auf die dem Strahlenschutz dienenden Maßnahmen hingewiesen wird.

Hinweis für den Benutzer des Gerätes:

Unsachgemäße Eingriffe, insbesondere verändern der Hochspannung oder Auswechseln der Bildröhren können dazu führen, daß Röntgenstrahlung in erheblicher Stärke auftritt. Ein so veränderter Multiscan Projector entspricht nicht mehr dieser Zulassung und darf infolgedessen nicht mehr betrieben werden.

Die vor Ablauf der Frist in Verkehr gebrachten Geräte dürfen nach Ablauf der Frist weiter betrieben werden.



Die geforderte Stückprüfung hat ergeben, daß die gemessene Ortsdosis-Leistung unter dem im Prüfungsschein Nr. 6.52-S 1259 der PTB genannten Wert von 0,2 µSv/h liegt.

Table of Contents

Overview

Precautions	8
Features	11
Location and Function of Controls	13
Front	13
Rear	15
Remote Commander/Control Panel	17

Projecting

Projecting	21
Adjusting the Picture	24
Centering Adjustment	25
Adjusting the Size And Shift of the Picture	27
SIZE adjustment	27
SHIFT adjustment	27
Blanking adjustment	28

Adjustments and settings using the menu

Using the Menu	29
Basic Menu Operation	29
Menu Modes	30
The PIC CTRL (Picture Control) Menu	32
The PIC SETTING 1 (Picture Setting 1) Menu	34
The PIC SETTING 2 (Picture Setting 2) Menu	35
The INPUT SETTING Menu	36
The SET SETTING 1 Menu	38
The SET SETTING 2 Menu	39
The INPUT INFO (Information) Menu	41
The SET INFO (Information) Menu	42

Installation/Connection Examples

Installation Examples	43
Installation 1: Floor Installation Using Front Projection Flat Screen	44
Installation 2: Ceiling Installation Using Front Projection Flat Screen	45
Connection Examples	46
Connecting Directly to the Projector	46
Connecting Multiple Projectors	47
Using the PC-3000 Signal Interface Switcher	49
Confirming the System Construction	50
Using the PC-1271/1271M Signal Interface Switcher	51
Setting the Index Numbers	52

Maintenance / Other

Troubleshooting	55
Specifications	56
Index	59

Overview



Overview

Precautions

On safety

- Check that the operating voltage of your unit is identical with the voltage of your local power supply. If voltage adaptation is required, consult with qualified Sony personnel.
- Should any liquid or solid object fall into the cabinet, unplug the unit and have it checked by qualified personnel before operating it further.
- Unplug the unit from the wall outlet or set the MAIN POWER switch to OFF if it is not to be used for several days.
- To disconnect the cord, pull it out by the plug. Never pull the cord itself.
- The wall outlet should be near the unit and easily accessible.
- The unit is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.

On installation

- When the projector is mounted on the ceiling, the Sony PSS-90 Projector Suspension Support must be used for installation. Read the installation manual of the PSS-90 carefully, since the ceiling should be reinforced for safety.
- Allow adequate air circulation to prevent internal heat build-up. Do not place the unit on surfaces (rugs, blankets, etc.) or near materials (curtains, draperies) that may block the ventilation holes. Leave space of more than 30 cm (12 inches) between the wall and the projector. Be aware that room heat rises to the ceiling; check that the temperature near the installation location is not excessive.
- Do not install the unit in a location near heat sources such as radiators or air ducts, or in a place subject to direct sunlight, excessive dust or humidity, mechanical vibration or shock.

- To avoid moisture condensation, do not install the unit in a location where the temperature may rise rapidly.
- Fans are installed inside the projector to prevent internal heat build-up. The fans produce a humming noise when the power is switched on, which is normal. Should the noise sound abnormal, please consult qualified Sony personnel.

On illumination

- To obtain the best picture, the front of the screen should not be exposed to direct lighting or sunlight.
- Ceiling-mounted spot lighting is recommended. Use a cover over fluorescent lamps to avoid lowering the contrast ratio.
- Cover any windows that face the screen with opaque draperies.
- It is desirable to install the projector in a room where floor and walls are not of light-reflecting material. If the floor and walls are of reflecting material, it is recommended that the carpet and wall paper be changed to a dark color.

On operation

To turn on the projector after the projector has been turned off due to a brief loss of power, press the ON key on the remote commander, or turn off the MAIN POWER switch so that the STANDBY indicator turns off and then turn on the MAIN POWER switch.

On cleaning

- To keep the cabinet looking new, periodically clean it with a soft cloth. Stubborn stains may be removed with a cloth lightly dampened with a mild detergent solution. Never use strong solvents, such as thinner, benzene, or abrasive cleansers, since these will damage the cabinet.
- Avoid touching the lens. To remove dust on the lens, use a soft dry cloth. Do not use a damp cloth, detergent solution, or thinner.

Precautions

CRT burns

When a static picture of a computer, etc. is displayed for more than about an hour, a CRT burn may result. This means that an after-image impression of the static picture remains on the screen even after the picture has changed. If it is necessary to display the same static picture for more than an hour, we recommend that you set the CONTR (contrast) control to the lowest setting.

Also, when a picture of different size is displayed beyond a certain length of time, an after-image impression of the frame of the smaller picture may be burnt on the screen (such as displaying a 16:9 wide size picture on a 4:3 screen). To avoid this, we recommend that you use the same picture size when possible. However, if it is necessary to use a different picture size, set the CONTR (contrast) control and the BRT (brightness) control of the smaller picture to the lowest setting possible. This will minimize the risk of creating an after-image impression.

If the CRT burns, it must be replaced. In this case, refer to the warranty provided with this unit. Consult your Sony dealer or Qualified Service Personnel.

On repacking

Save the original shipping carton and packing material; they will come in handy if you ever have to ship your unit. For maximum protection, repack your unit as it was originally packed at the factory.

Features

Multiscan projector ¹⁾

This projector accepts and automatically detects horizontal scanning frequencies between 15 kHz and 150 kHz and vertical scanning frequencies between 38 Hz and 150 Hz. In addition to high-resolution pictures from computers, you can also project pictures from teletext decoders, VCRs and video cameras.

High resolution and brightness

A newly developed 9-inch electromagnetic focus CRT, a hybrid Sony HACC (High-resolution Aspherical and Color Corrected) lens and a wide-range cathode/G1 dual-drive video output circuit are incorporated in the projector to provide a sharp and bright high-quality picture with the high resolution of 2500 × 2000 pixels and the high light output of 350 lumen.

High contrast

The adoption of the optical coupling technologies, double-focus lens system and an anti-reflection coating gives a fine-detail and sharp picture with improved contrast in corners and screen center.

Easy operation—remote control, on-screen display

Adjustments such as input selection, picture control and centering adjustment can be remotely controlled from both the front and rear of the projector with the supplied remote commander. You can also use the commander as a wired remote control by connecting it to the projector with the supplied remote control cable.

Compatible with various color systems ¹⁾

NTSC, PAL, SECAM, NTSC-4.3 ²⁾ or PAL-M color system can be selected automatically or manually.

1) The VPH-G90E model is not equipped with the VIDEO connectors. To connect video signals, the optional IFB-G90E Video Interface Board is required.
2) NTSC-4.3 is the color system used when playing back a video recorded on NTSC on a NTSC-4.3 system VCR.

Features

Flexible setup

You can project a 90- to 300-inch picture (120-inch standard) with this projector. The projector can be set up on the floor or ceiling, for front or rear projection to suit the installation location, surrounding illumination, usage, etc.

Illuminated control panel/remote commander keys

The key names on the remote commander and the control panel of the projector can be illuminated for easy access in a dark place by pressing the LIGHT button.


DRC (Digital Reality Creation) circuit¹⁾

The DRC is Sony's unique double-scan technology which creates a 4-times density image from the NTSC signal. A normal NTSC signal (525 scanning lines) is converted into a high density signal (1050 scanning lines) using digital mapping technology. Compared with the conventional double-scan, the DRC creates a highly realistic moving picture without blurs.

1) The VPH-G90E model is not equipped with the VIDEO connectors.
To connect video signals, the optional IFB-G90E Video Interface Board is required.

Location and Function of Controls

Front



1 Blue lens

2 Green lens

3 Red lens

4 Control panel cover

The cover keys are inside the cover.
The locations and functions of the control keys are the same as those of the remote commander.

For details, see "Remote Commander/Control Panel" on page 17.

5 Handles

Used for carrying the projector. The handles are located on the front, rear, left and right sides.



6 Front remote control detector

7 Adjusters

Used to keep the projector level if it is installed on an uneven surface (equipped with four adjusters).

How to use the adjusters

Using the supplied tool, turn the adjusters to adjust the height so that the projector becomes level.




Notes

- The supplied tool can rotate the screw in one direction only. To rotate the screw in the reverse direction, turn the tool upside down.
- Do not turn the tool forcibly when the screw has fully rotated. Otherwise, the tool may slip out and injure your hand.

Location and Function of Controls


Using the handles

Carry the projector with **four persons or more** by using the front, rear and side (right and left) handles.
Pull out the front and rear handles or the side handles.




Putting away the handles

Push the handle release lever under each handle. The handle is automatically retracted.



Rear



1 Signal interface board attachment part (INPUT B)

An optional signal interface board such as IFB-12/12A and IFB-40 can be attached to this section.
When the IFB-12/12A is attached, the signal input to the INPUT A connectors can be output from the IFB-12/12A by setting it to output mode.

2 MAIN POWER switch

3 AC IN socket

Connect the supplied AC power cord.

4 Signal interface board attachment part (INPUT C)

An optional signal interface board can be attached to this section.

Notes

- The IFB-40 cannot be attached to INPUT C.
- When the IFB-12/12A is attached, the IFB-12/12A cannot be set to output mode.

5 ON indicator

When the projector is turned on, this indicator lights in green.

6 STANDBY indicator

When the MAIN POWER switch on the projector is turned ON, this indicator lights in orange, indicating that the projector can be turned on/off using the remote commander.

7 Rear remote control detector

8 INPUT A connectors (BNC type) R/R-Y/P_s, G/Y, B/B-Y/P_s, SYNC/HD, VD

connectors: Connect to the outputs of a computer or a video camera. According to the connected equipment, the RGB (R, G, B), component (R-Y, Y, B-Y) or HDTV (P_s, Y, P_s) signal is selected.

Location and Function of Controls

- VIDEO connectors***
VIDEO IN connector (BNC type): Connects to the composite video output of the video equipment.
VIDEO OUT connector (BNC type): Connects to the composite video input of a color monitor.
S VIDEO IN/OUT connectors (4-pin, mini-DIN type): Connects to the S video output or input of the video equipment.
Y IN, C IN connectors (BNC type): Connects to the Y and C video outputs of the video equipment.

Note
 The S VIDEO IN connector is disconnected when a cable is connected to the Y IN/C IN connectors.

* **Note on the VPH-G90E model**
 The optional IFB-G90E Video Interface Board is required for using the VIDEO connectors.

- LINK IN/OUT jacks (stereo minijack)**
 When connecting multiple projectors, connect the LINK OUT jack to the LINK IN jack on another projector. Then the ABL LINK function can be used.

- TRIGGER connector (minijack)**
 When the projector is turned on, 12 V is output. When it is turned off, 0 V is output. However, the connector cannot be used as the power source.

- LED display window**
 Self-diagnosis results and PJ COM communication conditions, etc. are displayed using two-digit numbers and alphabets.
 Self-diagnosis codes are displayed in red or orange, and the warning and communication conditions in green.

- CONTROL S jacks**
IN/PLUG IN POWER jack (stereo minijack):
 Connects to the CONTROL S OUT jack of other Sony equipment. Also connects to the CONTROL S OUT jack of the supplied remote commander with the supplied remote control cable (stereo cable) to be used as a wired remote control. In this case, this jack supplies the power to the remote commander to save the battery power.
OUT jack (stereo minijack): Connects to the CONTROL S IN jack of other Sony equipment.

- Note**
 When using this jack, the remote control detector on the projector does not function.
- DEVICE INDEX switches**
 When multiple projectors are connected, set the device index number of each projector.
 To display the device index number on the screen, press the NORMAL key, and the ENTER key on the remote commander.

Note
 Do not set the device index number to "00." If you do, the projector will not operate with the remote commander.
 You can operate the projector with the keys on the control panel of the projector but the connected equipment cannot be operated with the keys on the control panel.


- RS-232C/RS-422A selector**
 Selects the function of the RS-232C/RS-422A connector.
- RS-232C/422A REMOTE connector (D-sub 9-pin)**
 Used to expand the system connections using the RS-232C/422A interface.

- PJ COM (projector communication) IN/OUT connectors (D-sub 9-pin)**
 These are the connectors conforming to the RS-485 standards, especially designed to expand the system using Sony projectors.
 Use these connectors to connect the PJ COM system of the PC-3000 Signal Interface Switcher.
 When the cable is connected to the IN connector only, attach the supplied terminator to the OUT connector.
 To connect multiple projectors, connect the IN connector to the OUT connector of another projector in cascade, and attach the supplied terminator to the OUT connector of the last projector.
 For details on the specifications of the connector, refer to the Protocol Manual prepared by Sony.

Remote Commander/Control Panel

The locations and functions of the keys on the remote commander are the same as those on the control panel of the projector. (Only the remote commander is equipped with the transmission indicator and the COMMAND ON/OFF switch.)
 The remote commander may be used as a wired or wireless remote control.

- Notes**
 - The RGB APA/DOT PHASE ➊, VOL +/- ➋, INPUT SELECT D ➌, LCD LENS CONTROL ➍, and AUDIO MUTING ➎ keys do not function with this projector.
 - The RGB SIZE/SHIFT ➏, CENT R/B ➐, and BLKG ➑ keys function only in the pro-user mode.
 - The keys on the control panel are basically effective for this projector only. Only the commands from the SYS SET key and the switcher select commands are transmitted to the connected equipment via the PJ COM connector.



- LIGHT button**
 Illuminates the key indicators when the COMMAND switch ➑ is set to ON. If the COMMAND switch is set to OFF, only the COMMAND switch is illuminated.
 The key indicators turn off if you press the LIGHT button again.
 If you do not press any key for more than 30 seconds, the indicators also turn off automatically.
 When the remote commander is connected to the CONTROL S IN/PLUG IN POWER jack of the projector via the remote control cable, the power is supplied to the remote commander from the projector.
- Transmission indicator (only for the remote commander)**
 Lights each time you press a key. If it does not light, replace the batteries with new ones.
- STATUS ON/OFF keys**
 Press OFF to eliminate the on-screen display.
 Press ON to restore the on-screen display.
- Note**
 The menus and warning messages appear even if the OFF key is pressed.

Location and Function of Controls



Overview

- 4 RGB keys**
Adjust the picture.
APA: This key does not function with this projector.
DOT PHASE: This key does not function with this projector.
- SIZE:** Enters the size adjustment mode for the input signal in the pro-user mode. Next adjust the size of the picture using the four arrow keys. Each time you press this key, the COARSE and FINE modes are switched alternately.
- ↔: to reduce horizontal size
 - ↕: to expand horizontal size
 - ↔: to expand vertical size
 - ↕: to reduce vertical size
- SHIFT:** Enters the shift adjustment mode for the input signal in the pro-user mode. Next adjust the position of the picture using the four arrow keys. The picture shifts in the direction of the arrow on the pressed key. Each time you press this key, the COARSE and FINE modes are switched alternately.
- 5 COMMAND ON/OFF switch (only for the remote commander)**
No keys on the remote commander except the LIGHT button 1 function when this switch is set to OFF. This saves battery power when a button is pressed inadvertently.
- 6 CENT R/B keys**
Enter the centering adjustment mode of the red and blue in the pro-user mode.
R: Press to enter the red centering adjustment mode.
B: Press to enter the blue centering adjustment mode. Perform the centering adjustment using the four arrow keys.
- 7 MEMORY key**
Stores various adjusted data into memory.
- 8 ON/SYANDBY keys**
Turn on and off the projector when the MAIN POWER switch on the projector is set to ON.
- 9 MENU key**
Displays the main menu. Press it again to turn off the menu.
- 10 Arrow keys**
Adjust the value or select the item in the menu.




Overview

- 11 ENTER key**
Stores the settings in the menu, or selects and displays the index number.
- 12 FUNCTION key**
Press to use the extended functions.
- 13 RESET key**
Resets the adjusted levels to the factory preset or service adjusted levels.
- 14 POSITION +/- keys**
Select the position to be adjusted on the screen in focus, registration or blanking adjustment mode. Also, set V SHIFT to WIDE or NARROW in or HDTV RGB input signal's SHIFT adjustment mode.
- 15 PICTURE CONTROL keys**
Adjust the picture conditions: CONTR (contrast), BRIGHT (brightness), COLOR, HUE and SHARP (sharpness).
- 16 VOL (volume) +/- keys**
These keys do not function with this projector.
- 17 SWITCHER/VIDEO MEMORY/INDEX select switch**
Selects the function of the SWITCHER/VIDEO MEMORY/INDEX keys.
- SWITCHER:** to select the input from the PC-3000 or the PC-1271/1271M Signal Interface Switcher.
- VIDEO MEMORY:** to select the set and adjusted video memory data.
- INDEX:** to select a projector by its index number when multiple projectors are used.
- 18 SWITCHER/VIDEO MEMORY/INDEX keys**
When the SWITCHER/VIDEO MEMORY/INDEX select switch is set to SWITCHER
When the PC-3000 or the PC-1271/1271M Switcher is connected to the projector, press a number key (1 to 8) to select the input from the switcher. Number key 9 and the 10/0 (ALL) key do not function.
To select an input when multiple switchers are connected, set the SWITCHER/VIDEO MEMORY/INDEX select switch to SWITCHER, then press the SW NO/OFF/GROUP key. Next press the switcher number (1 to 8) and the input number (1 to 8) in sequence. Be sure to press the keys one after another within 2 seconds.
e.g. To select input 4 of switcher 2, press the keys as follows:
SW NO → 2 → 4.
- When the SWITCHER/VIDEO MEMORY/INDEX select switch is set to VIDEO MEMORY**
Select the number of the VIDEO MEMORY. To select the data set and adjusted in INPUT MEMORY, press the SW NO/OFF/GROUP key to set VIDEO MEMORY to OFF.
- Note**
The 10/0 (ALL) key can be used as "10" key only when the select switch is set to VIDEO MEMORY.
- When the SWITCHER/VIDEO MEMORY/INDEX select switch is set to INDEX**
When multiple projectors are connected, select the device index number of the projector to be adjusted. Press the device index number (1 to 99) and press the ENTER key. Be sure to press the keys one after another within 2 seconds.
e.g. To select 1, press the keys as follows:
0 → 1 → ENTER, or 1 → ENTER.
To select 12, press the keys as follows:
1 → 2 → ENTER.
When adjusting all the projectors simultaneously, press the 10/0 (ALL) key and ENTER key.
- Note**
Depending on the projector, pressing "0," "0" and "ENTER" is not effective.
- To select the projector to be adjusted when the projectors are divided into multiple groups**
First select the group index number and then the projector's device index number.
To select a group, press the SW NO/OFF/GROUP key, the group index number (1 to 99) and the ENTER key in sequence. When the group index has a double-digit number, be sure to press the SW NO/OFF/GROUP key before pressing each number key.
Then press the device index number of the projector (1 to 99) and finally press the ENTER key.
e.g. To select the index number 52 projector in group 91, press the keys as follows:
GROUP → 9 → GROUP → 1 → ENTER → 5 → 2 → ENTER.
- 19 INPUT SELECT keys**
Select the input signal.
VIDEO: Video or S video signal input from the VIDEO connectors of the projector (VPH-G90U/G90M) or the IFB-G90E Video Interface Board (VPH-G90E).
SELECT VIDEO/S VIDEO: Selects video or S video signal input from the VIDEO connectors after pressing the VIDEO key.
A: The RGB, component or HDTV signal input from the INPUT A connectors of the projector
B: The signal input from the INPUT B section when the optional interface board other than the IFB-40 is installed
C: The signal input from the INPUT C section when the optional interface board is installed.
D: This key does not function with this projector.
- Note**
To switch the input signal from the INPUT A, INPUT B or INPUT C section to the S VIDEO IN (or Y IN/C IN) connectors, first press the VIDEO key, then press the SELECT VIDEO/S VIDEO key.
- 20 SYS SET (system set) key**
When the PC-3000 Signal Interface Switcher is used in the system, press the key to confirm the status of the system, the settings of the interface board, and so on.
- 21 BLKG (blanking) key**
Enters the blanking adjustment mode in the pro-user mode.
You can adjust the blanking with the four arrow keys.
For details, see "Blanking Adjustment" on page 28.
- 22 PATTERN key**
Displays the internal test patterns of the projector. Each press of the key advances the test pattern sequentially.
- 23 LCD LENS CONTROL keys**
These keys do not function with this projector.
- 24 NORMAL key**
Erases the test pattern or cancels the various adjustment modes.
- 25 MUTING keys**
PIC (Picture): Cuts off the picture. To restore the picture, press the key again.
AUDIO: This key does not function with this projector.


Location and Function of Controls

Battery installation

1 Push to open the lid.




2 Install the three R6 (size AA) batteries (supplied) with the correct polarity.



Be sure to install the battery from the ⊕ side.

3 Replace the lid.




Notes on batteries

- Be careful that the battery orientation is correct when inserting batteries.
- Do not mix old battery with new one, or different types of batteries.
- If you do not intend to use the remote commander for a long time, remove the batteries to avoid damage from battery leakage. If a battery has leaked, remove the batteries, wipe the battery compartment dry and replace the batteries with new ones.

Notes on wireless remote control operation


- Be sure that there is nothing to obstruct the infrared beam between the remote commander and the projector.
- The operation range is limited. The shorter the distance between the remote commander and the projector, the wider the angle within which the remote commander can control the projector.
- The remote control detectors on the projector do not operate when the remote commander is being used as a wired remote control. If you wish to use the remote commander as a wireless remote control, be sure to remove the connecting cable from both the remote commander and the projector.

Connecting the remote commander to the projector



Projecting

Projecting




1 Press the MAIN POWER switch on the rear of the projector.
The  STANDBY indicator lights in orange and the projector goes into the standby mode.

(continued)

Projecting

- 2** Press the ON key on the remote commander or the control panel. The ON indicator on the rear of the projector lights in green.
- A white screen with the message shown below (warming up screen) appears on the screen. For getting a stable picture, make sure to allow the projector to warm up for 20 minutes after turning it on. The message disappears temporarily in about 35 seconds, and will appear subsequently for 5 seconds every 30 seconds.



Press the MENU key to cancel the warming up screen and see the picture immediately after the projector is turned on if, for example, the adjustment has been finished and warming up is not needed.

- 3** Turn on the power of the connected equipment.
- 4** Select the input signal to be projected with the INPUT SELECT keys.
- VIDEO and SELECT:** To project the signal input from the equipment connected to the VIDEO IN or S VIDEO IN (or Y IN/C IN) connectors, ¹⁾ Press the VIDEO key, then select VIDEO or S VIDEO by pressing the SELECT key.
- A:** To project the RGB, component or HDTV signal input from the equipment connected to the INPUT A connectors.
- B:** To project the signal input from the equipment connected to the optional interface board other than the IFB-40 installed to the INPUT B section.
- C:** To project the signal input from the equipment connected to the optional interface board installed to the INPUT C section.
- When the PC-3000 or PC-1271/1271M Signal Interface Switcher is connected:** Set the SWITCHER/VIDEO MEMORY/INDEX select switch to SWITCHER and then select the input with the number keys 1 to 8.

Note

When you select the input signal connected to the INPUT A, INPUT B or INPUT C section, be sure to select the correct signal in the SET SETTING 1 menu. If an incorrect signal is selected, picture may be distorted. For details, see "The SET SETTING 1 Menu" on page 36.

1) For the YPbPr-UYM model, the optional IFB-G90E Video Interface Board is required for using the VIDEO connectors.



Projecting

- 5** Adjust the picture.

For details, see "Adjusting the picture" on page 24.

- 6** To turn the power off, press the STANDBY key on the remote commander or on the control panel of the projector, then set the MAIN POWER switch on the projector to OFF.

To	Press
turn off the on-screen display	the STATUS OFF key. The menus and warning messages appear even if the STANDBY key is pressed. To restore the on-screen display, press the STATUS ON key.
cut off the picture	the MUTING PIC key. To restore the picture, press the MUTING PIC key.



Projecting

Adjusting the Picture

Adjust the picture for your preference. The adjustment data can be saved in the memory.

- 1 Adjust with the PICTURE CONTROL +/- keys.

BRIGHT	Brightness
CONTR	Picture contrast
COLOR	Color intensity
HUE	Hue
SHARP	Sharpness

The adjustment levels are digitally displayed with a range of MIN. 1, 2, ... 99, MAX.



- 2 Press the MEMORY key to save the data.

Restoring the initial data


- 1 Press the PICTURE CONTROL key of the item which you want to reset to the initial data.
- 2 Press the RESET key.
The selected item is reset to the initial data.

Notes


- The COLOR, SHARP and HUE keys do not function with the RGB input signals.
- The HUE and COLOR keys do not function if the input signal is black and white.
- The HUE key does not function with the PAL or SECAM color input source.

Centering Adjustment

The three colors, red, green and blue must converge for correct projection. If they do not converge, centering adjustment is necessary.




- 1 Turn the projector on by switching on the MAIN POWER switch and pressing the ON key on the remote commander.
- 2 Set the projector to the pro-user mode.
For details, see "Pro-user mode" on page 21.
- 3 Press the CENT R key.
The built-in CROSS HAIR test pattern appears and the red line will be adjustable.




Centering Adjustment


- 4** Press the arrow keys to move the red line until the red and green lines converge and become yellow.
The red line moves according to the direction of the arrow.



- 5** Press the CENT B key.
The blue line will be adjustable.



- 6** Press the arrow keys to move the blue line until the blue and yellow lines converge.
The blue line moves according to the direction of the arrow.
When all three color lines converge, the test pattern will become white.



- 7** Press the MEMORY key.
The normal display is restored.



Adjusting the Size And Shift of the Picture

The size and shift of the input picture can be adjusted to fit the screen in the pro-user mode only.

Note

When you connect multiple input sources to the projector, such as when using the switcher, adjust the picture size, picture shift and blanking for each input signal. The information about the input signal is shown in the INPUT INFO menu.




SIZE adjustment

Adjust the picture size if it does not fit the screen.

- 1** Press the RGB SIZE key.
(Use the RGB SIZE key even for the signal other than RGB.)

- 2** Adjust the picture size with the arrow keys.
- ↕ : The vertical size is expanded.
 - ↕ : The vertical size is reduced.
 - ↔ : The horizontal size is expanded.
 - ↔ : The horizontal size is reduced.



To adjust precisely, press the RGB SIZE key again. The projector enters the FINE adjustment mode, and you can fine adjust the size. By pressing the RGB SIZE key again, the COARSE adjustment mode is resumed.

- 3** Press the MEMORY key to save the adjustment data.

Resetting to the initial preset size

The picture size of the video signal can be reset to the initial preset size by pressing the RESET key in RGB SIZE adjustment mode. (The picture size of signals other than the video signal cannot be reset.)


SHIFT adjustment

If the picture needs to be shifted to fit the screen, adjust the position of the picture.

- 1** Press the RGB SHIFT key.
(Use the RGB SHIFT key even for the signal other than RGB.)

(continued)

Adjusting the Size And Shift of the Picture

- 2** Adjust the shift with the arrow keys.
- ↑ : The picture is shifted upward.
 - ↓ : The picture is shifted downward.
 - ↔ : The picture is shifted rightward.
 - ↕ : The picture is shifted leftward.
- 

To adjust precisely, press the RGB SHIFT key again. The projector enters the FINE adjustment mode, and you can fine adjust the horizontal shift only. By pressing the RGB SHIFT key again, the COARSE adjustment mode is resumed.

Note

When the RGB or HDTV signal is input, the adjustable range of the vertical shift (V SHIFT) can be set to WIDE or NARROW by pressing the POSITION +/- keys. When the video, S video, component or SDI 4 : 2 : 2 signal is input, V SHIFT is automatically fixed to NARROW and the adjustable range of the vertical shift will become narrower than that of the RGB or HDTV signal.


- 3** Press the MEMORY key to save the adjustment data.

Resetting to the initial preset position

The position of the picture of the video signal can be reset to the initial preset position by pressing the RESET key in RGB SHIFT adjustment mode. (The position of the picture of signals other than the video signal cannot be reset.)

Blanking adjustment


If the displayed picture is larger than the screen, cut off the excess parts.

- 1** Press the BLKG key.
- 2** Press the POSITION +/- keys or the BLKG key to select the part to be adjusted.
- When you press the + key or the BLKG key, the position cycles through the following order:
TOP → BOTTOM → LEFT → RIGHT → TOP ...
 - When you press the - key, the position cycles in reverse order.
- 3** Adjust with the arrow keys.
- Press the ↑ and ↓ keys to adjust the TOP and BOTTOM positions.
 - Press the ↔ and ↕ keys to adjust the LEFT and RIGHT positions.
- 4** Press the MEMORY key to save the adjustment data.
- 


Adjustments and settings using the menu

Using the Menu

The projector is equipped with an on-screen menu for making various adjustments and settings. There are two menu modes : user mode and pro-user mode, to limit the menu items according to the level of the operator of the projector.



- 1** Press the MENU key.
- The menu display appears.
- The menu presently selected is highlighted in blue.



- 2** Use the ↑ or ↓ keys to select a menu, then press the → key or the ENTER key.
- The selected menu appears.
- The setting items that are indicated in white cannot be selected.

- 3** Use the ↑ or ↓ keys to select a setting item, then press the → key or the ENTER key.
- The adjustment menu or the setting menu (pop-up menu) appears.

To go to the next page

If there are two or more pages for a menu, the ▼ indication appears below the bottom item. Move the cursor to the bottom item with the ↓ key, then press the → key.

To go back to the previous page

Move the cursor to the top item with the ↑ key, then press the → key.

(continued)

Using the Menu


- 4** Make adjustment or setting on the menu.

To change the adjustment level

To increase the level, press the $\blacktriangle$ or $\blacklozenge$ key.
To decrease the level, press the $\blacktriangledown$ or $\blacklozenge$ key.
Then press the ENTER key to store the level. The original screen is restored.

To select an item

Use the $\blacktriangle$ or $\blacklozenge$ key to select an item in a pop-up menu. For some items, the result or effect of the selection is simultaneously reflected on the screen. For other items, press the $\blacklozenge$ key or the ENTER key to confirm the selection. The selected setting is stored and the pop-up menu disappears.



For details on setting individual items, see the relevant menu pages.

To clear the menu display

Press the MENU key or NORMAL key.
The menu display also disappears automatically if no key is pressed for about one minute.

Memory of the settings

The settings in the menus are automatically stored in the projector memory. You can also store the settings by pressing the MEMORY key.


Menu Modes

There are two menu modes for this projector.

User mode

This is the menu mode for end users. Only the minimum menu items for usual settings and adjustments appear in this mode.

No indication for user mode




The user mode is factory preset. By pressing the MENU key for the first time, the user mode appears.

Pro-user mode (P)


This is the menu mode for advanced end users who know the operation and functions of the projector very well. The menu items for detailed settings and adjustments are provided so that they can get the most of the projector functions.

Pro-user mode indication




To set to the pro-user mode

- 1 Press the MENU key.
The menu in the user mode appears.
- 2 Press the $\blacklozenge$ or $\blacklozenge$ key to select SET SETTING 1, then press the ENTER or $\blacklozenge$ key.




- 3 Press the $\blacklozenge$ or $\blacklozenge$ key to select USER MODE, then press the ENTER or $\blacklozenge$ key.



- 4 Press the $\blacklozenge$ or $\blacklozenge$ key to select PRO in the pop-up menu, then press the ENTER or $\blacklozenge$ key.
The menu disappears.

- 5 Press the MENU key.

The menu in the pro-user mode appears with the letter "P" at the top-left of the screen.



To reset to the user mode


Perform the same steps for setting to the pro-user mode, and set USER MODE in the SET SETTING 1 menu to NORMAL.
Press the ENTER or $\blacklozenge$ key to turn off the menu. When the MENU key is pressed again, the menu in the user mode appears.



Adjustments and settings using the menu


The PIC CTRL (Picture Control) Menu [User/Pro-user modes]

The PIC CTRL menu displays the information on the picture adjustments.
To adjust the picture, use the keys on the remote commander.
Items that can be adjusted are highlighted in green.
You cannot select the items indicated in white.



VIDEO MEMORY

Indicates the number of video memory.
The number 1 to 10 can be selected with the VIDEO MEMORY keys on the remote commander.



The video memory is a part of the SET MEMORY, and stores 10 types of the aspect ratio, picture quality, etc.


Select a video memory number 1 to 10, then the aspect ratio and picture quality that you adjust will be stored in the selected video memory.
If you want to use the aspect ratio and picture quality data stored in the INPUT MEMORY, select OFF.

Contents of the video memory data
COLOR TEMPERATURE, D. PICTURE, V SHIFT, WIDE/NARROW, COMPONENT FORMAT, COMB FILTER, DRC LEVEL, CONTRAST, BRIGHT, COLOR, HUE, SHARP, RGB SIZE, RGB SHIFT, BLANKING

Aspect ratios preset at the factory
The data for the following aspect ratios have been stored in each video memory number at the factory.


No.	Aspect ratio
1	4:3
2	4:3
3	4:3
4	4:3
5	4:3
6	16:9
7	16:9
8	16:9
9	16:9
10	16:9

CONTRAST



The higher the setting, the greater the contrast.
The lower the setting, the lower the contrast.

BRIGHT (brightness)




The higher the setting, the brighter the picture.
The lower the setting, the darker the picture.

COLOR




The higher the setting, the greater the intensity.
The lower the setting, the lower the intensity.

HUE



At high settings, the picture becomes greenish.
At low settings, the picture becomes purplish.

SHARP (sharpness)



The higher the setting, the sharper the picture.
The lower the setting, the softer the picture.

Input signals and adjustable/setting items


Item	Video or S-Video (Y/C)	Component	HDTV	RGB
VIDEO MEMORY	Y	Y	Y	Y
CONTRAST	Y	Y	Y	Y
BRIGHT	Y	Y	Y	Y
COLOR	Y	Y	Y	N
HUE	Y	Y	Y	N
SHARP	Y	Y	Y	N

Y: Adjustable/can be set
N: Not adjustable/cannot be set
* For the VPH-G90E model, the optional IFB-G90E Video Interface Board is required.

The PIC SETTING 1 (Picture Setting 1) Menu


[Pro-user mode]

The PIC SETTING 1 menu is used for setting the picture quality.
Items that can be set are highlighted in green.
You cannot select the items indicated in white.



D. (Dynamic) PICTURE


Emphasizes the black of the composite video, S video (Y/C) or component signal.



ON: Emphasizes the black to produce a bolder "dynamic" picture.
OFF: Reproduces the dark portions of the picture accurately, in accordance with the source signal.

COLOR SYS (System)


Selects the color system of the composite video or S video (Y/C) signal.



Select among AUTO, NTSC3.58, PAL, SECAM, NTSC4.43 and PAL-M.
Normally, set to AUTO.
If the picture is distorted or colorless, select the color system according to the input signal.

SET UP


Changes the set up level (standard black level) to 0 IRE or 7.5 IRE according to the NTSC source signal.
You cannot select the items indicated in white.



0 IRE: Normally, set to this position.
7.5 IRE: Set to this position when the black color is too light.

COMPONENT FORMAT

Selects the format of the component input signal.



SMPT/EBU-N10: Set to this position if the input signal is the SMPT/EBU-N10 format component signal.
BETACAM7.5: Set to this position if the input signal is the Betacam format component signal.

Input signals and adjustable/setting items


Item	Video or S video (Y/C)	Component	HDTV	RGB
D. PICTURE	Y	Y	N	N
COLOR SYS	Y	N	N	N
SET UP	Y	N	N	N
COMPONENT FORMAT	N	Y	N	N

Y: Adjustable/can be set
N: Not adjustable/cannot be set
* For the VPH-G90E model, the optional IFB-G90E Video Interface Board is required.

The PIC SETTING 2 (Picture Setting 2) Menu


[Pro-user mode]

The PIC SETTING 2 menu is used for setting the picture quality.
Items that can be set are highlighted in green.
You cannot select the items indicated in white.




DRC LEVEL

Selects the effect of the DRC for the NTSC signal.
This item can be selected only for an interlaced signal.



COMB FILTER


Selects the comb filter which reduces the cross color and dot interference of the NTSC signal to reproduce clear images.



3D: Three-dimensional comb filter. Normally use this comb filter.
3LINE: 3LINE comb filter. This comb filter may be more effective for fast-moving pictures.

DRC (Digital Reality Creation)

Set to ON to make the NTSC signal 4-times density image.



Normally set to ON. When a 15 kHz signal is input, the DRC function activates. When the DRC is not required, set to OFF.

Note

The DRC is effective only when the 15 kHz signal complies with the timing of the video signal. If it has a particular timing, the image may be disturbed with the DRC ON.

Adjustments and settings using the menu


Input signals and adjustable/setting items

Item	Video or S video (Y/C)	Component	HDTV	RGB
COM FILTER	Y	N	N	N
DRC	Y	Y	N	Y
DRC LEVEL	Y	Y	N	Y

Y: Adjustable/can be set
N: Not adjustable/cannot be set
* For the VPH-G90E model, the optional IFB-G90E Video Interface Board is required.


The INPUT SETTING Menu [Pro-user mode]

The INPUT SETTING menu is used to adjust the input signal.
Items that can be adjusted are displayed in green.
You cannot select the items indicated in white.



COLOR TEMP (Temperature)


Selects the appropriate color temperature according to your application and the input source signal.



- 9300:** standard color temperature for consumer-use products
- 6500:** standard color temperature for business-use products
- 5400:** standard color temperature for HDTV
- 3200:** standard color temperature for medical products and studio cameras
- CUSTOM:** If you wish to make the color of a particular input signal uniform to that of another display, select CUSTOM, then adjust the white balance.

CLAMP

Corrects the luminance of the input picture.



CLAMP is used as a standard for setting the black level of a picture correctly. The standard position of the clamp depends on the kind of sync signal being used. Normally, the projector CPU judges the signal and sets the position automatically. However, the CPU can misjudge the signal because of noise. If the luminance of the picture seems to be incorrect, the clamp position may need to be changed.

AUTO: Automatic setting mode. Normally set to this position.

SonG: Set to this position if the black seems too light or greenish.

H/C: Set to this position if the picture is too dark or luminance is unstable.

HP: If the luminance is still incorrect after changing to the SonG or H/C position, set to this position and perform the H-SHIFT adjustment.

TRI-LEVEL S: Set to this position if the picture is dark when using the tri-level sync.

Notes

- If the external signal does not have the SonG signal, the H/C position is recommended.
- If the luminance is still incorrect after changing the clamp setting, check the input signal and the connections.

V (Vertical) SHIFT

Sets the adjustable range of the vertical shift of the input signal.




WIDE: Normally, set to this position (factory preset).
NARROW: When some signal such as a superimposed signal with unstable vertical sync. signal is input, the picture may be distorted vertically. In this case, set to this position. Adjustable range in the lower direction will become narrow.

Note

When the video, S video, component or SDI 4:2:2 signal is input, V SHIFT is fixed to NARROW.

SYNC SEL (select)

Selects the sync signal when using an external sync signal.



When an RGB signal is input

AUTO: Automatic setting mode. Normally set to this position.

SonG: Set to this position if you project the picture using the sync on G signal.

C: Set to this position if you project the picture using the composite sync signal.

HV: Set to this position when using the horizontal/vertical sync signal.

When an HDTV signal is input

You can select the items below instead of the above items.

AUTO: Automatic setting mode. Normally set to this position.

INT: Set to this position when using the internal sync signal.

EXT [C]: Set to this position when using the external composite sync signal.


EXT [HV]: Set to this position when using the external horizontal/vertical sync signal.

Note

For an RGB signal, this item can be selected only when SonG and C/HV are included.

SYNC ROUTE

Selects the route of the sync signal when the RGB signal is input to INPUT A.



Adjustments and settings using the menu


AUTO: Automatic setting mode. Normally set to this position.

NORMAL: Set to this position for a normal sync input, that is, when there is no video signal on the sync line.

SYNC w VIDEO: Set to this position when the video signal is on the sync line and the sync of the image is distorted in the AUTO position.

VIDEO LOCK

Selects the range of the frequency deviation of the input signal so that the INPUT MEMORY data is switched automatically if the frequency deviation exceeds the selected range. This item can be selected only for RGB input signals.



NORMAL: Normally set to this position.

WIDE: Set to this position if the input signal is unstable or flickers. This phenomenon may appear during variable speed playback by the VCR, etc.

Input signals and adjustable/setting items

Item	Video or S video (V/C)*	Component	SDI 4:2:2	HDTV	RGB
COLOR TEMP	Y	Y	Y	Y	Y
CLAMP	N	N	N	N	Y
V SHIFT	N	N	N	Y	Y
SYNC SEL	N	N	N	Y	Y
SYNC ROUTE	N	N	N	N	Y
VIDEO LOCK	N	N	N	N	Y

Y: Adjustable/can be set


N: Not adjustable/cannot be set

* For the VPH-G90E model, the optional I/FB-G90E Video Interface Board is required.

The SET SETTING 1 Menu


[User/Pro-user modes]

The SET SETTING 1 menu is used for changing the default settings of the projector.
Items that can be adjusted are highlighted in green.
You cannot select the items indicated in white.



STATUS


Selects the on-screen display mode.



ON: Shows all of the on-screen displays.
OFF: Turns off all of the on-screen displays except for warning messages and menu displays.


PIC. (Picture) MUTING

Set to ON to cut off the picture.
When set to ON, "PIC MUTING" appears on the screen.



INPUT A


Selects the signal input from the INPUT A connectors.



RGB: Inputs the RGB signal.
COMPONENT: Inputs the component signal.
HDTV-YPbPr: Inputs the HDTV(YPbPr) signal.
HDTV-GBR: Inputs the HDTV(GBR) signal.

INPUT B

Selects the signal input from the IFB-12/12A Signal Interface Board (not supplied) installed to the INPUT B section and set to the INPUT mode.



RGB: Inputs the RGB signal.
COMPONENT: Inputs the component signal.
HDTV-YPbPr: Inputs the HDTV(YPbPr) signal.
HDTV-GBR: Inputs the HDTV(GBR) signal.
VIDEO: Inputs the composite video signal.
S-VIDEO: Inputs the S video signal.

Note


When a signal interface board other than the IFB-12/12A is installed or the IFB-12/12A is set to the OUTPUT mode, the menu items cannot be selected.

The SET SETTING 2 Menu

[User/Pro-user modes]

The SET SETTING 2 menu is used for changing the default settings of the projector.
Items that can be adjusted are highlighted in green.
You cannot select the items indicated in white.

User mode



GROUP INDEX

Indicates the group index number when the group index is set.

Note

The group index number can be set in the pro-user mode.


DEVICE INDEX

Indicates the device index number which is set by the DEVICE INDEX switches on the rear of the projector.

Adjustments and settings using the menu

The SET SETTING 2 Menu

Pro-user mode



GROUP INDEX

Sets the group index number with which multiple projectors and switcher are assigned in the same group. 1 to 99 group index number can be set.




DEVICE INDEX

Indicates the device index number which is set by the DEVICE INDEX switches on the rear of the projector.

SIRCS RECEIVER

Selects the remote control detectors on the front and rear of the projector, if the wireless remote control does not operate correctly due to the influence of a fluorescent lamp, etc.



FRONT & REAR: Activates both the front and rear detectors.

FRONT: Activates the front detector only.

REAR: Activates the rear detector only.

OFF: Deactivates both the front and rear detectors.

LANGUAGE


Selects the language used in the on-screen displays.



Available languages are: English, FRANCAIS (French), DEUTSCH (German), ITALIANO (Italian), ESPANOL (Spanish), 日本語 (Japanese) and 中文 (Chinese).

The INPUT INFO (Information) Menu [User/Pro-user modes]

The INPUT INFO menu displays the information on the current input signal.



fH (Horizontal frequency)

Indicates the horizontal frequency of the input signal. This indication is not an absolute value, but is only used as a guide. The horizontal frequency of the input signal is indicated in green; that of the internal signal in yellow.

fV (Vertical frequency)

Indicates the vertical frequency of the input signal. This indication is not an absolute value, but is only used as a guide. The vertical frequency of the input signal is indicated in green; that of the internal signal in yellow.

H/C (Horizontal/Composite sync)
V (Vertical sync)
Song (Sync on Green)

Indicates the polarity and use of each sync signal.
P: The polarity of the sync signal is positive.
N: The polarity of the sync signal is negative.
--: No sync signal is input.

INPUT SIGNAL

Displays the type of current input signal.
INT. OSC: No input
COMPONENT: Component input signal
IDTV: IDTV input signal from the optional PC-1271/1271M Signal Interface Switcher via the optional IFB-3000 Interface Board installed to the PC-1271/1271M.
15 KRGB: 15 kHz RGB input signal
RGB: RGB input signal
HDTV YPBPR: HDTV YPbPr input signal
HDTV GBR: HDTV GBR input signal
SDI 4:2:2: SDI 4:2:2 input signal
DRC: when the DRC is set to ON

Video or S video signals

NTSC 3.58: NTSC 3.58 input signal
NTSC 4.43: NTSC 4.43 input signal
PAL: PAL input signal
PAL-M: PAL-M input signal
SECAM: SECAM input signal
B/W: Black and white input signal
S-VIDEO: S video input signal

INPUT MEMORY No.


The upper number is the memory number of the data automatically loaded when the current signal is input. The lower number is the new memory number in which the adjustment data of the current input signal is stored. The existing memory number is displayed in green, and a new memory number in yellow.

VIDEO MEMORY

The selected video memory number is indicated.

The SET INFO (information) Menu [Pro-user mode]

The SET INFO menu displays the information on the serial number.



SER. (serial) No.

Indicates the serial number of the projector.

 Adjustments and settings using the menu

Installation/connection examples


Installation Examples

Installation and the preliminary adjustments should be carried out by Qualified Sony Personnel. This projector allows you to project the picture between 90 and 300 inches.

Installation Examples

Installation 1: Floor Installation Using Front Projection Flat Screen

Be sure that the projector is level to the floor.




Installation/connection examples

- a) Sony VPS-100FM
- b) Sony VPS-120FH and VPS-120FM

Installation 2: Ceiling Installation Using Front Projection Flat Screen

Use the PSS-90 Projector Suspension Support (not supplied).




Installation/connection examples

Connection Examples

When making connections:


- Before connecting any cables, make sure that each piece of equipment to be connected is turned off.
- Use cables appropriate for the equipment to be connected.
- A loose connection may cause hum or noise.
- When disconnecting a cable, pull it out from the plug; not the cable itself.
- Also refer to the instruction manual of the equipment to be connected.

Connecting a BNC connector:



Connecting Directly to the Projector

Use the IFU-1271/1271M Signal Interface Unit.




Setting up

- Set INPUT A in the SET SETTING 1 menu (page 38) to RGB.
- Select VIDEO or S VIDEO by pressing the INPUT SELECT keys on the remote commander.



Connecting Multiple Projectors

This is an example to connect multiple projectors directly using the PJ COM interface.
Install the optional IFB-12/12A Signal Interface Board to the INPUT B section of the projector.



(continued)

Connection Examples

Note

Be sure to terminate the PJ COM IN or OUT connector not in use by attaching the supplied terminator.

Setting up


- Set the IN/OUT selector on the IFB-12/12A to OUT (output). The signal input to INPUT A is output from the IFB-12/12A.
- Set the device index number of the first projector which is connected directly to the video equipment or computer to "01," and the second projector to "02" (page 52).
- When using the remote commander as a wireless remote control, activate the remote control detector of a piece of the equipment in the system only and deactivate those of the other equipment. Perform the setting on the projector using "SIRCS RECEIVER" in the SET SETTING 2 menu (page 40).



Installation/connection examples

Using the PC-3000 Signal Interface Switcher

When you connect the PC-3000 Signal Interface Switcher (not supplied) to the INPUT A section, you can connect easily various input sources and switch them by pressing the SWITCHER/VIDEO MEMORY/INDEX keys on the remote commander.



Installation/connection examples

Note

Be sure to terminate the PJ COM IN or OUT connector not in use by attaching the supplied terminator.

Setting up

- Set the device index number of the projector to "01" (page 52).
 - Set the switcher number to "1" on the switcher.
- For setting, refer to the *Operating Instructions of the switcher*.
- When using the remote commander as a wireless remote control, activate the remote control detector of a piece of the equipment in the system only and deactivate those of the other equipment. Perform the setting on the projector using "SIRCS RECEIVER" in the SET SETTING 2 menu (page 40).
- For setting on the switcher, refer to the *Operating Instructions of the switcher*.

Connection Examples

Confirming the System Construction

After all the connections are complete, confirm that equipment of the system is properly setup.

1 Connect the AC power cords of all equipment to the AC outlets.

2 Press the SYS SET key on the remote commander or the control panel. Information on the system construction and the settings of the interface boards, etc. are automatically confirmed. Then the message disappears.

Note

When you want to use the projector without connecting the switcher after using the switcher in the system connections, it is necessary to confirm the system construction again by pressing the SYS SET key after all the connections are complete. If you press the key, "Master Switcher not exit" appears, but the system construction is automatically recognized.

When a system error is detected

The following messages are displayed on the screen.


Message	Remedy
Master Switcher not exist.	Set the switcher that outputs the signal to the projector to number 1.
Same DEVICE INDEX for Projector detected.	Change either number of the projectors that have the same number.
Same DEVICE INDEX for Switcher detected.	Change either number of the switchers that have the same number.



Using the PC-1271/1271M Signal Interface Switcher

When you install the optional IFB-40 Signal Interface Board to the projector and connect the PC-1271/1271M Signal Interface Switcher to the IFB-40, you can connect easily various input sources.

You can select the input to the switcher easily by pressing the SWITCHER/VIDEO MEMORY/INDEX keys on the remote commander.



Choose the appropriate cable from the following table.

Cable	1 m	2 m	5 m	10 m	15 m	25 m	50 m
CCQ-2BRS	CCQ-5BRS	CCQ-10BRS	—	—	—	CCQ-25BRS	CCQ-50BRS
SIC-M-1	—	—	SIC-M-5	—	SIC-M-15	SIC-M-25	SIC-M-50

Notes

- Insert the female and male plugs of the SIC-M or CCQ-BRS cable correctly.
- You can extend the SIC-M or CCQ-BRS cable up to 50 m.
- The video signal input to the IFB-40 installed to the INPUT B section should not exceed 70 MHz. When projecting the video signal which exceeds 70 MHz, connect the signal source to the INPUT A connectors using the 5BNC cables.

Setting up

- Set INPUT-A in the SET SETTING 1 menu (page 38) to RGB.
- Select VIDEO or S VIDEO by pressing the INPUT SELECT keys on the remote commander.
- Set the SINGLE/SECOND/OTHER select switch on the switcher to SINGLE.


Setting the Index Numbers

When you connect multiple projectors in your system, you have to set the group index and device index numbers for each projector.


To set the group index number

If you set the same group index number to multiple projectors and switchers, you can operate them simultaneously, for example, to select the input, by designating the group index number.

- 1 Set the projector to the pro-user mode.
For details, see "Menu Modes" on page 30.
- 2 Display the SET SETTING 2 menu, select GROUP INDEX by pressing the **4** or **5** key, and press the ENTER key.




- 3 Set a group index number 1 to 99 by pressing the **4** or **5** key, then press the ENTER key.



- 4 Press the MENU key to exit the menu mode.

To set the device index number

If you set the device index number, you can control each projector individually with the supplied remote commander.
Set the device index number with the DEVICE INDEX switches on the rear of the projector. Device index number "01" is set at the factory. Do not change from "01" if the projector is used alone.




Installation/connection examples

Notes

- Do not set the same device index number on multiple projectors in the same system.
- Do not set the device index number to "00." If you do, the projector will be operated only with the keys on the control panel. It cannot be controlled with the wired or wireless Remote Commander, or with an external equipment via the PJ COM connector.

Notes on setting of the index number


- Set the same group index number for all equipment of the same system connection (those on the signal route between the signal source and the projector).



- Set the correct group and device index numbers and the switcher number.

Do not set the same device index number or the same switcher number in one group.
For example, if there are different pieces of equipment with the switcher number 1, the error message will appear when the SYS SET key is pressed.

- Set the switcher that outputs the signal to the projector to number 1.




Notes on connections when two or more switchers are used

- Mount the IFB-12/12A interface board to the slot 1 of the number (n) switcher and connect the output connector of the number (n+1) switcher to the IFB-12/12A.
- You can attach the IFB-12/12A signal interface board (when the IN/OUT switch is set to OUT) only to the number 1 switcher.

Setting the Index Numbers

To select the projector by designating the index numbers

When the switchers and projectors are connected as illustrated, select the desired projector by pressing the keys on the remote commander as shown below.



Example:

- To select all the projectors
GROUP → ALL → ENTER → ALL → ENTER
Projectors A, B, C and D are selected.
 - To select projectors with device index 01 from all the groups
GROUP → ALL → ENTER → 1 → ENTER
Projectors A and C are selected.
 - To select a projector with device index 01 from group index 2
GROUP → 2 → ENTER → 1 → ENTER
Projector C is selected.
 - To select all the projectors from group index 2
GROUP → 2 → ENTER → ALL → ENTER
Projectors C and D are selected.
- Notes**
- Set the group index and device index numbers correctly. If more than two projectors are set to the same group index and device index numbers, an error message will be displayed when the SYS SET key is pressed.
 - If the group index is a tens digit number, press the GROUP key before each press of the number key.
- Example:**
- To select a projector with device index 13 of group index 12
GROUP → 1 → GROUP → 2 → ENTER → 1 → 3 → ENTER

Maintenance / Other

Troubleshooting

If the projector appears to be operating erratically, try to diagnose and correct the problem using the following guide. If the problem still persists, consult with qualified Sony personnel.

Symptom	Cause	Remedy
The power does not turn on.	The MAIN POWER switch is turned off.	Press the MAIN POWER switch on the projector (see page 21).
The power turns on and immediately turns off.	There may be an internal problem.	Check the error code in the LED display window on the rear of the projector and consult with qualified personnel.
Picture does not appear.	The picture is cut off.	Press the MUTING PIC key (see page 23).
	If no menu appears, external signal and/or sync is not input correctly.	Check the input signal and sync in the INPUT INFO menu and connect them correctly (see page 41).
	If menu appears with no input, sync connection is not correct.	Check SYNC SEL in the INPUT SETTING menu and connect the sync correctly, if necessary (see page 37).
	If no menu appears with no input, there may be an internal problem.	Consult with qualified personnel.
Picture is too dark.	Contrast is set to minimum.	Adjust the contrast with the CONTR + key (see page 24).
	Clamp setting is not correct.	Change the clamp setting in the INPUT SETTING menu (see page 36).
Picture is distorted.	The input signal is not selected correctly.	Select a correct signal in the INPUT A, INPUT B or INPUT C option in the SET SETTING 1 menu (see page 38).
On-screen displays do not appear.	The on-screen displays are turned off.	Press the STATUS OFF key (see page 23).
The projector does not operate with the remote commander.	The device index number is set to "00."	Set the DEVICE INDEX switches on the projector to a number other than "00" (see page 32).
INPUT A cannot be selected.	INPUT A is in switcher mode.	Press the SYS SET key (see page 50).
INPUT B cannot be selected.	The IFB/12/12A interface board installed to INPUT B is in OUT mode.	Set the IN/OUT selector on the IFB/12/12A to IN.

Specifications

Optical characteristics

Projection system	3 picture tubes, 3 lenses, horizontal inline system
Picture tube	9-inch high luminance, electromagnetic focus tubes, with coolant sealed
Projection lens	HACC (High-resolution Aspherical and Color Corrected) multicoating lenses
Projected picture size	Factory-adjusted to 120 inches (diagonal measure) Range: 90 to 300 inches (diagonal measure) adjustable ANSI lumen ¹⁾ (color temperature: 6500°K) 350 lm (fH: 150 kHz, fV: 50 Hz) 280 lm (fH: 15 kHz, fV: 60 Hz) Peak white: 1300 lm All white: 500 lm

Electrical characteristics

Color system	NTSC, PAL, SECAM, NTSC ^{4),5)} , and PAL-M switched automatically
Resolution	700 TV lines (video input) 1100 TV lines (HDTV input) 2500 × 2000 pixels (RGB input at fH: 102 kHz, fV: 50 Hz)
RGB inputs	Horizontal frequency: 15 kHz to 150 kHz Vertical frequency: 38 Hz to 150 Hz Various test pattern generators incorporated
Test signal	



Maintenance/Other

Input/Output

VIDEO (VPH-G90U/G90M only)	VIDEO IN: BNC type (1) Composite video input, 1 Vp-p ± 2 dB, sync negative, 75 ohms terminated
S VIDEO (VPH-G90U/G90M only)	VIDEO OUT: BNC type (1) Loop-through output of VIDEO IN Y IN: BNC type (1) Luminance signal, 1 Vp-p ± 2 dB, sync negative, 75 ohms terminated C IN: BNC type (1) Chrominance signal, 1 Vp-p ± 2 dB, sync negative, 75 ohms terminated S VIDEO IN: 4-pin mini-DIN (1) Y (luminance) signal: 1 Vp-p ± 2 dB, sync negative, 75 ohms terminated C (luminance) signal: 0.286 Vp-p ± 2 dB, 75 ohms terminated (NTSC) 0.3 Vp-p ± 2 dB, 75 ohms terminated (PAL) S VIDEO OUT: 4-pin mini-DIN (1) Loop-through output of S VIDEO IN BNC type (5) Analog RGB/Component: R/R-Y: 0.7 Vp-p ± 2 dB, 75 ohms terminated, positive G: 0.7 Vp-p ± 2 dB, 75 ohms terminated, positive G with sync/Y: 1 Vp-p ± 2 dB, 75 ohms terminated, sync negative B/B-Y: 0.7 Vp-p ± 2 dB, 75 ohms terminated, positive SYNC/HD: Composite sync: 0.6–8 Vp-p high impedance, sync positive/negative Vertical sync width: wider than horizontal scanning interval (2H) V/D: Vertical sync: 0.6–8 Vp-p high impedance, sync positive/negative Vertical sync width: Wider than horizontal scanning interval (2H)

1) ANSI lumen is a measuring method of American National Standard IT7.2:15.

HDTV Y/Pb/Pk:	Y: 1 Vp-p ± 2 dB, 75 ohms terminated, Tri-level sync: ±0.3 Vp-p, Bi-level sync: 0.3 Vp-p Pb/Pk: 0.35 Vp-p ± 2 dB, 75 ohms terminated HDTV GBR:	Supplied Accessories
G with sync: 1 Vp-p ± 2 dB, 75 ohms terminated, Tri-level sync: ±0.3 Vp-p, Bi-level sync: 0.3 Vp-p B/R: 0.7 Vp-p ± 2 dB, 75 ohms terminated	Operating Instructions (1) PJ COM terminator (1) Lens cap (3) AC Power cord (1) Remote control cable (15 m (49.5 feet) long) (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3)	Operating Instructions (1) PJ COM terminator (1) Lens cap (3) AC Power cord (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3) Remote control cable (15 m (49.5 feet) long) (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3)
CONTROL S	IN/PLUG IN POWER: stereo minijack type (1) 5 Vp-p, plug in power, DC 5 V maximum output 60 mA OUT: stereo minijack type (1) loop-through output of CONTROL S IN	Operating Instructions (1) PJ COM terminator (1) Lens cap (3) AC Power cord (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3) Remote control cable (15 m (49.5 feet) long) (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3)
TRIGGER	Minijack type (1) POWER ON: DC 12 V, output impedance 4.7 kilohms POWER OFF: 0 V	Operating Instructions (1) PJ COM terminator (1) Lens cap (3) AC Power cord (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3) Remote control cable (15 m (49.5 feet) long) (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3)
LINK	IN: minijack (1) OUT: minijack (1) RS-232C/422A D-sub 9-pin type (1) D-sub 9-pin type (2)	Operating Instructions (1) PJ COM terminator (1) Lens cap (3) AC Power cord (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3) Remote control cable (15 m (49.5 feet) long) (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3)
PJ COM		Operating Instructions (1) PJ COM terminator (1) Lens cap (3) AC Power cord (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3) Remote control cable (15 m (49.5 feet) long) (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3)
General	Dimensions Mass Power requirements Power consumption	Operating Instructions (1) PJ COM terminator (1) Lens cap (3) AC Power cord (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3) Remote control cable (15 m (49.5 feet) long) (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3)
	750 × 385.5 × 1,066 mm (29 7/32 × 15 3/16 × 41 3/32 inches) (w/h/d) Approx. 110 kg (242 lb 8 oz) VPH-G90U: AC 120 V; 9 A, 50/60 Hz VPH-G90E/G90M: AC 220-240 V; 5 A, 50/60 Hz VPH-G90U: Max. 1,050 W (Standby mode: 14 W) VPH-G90E/G90M: Max. 1,000 W (Standby mode: 14 W) Operating temperature Operating humidity Storage temperature Storage humidity	Operating Instructions (1) PJ COM terminator (1) Lens cap (3) AC Power cord (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3) Remote control cable (15 m (49.5 feet) long) (1) Remote control RM-PJ1001 (1) R6 (size AA) batteries (3)

Some items may not be available in certain areas. For details, please consult your nearest Sony office.




Maintenance/Other

Specifications


Pin assignment

RS-232C/422A connector (D-sub 9-pin, female)




Pin No.	Signal
1	GND
2	TX
3	RX
4	GND
5	Not used
6	GND
7	TX
8	RX
9	GND

PJ COM connector (D-sub 9-pin, female)



Pin No.	Signal
1	GND
2	BUS BUSY
3	TX/RX
4	GND
5	Not used
6	GND
7	BUS BUSY
8	TX/RX
9	GND

S VIDEO connector (mini-DIN 4-pin)
(VPH-G90U/G90M only)



Design and specifications are subject to change without notice.

Index

A

Adjusters 13
Adjusting
the blanking 28
the centering 25
the picture 24
the size/shift of the picture 27

B

Battery
installation 20
notes 20
Blanking adjustment 28

C

Carrying the projector 14
Clamp setting 36
Connecting
remote commander to the projector 20
directly to the projector 46
multiple projectors 47
using the PC-3000 Signal Interface Switcher 49
Control panel
location and function of controls 17
Cutting off the picture 23

D, E, F

Device index number 40, 52
Dynamic picture 34
DRC (Digital Reality Creation) 35

G

Group index number 40, 52

H

Handles 14

I, J, K, L

Index 40, 52
Initialization screen 22
Input signal selection 22
Installation
ceiling installation 45
diagrams 44, 45
floor installation 44

M

Menu
INPUT INFO menu 41
INPUT SETTING menu 36
Operation 29
Modes 30
PIC CTRL menu 32
PIC SETTING 1 menu 34
PIC SETTING 2 menu 35
SET INFO menu 42
SET SETTING 1 menu 38
SET SETTING 2 menu 39

N

Notes
for wireless remote control operation 20
on batteries 20

O

Optional accessories 57

P, Q

Pin assignment 58
Precautions 8
Pro-user mode 31
Projecting the picture 21

R

Remote commander
location and function of controls 17
notes 20
Resetting
picture settings to the initial preset levels 24
the size/shift to the initial preset levels 27, 28

S

Supplied accessories 57
Supplied tool 13

T

Turning off the on-screen display 23

U

User mode 30

V

Video memory 32

W

Warming up screen 22



Maintenance/Other

SONY.

3-985-264-11 (2)

Multiscan Projector

Installation Manual for Dealers

**VPH-G90E
VPH-G90M
VPH-G90U**

©1998 by Sony Corporation

Table of Contents

Installation

Installation Procedures	5
Before Installation	6
Using the Handles to Carry the Projector	6
Necessary Clearance for Installation and Maintenance	7
Notes on Screen	10
Installation Diagrams	12
Floor Installation Using Front Projection Flat Screen	12
Ceiling Installation Using Front Projection Flat Screen	14
Floor Installation Using Rear Projection Flat Screen	16
Modifying Parts	18
Opening the Upper Cover	18
Using the Adjusters	19
Changing the Polarity	20
Adjusting the CRT Conversion Angle	22

Connections

Location and Function of the Rear Panel	24
Switching the 75-ohm Terminate Connectors (VPH-G90M/G90U only)	27
Connecting Directly to the Projector	29
Connecting Multiple Projectors	30
Using the PC-3000 Signal Interface Switcher	32
Confirming the System Construction	37
Using the PC-1271/1271M Signal Interface Switcher ..	38

Before Adjustment

For Remote Control	42
Preparation of the Remote Commander	42
Keys on the Remote Commander	46
Using the MENU	50
Basic Menu Operation	50
Menu Modes	51
The PIC CTRL (Picture Control) Menu	55
The PIC SETTING 1 (Picture Setting 1) Menu	57
The PIC SETTING 2 (Picture Setting 2) Menu	58
The INPUT SETTING Menu	59
The SET SETTING 1 Menu	62
The SET SETTING 2 Menu	63
The INPUT INFO (Information) Menu	65

The INPUT MEM. (memory) OPTION Menu	66
The SET INFO (information) Menu	68
The SERVICE SETTING 1 Menu	68
The SERVICE SETTING 2 Menu	69
The SERVICE SETTING 3 Menu	70
The PIC ORBITING Menu	71
The INT. OSC (internal oscillation) SETTING Menu	72
The TIMER Menu	73
The ABL (Automatic Brightness Limiter) LINK Menu	74
Test Patterns	75
Test Patterns	75
Test Patterns in Each Mode	76
Warm-up before adjustment	77

Adjustments

Adjustment Procedure	78
Adjusting the Lens Focus and Scheimpflug	81
Preparation	81
Adjusting the Green Lens Focus and Scheimpflug	85
Adjusting the Red Lens Focus and Scheimpflug	86
Adjusting the Blue Lens Focus and Scheimpflug	87
Adjusting the Magnetic Focus	92
Saving the Standard Magnetic Focus Data	93
Adjusting the Registration	93
Preparation	93
Keys for Adjusting	94
Adjusting the Green Registration	95
Adjusting the Red Registration	108
Adjusting the Blue Registration	119
Saving the Standard Registration Data	121
Fine Adjustment for Each Input Signal	122
Selecting the Input Signal	122
Fine Magnetic Focus and AQP/DQP Adjustments	122
Fine Registration Adjustment	122
SIZE Adjustment	123
SHIFT Adjustment	123
Blanking Adjustment	124
Adjusting the White Balance	125
Adjusting the Picture Quality	129

(continued)

Table of contents

Saving the Adjustment Data 130

Memory Blocks 130

Saving the Data to the Service Block 132

Input Memory 133

Video Memory 137

Resetting the Data 138

Resetting the Item in Adjustment Only (Normal Reset) 138

Resetting Multiple Items Simultaneously (All Data Reset) 139

Others

Setting the Index Numbers 141

Link Functions 145

Using the Linked ABL Function 145

Self-diagnosis Function 148

List of the Projection Distance by Angle of Optical Axis 150

Index 156

Installation

Installation Procedures

By default, this projector is adjusted for 120-inch front projection on the floor/desk. If you install the projector in other conditions, you have to change some settings. Therefore, installation procedures depend on the screen size or type, and installation method.

- ① Verify the conditions of installation, such as angle of optical axis, projection distance, height of the projector and screen.
↓
- ② Change the polarity according to the projection patterns. (page 20)
↓
- ③ Install the projector and screen. (page 12)
↓
- ④ Adjust the lens focus approximately. (page 81)
↓
- ⑤ Reset the registration data to the factory setting. (page 138)
↓
- ⑥ Adjust the CRT conversion angle. (page 22)
↓
- ⑦ Connect external video equipment. (page 27)
↓

The installation is completed.
Perform the adjustments following the adjustment procedure.
(page 76)

Before Installation




Installation

Using the Handles to Carry the Projector

Carry the projector with four persons or more by using the front, rear and side (right and left) handles.


Using the handles

Pull out the front and rear handles or the side handles.



Putting away the handles

Push the handle release lever under each handle. The handle is automatically retracted.



Installation


Necessary Clearance for Installation and Maintenance

Make sure to provide enough room for maintenance service. Install the projector, making reference to the dimensions below.


Note

There should be a space of at least 30 cm (1 1/8 inches) around the ventilation holes at the rear. Never block the holes with any material.

Front



Rear



Before Installation


Bottom




The standard hole for installation on the bottom surface is useful for reference when measuring for installation. There are seven holes on the bottom surface of the projector. For ceiling installation using the optional PSS-90 Projector Suspension Support, use five holes to attach the PSS-90. The other two holes are spare ones.

Notes


- Use only the M8 meter screws of 10 mm ($^{11}/_{32}$ inches) to 30 mm ($1\frac{1}{16}$ inches) long for the attachment holes for the PSS-90.
- When attaching the PSS-90, use the M8 meter screws of 20 mm ($^{27}/_{16}$ inches) supplied with the PSS-90.



Side



With the covers open




Before Installation



Notes on Screen

Screen size

The screen size is the diagonal length of the screen in inches, while the aspect ratio of the screen is 4:3. The ratio of the screen height, width, and diagonal is 3:4:5.



If you use a screen with 4:3 aspect ratio whose size is not given in the table below, you can calculate the screen height and width from the screen size (inches) as follows.
Calculate at the conversion rate of 25.4 mm to the inch.

Height (mm) = Screen size $\times 25.4 \times \frac{3}{5}$
Width (mm) = Screen size $\times 25.4 \times \frac{4}{5}$

Screen size and dimensions

Screen size (Diagonal)	Height (mm)	Width (mm)
90	1372	1829
100	1524	2032
120	1829	2438
150	2286	3048
180	2743	3658
200	3048	4064
250	3810	5080
300	4572	6096

Screens with an aspect ratio other than 4:3

When the height is greater
Calculate the screen size with 4:3 aspect ratio from the screen height as shown below. Install the projector and screen in accordance with the screen size obtained.




---: Screen whose aspect ratio is 4:3

Screen size (inch) = (height (mm) $\times \frac{3}{4}$) $\times \frac{1}{25.4}$

Example: When the screen height is 1500 mm
(1500 (mm) $\times \frac{3}{4}$) $\times \frac{1}{25.4}$ = Approx. 98 inches

When the width is greater

Calculate the screen size with 4:3 aspect ratio from the screen width as shown below. Install the projector and screen in accordance with the screen size obtained.



---: Screen whose aspect ratio is 4:3


Screen size (inch) = (width (mm) $\times \frac{4}{3}$) $\times \frac{1}{25.4}$

Example: When the screen width is 2000 mm
(2000 (mm) $\times \frac{4}{3}$) $\times \frac{1}{25.4}$ = Approx. 98 inches




Types of screen


Front projection screen for floor installation
The bead screen is recommended. A screen of this type reflects the brightest light.




Front projection screen for ceiling installation
The silver screen is recommended. You can get a picture that is two to four times brighter than that of the white screens.



Rear projection screen
A screen manufactured using two sheets, the fresnel and lenticular, is recommended for a bright and clear full-screen picture projection.




White screen
When viewers watch the projected picture in a wide area, you can obtain a picture that appears equally bright from all parts of the room using the white screen for both floor and ceiling installations. Note that you will not be able to get a clear picture in this case unless the room is dark.



Installation Diagrams

Floor Installation Using Front Projection Flat Screen

Be sure that the projector is level to the floor.



Screen size (inches)	90	100	120	150	180	200	250	300
The distances in gray are the factory preset settings. Unit: mm (inches)								
A (Vaize)	1372 (54 1/8)	1524 (60)	1829 (72 3/8)	2286 (90)	2743 (108)	3048 (120)	3810 (150)	4572 (180)
B (Hcent)	889 (35)	950 (37 1/2)	1074 (42 3/8)	1288 (50 3/4)	1488 (58 5/8)	1621 (63 3/4)	1942 (76 1/2)	2287 (90 1/4)
C (Width)			28" (1 1/8)	32" (1 1/4)				
D (TD)	2587 (101 7/8)	2847 (112 1/8)	3373 (132 7/8)	4285 (168 3/4)	5137 (202 1/4)	5702 (224 1/2)	7065 (278 1/4)	8533 (336)
E (Xiens)	2514 (99)	2767 (109)	3278 (128 3/4)	4165 (164)	4993 (196 1/4)	5542 (218 1/4)	6867 (270 1/4)	8294 (326 3/4)
F (Lhole)	2795 (110 1/8)	3048 (120)	3559 (140 1/4)	4445 (175)	5273 (207 3/4)	5823 (229 1/2)	7147 (281 1/2)	8574 (337 3/4)
G (Lmax)	3520 (138 5/8)	3773 (148 5/8)	4294 (169 1/4)	5171 (203 3/4)	5999 (236 1/4)	6549 (257 1/2)	7873 (310)	9300 (366 3/4)
H (Lfront)	2437 (96)	2690 (106)	3201 (126 1/4)	4088 (161)	4916 (193 3/4)	5465 (215 1/4)	6790 (267 3/4)	8217 (323 3/4)


- a) Sony VPS-100FM
b) Sony VPS-120FH and VPS-120FM

When the Screen Size is not Mentioned in the Tables

You can calculate the installation measurements described below when you use the screen whose size is not mentioned in the tables on pages 12 and 14.

Check your installation conditions:

- Screen size to be used (S)
 - Installation measurements at the end of the manual, ES and BS for smaller screen size and EL and BL for larger screen size
- See the tables on pages 150 to 155.



Now you can calculate the installation measurements as follows:

$$E \text{ (mm)} = ES + (S - \text{smaller screen size}) \times (EL - ES) \times 0.1$$
$$B \text{ (mm)} = BS + (S - \text{smaller screen size}) \times (BL - BS) \times 0.1 + 289$$

Example: when using 124-inch screen

According to the tables on page 151, the values E and B are as follows:

$$ES = 3279, BS = 791 \text{ (As the smaller screen size is 120 inch.)}$$

$$EL = 3570, BL = 861 \text{ (As the smaller screen size is 130 inch.)}$$

Therefore,


$$E \text{ (mm)} = 3279 + ((124 - 120) \times (3570 - 3279) \times 0.1) = 3395.4 \text{ (mm)}$$

$$B \text{ (mm)} = 791 + ((124 - 120) \times (861 - 791) \times 0.1) + 289 = 1108 \text{ (mm)}$$

Installation Diagrams

Ceiling Installation Using Front Projection Flat Screen

Use the PSS-90 Projector Suspension Support (not supplied).




Screen size (inches)	90	100	120	150	180	200	250	300
A (Vsize)	1372 (54 1/4)	1524 (60)	1829 (72 1/4)	2286 (90)	2743 (108)	3048 (120)	3810 (150)	4572 (180)
B (Hcent)	985 (38 3/4)	1046 (41 1/4)	1170 (46 1/4)	1384 (54 1/2)	1584 (62 1/4)	1717 (67 1/4)	2038 (80 1/4)	2383 (93 3/4)
D (TD)	2587 (101 7/8)	2847 (112 1/4)	3373 (132 5/8)	4285 (168 3/4)	5137 (202 1/4)	5702 (224 1/2)	7065 (278 1/4)	8533 (336)
E (Xlens)	2514 (99)	2767 (109)	3278 (129 1/4)	4165 (164)	4993 (196 1/4)	5542 (218 1/4)	6867 (270 3/4)	8294 (326 1/4)
F (Lhole)	2932 (115 1/2)	3185 (125 1/2)	3696 (145 1/4)	4310 (169 3/4)	5138 (202 1/4)	5687 (224)	7012 (276 1/4)	8439 (332 1/4)
G (Lmax)	3520 (138 3/4)	3773 (148 3/4)	4284 (168 3/4)	5171 (203 3/4)	5999 (236 1/4)	6548 (257 1/4)	7873 (310)	9300 (366 1/4)
H (Lfront)	2437 (96)	2690 (106)	3201 (126 1/4)	4088 (161)	4916 (193 3/4)	5465 (215 1/4)	6790 (267 1/4)	8217 (323 3/4)

Necessary parts modifications
Changing the polarity used for "Ceiling installation, front projection"
For details, see "Changing the Polarity" on page 20.


Attaching the PSS-90 Projector Suspension Support

Attach the projector mounting bracket to the bottom surface of the projector.
Use five each of the M8x20 bolts, M8 washers and spring washers, all of which are supplied with the PSS-90.

- 1 Align the two projections on the projector mounting bracket with the receptacles on the bottom surface of the projector.
- 2 Fasten the five bolts and washers to fix the mounting bracket to the five holes for attaching the PSS-90 on the bottom surface of the projector.



For attaching the PSS-90 to the ceiling, refer to the Installation Manual of the PSS-90 Projector Suspension Support.



Installation Diagrams


Floor Installation Using Rear Projection Flat Screen

What is the optical axis angle?

The optical axis angle is the angle between the horizontal level line and the straight line from the center of the projector's green lens to the center of the screen. When using a rear projection screen, you can get the brightest picture when the center of the screen is aligned with a straight line extension of the center of the green lens.

Therefore, the most suitable optical axis angle varies depending on the height of the screen and your line of sight.

When the optical axis angle is 2°



Screen size (inches)	90	100	120	150	180	200	250	300
A (Vsize)	1372 (54 1/8)	1524 (60)	1829 (72 1/8)	2286 (90)	2743 (108)	3048 (120)	3810 (150)	4572 (180)
B (Hcent)	95 (3 3/4)	86 (3 1/2)	67 (2 3/4)	36 (1 7/8)	6 (1/4)	-13 (-1 1/8)	-60 (-2 3/8)	-111 (-4 3/8)
E (Xlens)	2567 (101 1/8)	2826 (111 1/8)	3348 (131 1/8)	4252 (167 1/2)	5097 (200 3/4)	5559 (222 1/8)	7011 (276 1/8)	8467 (333 3/8)
F (Lhole)	2873 (113 1/8)	3132 (123 3/8)	3653 (143 7/8)	4558 (179 1/2)	5402 (212 3/4)	5964 (234 7/8)	7316 (288 1/8)	8772 (345 3/8)
G (Lmax)	3594 (141 1/2)	3953 (155 7/8)	4375 (172 1/4)	5279 (207 7/8)	6124 (241 1/4)	6686 (263 1/4)	8038 (316 1/2)	9494 (373 3/8)

Necessary parts modifications

Changing the polarity used for "Floor installation, rear projection"
For details, see "Changing the Polarity" on page 20.




Variable Range of the Optical Axis Angle in Rear Projection

You can change the optical axis angle within the following ranges by adjusting the scheimpflug.

For adjusting the scheimpflug, see page 81.


On floor installation

You can install the projector within an angle of optical axis -13.6° to +2°.



On ceiling installation

You can install the projector within an angle of optical axis +3° to +13.6°.



Modifying Parts




Installation

Opening the Upper Cover


Most modifications can be performed only by opening the upper cover.

- 1 Turn off the main power of the projector.
- 2 Unlock the two screws on the projector by using a screwdriver, and then open the upper cover.



To remove the supplied tool


The tool is located on the back of the upper cover. Loosen the screw by using a screwdriver and remove the tool.



Installation

Using the Adjusters

When the projector installation location is not horizontal, adjust the adjusters so that the projector is placed horizontally. Use the supplied tool to turn the adjuster.



Note

The supplied tool can rotate the screw in one direction only. To rotate the screw in the reverse direction, turn the tool upside down.

Caution

Do not turn the tool forcibly when the screw has fully rotated. Otherwise, the tool may slip out and injure your hand.


Modifying Parts

Changing the Polarity


The polarity of the projector is adjusted at the factory to use the projector for front projection on the floor.
When the projector is installed on the ceiling or used in rear projection, it is necessary to change the settings of the polarity switches.

How to change the polarity

- 1 Turn off the power of the projector.
- 2 Open the control panel cover, loosen the screw, and open the cover of the polarity switches.



- 3 Change the position of the polarity switches (V and H switches), if necessary.



- 4 Close the cover of the polarity switches, tighten the screw and close the control cover.

Note

If the cover of the polarity switches does not shut firmly, the power of the projector is not turned on in order to protect the CRTs.



Installation methods and settings of the polarity switches



Installation methods	Position of the V switch	Position of the H switch	On-screen display by default (See below.)
Front projection, floor	Upper	Left	Correct
Front projection, ceiling	Lower	Right	C
Rear projection, floor	Upper	Right	A
Rear projection, ceiling	Lower	Left	B
Others	Display letters on the screen so that you can determine which changes to make. For on-screen display and necessary changes, see below.		

Polarity and on-screen display

When the projector is installed on the ceiling or used in rear projection without changing the polarity, one of the following on-screen displays appears. In this case, you have to change the polarity corresponding to the installation methods.


- A The letters are backward.
- B The letters are upside down.

Change the position of the V switch.



- C The letters are upside down and backward.

Change the positions of the H and V switches.




Modifying Parts



Adjusting the CRT Conversion Angle


Adjust the CRT conversion angle so that the three CRT images converge exactly.

- 1 Open the upper cover.
For details, see "Opening the Upper Cover" on page 18.
- 2 Turn on the power of the projector.
- 3 Set the remote commander to the service mode.
For details, see "Preparation of the Remote Commander" on page 43.
- 4 Reset the green, red and blue centering.
For details, see "Resetting the Data" on page 138.
- 5 Make sure that the on-screen display is shown as follows:
 - The center of the green hatch pattern aligns with the horizontal center of the screen.
 - The center of the red and blue hatch patterns align at even intervals from the green hatch pattern.




If the center of the green hatch pattern does not align with the center of the screen, re-install the projector correctly.

- 6 Loosen the two red CRT fixing screws (black) by using a Philips-head screwdriver. Make sure not to remove the screws.



- 7 Insert the two adjustment screws (gold) into the appropriate adjustment holes corresponding to the screen size.



By default, the two adjustment screws (gold) are fixed to the two adjustment holes for 120 inch screens.
For 90 and 300 inch screens other than 120 inch ones, remove the adjustment screw from the 120 inch hole and insert it into the elliptic hole for 90-300 inch screens. Then, loosen the other adjustment screw.

- 8 For screens other than 120 inch screens, move the red CRT right and left so that the vertical line of the red cross hatch pattern converges with the green pattern, then tighten the two adjustment screws (gold).


Caution

When moving the CRT, do not insert your hands into the small opening between the lenses. Doing so may injure your hand.

- 9 Tighten the two red CRT fixing screws (black).
- 10 Repeat steps 6 to 9 to loosen the two blue CRT fixing screws (black), adjust the blue CRT conversion angle and tighten the two adjustment screws (gold).

Connections

Location and Function of the Rear Panel



- 1 Signal interface board attachment part (INPUT B)**
An optional signal interface board such as IFB-12/12A and IFB-40 can be attached to this section. When the IFB-12/12A is attached, the signal input to the INPUT A connectors can be output from the IFB-12/12A by setting it to output mode.
- 2 MAIN POWER switch**
- 3 AC IN socket**
Connect the supplied AC power cord.

- 4 Signal interface board attachment part (INPUT C)**
An optional signal interface board can be attached to this section.

Notes

- The IFB-40 cannot be attached to INPUT C.
- When the IFB-12/12A is attached, the IFB-12/12A cannot be set to output mode.

ON indicator

When the projector is turned on, this indicator lights in green.

STANDBY indicator

When the MAIN POWER switch on the projector is turned ON, this indicator lights in orange, indicating that the projector can be turned on/off using the remote commander.

Rear remote control detector

INPUT A connectors (BNC type)
R/R-Y/Ps, G/Y, B/B-Y/Ps, SYNC/HD, VD connectors: Connect to the outputs of a computer or a video camera. According to the connected equipment, the RGB (R, G, B), component (R-Y, Y, B-Y) or HDTV (Ps, Y, Pb) signal is selected.

VIDEO connectors*

VIDEO IN connector (BNC type): Connects to the composite video output of the video equipment.
VIDEO OUT connector (BNC type): Connects to the composite video input of a color monitor.
S VIDEO IN/OUT connectors (4-pin, mini-DIN type): Connects to the S video output or input of the video equipment.
Y IN, C IN connectors (BNC type): Connects to the Y and C video outputs of the video equipment.

Note

The S VIDEO IN connector is disconnected when a cable is connected to the Y IN/C IN connectors.

* Note on the VPH-G90E model

The optional IFB-G90E Video Interface Board is required for using the VIDEO connectors.

LINK IN/OUT jacks (stereo minijack)
When connecting multiple projectors, connect the LINK OUT jack to the LINK IN jack on another projector. Then the ABL LINK function can be used. For details of the link function, see page 146.

TRIGGER connector (minijack)

When the projector is turned on, 12 V is output. When it is turned off, 0 V is output. However, the connector cannot be used as the power source.

LED display window

Self-diagnosis results and PJ COM communication conditions, etc. are displayed using two-digit numbers and alphabets.

Self-diagnosis codes are displayed in red or orange, and the warning and communication conditions in green.

For details, see "Self-diagnosis functions" on page 148.

CONTROL S jacks

IN/PLUG IN POWER jack (stereo minijack):

Connects to the CONTROL S OUT jack of other Sony equipment. Also connects to the CONTROL S OUT jack of the supplied remote commander with the supplied remote control cable (stereo cable) to be used as a wired remote control. In this case, this jack supplies the power to the remote commander to save the battery power.

OUT jack (stereo minijack): Connects to the CONTROL S IN jack of other Sony equipment.

Note

When using this jack, the remote control detector on the projector does not function.



Location and Function of the Rear Panel

④ DEVICE INDEX switches

When multiple projectors are connected, set the device index number of each projector.

To display the device index number on the screen, press the NORMAL key, and the ENTER key on the remote commander.

Note

Do not set the device index number to "00." If you do, the projector will not operate with the remote commander.
You can operate the projector with the keys on the control panel of the projector but the connected equipment cannot be operated with the keys on the control panel.

⑤ RS-232C/RS-422A selector

Selects the function of the RS-232C/RS-422A connector.

⑥ RS-232C/422A REMOTE connector (D-sub 9-pin)

Used to expand the system connections using the RS-232C/422A interface.

⑦ PJ COM (projector communication) IN/OUT connectors (D-sub 9-pin)

These are the connectors conforming to the RS-485 standards, especially designed to expand the system using Sony projectors.

Use these connectors to connect the PJ COM system of the PC-3000 Signal Interface Switcher.

When the cable is connected to the IN connector only, attach the supplied terminator to the OUT connector.

To connect multiple projectors, connect the IN connector to the OUT connector of another projector in cascade, and attach the supplied terminator to the OUT connector of the last projector.

For details on the specifications of the connector, refer to the Protocol Manual prepared by Sony.

About the keys on the control panel

The control panel is located inside the cover on the top of the projector. The locations and functions of the keys on the control panel are the same as those on the remote commander.

For the keys on the remote commander, see page 46.

The keys on the control panel are basically effective for this projector only. Only the commands from the SYS SET key and the switcher select commands are transmitted to the connected equipment via the PJ COM connector.


Note

If you set the device index number to "00," the commands from the SYS SET key and the switcher select commands will not be transmitted to the other equipment. Do not set the device index number to "00."


Switching the 75-ohm Terminate Connectors (VPH-G90M/G90U only)

Depending on the connections of the computer and color monitor to the projector, it may be necessary to switch the 75-ohm terminate connectors on the BA board at the rear of the projector.

- 1 Loosen the ten screws at the rear of the projector to remove the connector panel.



- 2 Disconnect the CN351 connector from the BA board.




(continued)




Switching the 75-ohm Terminate Connectors

3 Open the card pullers and pull out the BA and BB boards carefully. Be careful not to pull the wires.




4 Switch the CN347, CN348 and CN349 connectors on the BA board. 75 Ω (pin position 3) is selected at the factory. Set to OPEN (pin position 1) when the input signal is distributed into other equipment using a branch connector and is terminated at 75 ohms on that equipment.



Connecting Directly to the Projector

This is an example to connect pieces of video equipment directly to a single projector. Use the IFU-1271/1271M Signal Interface Unit.




Setting up

- Set INPUT A in the SET SETTING 1 menu (page 62) to RGB.
- Select VIDEO or S VIDEO by pressing the INPUT SELECT keys on the remote commander.
- Switch the 75-ohm terminate connectors on the BA board according to the connections of the computer and color monitor.

For details, see "Switching the 75-ohm Terminate Connectors" on page 27.

Connecting Multiple Projectors

This is an example to connect multiple projectors directly using the PJ COM interface. Install the optional IFB-12/12A Signal Interface Board to the INPUT B section of the projector.



Setting up

- Set the IN/OUT selector on the IFB-12/12A to OUT (output). The signal input to INPUT A is output from the IFB-12/12A.
- Set the device index number of the first projector which is connected directly to the video equipment or computer to "01," and the second projector to "02" (page 142).
- Switch the 75-ohm terminate connectors on the BA board according to the connections of the computer and color monitor.
For details, see "Switching the 75-ohm Terminate Connectors" on page 27.
- When using the remote commander as a wireless remote control, activate the remote control detector of a piece of the equipment in the system only and deactivate those of the other equipment. Perform the setting on the projector using "SIRCS RECEIVER" in the SET SETTING 2 menu (page 64).


Note

Be sure to terminate the PJ COM IN or OUT connector not in use by attaching the supplied terminator.

Using the PC-3000 Signal Interface Switcher

When you connect the PC-3000 Signal Interface Switcher (not supplied) to the INPUT A section, you can connect easily various input sources and switch them by pressing the SWITCHER/VIDEO MEMORY/INDEX keys on the remote commander.

When one PC-3000 switcher is used



Note


Be sure to terminate the PJ COM IN or OUT connector not in use by attaching the supplied terminator.

Setting up

- Set the device index number of the projector to "01" (page 142).
- Set the switcher number to "1" on the switcher.
- For setting, refer to the Operating Instructions of the switcher.
- When using the remote commander as a wireless remote control, activate the remote control detector of a piece of the equipment in the system only and deactivate those of the other equipment. Perform the setting on the projector using "SIRCS RECEIVER" in the SET SETTING 2 menu (page 64).
- For setting on the switcher, refer to the Operating Instructions of the switcher.

When two or more PC-3000 switchers are used

This is an example to connect multiple PC-3000 switchers. Up to 8 switchers can be selected.



Notes

- Be sure to terminate the PJ COM IN or OUT connector not in use by attaching the supplied terminator.
- The signal from the second to 8th switchers should be input to the first switcher via the IFB-12/12A Signal Interface Board installed to slot 1 of the first switcher.
- For details, refer to the Operating Instructions of the switcher.

(continued)

Using the PC-3000 Signal Interface Switcher

Setting up


- Set the device index number of the projector to "01" (page 142).
 - Set the switcher number of the switcher which is connected directly to the projector to "1," and that of the second switcher to "2," and so on.
For details, refer to the Operating Instructions of the switcher.
 - When using the remote commander as a wireless remote control, activate the remote control detector of a piece of the equipment in the system only and deactivate those of the other equipment. Perform the setting on the projector using "SIRCS RECEIVER" in the SET SETTING 2 menu (page 63).
- For setting on the switcher, refer to the Operating Instructions of the switcher.*



Connections

Connecting multiple projectors using the PC-3000 switcher(s)

This is an example to connect multiple projectors and two PC-3000 switchers.
Install the IFB-12/12A Signal Interface Board to the INPUT B section of the first projector.



(continued)

Using the PC-3000 Signal Interface Switcher

Notes

- Be sure to terminate the PJ COM IN or OUT connector not in use by attaching the supplied terminator.
 - The signal from the second switcher should be input to the first switcher via the IFB-12/12A signal interface board installed to slot 1 of the first switcher.
- For details, refer to the *Operating Instructions of the switcher*.

Setting up

- Set the IN/OUT selector on the IFB-12/12A to OUT (output). The signal input to INPUT A is output from the IFB-12/12A.
 - Set the device index number of the first projector which is connected directly to the video equipment or computer to "01," and the second projector to "02." (page 142).
 - Set the switcher number of the switcher which is connected directly to the projector to "1," and that of the second switcher to "2," and so on.
 - For details, refer to the *Operating Instructions of the switcher*.
 - When using the remote commander as a wireless remote control, activate the remote control detector of a piece of the equipment in the system only and deactivate those of the other equipment. Perform the setting on the projector using "SIRCS RECEIVER" in the SET SETTING 2 menu (page 64).
- For setting on the switcher, refer to the *Operating Instructions of the switcher*.



Connections

Confirming the System Construction

After all the connections are complete, confirm that equipment of the system is properly setup.

- 1 Connect the AC power cords of all equipment to the AC outlets.
- 2 Press the SYS SET key on the remote commander or the control panel. Information on the system construction and the settings of the interface boards, etc. are automatically confirmed. Then the message disappears.

Note

When you want to use the projector without connecting the switcher after using the switcher in the system connections, it is necessary to confirm the system construction again by pressing the SYS SET key after all the connections are complete. If you press the key, "Master Switcher not exit" appears, but the system construction is automatically recognized.

When a system error is detected

The following messages are displayed on the screen.


Message	Remedy
Master Switcher not exist.	Set the switcher that outputs the signal to the projector to number 1.
Same DEVICE INDEX for Projector detected.	Change either number of the projectors that have the same number.
Same DEVICE INDEX for Switcher detected.	Change either number of the switchers that have the same number.

Using the PC-1271/1271M Signal Interface Switcher

When you install the optional IFB-40 Signal Interface Board to the projector and connect the PC-1271/1271M Signal Interface Switcher to the IFB-40, you can connect easily various input sources.

You can select the input to the switcher easily by pressing the SWITCHER/VIDEO MEMORY/INDEX keys on the remote commander.

Connecting the PC-1271/1271M using the SIC-M or CCQ-BRS connecting cable



Notes


- Insert the female and male plugs of the SIC-M or CCQ-BRS cable correctly.
- You can extend the SIC-M or CCQ-BRS cable up to 50 m.
- The video signal input to the IFB-40 installed to the INPUT B section should not exceed 70 MHz. When projecting the video signal which exceeds 70 MHz, connect the signal source to the INPUT A connectors using the 5BNC cables.

Setting up

- Set INPUT-A in the SET SETTING 1 menu (on page 62) to RGB.
- Select VIDEO or S VIDEO by pressing the INPUT SELECT keys on the remote commander.
- Set the SINGLE/SECOND/OTHER select switch on the switcher to SINGLE.

Connecting the PC-1271/1271M using both the SIC-M or CCQ-BRS connecting cable and the 5BNC cables (5BNC mode 1)

When you connect both the video and RGB signal input sources to the PC-1271/1271M switcher, use the SIC-M or CCQ-BRS connecting cable and the BNC cables for connection between the projector and switcher.



Notes

- Insert the female and male plugs of the SIC-M or CCQ-BRS cable correctly.
- You can extend the SIC-M or CCQ-BRS cable up to 50 m.
- The video signal input to the signal interface board IFB-40 installed to the INPUT B section should not exceed 70 MHz. When projecting the video signal which exceeds 70 MHz, connect the signal source to the INPUT A connectors using the 5BNC cables.

(continued)

Using the PC-1271/1271M Signal Interface Switcher


Setting up

- Set INPUT-A in the SET SETTING 1 menu (page 62) to RGB and 5BNC MODE in the SERVICE SETTING 1 menu (page 69) to ON.
- Select VIDEO or S VIDEO by pressing the INPUT SELECT keys on the remote commander.
- Set the SINGLE/SECOND/OTHER select switch on the switcher to SINGLE.



Connecting the PC-1271/1271M using the 5BNC cables (5BNC mode 2)

When the PC-1271/1271M switcher is to be connected is more than 50 m away from the projector, or the SIC-M or CCQ-BRS cable cannot be used for the connection between the projector and switcher, connect the RGB signal sources to the switcher and the video signal sources to the projector.



Setting up

- Set INPUT-A in the SET SETTING 1 menu (page 62) to RGB and 5BNC MODE in the SERVICE SETTING 1 menu (page 69) to ON.
- Select VIDEO or S VIDEO by pressing the INPUT SELECT keys on the remote control.
- Set the SINGLE/SECOND/OTHER select switch on the switcher to SINGLE.
- When the HDTV signal is input to the switcher, set the output of the connected equipment or the IFB-1301 Signal Interface Board installed to the switcher to GBR OUT.
- When the component signal is input to the switcher, set the output of the connected equipment or the IFB-1200 Signal Interface Board installed to the switcher to RGB OUT.


Before Adjustment

For Remote Control

All adjustments, except focusing the lens and adjusting the scheimpflug, can be made with the supplied remote commander.
 Since the remote commander uses infrared, you can use it without a wire. However, in order to correctly control the projector, you should connect the remote commander to the projector with the supplied remote control cable.
 Normally, the remote commander is set to the user mode and the adjustment keys on the remote commander are inoperable to prevent accidental adjustments. Cancel the protection before adjusting.

Preparation of the Remote Commander


- 1 Insert the three supplied R6 (size AA) batteries with the polarities lined up correctly.
For details, see "Battery installation" on page 44.
- 2 Connect the remote commander to the projector.
See "Connecting the remote commander to the projector" on page 45.
- 3 Make sure that the COMMAND ON/OFF switch on the remote commander is set to ON.
- 4 Turn on the MAIN POWER switch on the projector, and then press the ON key on the remote commander.
- 5 Open the panel cover of the adjustment keys.



6 Press the keys in the following order:

ENTER → ENTER → ♦ → ♦ → ENTER

Be sure to press the keys one after another within 2 seconds.
 The following display appears.



7 Press the ♦ or ♦ key to select YES, then press the ENTER key.

The protection on the adjustment keys is cancelled and the service adjustment keys are enabled (service mode).

After the adjustment, reset to the user mode to reactivate the protection.
To reset to the user mode, see "To exit from the service mode" on page 53.


For Remote Control

Notes for wireless remote control operation


- Be sure that there are no obstructions between the remote commander and the projector.
- Operating range is limited. The shorter the distance between the remote commander and the projector, the wider the angle in which the remote commander can control the projector.

Battery installation


1 Push to open the lid.



2 Install three R6 (size AA) batteries (supplied) with the correct polarity.




3 Replace the lid.



Notes on batteries

- If the projector does not operate properly, the batteries might be worn out. Replace all three of them with new ones.
- The life of the batteries depends on frequency of usage and how often you use the LIGHT button. If they are worn out quickly, replace them with new alkaline batteries.
- To avoid damage from possible battery leakage, remove the batteries when the remote commander will not be used for a long time.

Connecting the remote commander to the projector



Note

When you connect the remote commander to the projector as mentioned above, the remote control detector of the projector does not function. For wireless operation, be sure to disconnect both plugs from the projector and the remote commander.




Before Adjustment

For Remote Control

Keys on the Remote Commander

Notes

- The RGB APA/DOT PHASE **4**, VOL +/- **10**, FOCUS LENS **19**, INPUT SELECT D **25**, LCD LENS CONTROL **26** and AUDIO MUTING **27** keys do not function with this projector.
- The RGB SIZE/SHIFT **4**, CENT R/B **5** and BLKG **28** keys function only in the pro-user, service or expert mode.
- The MG FOCUS **1**, W/B BIAS/GAIN **29**, REGISTRATION **30**, ADJ R/G/B **31** and CUT OFF R/G/B **32** keys function only in the service or expert mode.



1 LIGHT button

Illuminates the key indicators when the COMMAND switch **5** is set to ON. If the COMMAND switch is set to OFF, only the COMMAND switch is illuminated. The key indicators turn off if you press the LIGHT button again.

If you do not press any key for more than 30 seconds, the indicators also turn off automatically. When the remote commander is connected to the CONTROL S IN/PLUG IN POWER jack of the projector via the remote control cable, the power is supplied to the remote commander from the projector.

2 Transmission indicator

Lights each time you press a key. If it does not light, replace the batteries with new ones.

3 STATUS ON/OFF keys

Press OFF to eliminate the on-screen display. Press ON to restore the on-screen display.

Note

The menus and warning messages appear even if the OFF key is pressed.

4 RGB keys

Adjust the picture.
APA: This key does not function with this projector.
DOT PHASE: This key does not function with this projector.

SIZE: Enters the size adjustment mode for the input signal. Next adjust the size of the picture using the four arrow keys. Each time you press this key, the COARSE and FINE modes are switched alternately.

• to reduce horizontal size

• to expand horizontal size

• to reduce vertical size

• to expand vertical size

SHIFT: Enters the shift adjustment mode for the input signal. Next adjust the position of the picture using the four arrow keys. The picture shifts in the direction of the arrow on the pressed key. Each time you press this key, the COARSE and FINE modes are switched alternately.

5 COMMAND ON/OFF switch

No keys on the remote commander except the LIGHT button **1** function when this switch is set to OFF. This saves battery power when a button is pressed inadvertently.

6 CENT R/B keys

Enter the centering adjustment mode of the red and blue.

R: Press to enter the red centering adjustment mode.

B: Press to enter the blue centering adjustment mode. Perform the centering adjustment using the four arrow keys.

7 MEMORY key

Stores various adjusted data into memory.

8 ON/SYNDRY keys

Turn on and off the projector when the MAIN POWER switch on the projector is set to ON.

9 MENU key

Displays the main menu. Press it again to turn off the menu.

10 Arrow keys

Adjust the value or select the item in the menu.

11 ENTER key

Stores the settings in the menu, or selects and displays the index number.

12 FUNCTION key

Press to use the extended functions.

13 RESET key

Resets the adjusted levels to the factory preset or service adjusted levels.
For details, see page 138.

14 POSITION +/- keys

Select the position to be adjusted on the screen in focus, registration or blanking adjustment mode. Also, set V SHIFT to WIDE or NARROW in RGB or HDTV input signal's SHIFT adjustment mode and select the color temperature in white balance adjustment mode.

15 PICTURE CONTROL keys

Adjust the picture conditions: CONTR (contrast), BRIGHT (brightness), COLOR, HUE and SHARP (sharpness).

16 VOL (volume) +/- keys

These keys do not function with this projector.

17 MG FOCUS key

Enters the magnetic focus adjustment mode.
For details, see "Adjusting the green magnetic focus, AQP/DQP and AHP/DHP" on page 87.

18 FOCUS LENS key

This key does not function with this projector.

19 POSITION +/- keys

Function the same as the POSITION +/- **14** keys.

20 W/B (white balance) keys

Enter the white balance adjustment mode.
BIAS: Adjusts cut off.
GAIN: Adjusts drive.

21 REGISTRATION keys

Select the desired item for registration adjustment with each key, then adjust the item with the arrow keys.
For details, see "Keys for Adjusting" on page 94.

22 ADJ R/G/B (adjust red/green/blue) keys

Select the color to be adjusted when adjusting the focus, registration and white balance adjustments.

R: Red signal

G: Green signal

B: Blue signal



Before Adjustment



Before Adjustment

For Remote Control

② CUT OFF keys

Select the color to be turned off when adjusting the registration. Press again to turn on the color.

R: Red signal

G: Green signal

B: Blue signal

② SWITCHER/VIDEO MEMORY/INDEX select switch

Selects the function of the SWITCHER/VIDEO MEMORY/INDEX keys.

SWITCHER: to select the input from the PC-3000 or the PC-1271/1271M Signal Interface Switcher.

VIDEO MEMORY: to select the set and adjusted video memory data.

INDEX: to select a projector by its index number when multiple projectors are used.

② SWITCHER/VIDEO MEMORY/INDEX keys

When the SWITCHER/VIDEO MEMORY/INDEX select switch is set to SWITCHER

When the PC-3000 or the PC-1271/1271M Switcher is connected to the projector, press a number key (1 to 8) to select the input from the switcher. Number key 9 and the 10/0 (ALL) key do not function.

To select an input when multiple switchers are connected, set the SWITCHER/VIDEO MEMORY/INDEX select switch to SWITCHER, then press the SW NO/OFF/GROUP key. Next press the switcher number (1 to 8) and the input number (1 to 8) in sequence. Be sure to press the keys one after another within 2 seconds.

e.g. To select input 4 of switcher 2, press the keys as follows:
SW NO → 2 → 4.

When the SWITCHER/VIDEO MEMORY/INDEX select switch is set to VIDEO MEMORY

Select the number of the VIDEO MEMORY. To select the data set and adjusted in INPUT MEMORY, press the SW NO/OFF/GROUP key to set VIDEO MEMORY to OFF.

Note

The 10/0 (ALL) key can be used as "10" key only when the select switch is set to VIDEO MEMORY.

When the SWITCHER/VIDEO MEMORY/INDEX select switch is set to INDEX

When multiple projectors are connected, select the device index number of the projector to be adjusted. Press the device index number (1 to 99) and press the ENTER key. Be sure to press the keys one after another within 2 seconds.

e.g. To select 1, press the keys as follows:

0 → 1 → ENTER, or 1 → ENTER.

To select 12, press the keys as follows:

1 → 2 → ENTER.

When adjusting all the projectors simultaneously, press the 10/0 (ALL) key and ENTER key.

Note

Depending on the projector, pressing "0," "0" and "ENTER" is not effective.

To select the projector to be adjusted when the projectors are divided into multiple groups

First select the group index number and then the projector's device index number.

To select a group, press the SW NO/OFF/GROUP key, the group index number (1 to 99) and the ENTER key in sequence. When the group index has a double-digit number, be sure to press the SW NO/OFF/GROUP key before pressing each number key.

Then press the device index number of the projector (1 to 99) and finally press the ENTER key.

e.g. To select the index number 52 projector in group 91, press the keys as follows:

GROUP → 9 → GROUP → 1 → ENTER → 52 → 2 → ENTER.

② INPUT SELECT keys

Select the input signal.

VIDEO: Video or S video signal input from the VIDEO connectors of the projector (VPH-G90U/G90M) or the optional IFB-G90E Video Interface Board (VPH-G90E)

SELECT VIDEO/S VIDEO: Selects video or S video signal input from the VIDEO connectors after pressing the VIDEO key.

A: The RGB, component or HDTV signal input from the INPUT A connectors of the projector

B: The signal input from the INPUT B section when the optional interface board other than the IFB-40 is installed

C: The signal input from the INPUT C section when the optional interface board is installed.

D: This key does not function with this projector.

Note

To switch the input signal from the INPUT A, INPUT B or INPUT C section to the S VIDEO IN (or Y IN/C IN) connectors, first press the VIDEO key, then press the SELECT VIDEO/S VIDEO key.

② SYS SET (system set) key

When the PC-3000 Signal Interface Switcher is used in the system, press the key to confirm the status of the system, the settings of the interface board, and so on.

② BLKG (blanking) key

Enters the blanking adjustment mode.

You can adjust the blanking with the four arrow keys. For details, see "Blanking Adjustment" on page 124.

② PATTERN key

Displays the internal test patterns of the projector.

Each press of the key advances the test pattern sequentially.

In the focus, registration or white balance adjustment mode, only the test patterns suitable for the adjustment will be displayed.

For details, see "Test Patterns" on page 75.



Before Adjustment

② LCD LENS CONTROL keys

These keys do not function with this projector.

② NORMAL key

Erases the test pattern or cancels the various adjustment modes.

② MUTING keys

PICTURE (Picture): Cuts off the picture. To restore the picture, press the key again.

AUDIO: This key does not function with this projector.


Using the MENU

The projector is equipped with an on-screen menu for making various adjustments and settings.

There are four menu modes for this projector. According to the level of the operator of the projector, the language used in the menu can be changed to French, German, Italian, Spanish, Japanese or Chinese. For details, see "LANGUAGE" on page 64.


Basic Menu Operation

- 1 Press the MENU key.
- The menu display appears.
- The menu presently selected is highlighted in blue.



- 2 Use the $\blacktriangle$ or $\blacktriangledown$ keys to select a menu, then press the $\blacktriangleright$ key or the ENTER key.
- The selected menu appears.
- The setting items that are indicated in white cannot be selected.

Menu items Setting items



- 3 Use the $\blacktriangle$ or $\blacktriangledown$ keys to select a setting item, then press the $\blacktriangleright$ key or the ENTER key.
- The adjustment menu or the setting menu (pop-up menu) appears.

To go to the next page

If there are two or more pages for a menu, the $\blacktriangledown$ indication appears below the bottom item. Move the cursor to the bottom item with the $\blacktriangledown$ key, then press the $\blacktriangleright$ key.

To go back to the previous page

Move the cursor to the top item with the $\blacktriangle$ key, then press the $\blacktriangleright$ key.

- 4 Make adjustment or setting on the menu.

To change the adjustment level

To increase the level, press the $\blacktriangle$ or $\blacktriangleright$ key.

To decrease the level, press the $\blacktriangledown$ or $\blacktriangleright$ key.

Then press the ENTER key to store the level. The original screen is restored.


To select an item

Use the $\blacktriangle$ or $\blacktriangledown$ key to select an item in a pop-up menu.

For some items, the result or effect of the selection is simultaneously reflected on the screen.

For the other items, press the $\blacktriangle$ key or the ENTER key to confirm the selection. The selected setting is stored and the pop-up menu disappears.

Pop-up menu



For details on setting individual items, see the relevant menu pages.

To clear the menu display

Press the MENU key or NORMAL key.

The menu display also disappears automatically if no key is pressed for about one minute.

Memory of the settings

The settings in the menus are automatically stored in the projector memory. You can also store the settings by pressing the MEMORY key.


Menu Modes

There are four menu modes for this projector.

User mode

This is the menu mode for end users. Only the minimum menu items for usual settings and adjustments appear in this mode.

No indication for user mode





The user mode is factory preset. By pressing the MENU key for the first time, the user mode appears.

Using the MENU


Pro-user mode (P)

This is the menu mode for advanced end users who know the operation and functions of the projector very well. The menu items for detailed settings and adjustments are provided so that they can get the most of the projector functions.




To set to the pro-user mode

- 1 Press the MENU key.
The menu in the user mode appears.
- 2 Press the $\blacklozenge$ or $\blacklozenge$ key to select SET SETTING 1, then press the ENTER or $\blacklozenge$ key.




- 3 Press the $\blacklozenge$ or $\blacklozenge$ key to select USER MODE, then press the ENTER or $\blacklozenge$ key.



- 4 Press the $\blacklozenge$ or $\blacklozenge$ key to select PRO in the pop-up menu, then press the ENTER or $\blacklozenge$ key.
The menu disappears.

5

Press the MENU key.
The menu in the pro-user mode appears with the letter "P" at the top-left of the screen.



To reset to the user mode

Perform the same steps for setting to the pro-user mode, and set USER MODE in the SET SETTING 1 menu to NORMAL.
Press the ENTER or $\blacklozenge$ key to turn off the menu. When the MENU key is pressed again, the menu in the user mode appears.


NOTE

When you cancel the service mode or expert mode, the menu mode is reset to either the user mode or the pro-user mode according to the setting of USER MODE in the SET SETTING 1 menu.

Service mode (S)


This is the menu mode for service personnel who are engaged in the installation, adjustments and maintenance of the projector. The menu items required for their jobs are provided.

Service mode indication



To set to the service mode

- 1 Press the NORMAL key.
- 2 Press the keys in the following order:
ENTER $\rightarrow$ ENTER $\rightarrow$ $\blacklozenge$ $\rightarrow$ $\blacklozenge$ $\rightarrow$ ENTER
Be sure to press the keys one after another within 2 seconds.
The following display appears.



- 3 Press the $\blacklozenge$ or $\blacklozenge$ key to select YES, then press the ENTER key.
If you select NO, the display disappears without changing the menu mode.
- 4 Press the MENU key.
The menu in the service mode appears with the letter "S" at the top-left of the screen.

To exit from the service mode

When you press the ON/STANDBY key after the adjustment in the service mode, the projector is set to the standby mode and the menu mode is returned to the user or pro-user mode automatically.
To reset to the user or pro-user mode before setting the projector to the standby mode, do the following:

- 1 Press the NORMAL key.
- 2 Press the keys in the following order:
ENTER $\rightarrow$ ENTER $\rightarrow$ $\blacklozenge$ $\rightarrow$ $\blacklozenge$ $\rightarrow$ ENTER
Be sure to press the keys one after another within 2 seconds.
The following display appears.



- 3 Press the $\blacklozenge$ or $\blacklozenge$ key to select YES, then press the ENTER key.
If you select NO, the display disappears leaving the service mode.

When you press the MENU key, the menu in the user or pro-user mode will appear.



Using the MENU



Expert mode (E)

This is the menu mode for the expert service personnel who have specialized technology and knowledge on the projector.

NOTE

Normally do not use this mode. An inappropriate operation in this mode may degrade the performance of the projector.


Expert mode indication



Before adjustment

To set to the expert mode

- 1 Set the projector to the service mode.
For details, see "To set to the service mode" on page 53.
- 2 Press the NORMAL key.
- 3 Press the keys in the following order:
ENTER → ENTER → → → → ENTER
Be sure to press the keys one after another within 2 seconds.
The following display appears.



- 4 Press the → or → key to select YES, then press the ENTER key.
If you select NO, the display disappears without changing the menu mode.
- 5 Press the MENU key.
The menu in the expert mode appears with the letter "E" at the top-left of the screen.


54 Before adjustment

To exit from the expert mode

When you press the ON/STANDBY key after the adjustment in the expert mode, the projector is set to the standby mode and the menu mode is returned to the user or pro-user mode automatically.

To reset to the service mode before setting the projector to the standby mode, do the following:

- 1 Press the NORMAL key.
- 2 Press the keys in the following order:
ENTER → ENTER → → → → ENTER
Be sure to press the keys one after another within 2 seconds.
The following display appears.




- 3 Press the → or → key to select YES, then press the ENTER key. The service mode is set.
If you select NO, the display disappears leaving the expert mode.

The PIC CTRL (Picture Control) Menu

(User/Pro-user/Service/Expert modes)


The PIC CTRL menu displays the information on the picture adjustments. To adjust the picture, use the keys on the remote commander.
Items that can be adjusted are highlighted in green.
You cannot select the items indicated in white.



Before adjustment

VIDEO MEMORY

Indicates the number of video memory.
The number 1 to 10 can be selected with the VIDEO MEMORY keys on the remote commander.



The video memory is a part of the SET MEMORY, and stores 10 types of the aspect ratio, picture quality, etc.

Select a video memory number 1 to 10, then the aspect ratio and picture quality that you adjust will be stored in the selected video memory.

If you want to use the aspect ratio and picture quality data stored in the INPUT MEMORY, select OFF.


Contents of the video memory data
COLOR TEMPERATURE, D. PICTURE, V. SHIFT, WIDE/NARROW, COMPONENT FORMAT, COMB FILTER, DRC LEVEL, CONTRAST, BRIGHT, COLOR, HUE, SHARP, RGB SIZE, RGB SHIFT, BLANKING

For details, see "Video Memory" on page 137.

Before adjustment 55


Using the MENU

CONTRAST



The higher the setting, the greater the contrast.
The lower the setting, the lower the contrast.

BRIGHT (brightness)




The higher the setting, the brighter the picture.
The lower the setting, the darker the picture.

COLOR




The higher the setting, the greater the intensity.
The lower the setting, the lower the intensity.

HUE



At high settings, the picture becomes greenish.
At low settings, the picture becomes purplish.

SHARP (sharpness)



The higher the setting, the sharper the picture.
The lower the setting, the softer the picture.


Input signals and adjustable/setting items

Item	Input signal			
	Video or S-video (Y/C)*	Component SDI 4:2:2	HDTV	RGB
VIDEO	Y	Y	Y	Y
MEMORY	Y	Y	Y	Y
CONTRAST	Y	Y	Y	Y
BRIGHT	Y	Y	Y	Y
COLOR	Y	Y	Y	N
HUE	Y	Y	Y	N
SHARP	Y	Y	Y	N

Y: Adjustable/can be set
N: Not adjustable/cannot be set
* For the VPH-G90E model, the optional IFB-G90E Video Interface Board is required.


The PIC SETTING 1 (Picture Setting 1) Menu
(Pro-user/Service/Expert modes)

The PIC SETTING 1 menu is used for setting the picture quality.
Items that can be set are highlighted in green.
You cannot select the items indicated in white.



D. (Dynamic) PICTURE


Emphasizes the black of the composite video, S video (Y/C) or component signal.



ON: Emphasizes the black to produce a bolder "dynamic" picture.
OFF: Reproduces the dark portions of the picture accurately, in accordance with the source signal.

COLOR SYS (System)


Selects the color system of the composite video or S video (Y/C) signal.



Select among AUTO, NTSC3.58, PAL, SECAM, NTSC4.43 and PAL-M.
Normally, set to AUTO.
If the picture is distorted or colorless, select the color system according to the input signal.

SET UP

Changes the set up level (standard black level) to 0 IRE or 7.5 IRE according to the NTSC source signal.



0 IRE: Normally, set to this position.
7.5 IRE: Set to this position when the black color is too light.




Before adjustment

Using the MENU

COMPONENT FORMAT

Selects the format of the component input signal.



SMPT/EBU-N10: Set to this position if the input signal is the SMPT/EBU-N10 format component signal.
BETACAM7.5: Set to this position if the input signal is the Betacam format component signal.


Input signals and adjustable/setting items

Item	Input signal		
	Video or S video (Y/C)	Component SDI 4:2:2	HDTV RGB
D. PICTURE	Y	Y	N
COLOR SYS	Y	N	N
SET UP	Y	N	N
COMPONENT FORMAT	N	Y	N

Y: Adjustable/can be set
N: Not adjustable/cannot be set
* For the VPH-G90E model, the optional IFB-G90E Video Interface Board is required.


The PIC SETTING 2 (Picture Setting 2) Menu
(Pro-user/Service/Expert modes)

The PIC SETTING 2 menu is used for setting the picture quality.
Items that can be set are highlighted in green.
You cannot select the items indicated in white.



COMB FILTER


Selects the comb filter which reduces the cross color and dot interference of the NTSC signal to reproduce clear images.



3D: Three-dimensional comb filter. Normally use this comb filter.
3LINE: 3LINE comb filter. This comb filter may be more effective for fast-moving pictures.

DRC (Digital Reality Creation)

Set to ON to make the NTSC signal 4-times density image.




Normally set to ON. When a 15 kHz signal is input, the DRC function activates. When the DRC is not required, set to OFF.

Note

The DRC is effective only when the 15 kHz signal complies with the timing of the video signal. If it has a particular timing, the image may be disturbed with the DRC ON.

DRC LEVEL

Selects the effect of the DRC for the NTSC signal. This item can be selected only for an interlaced signal.



HIGH is preset at the factory. Select LOW if the picture is glaring.

Input signals and adjustable/setting items

Item	Input signal		
	Video or S video (Y/C)	Component SDI 4:2:2	HDTV RGB
COM FILTER	Y	N	N
DRC	Y	Y	N
DRC LEVEL	Y	Y	N


Y: Adjustable/can be set
N: Not adjustable/cannot be set
* For the VPH-G90E model, the optional IFB-G90E Video Interface Board is required.



Before adjustment


The INPUT SETTING Menu
(Pro-user/Service/Expert modes)

The INPUT SETTING menu is used to adjust the input signal.
Items that can be adjusted are displayed in green.
You cannot select the items indicated in white.



COLOR TEMP (Temperature)

Selects the appropriate color temperature according to your application and the input source signal.




9300: standard color temperature for consumer-use products
6500: standard color temperature for business-use products
5400: standard color temperature for HDTV and studio cameras
3200: standard color temperature for medical products
CUSTOM: If you wish to make the color of a particular input signal uniform to that of another display, select CUSTOM, then adjust the white balance.

For details, see "Adjusting the White Balance" on page 125.

Using the MENU

CLAMP

Corrects the luminance of the input picture.



CLAMP is used as a standard for setting the black level of a picture correctly. The standard position of the clamp depends on the kind of sync signal being used. Normally, the projector CPU judges the signal and sets the position automatically. However, the CPU can misjudge the signal because of noise. If the luminance of the picture seems to be incorrect, the clamp position may need to be changed.

AUTO: Automatic setting mode. Normally set to this position.

SonG: Set to this position if the black seems too light or greenish.

H/C: Set to this position if the picture is too dark or luminance is unstable.

HP: If the luminance is still incorrect after changing to the SonG or H/C position, set to this position and perform the H-SHIFT adjustment.

TRI-LEVEL S: Set to this position if the picture is dark when using the tri-level sync.

Notes


- If the external signal does not have the SonG signal, the H/C position is recommended.
- If the luminance is still incorrect after changing the clamp setting, check the input signal and the connections.



Before adjustment

V (Vertical) SHIFT

Sets the adjustable range of the vertical shift of the input signal.



WIDE: Normally, set to this position (factory preset).


NARROW: When some signal such as a superimposed signal with unstable vertical sync. signal is input, the picture may be distorted vertically. In this case, set to this position. Adjustable range in the lower direction will become narrow.

Note

When the video, S video, component or SDI4:2:2 signal is input, V SHIFT is fixed to NARROW.

SYNC SEL (select)

Selects the sync signal when using an external sync signal.



When an RGB signal is input

AUTO: Automatic setting mode. Normally set to this position.

SonG: Set to this position if you project the picture using the sync on G signal.

C: Set to this position if you project the picture using the composite sync signal.

HV: Set to this position when using the horizontal/vertical sync signal.

When an HDTV signal is input

You can select the items below instead of the above items.

AUTO: Automatic setting mode. Normally set to this position.

INT: Set to this position when using the internal sync signal.

EXT (C): Set to this position when using the external composite sync signal.


EXT (HV): Set to this position when using the external horizontal/vertical sync signal.

Note

For an RGB signal, this item can be selected only when SonG and C/HV are included.

SYNC ROUTE

Selects the route of the sync signal when the RGB signal is input to INPUT A.




AUTO: Automatic setting mode. Normally set to this position.

NORMAL: Set to this position for a normal sync input, that is, when there is no video signal in the sync line.

SYNC w VIDEO: Set to this position when the video signal is on the sync line and the sync of the image is distorted in the AUTO position.

VIDEO LOCK

Selects the range of the frequency deviation of the input signal so that the INPUT MEMORY data is switched automatically if the frequency deviation exceeds the selected range. This item can be selected only for RGB input signals.



NORMAL: Normally set to this position.

WIDE: Set to this position if the input signal is unstable or flickers. This phenomenon may appear during variable speed playback by the VCR, etc.

Input signals and adjustable/setting items

Item	Input signal	
	Video or S Video (Y/C)	Component SDI 4:2:2
COLOR TEMP	Y	Y
CLAMP	N	N
V SHIFT	N	N
SYNC SEL	N	N
SYNC ROUTE	N	N
VIDEO LOCK	N	N

Y: Adjustable/can be set

N: Not adjustable/cannot be set


* For the VPH-G90E model, the optional I/FB-G90E Video Interface Board is required.

Using the MENU

The SET SETTING 1 Menu


(User/Pro-user/Service/Expert modes)

The SET SETTING 1 menu is used for changing the default settings of the projector.
Items that can be adjusted are highlighted in green.
You cannot select the items indicated in white.



STATUS


Selects the on-screen display mode.



ON: Shows all of the on-screen displays.
OFF: Turns off all of the on-screen displays except for warning messages and menu displays.

PIC. (Picture) MUTING


Set to ON to cut off the picture.
When set to ON, "PIC MUTING" appears on the screen.



62 Before Adjustment

INPUT C

Selects the signal input from the IFB-12/12A Signal Interface Board (not supplied) installed to the INPUT C section and set to the INPUT mode.




RGB: Inputs the RGB signal.
COMPONENT: Inputs the component signal.
HDTV-Y/PaPr: Inputs the HDTV (Y/PaPr) signal.
HDTV-Y/PaPr: Inputs the HDTV (Y/PaPr) signal.
VIDEO: Inputs the composite video signal.
S-VIDEO: Inputs the S video signal.

Note

When a signal interface board other than the IFB-12/12A is installed or the IFB-12/12A is set to the OUTPUT mode, the menu items cannot be selected.

USER MODE

Selects the menu mode between the user mode and the pro-user mode.



NORMAL: User mode
PRO: Pro-user mode

For details, see "Menu Modes" on page 51.

Note

When you change the setting of this item in the service or expert mode, the menu will change to the selected user or pro-user mode after you have exited from the service or expert mode.




Before adjustment

The SET SETTING 2 Menu

(User/Pro-user/Service/Expert modes)

The SET SETTING 2 menu is used for changing the default settings of the projector.
Items that can be adjusted are highlighted in green.
You cannot select the items indicated in white.

User mode



GROUP INDEX

Indicates the group index number when the group index is set.

Note


The group index number can be set in the pro-user, service or expert mode.

DEVICE INDEX

Indicates the device index number which is set by the DEVICE INDEX switches on the rear of the projector.

63 Before adjustment

Using the MENU




GROUP INDEX

Sets the group index number with which multiple projectors and switcher are assigned in the same group. 1 to 99 group index number can be set.



Before adjustment




For details on the group index, see "Setting the Index Number" on page 141.

DEVICE INDEX

Indicates the device index number which is set by the DEVICE INDEX switches on the rear of the projector.

SIRCS RECEIVER

Selects the remote control detectors on the front and rear of the projector, if the wireless remote control does not operate correctly due to the influence of a fluorescent lamp, etc.



FRONT & REAR: Activates both the front and rear detectors.

FRONT: Activates the front detector only.

REAR: Activates the rear detector only.

OFF: Deactivates both the front and rear detectors.

LANGUAGE

Selects the language used in the on-screen displays.




Available languages are: ENGLISH, FRANÇAIS (French), DEUTSCH (German), ITALIANO (Italian), ESPAÑOL (Spanish), 日本語 (Japanese) and 中文 (Chinese).

The INPUT INFO (Information) Menu

(User/Pro-user/Service/Expert modes)

The INPUT INFO menu displays the information on the current input signal.



fH (Horizontal frequency)

Indicates the horizontal frequency of the input signal. This indication is not an absolute value, but is only used as a guide.

The horizontal frequency of the input signal is indicated in green; that of the internal signal in yellow.

fV (Vertical frequency)

Indicates the vertical frequency of the input signal. This indication is not an absolute value, but is only used as a guide.

The vertical frequency of the input signal is indicated in green; that of the internal signal in yellow.

H/C (Horizontal/Composite sync)

V (Vertical sync)

SonG (Sync on Green)

Indicates the polarity and use of each sync signal.

P: The polarity of the sync signal is positive.

N: The polarity of the sync signal is negative.

-: No sync signal is input.

INPUT SIGNAL

Displays the type of current input signal.

INT: OSC: No input

COMPONENT: Component input signal

IDTV: IDTV input signal from the optional PC-1271/1271M Signal Interface Switcher via the optional IFB-3000 Interface Board installed to the PC-1271/1271M.

RGB: RGB input signal

HDTV YPbPr: HDTV YPbPr input signal

HDTV GBR: HDTV GBR input signal

15 kRGB: 15 kHz RGB input signal

SDI 4:2:2: SDI 4:2:2 input signal

DRC: when the DRC is set to ON

Video or S video signals

NTSC 3.58: NTSC 3.58 input signal

NTSC 4.43: NTSC 4.43 input signal

PAL: PAL input signal

PAL-M: PAL-M input signal

SECAM: SECAM input signal

B/W: Black and white input signal

S-VIDEO: S video input signal

INPUT MEMORY No.

The upper number is the memory number of the data automatically loaded when the current signal is input.

The lower number is the new memory number in which the adjustment data of the current input signal is stored.

The existing memory number is displayed in green, and a new memory number in yellow.

For details, see "Input Memory" on page 133.

VIDEO MEMORY


The selected video memory number is indicated.

Using the MENU

The INPUT MEM. (memory) OPTION Menu

(Expert mode)

This projector is provided with the INPUT MEM. OPTION menu especially for the expert service personnel. To display the INPUT MEM. OPTION menu in the expert mode, first enter into the expert mode. Then display the INPUT INFO menu and press the $\blacklozenge$ key.




For details on the input memory, see "Input Memory" on page 133.



Before adjustment

MEM. LOAD/SAVE

Specifies the input memory number to be loaded or saved.



AUTO: Set to this position to select the input memory number to be loaded or saved automatically according to the type of input signal. This position is selected at the factory.


MANUAL: Set to this position to specify the input memory number to be loaded or saved. This position is useful when the loaded input memory number is unstable because there are two or more input signals whose frequencies are very similar, or when you want to assign a specified input memory number for the specified input source, or when you want to save the adjusted data to the specified input memory number.

When MANUAL is selected, "LOAD -> SAVE" becomes selectable.


LOAD -> SAVE

Specifies the input memory numbers to be loaded and saved when MEM. LOAD/SAVE is set to MANUAL.

Press the $\blacklozenge$ or $\blacklozenge$ key to select LOAD or SAVE, and specify the desired input memory number with the $\blacklozenge$ or $\blacklozenge$ key.



After specifying, press the ENTER key. The following display appears.



Press the $\blacklozenge$ or $\blacklozenge$ key to select YES, then press the ENTER key. The specified input memory numbers are stored in memory and the INPUT MEM. OPTION menu is resumed. If you select NO, the specified numbers are canceled and the INPUT MEM. OPTION menu is resumed.

Notes

- You cannot specify a non-existent memory number (displayed in yellow) as LOAD.
- When MEM. LOAD/SAVE is set to MANUAL, the specified input memory numbers are effective even if the input signal or the input channel changes.
- Before you reset MEM. LOAD/SAVE from MANUAL to AUTO, press the MEMORY key to save the data stored in the memory number specified as LOAD to the memory number specified as SAVE.



Before adjustment


Using the MENU

The SET INFO (Information) Menu


(Pro-user/Service/Expert modes)

The SET INFO menu displays the information on the serial number and the software version.

Pro-user mode



Service/Expert modes



Before adjustment

SER. (serial) No.

Indicates the serial number of the projector.


SOFT VERSION

Indicates the version of the software used for the projector.

The SERVICE SETTING 1 Menu


(Service/Expert modes)

The SERVICE SETTING 1 menu is used for the adjustments performed by the service personnel.



SCREEN TYPE

Selects the screen to be used.




SCREEN B: Bead screen (equivalent to screen gain 2.0)

SCREEN M: Mat screen (equivalent to screen gain 1.3)

ABG (Automatic Background) MODE

Normally, set to ON (factory setting). Cutoff luminance will be set to a certain level. Set to OFF if you want to erase the horizontal luminescent line for cutoff level detection that may appear at the upper part of the picture.




Note

When ABG MODE is set to OFF, the black level of the white balance may change.

68 Before adjustment

NORMAL DEFOCUS MODE

Selects if the projector performs defocusing during projection.




ON: Normally set to this position. Just focusing is applied during the magnetic focus adjustment, and defocusing is applied when you exit from the magnetic focus adjustment mode.

OFF: Just focusing is applied even during projection.

SBNC MODE


Set to ON when you connect the MONITOR OUT connector on the PC-1271/1271M Signal Interface Switcher (not supplied) to the INPUT A connectors with the SBNC cables.



Before adjustment

DIRECT POWER ON

Set to ON to turn on the projector by pressing the MAIN POWER switch on the projector. Set to OFF to enter standby mode by pressing the MAIN POWER switch.



Note


When the projector is in standby mode with DIRECT POWER ON set to ON, the projector will be turned on automatically if the power interruption occurred and has been restored.

Before adjustment 69

Using the MENU

ALL WHITE MODE

Sets the duration of all white mode during a warm-up period.




Use the $\blacktriangle$, $\blacklozenge$, $\blacktriangledown$, or $\blacktriangleleft$ key to set the duration in 1 minute increments from 0 to 99 minutes. To set the projector to display the picture immediately after the projector is turned on, set the duration to "0 min."



Before adjustment


PJ. COM (projector communication)

Sets the communication baud rate for the PJ. COM terminal to 38.4 K, 19.2 K or 9600.



RS-232C/422A


Sets the communication baud rate for the RS-232C/422A terminal to 38.4K, 19.2K or 9600.



THE SERVICE SETTINGS MENU

(Expert mode)

The SERVICE SETTING 3 is used for the adjustments performed by the specialized service personnel only.




DEVICE CONTROL

This item is used when the service personnel has replaced the internal board. Do not use this item normally.

THE PIC ORBITTING MENU


(Service/Expert modes)

The PIC ORBITTING menu is used to shift the image on the screen automatically to prevent the CRT burn.




PIC ORBITTING

Set to ON to shift the images on the multiple projector screens regularly to prevent the CRT burn. This mode is recommended when you project a still picture for a long time.



SCAN LINE SHIFT

Set to ON to shift the vertical position of the images on the multiple projector screens regularly to prevent the CRT burn. This mode is recommended when you project a signal with a low horizontal frequency.




Before adjustment

Using the MENU

The INT. OSC (Internal Oscillation) SETTING Menu
(Service/Expert modes)


The INT. OSC SETTING menu is used for activating the internal oscillator.



Before adjustment

INT. (internal) OSC. (oscillation) MODE

Set to ON to activate the internal oscillator.




Note

When no signal is input, you cannot select this item.

INT. (internal) OSC (Oscillation) PATTERN


Selects the oscillation frequency pattern generated with the internal oscillator.
The horizontal and vertical frequencies for the selected pattern are displayed on the screen.



- P1: FH = 15.73 kHz, FV = 60.00 Hz
- P2: FH = 24.83 kHz, FV = 56.40 Hz
- P3: FH = 31.47 kHz, FV = 59.94 Hz
- P4: FH = 48.36 kHz, FV = 60.00 Hz
- P5: FH = 63.98 kHz, FV = 60.02 Hz
- P6: FH = 75.00 kHz, FV = 60.00 Hz
- P7: FH = 93.75 kHz, FV = 75.00 Hz
- P8: FH = 106.25 kHz, FV = 85.00 Hz
- P9: FH = 126.84 kHz, FV = 60.00 Hz
- P10: FH = 145.00 kHz, FV = 60.00 Hz

The TIMER Menu
(Service/Expert modes)

The TIMER menu indicates the total operation time of the projector and that of each CRT.




OPERATING TIMER

Indicates the total operation time (hours) of the projector.

CRT TIMER

Indicates the total operation time (hours) of the GREEN and BLUE CRTs, respectively.




Before adjustment

Using the MENU

The ABL (Automatic Brightness Limiter) LINK Menu (Service/Expert modes)

The ABL LINK menu is used for the adjustment to make the brightness of the multi-screen uniform when connecting multiple projectors.




ABL LINK

When set to ON, the ABL (Automatic Brightness Limiter) to control the brightness of the picture when it is too high) functions on all projectors once the ABL functions on any projector.




SUB CONTRAST

When ABL LINK is set to ON, adjust the brightness of each projector so that the brightness of all projectors looks the same.



ABL LEVEL


When ABL LINK is set to ON, adjust the brightness of each projector so that the brightness of all projectors looks the same.



Test Patterns

In each adjustment mode, an appropriate test pattern appears. In addition, you can display other test patterns by pressing the PATTERN key.

Test Patterns



(continued)


Test Patterns



● HATCH (5 x 5)
(for adjusting KEY and PIN only)



● CROSS (9 x 9)
(for adjusting ZONE only)




● PLUGE (for adjusting BIAS only)



● STAIR STEP (for adjusting GAIN only)



● 10 IRE
(for adjusting BIAS only)



● 100 IRE
(for adjusting GAIN and BIAS only)


The patterns ❶ to ❸ appear in numerical order when pressing the PATTERN key in service mode. The patterns ❹ to ❷ appear in specified adjustment modes only. The outmost bold line of each pattern in the illustration stands for the edge of the screen.



Before adjustment

Warm-up before adjustment

Before adjusting the registration, make sure to turn on the projector and allow it to warm up for 20 minutes. The projector is designed with a warm-up period of about 20 minutes after turning on the power. During this period, it displays a white screen with the message shown below. 35 seconds after the warm-up starts, the message will disappear temporarily and will appear subsequently for 5 seconds every 30 seconds.



Press the MENU key to cancel the warm-up, if you wish to see the picture immediately. You may also set the projector for a shorter, longer or no warm-up period.

For details, see "ALL WHITE MODE" in the SERVICE SETTING 2 menu on page 70.



Before adjustment

Test Patterns in Each Mode

The patterns cycle through the following order by pressing the PATTERN key.

Adjustment mode	Test pattern
CENT	CROSS HAIR → HATCH (9 x 9) → HATCH (17 x 17) → HATCH INV (17 x 17) → External signal / HATCH (17 x 17) → External signal → CROSS HAIR ...
SIZE	CROSS HAIR → Sub-pattern → HATCH (17 x 17) → HATCH INV (17 x 17) → External signal / HATCH (17 x 17) → External signal → CROSS HAIR ...
LIN	
SKEW	
BOW	
KEY	HATCH (5 x 5) → HATCH (9 x 9) → HATCH (17 x 17) → HATCH INV (17 x 17) → External signal / HATCH (17 x 17) → External signal → HATCH (9 x 9) ...
PIN	
ZONE	HATCH (9 x 9) → CROSS HAIR (9 x 9) → HATCH (17 x 17) → HATCH INV (17 x 17) → External signal / HATCH (9 x 9) → External signal → HATCH (9 x 9) ...
MG FOCUS	DOT (9 x 9) → DOT (17 x 17) & HATCH (5 x 5) → ME
AQ/DOP	→ ME INV → ALL WHITE → External signal → DOT (9 x 9) ...
GAIN	WINDOW → 100 IRE → STAIR STEP → External signal → WINDOW ...
BIAS	PLUGE → 10 IRE → STAIR STEP → External signal → PLUGE ...
GAMMA	STAIR STEP → STAIR STEP → STAIR STEP → External signal → STAIR STEP ...
BLKG	External signal / HATCH (17 x 17) ↔ External signal
RGB SIZE	External signal ↔ External signal / HATCH (17 x 17)
RGB SHIFT	
Service mode	Test patterns ❶ to ❷ shown on page 75.
User mode	CROSS HAIR → HATCH (9 x 9) → ME → COLOR BAR → CROSS HAIR ...

Adjustments

Adjustment Procedure

Before starting the adjustments

- Make sure that the projector is installed correctly and the CRT conversion angle is adjusted correctly.
- Set the projector to the service mode. (page 43)

1 Lens focus and scheimpflug (angle of the CRT) adjustment (pages 81 to 86)

- 1 Reset all the data to the factory preset data (if necessary). (page 138) ↓
- 2 Adjust the registration roughly (if necessary). (page 93) ↓
- 3 Select the internal oscillation pattern (P5, 1H=63.98 kHz). (page 81) ↓
- 4 Display the H-pattern or ME-pattern. (page 81) ↓
- 5 Adjust the green lens focus and scheimpflug. (page 81)
 - 1 Adjust the green lens focus.
 - 2 Adjust the green magnetic focus and AQP/DQP roughly (if necessary).
 - 3 Adjust the green scheimpflug.
 - 4 Adjust the green lens focus precisely.
- 6 Adjust the red lens focus and scheimpflug. (page 85)
 - 1 Adjust the red lens focus.
 - 2 Adjust the red magnetic focus and AQP/DQP roughly (if necessary).
 - 3 Adjust the red scheimpflug.
 - 4 Adjust the red lens focus precisely.

(continued)

7 Adjust the blue lens focus and scheimpflug. (page 86)

- 1 Adjust the blue lens focus.
- 2 Adjust the blue magnetic focus and AQP/DQP roughly (if necessary).
- 3 Adjust the blue scheimpflug.
- 4 Adjust the blue lens focus precisely.

2 Magnetic focus adjustment (pages 87 to 91)

1 Adjust the green magnetic focus, AQP/DQP and AHP/DHP. (page 87)

- 1 Adjust the green magnetic focus, AQP/DQP and AHP/DHP in the center of the screen.
- 2 Adjust the green AHP/DHP in the peripheral area of the screen (in expert mode only).
- 3 Adjust the green magnetic focus, and AQP/DQP in the peripheral area of the screen.

2 Adjust the red magnetic focus, AQP/DQP and AHP/DHP. (page 90)

- 1 Adjust the red magnetic focus, AQP/DQP and AHP/DHP.

3 Adjust the blue magnetic focus, AQP/DQP and AHP/DHP. (page 91)

- 1 Adjust the blue magnetic focus, AQP/DQP and AHP/DHP.

4 Adjust the uniformity of all-white mode screen. (page 91).

3 Saving the adjusted magnetic focus data as the standard data (page 92)

4 Registration adjustment (pages 93 to 120)

- 1 Mark the center of the screen. (page 93) ↓
- 2 Select NO INPUT mode. (page 93) ↓
- 3 Select the internal oscillation pattern to be used for the registration adjustment. (page 93) ↓
- 4 Reset the registration data to the factory preset levels. (Only if the adjustment data has been modified before.) (page 138) ↓
- 5 Adjust the green registration. (pages 95 to 107)
 - 1 Centering adjustment
 - 2 Size and linearity adjustment
 - 3 Skew and bow adjustment
 - 4 Keystone and pincushion adjustment in the whole screen
 - 5 Keystone and pincushion adjustment in the peripheral area of the screen
 - 6 Zone adjustment (if necessary)

(continued)



Adjustments

Adjustment Procedure

- ⑥ **Adjust the red registration.** (pages 108 to 118)
 - 1 Centering adjustment
 - 2 Size and linearity adjustment
 - 3 Skew and bow adjustment
 - 4 Keystone and pincushion adjustment
 - 5 Zone adjustment (if necessary)
- ⑦ **Adjust the blue registration.** (pages 119 to 120)
 - 1 Centering adjustment
 - 2 Size and linearity adjustment
 - 3 Skew and bow adjustment
 - 4 Keystone and pincushion adjustment
 - 5 Zone adjustment (if necessary)
- 5 **Saving the adjusted registration data as the standard data (page 121)**
- 6 **Fine adjustment for each input signal (pages 122 to 128)**
 - ① Select the input signal. (page 122)
 - ② Fine adjustment of the magnetic focus, AQP/DQP (if necessary) (page 122)
 - ③ Fine adjustment of the registration (if necessary) (page 122)
 - ④ Adjustment of the picture size (page 123)
 - ⑤ Adjustment of the picture shift (page 123)
 - ⑥ Blanking adjustment (page 124)
 - ⑦ White balance adjustment (if necessary) (page 125)
 - ⑧ Adjustments 1 to 7 for other input signal
- 7 **Picture quality adjustment (page 129)**




Adjustments

Adjusting the Lens Focus and Scheimpflug

Preparation

- 1 Reset all the data to the factory preset data.
For details, see "Resetting the Data" on page 138.
- 2 Adjust the registration very roughly, if necessary.
When the picture is larger than the screen or is projected from the rear of the screen, roughly adjust the registration.
For details, see "Adjusting the Registration" on page 93.
- 3 Display the INT. OSC. SETTING menu, set INT. OSC. MODE to ON and set INT. OSC. PATTERN to P5 (IH = 63.98 kHz).
For details, see "INT. OSC. menu" on page 72.



- 4 Reset the CONTRAST and BRIGHT levels.
The CONTR level resets to 80 by pressing the RESET key after pressing the PICTURE CONTROL CONTR key.
The BRIGHT level resets to 50 by pressing the RESET key after pressing the PICTURE CONTROL BRIGHT key.
For details, see "Adjusting the Picture Quality" on page 129.




Adjustments

Adjusting the Green Lens Focus and Scheimpflug

1 Adjusting the green lens focus


- 1 Reset the centering adjustment data of the green signal.
For details, see "Resetting the Data" on page 138.
- 2 Press the NORMAL key on the remote commander to turn off the test pattern once, then press the PATTERN key on the remote commander until the H-pattern or ME-pattern appears.

Example: H-pattern




Adjusting the Lens Focus and Scheimpflug

- 3 Press the CUT OFF R and B keys to display the green signal only.
- 4 Open the upper cover.
For opening the cover, see page 18.
- 5 Adjust the center-focus.
Loosen the G1 screw, slide it so that the letters H at the center of the screen are in focus, and then tighten the screw.



- 6 Adjust the corner-focus.
Loosen the G2 screw, slide it so that the letters H at all four corners of the screen (white areas illustrated below) are in focus, and then tighten the screw.
Repeat steps 5 and 6 until the green focus adjustment is completed.
(If the corner-focus cannot be adjusted completely, adjust it again after finishing the Scheimpflug adjustment of the green lens.)



Hint for the lens focus adjustment

The letter "H" is made up of dots. Adjust the focus so that dots of the letter "H" can be clearly seen as illustrated below.
Placing a white paper over the front of the screen will make it easier to see the dots.



Adjustments


2 Adjusting the green magnetic focus and AQP/DQP roughly, if necessary.

The magnetic focus and AQP/DQP will be adjusted precisely after the lens focus and scheimpflug adjustments. Adjust the green magnetic focus and AQP/DQP roughly at this stage to make the later adjustments easily.
For details of the magnetic focus and AQP/DQP adjustments, see page 87.


3 Adjusting the green scheimpflug

After adjusting the green lens focus, adjust the green scheimpflug (angle of the green CRT) so that the upper and lower parts, and the left and right parts of the screen are equally in focus.

- 1 Open the upper cover.
For how to open the upper cover, see page 18.
- 2 Place a white paper over the front of the screen. Note whether the focal planes on the upper, lower, left and right parts of the screen appear to be leaning forward or backward.



- 3 Adjust the focus on the upper and lower parts with the V screw on the green CRT using the supplied tool.
The supplied tool can rotate the screw in one direction only. To rotate the screw in the reverse direction, turn the tool upside down.



Caution

Do not turn the tool forcibly when the screw has fully rotated. Otherwise, the tool may slip out and injure your hand.


(continued)

Adjusting the Lens Focus and Scheimpflug


NOTE

Normally, adjust only the V screw for the green CRT. Adjusting the H screw is required only for non-standard installation. If the left and right parts of the screen are not in focus, make sure that the projector and the screen are installed correctly. For the red and blue scheimpflug, adjust both the H and V screws.

By turning the V screw, the CRT moves vertically to adjust the vertical tilt of the focal plane.



By turning the H screw, the CRT moves horizontally to adjust the horizontal tilt of the focal plane.



Repeat the above process until the upper and lower parts and the right and left parts of the screen are in focus.

4 Adjusting the green lens focus precisely

After adjusting the green scheimpflug, readjust the green lens focus until the perfect focus is obtained. For the procedure of the adjustment, see "1 Adjusting the green lens focus" on page 81.

Proceed to the red lens focus and scheimpflug adjustments.

Adjusting the Red Lens Focus and Scheimpflug

1 Adjusting the red lens focus

- 1 Reset the centering adjustment data of the red signal. For details, see "Resetting the Data" on page 138.
- 2 Press the PATTERN key until the H-pattern or ME-pattern is displayed.
- 3 Press the CUT OFF G and B keys to display the red signal only.
- 4 Loosen the R1 screw, slide it so that the letters H at the center of the screen are in focus, then tighten the screw. For details, see "Adjusting the green lens focus" on page 81.
- 5 Loosen the R2 screw, slide it so that the letters H at all four corners of the screen are in focus, then tighten the screw. Repeat steps 4 and 5 until the red focus adjustment is completed.

2 Adjusting the red magnetic focus and AQP/DQP roughly, if necessary.

The magnetic focus and AQP/DQP will be adjusted precisely after the lens focus and scheimpflug adjustments. Adjust the red magnetic focus and AQP/DQP roughly at this stage to make the later adjustments easily. For details of the magnetic focus and AQP/DQP adjustments, see page 87.

3 Adjusting the red scheimpflug

After adjusting the red lens focus, adjust the red scheimpflug (angle of the red CRT). Check the tilt of the focal planes at the upper, lower, left and right parts of the screen, then adjust the focus with the H and V screws on the red CRT. For details, see "Adjusting the green scheimpflug" on page 83.

4 Adjusting the red lens focus precisely

After adjusting the red scheimpflug, readjust the red lens focus until the perfect focus is obtained. For the procedure of the adjustment, see "1 Adjusting the green lens focus" on page 81.

Proceed to adjust the blue lens focus and scheimpflug.

Adjusting the Lens Focus and Scheimpflug

Adjusting the Blue Lens Focus and Scheimpflug

1 Adjusting the blue lens focus

- 1 Reset the centering adjustment data of the blue signal.
For details, see "Resetting the Data" on page 138.
- 2 Press the PATTERN key until the H-pattern or ME-pattern is displayed.
- 3 Press the CUT OFF G and R keys to display the blue signal only.
- 4 Loosen the B1 screw, slide it so that the letters H at the center of the screen are in focus, then tighten the screw.
For details, see "Adjusting the green lens focus" on page 81.
- 5 Loosen the B2 screw, slide it so that the letters H at all four corners of the screen are in focus, then tighten the screw.
Repeat steps 4 and 5 until the blue focus adjustment is completed.

2 Adjusting the blue magnetic focus and AQP/DQP roughly, if necessary

The magnetic focus and AQP/DQP will be adjusted precisely after the lens focus and scheimpflug adjustments. Adjust the blue magnetic focus and AQP/DQP roughly at this stage to make the later adjustments easily.
For details of the magnetic focus and AQP/DQP adjustments, see page 83.

3 Adjusting the blue scheimpflug

After adjusting the blue lens focus, adjust the blue scheimpflug (angle of the blue CRT).
Check the tilt of the focal planes at the upper, lower, left and right parts of the screen, then adjust the focus with the H and V screws on the blue CRT.
For details, see "Adjusting the green scheimpflug" on page 83.

4 Adjusting the blue lens focus precisely


After adjusting the blue scheimpflug, readjust the blue lens focus until the perfect focus is obtained.
For the procedure of the adjustment, see "1 Adjusting the green lens focus" on page 81.

Proceed to adjust the green magnetic focus and AQP/DQP.


Adjusting the Magnetic Focus

After adjusting the lens focus and scheimpflug, adjust the magnetic focus, AQP (Axis Quadrupole)/DQP (Diagonal Quadrupole) and AHP (Axis Hexapole)/DHP (Diagonal Hexapole).

What is the AQP/DQP adjustment?




What is the AHP/DHP adjustment?



1 Adjusting the green magnetic focus, AQP/DQP and AHP/DHP

- 1 Press the CUT OFF R and B keys to display the green signal only.
- 2 Press the MG FOCUS key.
The DOT pattern (9 x 9) appears on the screen, and a square for adjusting focus is displayed on the center of the screen. The adjustment mode, adjustment position No., and adjustment items overlap with the DOT pattern.




- 3 Adjust the focus at the center (position No.1) of the screen.
Press the $\blacktriangle$ or $\blacktriangledown$ key to select the item (by moving [] to the item), and press the $\blacktriangle$ or $\blacktriangledown$ key to adjust the data.
① Press the $\blacktriangle$ or $\blacktriangledown$ key to set ALL to +40 so that flare appears on the screen.
② Press the $\blacktriangle$ or $\blacktriangledown$ key to select 2PH, then press the $\blacktriangle$ or $\blacktriangledown$ key so that the core of a spot is located at the horizontal center of the flare.
③ Select 2PV, then adjust so that the core of a spot is located at the vertical center of the flare.

(continued)

Adjusting the Magnetic Focus



- ④ Repeat steps ② and ③ so that the core of a spot is located at the center of the flare.
- ⑤ Select ALL again, then set the value to -80 so that the spot is focused.
- ⑥ Select 4PA, then correct the vertical and horizontal distortion of the spot.
- ⑦ Select 4PD, then correct the diagonal distortion of the spot.
- ⑧ Select 6PA and correct the vertical triangular-form distortion of the spot.
- ⑨ Select 6PD and correct the diagonal triangular-form distortion of the spot.
- ⑩ Repeat steps ⑤ to ⑨ so that the spot becomes a correct circle.
- ⑪ Select ALL, display the ME-pattern by pressing the PATTERN key, and adjust so that the spot is in focus.



- ④ Adjust the AHP/DHP at corners of the screen. (in expert mode only)
For details, see "AHP/DHP adjustment" on page 89.

- ⑤ Press the PATTERN key repeatedly to display the ME-pattern.

- ⑥ Press the POSITION + key once to enter the focus adjustment mode for the upper parts (position No.2).
When you press the POSITION + key, the part to be adjusted cycles through the order as illustrated on the left. The position number is displayed at the upper right corner.
If you press the POSITION - key, the part cycles through the reverse order.



- ⑦ Adjust the focus and AQP/DQP for the upper part of the screen (position No.2).
 - ① Press the ◀ or ▶ key so that the upper part of the screen is in focus.
 - ② Select AQP with the ◀ or ▶ key, and press the ◀ or ▶ key so that the letters ME are clearly visible. (AQP adjustment)
 - ③ Select DQP with the ◀ or ▶ key, and press the ◀ or ▶ key so that the letters ME are clearly visible. (DQP adjustment)
 - ④ Repeat steps ① to ③ until the letters ME are in best focus.

- ⑧ Perform the magnetic focus, AQP and DQP for every part of the screen (positions No.3 to No.9) in numeric order.
 - ① Press the POSITION + key to select the part to be adjusted.
 - ② Press the ◀ or ▶ key to select the adjustment item.
 - ③ Press the ◀ or ▶ key to adjust.Repeat steps ② and ③ for each adjustment item.

Proceed to adjust the red magnetic focus (page 90) if the green adjustments are completed.
If the green adjustments are not complete, repeat from the green lens focus again.


AHP/DHP adjustment (in expert mode only)

To adjust the spot at the corner of the screen more precisely, the unit is provided with the AHP (Axis Hexapole)/DHP (Diagonal Hexapole) adjustment in expert mode only. The AHP/DHP adjustment corrects the astigmatic distortion which cannot be corrected with the AQP/DQP adjustment.


Perform the AHP/DHP adjustment before adjusting the magnetic focus and AQP/DQP adjustment at the corners of the screen.



What is the AHP/DHP adjustment?




- ① Press the NORMAL key on the remote commander to turn off the test pattern.
- ② Press the keys in the following order:
ENTER → ENTER → ◀ → ▶ → ENTER
Press the keys one after another within 2 seconds.
The following display appears.



- ③ Press the ◀ or ▶ key to select YES, then press the ENTER key.
The unit enters the expert mode, and "E" appears at the top-left of the screen when the menu is displayed.
- ④ Press the FUNCTION key once.
"Spot Shape" is displayed on the screen and the spots become large for easier adjustment.

(continued)

Adjusting the Magnetic Focus



- 5 Press the POSITION + key once to enter the focus adjustment mode for the upper parts (position No. 2). When you press the POSITION + key, the part to be adjusted cycles through the order as illustrated on the left. The position number is displayed at the upper right corner. If you press the POSITION - key, the part cycles through the reverse order.

POSITION	1	2	3	4	5	6	7	8	9
1	1	2	3	4	5	6	7	8	9
2	2	1	4	3	6	5	8	7	9
3	3	4	1	2	8	7	6	5	9
4	4	3	2	1	9	8	7	6	5
5	5	6	7	8	1	2	3	4	9
6	6	5	8	7	2	1	9	4	3
7	7	8	7	6	3	4	1	2	9
8	8	7	6	5	4	3	2	1	9
9	9	9	9	9	9	9	9	9	1

- 6 Adjust the AQP, DQP, AHP and DHP for position No. 2. Press the $\blacklozenge$ or $\blacklozenge$ key to select the adjustment item and press the $\blacklozenge$ or $\blacklozenge$ key to correct the distortion of the spot.
- 7 Press the POSITION + or - key to select the adjustment position and repeat steps 5 and 6 for each position. Adjust positions No.3 to No.9 in order.
- 8 Press the FUNCTION key once to exit from the Spot Shape mode.
- 9 Display the ME-pattern with the PATTERN key.
- 10 Press the POSITION + or - key to select the adjustment position No. 2 to No. 9 and adjust MG, AQP and DQP so that the letters ME are clearly visible for every part of the screen.

Note

Do not adjust AHP and DHP for positions No. 2 to No. 9.

- 11 Press the CUT OFF G and B keys to display the red signal only, and adjust AQP, DQP, AHP and DHP in the same manner as the green signal.
- 12 Press the CUT OFF G and R keys to display the blue signal only, and adjust AQP, DQP, AHP and DHP in the same manner as the green signal.

2 Adjusting the red magnetic focus, AQP/DQP and AHP/DHP

Press the CUT OFF G and B keys to display the red signal only. Then adjust the red magnetic focus, AQP/DQP and AHP/DHP. To adjust them, perform the same procedure as for the green signal.
For details, see "Adjusting the green magnetic focus, AQP/DQP and AHP/DHP" on pages 87 to 90.



Adjustments

Proceed to adjust the blue magnetic focus if every part of the screen for red signal is completely in focus.

Note

When the red magnetic focus adjustment mode is canceled, the red signal is slightly defocused. This is because the offset function activates so that the optimum picture is projected. (when NORMAL DEFOCUS MODE is ON in SERVICE SETTING 1 menu)

3 Adjusting the blue magnetic focus, AQP/DQP and AHP/DHP

Press the CUT OFF G and R keys to display the blue signal only. Then adjust the magnetic focus, AQP/DQP and AHP/DHP. To adjust them, perform the same procedure as for the green signal.
For details, see "Adjusting the green magnetic focus, AQP/DQP and AHP/DHP" on pages 87 to 90.

If every part of the screen for blue signal is completely in focus, proceed to adjust the uniformity of all white mode screen.

Note

When the blue magnetic focus adjustment mode is canceled, the blue signal is slightly defocused. This is because the offset function activates so that the optimum picture is projected. (when NORMAL DEFOCUS MODE is ON in SERVICE SETTING 1 menu)

4 Adjusting the uniformity of all-white mode screen

After completing the green, red and blue focus adjustments, check the uniformity of all-white mode screen.

- 1 Press the MG FOCUS, B ADJ and MG FOCUS keys to enter the defocused mode. DEFOCUS is displayed on the screen and the blue signal is slightly defocused.
- 2 Press the PATTERN key until the all-white screen appears.
- 3 If the all-white screen does not seem uniform, adjust the blue magnetic focus for every part of the screen so that the screen becomes uniform white.

Proceed to save the adjusted magnetic focus data as standard data, if the uniformity of the all-white mode screen is adjusted completely.



Adjustments

Adjusting the Magnetic Focus


Saving the Standard Magnetic Focus Data

After adjusting all the magnetic focus data, save the adjusted data as the standard data for the projector. The projector automatically changes the magnetic focus data of position No. 1 in every input memory according to the standard data.

- 1 Hold down the MEMORY key for more than 5 seconds.
"MEMORY DATA is saving" is displayed while the projector saves the magnetic focus data. When saving is completed, the following display appears.



- 2 Press the $\blacklozenge$ or $\blacklozenge$ key to select YES, then press the ENTER key.
If you select YES, the STANDARD DATA SAVE MODE display appears.



If you select NO, the original display is resumed.

- 3 Press the $\blacklozenge$ or $\blacklozenge$ key to select FOCUS DATA, then press the ENTER key.
The magnetic focus data of position No. 1 in all the input memory are changed according to the standard data saved in step 1.


NOTES

- No keys function while the data is being saved.
- If the standard data save is performed, the magnetic focus data of position No. 1 in every input memory will be changed into the standard data. If necessary, readjust the magnetic focus for each input signal.

Adjusting the Registration

Preparation


- 1 Mark the center of the screen.
Measure the height and width of the screen to determine the center. Marking five points with white tape, as illustrated below, will help you adjust registration.



- 2 Set the remote commander to the service mode.
For details, see "Preparation of the Remote Commander" on page 42.
- 3 Press one of the INPUT SELECT keys corresponding to the input that is not connected to a signal so that "NO INPUT" appears.
Or, set the SWITCHER/VIDEO MEMORY/INDEX select switch to SWITCHER and then press the number key from 1 to 8, corresponding to the input that is not connected to a signal.



- 4 Display the INT. OSC SETTING menu, set INT. OSC MODE to ON, then select the frequency to be used for the adjustment on INT. OSC PATTERN.
For details, see "The INT. OSC SETTING Menu" on page 72.



- 5 Reset the standard data to the factory preset level.
(Only when you have adjusted the registration and have saved the adjustment data.)
For details, see "Resetting the Data" on page 138.


(continued)

Adjusting the Registration

Notes

- The center of the screen and the center of the CROSS HAIR pattern can be aligned by performing the centering adjustment.
For details, see "Green CENT (centering) adjustment" on page 95.
- When the optical axis angle is smaller, the HATCH pattern becomes trapezoidal. Perform the KEY (keystone) adjustment to correct the distortion.
For details, see "Green KEY and PIN adjustments for the whole screen" on page 100.

Keys for Adjusting



Indications on the REGISTRATION keys and the adjustment items

Indicated on the commander	Adjustment items
CENT	Centering
SIZE	Size
LIN	Linearity
SKEW	Skew
BOW	Bow
KEY	Keystone
PIN	Pincushion
ZONE	Zone

Adjusting the Green Registration


Be sure to adjust the green registration first.

1 Green CENT (centering) adjustment

Adjust so that the center of the test pattern is aligned with the center of the screen.

- 1 Press the CENT key.
The CROSS HAIR pattern and the cursor appear.
- 2 Press the ADJ G key.
- 3 Press the CUT OFF R and B keys to display green only.
- 4 Reset the FINE centering data.
See "Resetting the Data" on page 138.

- 5 Press the arrow keys to align the center of the CROSS HAIR pattern with the center of the screen.



- 6 If the test pattern is not aligned with the center, press the CENT key again.
The projector enters the FINE centering mode for fine adjustment. Each time you press the CENT key, the COARSE mode and FINE mode are selected alternately, and you can use the two modes appropriately. The adjustment data is stored for each mode separately. While you hold down the arrow key in the FINE mode, "f" is displayed around the adjustment position.


- 7 Press the arrow keys to align the center precisely.

Notes

- If the test pattern is off-centered by a large amount, check if the projector is installed or adjusted correctly.
- If the upper, lower, left or right part of the screen is de-focused, check if the scheming plug is adjusted correctly.
For details, see "Adjusting the green scheming plug" on page 83.

Adjusting the Registration

2 Green SIZE and LIN (linearity) adjustment



Adjust the picture size with respect to the screen, and the picture's up, down, left and right balance.

- 1 Press the LIN key.
The CROSS HAIR pattern appears.
You can also change to the 9 × 9 HATCH pattern by pressing the PATTERN key.

- 2 Press the ADJ G key.
Pay attention only to the encircled portions illustrated on the left.

- 3 Reset the FINE linearity data.
See "Resetting the Data" on page 138.

- 4 Adjust with the $\blacktriangleleft$ and $\blacktriangleright$ keys until parts (a) (distances from the right and left ends of the screen to the first vertical lines) are of equal length.



$\blacktriangleleft$: The left and right vertical lines are shifted to the left while the vertical center line remains unmoved.



$\blacktriangleright$: The left and right vertical lines are shifted to the right while the vertical center line remains unmoved.

- 5 Press the SIZE key.

- 6 Reset the FINE size data.
See "Resetting the Data" on page 138.

- 7 Adjust with the $\blacktriangleleft$ and $\blacktriangleright$ keys until parts (a) on the left and right are 15 to 20 mm long.



$\blacktriangleleft$: The horizontal scale is reduced.



$\blacktriangleright$: The horizontal scale is expanded.



Adjustments

- 8 If they are not aligned, press the LIN key or the SIZE key and repeat the adjustment by pressing the $\blacktriangleleft$ or $\blacktriangleright$ key.
Each time you press the LINE or SIZE key, the COARSE mode and FINE mode are selected alternately, and you can use the two modes appropriately. The adjustment data is stored for each mode separately. While you hold down the arrow key in the FINE mode, "F" is displayed around the adjustment position.

- 9 If the CROSS HAIR pattern is off-centered on the screen, adjust the centering again and repeat steps 1 to 8 for the horizontal scale adjustment.
For details of the centering adjustment, see "Green CENT (centering) adjustment" on page 95.

- 10 Press the LIN key.

- 11 Adjust with the $\blacktriangleleft$ and $\blacktriangleright$ keys until parts (a) on page 96 (distances from the top and bottom ends of the screen to the first horizontal lines) are of equal length.



$\blacktriangleleft$: The upper and lower horizontal lines are shifted upward while the horizontal center line remains unmoved.



$\blacktriangleright$: The upper and lower horizontal lines are shifted downward while the horizontal center line remains unmoved.

- 12 Press the SIZE key.

- 13 Adjust with the $\blacktriangleleft$ and $\blacktriangleright$ keys until parts (a) at the top and bottom are about 15 to 20 mm long.



$\blacktriangleleft$: The vertical scale is expanded.



$\blacktriangleright$: The vertical scale is reduced.


- 14 If they are not aligned, repeat steps 10 to 13.

- 15 If the CROSS HAIR pattern is off-centered on the screen, adjust the centering again and then repeat steps 10 to 14 for the vertical scale adjustment.
For details of the centering adjustment, see "Green CENT (centering) adjustment" on page 95.



Adjustments


Adjusting the Registration





B Vertical line adjustment

If the picture's borders are as shown by the dotted line in the illustrations below, adjust them with the corresponding arrow key so that they are parallel (bold lines illustrated on the left).

- 1 Press the KEY key.
The HATCH pattern appears.
- 2 Adjust the distortion as illustrated below with the $\blacktriangleleft$ and $\blacktriangleright$ keys.
In position No. 1 of green adjustment, the green, red and blue lines move together by pressing the $\blacktriangleleft$ or $\blacktriangleright$ key.



- 3 Press the PIN key.
- 4 Adjust the distortion as illustrated below with the $\blacktriangleleft$ and $\blacktriangleright$ keys.
In position No. 1 of green adjustment, the green, red and blue lines move together by pressing the $\blacktriangleleft$ or $\blacktriangleright$ key.




- 5 Repeat steps 1 to 4 until the vertical lines become parallel to the screen edges.



Adjustments



5 Green KEY (keystone) and PIN (pincushion) adjustments on the peripheral area of the screen

Separately adjust the distortion at the top, bottom, right end and left end of the screen which may still remain even after the KEY and PIN adjustments for the whole screen.



A Horizontal line adjustment at the top

- 1 Press the KEY key and press the POSITION + key once.
The projector enters the upper keystone adjustment mode (POSITION No. 2).
When you press the POSITION + key, the adjustment position changes in the numerical order 2 to 5 as illustrated on the left. The selected position number appears at the upper right corner of the screen. When you press the POSITION - key, the position number is selected in the reverse order.



- 2 Adjust the distortion of the horizontal line at the top with the $\blacktriangleleft$ and $\blacktriangleright$ keys.
Only the green line moves.
 - $\blacktriangleleft$: The horizontal line rotates counter-clockwise, rotating around the center.
 - $\blacktriangleright$: The horizontal line rotates clockwise, rotating around the center.
- 3 Press the PIN key and press the POSITION + key once.
The projector enters the upper pincushion adjustment mode (POSITION No. 2).
When you press the POSITION + key, the adjustment position changes in the numerical order 2 to 5 as illustrated on the left. The selected position number appears at the upper right corner of the screen. When you press the POSITION - key, the position number is selected in the reverse order.




Adjustments

(continued)

- 4** Adjust the distortion of the horizontal line on the top with the $\blacklozenge$ and $\blackstar$ keys.
Only the green line moves.



$\blacklozenge$: The left and right ends of the horizontal line curve upward while the center remains unchanged.



$\blackstar$: The left and right ends of the horizontal line curve downward while the center remains unchanged.

- 5** Repeat the adjustment with the KEY or PIN key and the $\blacklozenge$ and $\blackstar$ keys until the horizontal line on the top becomes parallel to the screen edge.

B Horizontal line adjustment at the bottom

- 1** Press the KEY key and press the POSITION + key once.
The projector enters the lower keystone adjustment mode (POSITION No. 3).

- 2** Adjust the distortion of the horizontal line at the bottom with the $\blacklozenge$ and $\blackstar$ keys.

$\blacklozenge$: The horizontal line rotates counter-clockwise, rotating around the center.

$\blackstar$: The horizontal line rotates clockwise, rotating around the center.

- 3** Press the PIN key and press the POSITION + key once.
The projector enters the lower pincushion adjustment mode (POSITION No. 3).

- 4** Adjust the distortion of the horizontal line at the bottom with the $\blacklozenge$ and $\blackstar$ keys.

$\blacklozenge$: The left and right ends of the horizontal line curve upward while the center remains unchanged.

$\blackstar$: The left and right ends of the horizontal line curve downward while the center remains unchanged.

- 5** Repeat the adjustment with the KEY or PIN key and the $\blacklozenge$ and $\blackstar$ keys until the horizontal line at the bottom becomes parallel to the screen edge.



Adjustments


C Vertical line adjustment at the left side

- 1** Press the KEY key and press the POSITION + key once.
The projector enters the left keystone adjustment mode (POSITION No. 4).

- 2** Adjust the distortion of the vertical line at the left side with the $\blacklozenge$ and $\blackstar$ keys.



$\blacklozenge$: The vertical line rotates counter-clockwise, rotating around the center.



$\blackstar$: The vertical line rotates clockwise, rotating around the center.

- 3** Press the PIN key and press the POSITION + key once.
The projector enters the left pincushion adjustment mode (POSITION No. 4).

- 4** Adjust the distortion of the vertical line at the left side with the $\blacklozenge$ and $\blackstar$ keys.



$\blacklozenge$: The upper and lower ends of the vertical line curve towards the left while the center remains unchanged.



$\blackstar$: The upper and lower ends of the vertical line curve towards the right while the center remains unchanged.

- 5** Repeat the adjustment with the KEY or PIN key and the $\blacklozenge$ and $\blackstar$ keys until the vertical line at the left side becomes parallel to the screen edge.



Adjustments

Adjusting the Registration

D Vertical line adjustment at the right side

- 1** Press the KEY key and press the POSITION + key once.
The projector enters the right keystone adjustment mode (POSITION No. 5).
- 2** Adjust the distortion of the vertical line at the right side with the ◀ and ▶ keys.
 - ◀: The vertical line rotates counter-clockwise, rotating around the center.
 - ▶: The vertical line rotates clockwise, rotating around the center.
- 3** Press the PIN key and press the POSITION + key once.
The projector enters the right pincushion adjustment mode (POSITION No. 5).
- 4** Adjust the distortion of the vertical line at the right side with the ◀ and ▶ keys.
 - ◀: The upper and lower ends of the vertical line curve towards the left while the center remains unchanged.
 - ▶: The upper and lower ends of the vertical line curve towards the right while the center remains unchanged.
- 5** Repeat the adjustment with the KEY or PIN key and the ◀ and ▶ keys until the vertical line at the right side becomes parallel to the screen edge.



Adjustments

6 Green ZONE adjustment

When adjusting the green registration, do not greatly change the ZONE adjustment. If you change the green ZONE in the large range considerably, the adjustment for red and blue may be difficult.
If you need the green ZONE adjustment, refer to "Red ZONE adjustment" on page 117.

**The green registration adjustment is all completed.
Proceed to the adjustment for the red signal.**



Adjustments

Adjusting the Registration

Adjusting the Red Registration

Adjust the red signal so that it converges with the green signal and is seen as yellow.

Note

When you have adjusted the red registration data and have saved the adjustment data, reset the red centering to the factory preset level.
For resetting, see page 138.

7 Red CENT (centering) adjustment

Adjust so that the center of the red CROSS HAIR pattern is aligned with that of the green CROSS HAIR pattern.

- 1 Press the CENT key.
The CROSS HAIR pattern and the cursor appear.
- 2 Press the ADJ R key.
- 3 Press the CUT OFF B key to display green and red.
- 4 Reset the FINE centering data.
See "Resetting the Data" on page 138.
- 5 Press the arrow keys to align the center of the red CROSS HAIR pattern with that of the green pattern.
- 6 If the centers do not converge, press the CENT key again.
The projector enters the FINE centering mode for fine adjustment. Each time you press the CENT key, the COARSE mode and FINE mode are selected alternately, and you can use the two modes appropriately. The adjustment data is stored for each mode separately. While you hold down the arrow key in the FINE mode, "f" is displayed around the adjustment position.
- 7 Press the arrow keys to align the center precisely.


Notes

- If the red vertical line is not aligned with that of the green pattern, adjust the red CRT conversion angle again.
For details, see "Adjusting the CRT Conversion Angle" on page 22.
- If the upper, lower, left or right part of the screen is de-focused, adjust the red schemppflug again.
For details, see "Adjusting the green schemppflug" on page 83.



Adjustments

8 Red SIZE and LIN (linearity) adjustments



- 1 Press the LIN key.
The CROSS HAIR pattern appears.
You can also change to the 9 × 9 HATCH pattern by pressing the PATTERN key.
- 2 Press the ADJ R key.
Pay attention only to the encircled portions in the illustration on the left.
- 3 Reset the FINE linearity data.
See "Resetting the Data" on page 138.
- 4 Adjust with the ◀ and ▶ keys until the parts (⊙) (distances between the red and green lines) on the left and right are of equal length.
◀: The left and right vertical lines are shifted to the left while the vertical center line remains unmoved.
▶: The left and right vertical lines are shifted to the right while the vertical center line remains unmoved.
- 5 Press the SIZE key.
- 6 Reset the FINE size data.
See "Resetting the Data" on page 138.
- 7 Adjust with the ◀ and ▶ keys so that the red and green lines in the right and left encircled portions converge.
◀: The horizontal scale is reduced.
▶: The horizontal scale is expanded.
- 8 If the lines do not converge, press the LIN or SIZE key and repeat the adjustment by pressing the ◀ or ▶ key.
Each time you press the LINE or SIZE key, the COARSE mode and FINE mode are selected alternately, and you can use the two modes appropriately. The adjustment data is stored for each mode separately. While you hold down the arrow key in the FINE mode, "f" is displayed around the adjustment position.
- 9 If the CROSS HAIR pattern is off-centered on the screen, adjust the centering again and repeat steps 1 to 8 for the horizontal scale adjustment.
For details of the centering adjustment, see "Red CENT (centering) adjustment" on page 108.
- 10 Press the LIN key.

(continued)


Adjusting the Registration

- 11** Adjust with the $\blacklozenge$ and $\blacktriangleright$ keys until parts (B) (distances between the red and green lines) at the top and bottom are of equal length.
 - $\blacklozenge$: The upper and lower horizontal lines are shifted upward while the horizontal center line remains unmoved.
 - $\blacktriangleright$: The upper and lower horizontal lines are shifted downward while the horizontal center line remains unmoved.
- 12** Press the SIZE key.
- 13** Adjust with the $\blacklozenge$ and $\blacktriangleright$ keys so that the red and green lines at the top and bottom encircled portions converge.
 - $\blacklozenge$: The vertical scale is expanded.
 - $\blacktriangleright$: The vertical scale is reduced.
- 14** If the lines do not converge, repeat steps **10** to **13**.
- 15** If the CROSS HAIR pattern is off-centered on the screen, adjust the centering again and repeat steps **10** to **14** for the vertical scale adjustment.
 For details of the centering adjustment, see "Red CENT (centering) adjustment" on page 108.



Adjustments


9 Red SKEW and BOW adjustments




A Horizontal line adjustment

If the horizontal line of the picture is as shown by the dotted line in the illustrations below, adjust it with the corresponding arrow key so that it is perpendicular to the vertical line (bold line illustrated on the left).

- 1** Press the BOW key.
 The CROSS HAIR pattern appears.
 You can also change to the 9×9 HATCH pattern by pressing the PATTERN key.
- 2** Reset the FINE bow data.
 See "Resetting the Data" on page 138.
- 3** Adjust the distortion as illustrated below with the $\blacklozenge$ and $\blacktriangleright$ keys.
 - $\blacklozenge$: The left and right ends of the horizontal line curve upward while the center remains unchanged.
 - $\blacktriangleright$: The right and left ends of the horizontal line curve downward while the center remains unchanged.
- 4** Press the SKEW key.
- 5** Reset the FINE skew data.
 See "Resetting the Data" on page 138.
- 6** Adjust the distortion as illustrated below with the $\blacklozenge$ and $\blacktriangleright$ keys.
 - $\blacklozenge$: The horizontal line rotates counter-clockwise, rotating around the center.
 - $\blacktriangleright$: The horizontal line rotates clockwise, rotating around the center.
- 7** Repeat steps **1** to **6** until the red horizontal line converges with the green line.
 Each time you press the BOW or SKEW key, the COARSE mode and FINE mode are selected alternately, and you can use the two modes appropriately. The adjustment data is stored for each mode separately. While you hold down the arrow key in the FINE mode, "F" is displayed around the adjustment position.



Adjusting the Registration



[B] Vertical line adjustment

If the vertical line of the picture is as shown by the dotted line in the illustrations below, adjust it with the corresponding arrow key so that it is perpendicular to the vertical line (bold line illustrated on the left).

1

Press the BOW key.

The CROSS HAIR pattern appears.

You can also change to the 9 × 9 HATCH pattern by pressing the PATTERN key.

2

Adjust the distortion as illustrated below with the ◀ and ▶ keys.



◀ : The upper and lower ends of the vertical line curve towards the left while the center remains unchanged.



▶ : The upper and lower ends of the vertical line curve towards the right while the center remains unchanged.

3

Press the SKEW key.

4

Adjust the distortion as illustrated below with the ◀ and ▶ keys.



◀ : The vertical line rotates counter-clockwise, rotating around the center.



▶ : The vertical line rotates clockwise, rotating around the center.

5

Repeat steps **1** to **4** until the red vertical line converges with the green line.

Each time you press the BOW or SKEW key, the COARSE mode and FINE mode are selected alternately, and you can use the two modes appropriately. The adjustment data is stored for each mode separately. While you hold down the arrow key in the FINE mode, "r" is displayed around the adjustment position.



Adjustments

10 Red KEY (keystone) and PIN (pincushion) adjustments

Adjust the trapezoidal and pincushion distortion at the top, bottom, right end and left end of the screen separately so that the red lines converge with the green lines.

[A] Horizontal line adjustment at the top

1

Press the KEY key.

The HATCH pattern appears.

The projector enters the upper keystone adjustment mode (POSITION No. 1) of the red signal.

When you press the POSITION + key, the adjustment position changes in the numerical order **1** to **4** as illustrated on the left. The selected position number appears at the upper right corner of the screen. When you press the POSITION - key, the position number is selected in the reverse order.


2

Adjust the distortion of the horizontal line at the top with the ◀ and ▶ keys.

Only the red line moves.



◀ : The horizontal line rotates counter-clockwise, rotating around the center.



▶ : The horizontal line rotates clockwise, rotating around the center.

3

Press the PIN key.

The projector enters the upper pincushion adjustment mode


(POSITION No. 1) of the red signal.

When you press the POSITION + key, the adjustment position changes in the numerical order **1** to **4** as illustrated on the left. The selected position number appears at the upper right corner of the screen. When you press the POSITION - key, the position number is selected in the reverse order.

(continued)

Adjusting the Registration

- 4** Adjust the distortion of the horizontal line on the top with the $\blacktriangle$ and $\blacktriangledown$ keys.
Only the red line moves.



$\blacktriangle$: The left and right ends of the horizontal line curve upward while the center remains unchanged.

$\blacktriangledown$: The left and right ends of the horizontal line curve downward while the center remains unchanged.

- 5** Repeat the adjustment with the KEY or PIN key and the $\blacktriangle$ and $\blacktriangledown$ keys until the red horizontal line on the top converges with the green line.

Horizontal line adjustment at the bottom

- 1** Press the KEY key and press the POSITION + key once.
The projector enters the lower keystone adjustment mode (POSITION No. 2) of the red signal.

- 2** Adjust the distortion of the horizontal line at the bottom with the $\blacktriangle$ and $\blacktriangledown$ keys.

$\blacktriangle$: The horizontal line rotates counter-clockwise, rotating around the center.

$\blacktriangledown$: The horizontal line rotates clockwise, rotating around the center.

- 3** Press the PIN key and press the POSITION + key once.
The projector enters the lower pincushion adjustment mode (POSITION No. 2) of the red signal.

- 4** Adjust the distortion of the horizontal line at the bottom with the $\blacktriangle$ and $\blacktriangledown$ keys.

$\blacktriangle$: The left and right ends of the horizontal line curve upward while the center remains unchanged.

$\blacktriangledown$: The left and right ends of the horizontal line curve downward while the center remains unchanged.

- 5** Repeat the adjustment with the KEY or PIN key and the $\blacktriangle$ and $\blacktriangledown$ keys until the horizontal line at the bottom converges with the green line.




Adjustments


Vertical line adjustment at the left side

- 1** Press the KEY key and press the POSITION + key once.
The projector enters the left keystone adjustment mode (POSITION No. 3) of the red signal.

- 2** Adjust the distortion of the vertical line at the left side with the $\blacktriangle$ and $\blacktriangledown$ keys.




$\blacktriangle$: The vertical line rotates counter-clockwise, rotating around the center.



$\blacktriangledown$: The vertical line rotates clockwise, rotating around the center.

- 3** Press the PIN key and press the POSITION + key once.
The projector enters the left pincushion adjustment mode (POSITION No. 3) of the red signal.

- 4** Adjust the distortion of the vertical line at the left side with the $\blacktriangle$ and $\blacktriangledown$ keys.



$\blacktriangle$: The upper and lower ends of the vertical line curve towards the left while the center remains unchanged.



$\blacktriangledown$: The upper and lower ends of the vertical line curve towards the right while the center remains unchanged.

- 5** Repeat the adjustment with the KEY or PIN key and the $\blacktriangle$ and $\blacktriangledown$ keys until the vertical line at the left side converges with the green line.



Adjustments

Adjusting the Registration

Vertical line adjustment at the right side

- 1 Press the KEY key and press the POSITION + key once.
The projector enters the right keystone adjustment mode (POSITION No. 4) of the red signal.
- 2 Adjust the distortion of the vertical line at the right side with the ◀ and ▶ keys.
 ▶: The vertical line rotates counter-clockwise, rotating around the center.
 ▶: The vertical line rotates clockwise, rotating around the center.
- 3 Press the PIN key and press the POSITION + key once.
The projector enters the right pincushion adjustment mode (POSITION No. 4) of the red signal.
- 4 Adjust the distortion of the vertical line at the right side with the ◀ and ▶ keys.
 ▶: The upper and lower ends of the vertical line curve towards the left while the center remains unchanged.
 ▶: The upper and lower ends of the vertical line curve towards the right while the center remains unchanged.
- 5 Repeat the adjustment with the KEY or PIN key and the ◀ and ▶ keys until the vertical line at the right side converges with the green line.




Adjustments

Red ZONE adjustment

Adjust red ZONE after the red lines have converged with the green lines by performing the adjustments 7 to 10.

- 1 Press the ZONE key.
The 9 x 9 HATCH pattern and the cursor appear, and the projector enters the center zone adjustment mode (POSITION No. 1).



- 2 Reset the FINE zone data.
See "Resetting the data" on page 138.
- 3 Adjust the red line distortion in the cursor positioning area with the arrow keys.

For fine adjustment, press the ZONE key once to set the projector to the FINE mode. While you hold down the arrow key in the FINE mode, "f" is displayed around the adjustment position.


When you press the ZONE key in position No. 1, the adjustment mode changes as follows:

COARSE adjustment mode → FINE adjustment mode → position select mode → COARSE adjustment mode ...

- 4 After the adjustment is complete, press the ZONE key to set the projector to the position select mode.

- 5 Press the POSITION +/- keys to select the part to be adjusted.
When you press the + key, the cursor moves in the numerical order as illustrated.

When you press the - key, the cursor moves in the reverse order. The selected position number appears at the upper right corner.



- 6 Press the ZONE key again after selecting the position.
The projector enters the COARSE adjustment mode.

- 7 Adjust the red line distortion in the cursor positioning area with the arrow keys.

(continued)

Adjusting the Registration

- 8** Press the ZONE key and repeat steps **5** to **7** to adjust in positions No. 2 to No.25 in order.

- 9** After the adjustment is complete, press the MEMORY key to save the adjustment data.

**The red registration adjustment is complete.
Proceed to the registration adjustment of the blue signal.**



Adjustments

Adjusting the Blue Registration

Adjust the blue signal so that it converges with the red signal which has been adjusted. When the blue and red test patterns converge, the pattern is seen as magenta.

Note

When you have adjusted the blue registration data and have saved the adjustment data, reset the blue centering to the factory preset level.
For resetting, see page 138.

12 Blue CENT (centering) adjustment

Adjust so that the center of the blue CROSS HAIR pattern is aligned with that of the red pattern.

- 1** Press the CENT key.
The CROSS HAIR pattern and the cursor appear.
- 2** Press the ADJ B key.
- 3** Press the CUT OFF G key to display blue and red.
- 4** Reset the FINE centering data.
See "Resetting the Data" on page 138.
- 5** Press the arrow keys to align the center of the blue CROSS HAIR pattern with that of the red pattern.
- 6** If the centers do not converge, press the CENT key again.
The projector enters the FINE centering mode for fine adjustment. Each time you press the CENT key, the COARSE mode and FINE mode are selected alternately, and you can use the two modes appropriately. The adjustment data is stored for each mode separately. While you hold down the arrow key in the FINE mode, "f" is displayed around the adjustment position.
- 7** Press the arrow keys to align the center precisely.

Notes

- If the blue vertical lines are not aligned with those of the red pattern, adjust the CRT conversion angle again.
For details, see "Adjusting the CRT Conversion Angle" on page 22.
- If the upper, lower, left or right part of the screen is de-focused, adjust the scheimpflug again.
For details, see "Adjusting the green scheimpflug" on page 83.




Adjustments

Adjusting the Registration

13 Blue SIZE, LIN (linearity), SKEW, BOW, KEY (keystone), PIN (pincushion) and ZONE adjustments

Adjust so that the blue signal converges with the red signal in each adjustment. The procedures are the same as for adjusting the red registration.
For details, see pages 108 to 118.

Make sure that “—B—” appears on the screen when adjusting the blue signal.



The blue adjustment is complete. Save the adjustment data as the standard data.




Saving the Standard Registration Data

After adjusting all the registrations for the green, red and blue signals, save the adjustment data as the standard data for the projector. The projector automatically changes the registration data of every input memory according to the standard data.

- 1 Hold down the MEMORY for more than 5 seconds.
“MEMORY DATA is saving!” is displayed while the projector saves the registration data. When saving is complete, the following display appears.



- 2 Press the $\blacktriangle$ or $\blacklozenge$ key to select YES, then press the ENTER key.
If you select YES, the STANDARD DATA SAVE MODE display appears.



If you select NO, the registration adjustment mode is resumed.

- 3 Press the $\blacktriangle$ or $\blacklozenge$ key to select REGISTRATION DATA, then press the ENTER key.
The registration data of all the input memory are changed according to the standard data saved in step 1.

Notes

- No keys function while the data is being saved.
- If the standard data save is performed, the registration data stored in every input memory will be changed into the standard data. If necessary, readjust the registration for each input signal.



Fine Adjustment for Each Input Signal

After the registration adjustment is performed without an input source and the adjustment data is saved as the standard data, input an external signal and fine adjust for each input signal.

Selecting the Input Signal

- 1 Input an external signal.
Input the signal to the INPUT A connectors of the projector, the VIDEO connectors of the IFB-G90E Video Interface Board, or the signal interface board installed to the INPUT B or INPUT C section.
- 2 Select the video input source by pressing the INPUT SELECT keys on the remote commander.

Fine Magnetic Focus and AQP/DQP Adjustments

- 1 Press the PATTERN key to display the 9×9 DOT pattern.
- 2 If necessary, fine adjust the magnetic focus, AQP and DQP.
For details, see "Adjusting the green magnetic focus, AQP/DQP and AHP/DHP" on page 87.
- 3 Press and release the MEMORY key to save the adjustment data.

Note

Do not hold down the MEMORY key in step 3.

Fine Registration Adjustment

- 1 Press the PATTERN key to display the CROSS HAIR pattern.
- 2 If necessary, fine adjust the registrations.
For details of the adjustment procedure, see "Adjusting the Registration" on pages 93 to 120.
- 3 If two or more input sources are connected, fine adjust the registration for each input signal.

- 4 Press and release the MEMORY key to save the adjustment data.

Note

Do not hold down the MEMORY key in step 4.



Adjustments


SIZE Adjustment

Adjust the picture size if it does not fit the screen.

- 1 Press the RGB SIZE key.
(Use the RGB SIZE key even for the signal other than RGB.)

- 2 Adjust the picture size with the arrow keys.

- ⬆: The vertical size is expanded.
- ⬆: The vertical size is reduced.
- ⬅: The horizontal size is expanded.
- ⬅: The horizontal size is reduced.



To adjust precisely, press the RGB SIZE key again. The projector enters the FINE adjustment mode, and you can fine adjust the size. By pressing the RGB SIZE key again, the COARSE adjustment mode is resumed.

- 3 Press the MEMORY key to save the adjustment data.

SHIFT Adjustment

If the picture needs to be shifted to fit the screen, adjust the position of the picture.

- 1 Press the RGB SHIFT key.
(Use the RGB SHIFT key even for the signal other than RGB.)


- 2 Press the POSITION +/- keys to select the adjustable range of the vertical shift (V SHIFT).

Note

When the video, S video, component or SDI 4:2:2 signal is input, V SHIFT is automatically fixed to NARROW and the adjustable range will become narrower than that of the RGB or HDTV signal.
(continued)

Fine Adjustment for Each Input Signal

- 3 Adjust the shift with the arrow keys.
- : The picture is shifted upward.
 - : The picture is shifted downward.
 - : The picture is shifted rightward.
 - : The picture is shifted leftward.



To adjust precisely, press the RGB SHIFT key again. The projector enters the FINE adjustment mode, and you can fine adjust the horizontal shift only. By pressing the RGB SHIFT key again, the COARSE adjustment mode is resumed.

- 4 Press the MEMORY key to save the adjustment data.

Blanking Adjustment

If the displayed picture is larger than the screen, cut off the excess parts.

- 1 Press the BLKG key.
The external signal and the 17 × 17 HATCH pattern overlap. You can also change to the external signal only by pressing the PATTERN key.
- 2 Press the POSITION +/- keys or the BLKG key to select the part to be adjusted.
- When you press the + key or the BLKG key, the position cycles through the following order:
TOP → BOTTOM → LEFT → RIGHT → TOP ..
 - When you press the - key, the position cycles in reverse order.
- 3 Adjust with the arrow keys.
- Press the • and • keys to adjust the TOP and BOTTOM positions.
 - Press the • and • keys to adjust the LEFT and RIGHT positions.



- 4 Press the MEMORY key to save the adjustment data.

Note

When you connect multiple input sources to the projector, such as when using the switcher, adjust the picture size, picture shift and blanking for each input signal. The information about the input signal is shown in the INPUT INFO menu.

Adjusting the White Balance

The color temperatures are preset at the factory to 9300K, 6500K, 5400K and 3200K for two types of screen, respectively. However, if you change these levels or set a color temperature other than the factory preset levels, you can adjust the white balance and save it in the memory.

Selecting the screen type

Select the type of screen in use: bead screen or mat screen.

- 1 Display the SERVICE SETTING 1 menu.
Press the MENU key, select SERVICE SETTING 1 by pressing the • or • key, and press the ENTER key.
- 2 Press the • or • key to select SCREEN TYPE, then press the ENTER key.
- 3 Press the • or • key to select SCREEN B for bead screen or SCREEN M for mat screen, then press the ENTER key.



Setting the color temperature


- 1 Display the INPUT SETTING menu.
Press the MENU key, select INPUT SETTING with the • or • key, then press the ENTER key.
- 2 Press the • or • key to select COLOR TEMP, then press the ENTER key.

(continued)



Fine Adjustment for Each Input Signal

- 3 Press the $\blacklozenge$ or $\blacklozenge$ key to select the desired color temperature, then press the ENTER key.



Normally set to 6500.

Select the appropriate color temperature 9300, 6500, 5400 or 3200 according to your application and the picture source.
Select CUSTOM to adjust the white balance for a particular input signal and store the adjusted data to the input memory.

- 4 Press the MEMORY key to save the adjustment data.

Adjusting the white balance

You can readjust the color temperature or the CUSTOM data selected in COLOR TEMP of the INPUT SETTING menu. For example, adjust the white balance when you wish to make the color uniform with that of another display.

Adjusting the black level (BIAS adjustment)

- 1 Reset the CONTRAST level to 80 and BRIGHT level to 50.
For details, see "Adjusting the Picture Quality" on page 129.
- 2 Press the W/B BIAS key.
The PLUGE pattern appears. Press the PATTERN key repeatedly to display the external signal.
- 3 Press the ADJ R, G or B key to select the color to be adjusted.
When selecting the color, pay attention to the black part of the picture displayed on the screen and note which color stands out compared to that of another display.
- 4 Press the $\blacklozenge$ or $\blacklozenge$ key so that the black part in the picture on the screen looks the same as that of the display.
If the brightness of that part does not look the same as that of the display, adjust the other colors by pressing the ADJ R, G or B key and the $\blacklozenge$ or $\blacklozenge$ key.
- 5 Press the MEMORY key to save the adjustment data.



Adjustments

Adjusting the white level (GAIN adjustment)

- 1 Reset the CONTRAST level to 80 and BRIGHT level to 50.
For details, see "Adjusting the Picture Quality" on page 129.
- 2 Press the W/B GAIN key.
When the GAIN adjustment is followed by the BIAS adjustment, the external signal appears automatically.
When you start with the GAIN adjustment, the stair step pattern appears. Press the PATTERN key repeatedly to display the external signal.
- 3 Press the ADJ R, G or B key to select the color to be adjusted.
When selecting the color, pay attention to the white part of the picture displayed on the screen and note which color stands out compared to that of another display.
- 4 Press the $\blacklozenge$ or $\blacklozenge$ key so that the white part in the picture on the screen looks the same as that of the display.
If the brightness does not look the same as that of the display, adjust the other colors by pressing the ADJ R, G or B key and the $\blacklozenge$ or $\blacklozenge$ key.
- 5 Press the MEMORY key to save the adjustment data.

Adjusting the gray level (GAMMA adjustment)

- 1 Set the projector to the expert mode.
For entering into the expert mode, see "Expert mode" on page 54.
- 2 Reset the CONTRAST level to 80 and BRIGHT level to 50.
For details, see "Adjusting the Picture Quality" on page 129.
- 3 Press the W/B BIAS and GAIN keys simultaneously.
The stair step pattern appears. Press the PATTERN key repeatedly to display the external signal.
- 4 Press the ADJ R, G or B key to select the color to be adjusted.
When selecting the color, pay attention to the gray part of the picture displayed on the screen and note which color stands out compared to that of another display.
- 5 Press the $\blacklozenge$ or $\blacklozenge$ key so that the gray part in the picture on the screen looks the same as that of the display.
If the brightness does not look the same as that of the display, adjust the other colors by pressing the ADJ R, G or B key and the $\blacklozenge$ or $\blacklozenge$ key.
- 6 Press the MEMORY key to save the adjustment data.



Adjustments

Fine Adjustment for Each Input Signal

When using multiple projectors

Input the same signal to the base projector and the projector to be adjusted. Set COLOR TEMP in the INPUT SETTING menu to the same position on both projectors, and then follow the procedures described above to make the black, white and gray colors uniform between the base projector and the projector to be adjusted.

Notes

- When adjusting the white balance, use the external color monitor for the reference of the color.
- To adjust the white balance easily without the on-screen display, press the STATUS OFF key on the remote commander or set the STATUS option in the SET SETTING 1 menu to OFF.
- You can adjust the white balance more easily if you set the color level to MIN to display the black and white picture.



Adjustments

Adjusting the Picture Quality

Adjust the picture for your preference. The adjustment data can be saved in the memory.

- 1** Adjust with the PICTURE CONTROL +/- keys.

BRIGHT	Brightness
CONTR	Picture contrast
COLOR	Color intensity
HUE	Hue
SHARP	Sharpness

The adjustment levels are digitally displayed with a range of MIN, 1, 2, ... 99, MAX.



- 2** Press the MEMORY key to save the data.



Adjustments

Restoring the initial data

- 1** Press the PICTURE CONTROL key of the item which you want to reset to the initial data.

- 2** Press the RESET key.
The selected item is reset to the initial data.

Notes

- The COLOR, SHARP and HUE keys do not function with the RGB input signals.
- The HUE and COLOR keys do not function if the input signal is black and white.
- The HUE key does not function with the PAL or SECAM color input source.

Saving the Adjustment Data

Memory Blocks

The memory structure of this projector consists of the following four memory blocks.

See the diagram "Structure of memory blocks" on the next page.

User block

This is the memory block normally in use when the user operates the projector. The set/adjusted data are stored to this block automatically or by pressing the MEMORY key. The data for the floor installation using the front projection and a 120-inch screen are adjusted at the factory and stored to input memory numbers 00 to 12 (Original Input Memory).

Memory contents in the user block

- Setting memory
- Channel memory
- 150 input memory (Original Memory No. 00 – 12 and Custom Memory No. 13 – 149)

Service block

This is the memory block that backs up the set/adjusted data in the user block. The same data as those in the user block are stored at the factory to the Original Input Memory No. 00 – 12.

Memory contents in the service block

- Setting memory
- Channel memory
- 150 input memory (Original Memory No. 00 – 12 and Custom Memory No. 13 – 149)

Factory block

This is the memory block used at the factory. The data for the floor installation using the front projection and a 120-inch screen are adjusted at the factory and stored to input memory numbers 00 to 12 (Original Input Memory). The registration data and magnetic focus data in this block are used as reference values for the Standard Data Save.


Memory contents in the factory block

- Setting memory
- Channel memory
- 150 input memory (Original Memory No. 00 – 12)

Normal adjustment area

This is the memory block that temporarily stores the data adjusted by the remote commander so that the projector can reflect adjustments directly.

Structure of memory blocks



Setting memory

The setting memory stores the set/adjusted data of the items that have only one value for the projector.

Channel memory

The channel memory stores the set/adjusted data for each input channel, such as the input channel, type of input signal, and DRC ON/OFF setting.

Input memory

The input memory stores the set/adjusted data for each input signal type. This projector has 150 input memory. For details, see page 132.

Saving the Adjustment Data

Saving the Data to the Service Block

When you press the MEMORY key during adjustment, the adjusted data is stored in the user block. After all the adjustments are completed, we recommend that you store the adjustment data in the user block to the service block as service data.

- 1 Set the projector to the service or expert mode.
For details, see "Menu Modes" on page 51.
- 2 Press the NORMAL key.
- 3 Press the ENTER key for 5 seconds.
The following display appears.



- 4 Press the $\blacklozenge$ or $\blacklozenge$ key to select "YES," then press the ENTER key.

The data stored in the user block are saved to the service block as service data.

How to recall the service data

By recalling the service data, you can easily reset the projector to the previously adjusted conditions.
To reset to the service data, select "All Data Reset," "ALL MEMORY," and "Service Data" following the resetting procedure.
For details, see "Resetting Multiple Items Simultaneously" on page 139.

Input Memory

Contents of input memory

- The 150 input memory of this projector is divided into two.
Either input memory stores the same data contents.
- **Original Input Memory** No. 00 – 12
 - **Custom Input Memory** No. 13 – 149
- Each input memory consists of the following data.
- **Identification data for the input signal**
 - **Set/adjusted data** (registration, magnetic focus, CUSTOM data of white balance)
 - **Data of video memory OFF**

Identification data for the input signal

The projector judges the input signal using the following identification data, and searches for and selects the appropriate input memory for the input signal.

Item	Data
Input channel (Custom Memory only)	Input channel selected when the input memory is registered to a new number VIDEO, INPUT-A, INPUT-B, INPUT-C, SWITCHER 1–1 to 8–8
Input signal type (Original and Custom Memory)	Type of the input signal when the input memory is registered to a new number VIDEO, S.VIDEO, COMPONENT, RGB, 15 k RGB, HDTV-YBPBP, HDTV-GBR, SDI 4:2:2, DRC, IDTV, etc.
Sync signal type (Custom Memory only)	Type of the sync signal used when the input memory is registered to a new number H/C: P/N/– V: P/N/– S/G: N/– P (positive), N (negative), – (no sync)
Input frequency (Original and Custom Memory)	Hz (horizontal frequency), Hz (vertical frequency), scanning lines

Original Input Memory (No. 00 – 12)

The Original Input Memory stores the data set/adjusted at the factory.
When a new type of signal is input, no signal is input or the internally generated signal is used, the projector loads the data of the Original Input Memory.

(continued)

Saving the Adjustment Data

As the Original Input Memory only includes the type of input signal and the input frequency (for RGB only) as identification data, the data most similar to the input signal is selected by judging the two types of information. The data of the selected memory are loaded. The Original Input Memory numbers cannot be deleted in any way.

Original Input Memory

Memory No.	fH	fV	Scanning lines	Type of input signal
00	15.73 kHz	60.00 Hz	262	VIDEO (NTSC _{3.58})
01	15.73 kHz	60.00 Hz	262	RGB
02	24.83 kHz	56.40 Hz	440	RGB
03	31.47 kHz	59.94 Hz	525	RGB
04	48.36 kHz	60.00 Hz	806	RGB
05	63.98 kHz	60.02 Hz	1066	RGB
06	75.00 kHz	60.00 Hz	1250	RGB
07	93.75 kHz	75.00 Hz	1250	RGB
08	106.25 kHz	85.00 Hz	1250	RGB
09	126.84 kHz	60.00 Hz	2114	RGB
10	145.00 kHz	60.00 Hz	2417	RGB
11	31.47 kHz	60.00 Hz	525	Double scan DRG (NTSC _{3.58})
12	33.75 kHz	60.00 Hz	562	HDTV (YPbPr)

Custom Input Memory (No.13 – 149)

The Custom Input Memory stores the data of the input signals which are input after shipment. Each time a new signal is input, a new memory number is registered. When 150 input memory numbers including the Original Input Memory is reached, the Custom Input Memory with the lowest number is replaced.


Automatic loading/saving of the input memory

When MEM. LOAD/SAVE is set to AUTO in the INPUT MEM. OPTION menu (page 66), the projector selects the input memory according to the input signal, loads its data and saves the set/adjusted data to the input memory automatically. The automatic selection mode differs if the input signal is new or existing.

When a new signal is input


When a new signal is input, the projector searches for the Original Input Memory and loads the data most similar to the input signal. When setting/adjustment is complete, press the MEMORY key. A new Custom Input Memory is registered, and simultaneously, the adjusted data are overwritten on the Original Input Memory. With this method, the Original Input Memory is updated, making the adjustment for the next new signal easier.

Example: When a new signal (fH = 31.5 kHz) is input with up to No. 13 Custom Input Memory registered



When the same signal has been input to another input channel
When a signal is input, the projector searches for the Original and Custom Input Memory and loads the data most similar to the input signal. When setting/adjustment is complete, press the MEMORY key. A new Custom Input Memory is registered, and simultaneously, the adjusted data are overwritten on the Original Input Memory.


Example: When the same signal (fH = 31.5 kHz) is input on another channel with up to No. 13 Custom Input Memory registered



Saving the Adjustment Data

When the same signal has been input
When the same signal has been input, the projector searches for the Original and Custom Input Memory and loads the data of the existing input memory for that signal. When setting/adjustment is complete, press the MEMORY key. The adjusted data is overwritten on the loaded Custom Input Memory, and simultaneously, on the Original Input Memory that was the base of the loaded Custom Input Memory.

Example: When the same signal (fH = 31.5 kHz) as that registered to No. 13 Custom Input Memory is input



Specifying the input memory to be loaded or saved

When MEM. LOAD/SAVE is set to MANUAL in the INPUT MEM. OPTION menu, you can specify the input memory number to be loaded or saved.

For details, see "The INPUT MEM. OPTION menu" on page 66.

Video Memory

The video memory stores the aspect ratio and picture control data. This projector has No. 1 – 10 video memory, and each video memory stores the same data contents.
If you set the video memory to OFF, the aspect ratio and picture control data stored in the input memory are loaded.

Contents of Video Memory

Item	Data
COLOR TEMPERATURE	9300/6500/5400/3200/CUSTOM
WHITE BALANCE	GAIN: R/G/B
CUSTOM	BIAS Coarse: R/G/B
	BIAS Fine: R/G/B
	GAMMA: R/G/B
	(Different data for two screen types)
DYNAMIC PICTURE	ON/OFF
V SHIFT	WIDE/NARROW
NTSC SET UP	0/7.5
COMPONENT FORMAT	SMPT-EBU-NT0/BETACAM7.5
COMB FILTER	3D/3LINE
DRC LEVEL	HIGH/LOW
PICTURE CONTROL	CONTRAST/BRIGHTNESS/COLOR/HUE/SHARPNESS
RGB SIZE	Hc/Hv/Vc/Vf
RGB SHIFT	Hc/Hv/Vc
BLANKING	TOP/BOTTOM/LEFT/RIGHT

Specifying the video memory

Set the SWITCHER/VIDEO MEMORY/INDEX select switch to VIDEO MEMORY, and select a video memory number using the SWITCHER/VIDEO MEMORY/INDEX keys on the remote commander or the control panel.
For details, see page 48.

Resetting the Data

This projector has the following reset modes.

Normal Reset mode: Resets the data being adjusted.
For resetting items, see "List of Resetting Items" on page 140.


All Data Reset mode: Resets multiple items together.
For example, you can reset the data of the selected input memory, or all the data simultaneously.

Depending on the resetting item, select the memory block which stores the data to be reset.

- **Data in the service block**
- **Data in the factory block**
- **FINE128 data** (for items with the FINE mode only)
- **128 data** (ZONE only)

Resetting the Item in Adjustment Only (Normal Reset)

- 1 Set the item you want to reset to the adjustment mode.
 - 2 Press the RESET key once.
(Depending on the selected item, data is reset at this stage.)
- If the item can be reset to the data in two or more memory blocks, the following display appears.
(Example: To reset the green centering data)




- 3 Press the $\blacklozenge$ or $\blackstar$ key to select the reset mode.
Service Data: To reset to the data in the service block
Factory Data: To reset to the data in the factory block
FINE128 Data: To reset to the data in FINE adjustment mode
- 4 Press the ENTER key.
The data is reset. When resetting is completed, "Reset Complete!" appears for about 3 seconds.


Note
If you do not operate the keys within more than one minute, the display is canceled.

Resetting Multiple Items Simultaneously (All Data Reset)


- 1 Set the projector to the service mode.
For details, see "Menu Modes" on page 53.
- 2 Press the RESET key for five seconds.
The following display appears.



- 3 Press the $\blacklozenge$ or $\blackstar$ key to select "YES," then press the ENTER key.
The projector enters into the ALL RESET MODE, and the following display appears.



- 4 Press the $\blacklozenge$ or $\blackstar$ key to select the memory block, then press the ENTER key.
SELECTED INPUT MEMORY: To reset the data of the selected input memory
ALL MEMORY: To reset all the adjustment data



- 5 Press the $\blacklozenge$ or $\blackstar$ key to select the reset mode.
Service Data: To reset to the data in the service block
Factory Data: To reset to the data in the factory block
- 6 Press the ENTER key.
The data is reset. When resetting is completed, "Reset Complete!" appears for about three seconds.

Note
If you do not operate the keys within more than one minute, the display is canceled.

Saving the Adjustment Data

List of Resetting Items

Adjustment mode while resetting	Color to be reset	Data to be reset simultaneously	Reset mode	Projector mode
CENTERING Coarse	Selected color	Hc/Hf/Vc/Vf ¹⁾	Service Data or Factory Data	Service/Expert
CENTERING Fine	Selected color	Hc/Hf/Vc/Vf ¹⁾	Service Data or Factory Data	Pro-user/Service/Expert
SIZE Coarse	Selected color	CENTERING/SIZE/LIN/SKEW/BOW (Hc/Hf/Vc/Vf)	Service Data or Factory Data	Service/Expert
SIZE Fine	---	KEY/PIN (all positions)	---	---
LIN Coarse	---	ZONE (all positions)	---	---
LIN Fine	---	---	---	---
SKREW Coarse	---	---	---	---
BOW Coarse	---	---	---	---
BOW Fine	---	---	---	---
KEY	Selected color	CENTERING/SIZE/LIN/SKEW/BOW (Hc/Hf/Vc/Vf)	Service Data or Factory Data	Service/Expert
PIN	---	KEY/PIN (all positions)	---	---
ZONE	Selected color	ZONE (except position 1) ¹⁾	Service Data or Factory Data	Service/Expert
MG FOCUS	All colors (RGB)	FOCUS, 2/4/6-pole AQP/DQP/AHP/DHP (all data of all positions)	Service Data or Factory Data	Service/Expert
BIAS Coarse	---	BIAS Coarse, BIAS Fine, GAIN, GAMMA (Expert mode only) ²⁾	Service Data or Factory Data	Service/Expert
BIAS Fine	---	---	---	---
GAIN	---	---	---	---
GAMMA	---	---	---	---
RGB SIZE	---	RGB SIZE (Hc/Hf/Vc/Vf) ^{3) 4)}	Factory Data	Pro-user/Service/Expert
RGB SHIFT	---	RGB SHIFT ^{3) 4)}	Factory Data	Pro-user/Service/Expert
BLANKING	---	BLANKING (TOP/BOTTOM/EFT/RIGHT) ^{3) 4)}	Factory Data	Pro-user/Service/Expert
CONTRAST	---	CONTRAST ²⁾	80	User/Pro-user/Service/Expert
BRIGHT	---	BRIGHT ³⁾	50	User/Pro-user/Service/Expert
COLOR	---	COLOR ³⁾	50	User/Pro-user/Service/Expert
SHARP	---	SHARPNESS ³⁾	50	User/Pro-user/Service/Expert
HUE	---	HUE ³⁾	50	User/Pro-user/Service/Expert
PIC CTRL menu	---	CONTRAST/BRIGHT/COLOR/SHARPNESS/HUE ³⁾	80, 50, 50, 50, 50	User/Pro-user/Service/Expert

1) Data of the currently selected input memory for the current input channel in RAM
2) Data for the currently selected screen type and color temperature in RAM
3) Data of the currently selected input memory or video memory in RAM
4) Effective for VIDEO, S-VIDEO, COMPONENT, SDI 4:2:2, IDTV (INT DRC/via IFB-3000) and HDTV (YPbPr/GRB) only

Others


Setting the Index Numbers

When you connect multiple projectors in your system, you have to set the group index and device index numbers for each projector.


To set the group index number

If you set the same group index number to multiple projectors and switchers, you can operate them simultaneously, for example, to select the input, by designating the group index number.

- 1 Set the projector to the pro-user, service or expert mode.
For details, see "Menu Modes" on page 51.
- 2 Display the SET SETTING 2 menu, select GROUP INDEX by pressing the $\blacklozenge$ or $\blacklozenge$ key, and press the ENTER key.



- 3 Set a group index number 01 to 99 by pressing the $\blacklozenge$ or $\blacklozenge$ key, then press the ENTER key.



(continued)




Adjustments

Setting the Index Numbers

- 4** Press the MENU key to exit the menu mode.

To set the device index number

If you set the device index number, you can control each projector individually with the supplied remote commander.
Set the device index number with the DEVICE INDEX switches on the rear of the projector. Device index number "01" is set at the factory. Do not change from "01" if the projector is used alone.




Notes

- Do not set the same device index number on multiple projectors in the same system.
- Do not set the device index number to "00." If you do, the projector will be operated only with the keys on the control panel. It cannot be controlled with the wired or wireless Remote Commander, or with an external equipment via the PJ COM connector.

Notes on setting of the index number

- Set the same group index number for all equipment of the same system connection (those on the signal route between the signal source and the projector).



Others

- Set the correct group and device index numbers and the switcher number.


Do not set the same device index number or the same switcher number in one group.

For example, if there are different pieces of equipment with the switcher number 1, the error message will appear when the SYS SET key is pressed.

Notes

- Do not set the same device index number on multiple projectors in the same system.

- Set the switcher that outputs the signal to the projector to number 1.



Notes on connections when two or more switchers are used

- Mount the IFB-12/12A interface board to the slot 1 of the number (n) switcher and connect the output connector of the number (n+1) switcher to the IFB-12/12A.
- You can attach the IFB-12/12A signal interface board (when the IN/OUT switch is set to OUT) only to the number 1 switcher.




Others

List of the Projection Distance by Angle of Optical Axis

To select the projector by designating the index numbers

When the switches and projectors are connected as illustrated, select the desired projector by pressing the keys on the remote commander as shown below.



Example:

- To select all the projectors
GROUP → ALL → ENTER → ALL → ENTER
Projectors A, B, C and D are selected.
- To select projectors with device index 01 from all the groups
GROUP → ALL → ENTER → 1 → ENTER
Projectors A and C are selected.
- To select a projector with device index 01 from group index 2
GROUP → 2 → ENTER → 1 → ENTER
Projector C is selected.
- To select all the projectors from group index 2
GROUP → 2 → ENTER → ALL → ENTER
Projectors C and D are selected.

Notes

- Set the group index and device index numbers correctly. If more than two projectors are set to the same group index and device index numbers, an error message will be displayed when the SYS SET key is pressed.
- If the group index is a tens digit number, press the GROUP key before each press of the number key.

Example:

- To select a projector with device index 13 of group index 12
GROUP → 1 → GROUP → 2 → ENTER → 1 → 3 → ENTER


Link Functions

Using the Linked ABL Function

What is linked ABL function?

The ABL (Automatic Brightness Limiter) function is incorporated with the projector. The ABL function prevents CRT burn by controlling the brightness of the screen if it becomes too high.

If you connect the LINK jacks of each projector when connecting multiple projectors to display a multi-screen, the ABL functions on all projectors once the ABL functions on any one projector. The linked ABL function allows the multi-screen's brightness uniform.




Setting up

Set ABL LINK in the ABL LINK menu to ON.
For details, see "The ABL LINK Menu" on page 74.

Link Functions

Adjusting the ABL LINK


- 1 Set the projector to the service mode.
For details, see "Service mode" on page 53.
- 2 Set the CONTRAST levels of all projectors to the same level.
- 3 Adjust the brightness of each projector to make its black level uniform.
- 4 Input an external signal to display the 1/16 window pattern.
- 5 Display the ABL LINK menu, select SUB CONTRAST with the $\blacktriangle$ or $\blacktriangledown$ key, then press the ENTER key.



- 6 Press the $\blacktriangle$ or $\blacktriangledown$ key to adjust the projector so that the brightness looks the same as that of the darkest projector, then press the ENTER key.



- 7 Repeat steps 4 to 6 on each projector so that the brightness of all projectors looks the same.
- 8 Input an external signal to display the all white pattern.
- 9 Select ABL LEVEL in the ABL LINK menu, then press the ENTER key.
- 10 Press the $\blacktriangle$ or $\blacktriangledown$ key to adjust the projector so that the brightness looks the same as that of the darkest projector, then press the ENTER key.



- 11 Repeat steps 8 to 10 on each projector so that the brightness of all projectors looks the same.
- 12 Set ABL LINK in the ABL LINK menu to ON, then press the ENTER key.
If the ABL functions on any one projector, the brightness of all projectors becomes uniform.




Others



Others

Self-diagnosis Function

When a operational trouble occurs, a double-digit code will light up on the LED window on the rear of the projector. Refer to the chart below for the meanings of the main self-diagnostic codes.



Code (color)	Type	Item	Meaning
3A (green)	Warning	Warning	Change in the input memory
40 (green)	Warning	Warning	Configuring the system
41 (green)	Warning	Warning	Same DEVICE INDEX for the projector detected
42 (green)	Warning	Warning	Same DEVICE INDEX for the switcher detected
43 (green)	Warning	Warning	Master switcher does not exist.
60 (orange)	Protector	Unknown	Abnormalities that do not come under the errors below.
61 (orange)	Protector	POW1	Abnormal in the 200 V line
62 (orange)	Protector	POW2	Abnormal in the 115 V line
63 (orange)	Protector	POW3	Abnormal in the 50 V line
64 (orange)	Protector	POW4	Abnormal in the 15 V line
65 (orange)	Protector	POL	The cover of the polarity switchers does not shut completely.
66 (orange)	Protector	H.STOP	Horizontal deflection is stopped.
67 (orange)	Protector	V.STOP	Vertical deflection is stopped.
68 (orange)	Protector	SUB	Abnormality of the DC board
69 (orange)	Protector	HV	Abnormal high voltage
6A (orange)	Protector	LOT	Abnormal load on a LOT of the PE board
6B (orange)	Protector	Ik	Current in any of the R, G and B CRTs exceeds the rated output.
6C (orange)	Protector	Σ Ik	There is abnormality in the CRTs.
6D (orange)	Protector	FAN 1	A large fan inside the projector does not work.
6E (orange)	Protector	FAN 2	A small fan inside the projector does not work.
6F (orange)	Protector	LENS	A lens is removed.
70 (orange)	Protector	CRTR	Current in the red CRT exceeds the rated output.
71 (orange)	Protector	CRTG	Current in the green CRT exceeds the rated output.
72 (orange)	Protector	CRTB	Current in the blue CRT exceeds the rated output.
73 (orange)	Protector	IFB	Abnormality of the interface board installed to the INPUT B section
74 (orange)	Protector	IFB	Abnormality of the interface board installed to the INPUT C section
80 (orange)	Protector	BA	Abnormality of the power line on the BA board
81 (orange)	Protector	DA	Abnormality of the power line on the DA board
82 (orange)	Protector	DB	Abnormality of the power line on the DB board
83 (orange)	Protector	DD	Abnormality of the power line on the DD board
84 (orange)	Protector	DE	Abnormality of the power line on the DE board



Others

Code (color)	Type	Item	Meaning
85 (orange)	Protector	EBR	Abnormality of the EBR board
86 (orange)	Protector	EBG	Abnormality of the EBG board
87 (orange)	Protector	EBB	Abnormality of the EBB board
88 (red)	Warning	Warning	Initializing
89 (orange)	Protector	EBH	Abnormality of the EBH board
8A (orange)	Protector	EBQ	Abnormality of the EBQ board

Types of code

There are three types of self-diagnostic codes.

Warning (green): The power remains. Check your system and connections.

Protector (orange): The power turns off and the projector is set to the standby condition. Remove the cause of the trouble and press the ON key on the remote commander to restore the power.

Error (red): The power turns off and the projector cannot receive any command from the remote commander. Remove the cause of the trouble and press the MAIN POWER switch on the projector to restore the power.


Notes

- When an error code lights up, the previous adjustment data may be cleared.
- The code disappears when the MAIN POWER switch is turned off.
- The code lights up every time the power is turned on until the operational trouble is returned to normal.
- Immediately after the MAIN POWER switch is turned on, "88" is displayed in red, then in orange, for about two seconds. This is not a problem. The unit initializes the CPU's during this period.



Others

List of the Projection Distance by Angle of Optical Axis



		Unit: mm (inches) for [E] Xhole and [G] Yhole only															
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°	
[B] / [E]	0.2419	0.2126	0.1944	0.1763	0.1584	0.1405	0.1228	0.1051	0.0875	0.0699	0.0524	0.0349	0.0175	0.0000	-0.0175	-0.0349	
[A] Angle	0.0°	1.6°	2.6°	3.6°	4.5°	5.4°	6.4°	7.3°	8.2°	9.1°	10.0°	10.9°	11.9°	12.8°	13.7°	14.6°	
[F] Xhole	281.3	288.6	293	297.3	301.1	304.9	308.9	312.5	316	319.4	322.8	326.1	329.6	332.7	335.7	338.6	
	(11 1/8)	(11 1/4)	(11 1/8)	(11 1/4)	(11 1/8)	(11 1/4)	(11 1/8)	(11 1/4)	(11 1/8)	(11 1/4)	(11 1/8)	(11 1/4)	(11 1/8)	(11 1/4)	(11 1/8)	(11 1/4)	
[G] Yhole	263.4	265.4	267.3	269.1	270.8	272.5	274.1	275.7	277.2	278.7	280.1	281.5	282.8	284.1	285.3	286.5	
	(10 3/8)	(10 3/4)	(10 7/8)	(11 1/8)	(11 1/4)	(11 3/8)	(11 1/2)	(11 5/8)	(11 3/4)	(11 7/8)	(12 1/8)	(12 1/4)	(12 3/8)	(12 1/2)	(12 5/8)	(12 3/4)	

When using the 90 inch screen																	Unit: mm (inches)				
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°					
[E] Xlens	2515 (99 1/8)	2529 (99 1/4)	2536 (99 1/2)	2543 (99 3/4)	2549 (100 1/8)	2554 (100 1/4)	2558 (100 1/2)	2562 (100 3/4)	2565 (101 1/8)	2567 (101 1/4)	2569 (101 1/2)	2570 (101 3/4)	2570 (101 7/8)	2570 (101 15/16)	2569 (101 1/2)	2568 (101 1/4)					
[B] Ylens	606 (23 3/8)	538 (21 1/4)	483 (19 1/2)	448 (17 3/4)	404 (16 1/2)	359 (14 3/4)	314 (12 3/4)	269 (10 3/4)	224 (8 3/4)	180 (6 3/4)	135 (4 3/4)	90 (2 3/4)	45 (1 3/4)	0 (0)	-45 (-1 3/4)	-90 (-3 3/4)					
[D] TD	2587 (101 1/2)	2585 (101 1/4)	2584 (101 1/8)	2582 (100 3/4)	2581 (100 1/2)	2579 (100 1/4)	2577 (100 1/8)	2575 (99 3/4)	2573 (99 1/2)	2571 (99 1/4)	2569 (98 3/4)	2567 (98 1/2)	2565 (98 1/4)	2563 (98 1/8)	2561 (97 3/4)	2559 (97 1/2)					
[C] dVoff	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)					

When using the 100 inch screen																	Unit: mm (inches)				
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°					
E Xlens	2768 (109)	2783 (108 1/2)	2791 (109)	2799 (110)	2805 (110 1/4)	2811 (110 1/2)	2816 (110 3/4)	2820 (111 1/8)	2823 (111 1/4)	2826 (111 1/2)	2827 (111 3/4)	2829 (111 7/8)	2829 (112 1/8)	2829 (112 1/4)	2828 (112 3/8)	2826 (112 1/2)					
B Ylens	667 (26 1/8)	592 (23 3/4)	543 (21 1/2)	494 (19 1/4)	444 (17 1/4)	395 (15 1/4)	346 (13 1/4)	296 (11 1/4)	247 (9 1/4)	198 (7 1/4)	148 (5 1/4)	99 (3 1/4)	49 (1 3/4)	0 (0)	-49 (-1 3/4)	-99 (-3 1/4)					
D TD	2847 (112 1/2)	2845 (112 1/4)	2844 (112 1/8)	2842 (112 1/4)	2840 (111 3/4)	2839 (111 1/2)	2837 (111 1/4)	2835 (111 1/8)	2834 (111 1/4)	2833 (111 1/2)	2831 (110 3/4)	2830 (110 1/2)	2829 (110 1/4)	2829 (110 1/8)	2828 (109 3/4)	2828 (109 1/2)					
C dVoff	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)					

When using the 110 inch screen

		Unit: mm (inches)															
		a TA (deg)															
		13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°
[E] Xlens		3025	3041	3050	3058	3065	3071	3077	3081	3085	3087	3089	3091	3091	3091	3090	3088
		(119 1/8)	(119 1/4)	(120 1/8)	(120 1/4)	(120 1/2)	(120 3/4)	(121 1/8)	(121 1/4)	(121 1/2)	(121 3/4)	(121 7/8)	(121 15/16)	(121 1/2)	(121 1/4)	(121 1/8)	(121 1/4)
[B] Ylens		729	646	593	539	486	432	378	324	270	216	162	108	54	0	-54	-108
		(28 3/8)	(25 3/4)	(23 1/2)	(21 1/4)	(19 1/4)	(17 1/4)	(15 1/4)	(13 1/4)	(11 1/4)	(9 1/4)	(7 1/4)	(5 1/4)	(3 1/4)	(2 1/4)	(1 1/4)	(-1 1/4)
[D] TD		3111	3109	3107	3106	3104	3102	3100	3098	3096	3095	3094	3093	3092	3091	3090	3090
		(122 1/2)	(122 1/4)	(122 1/8)	(122 1/4)	(122 1/8)	(122 1/4)	(122 1/8)	(122 1/4)	(122 1/8)	(122 1/4)	(121 3/4)	(121 1/2)	(121 1/4)	(121 1/8)	(121 1/4)	(121 1/8)
[C] dVoff		0	0	0	0	0	0	3	7	11	16	20	25	29	33	38	42
		(0)	(0)	(0)	(0)	(0)	(0)	(1/16)	(1/8)	(3/16)	(1/2)	(5/8)	(1)	(1 1/8)	(1 1/4)	(1 3/8)	(1 1/2)

When using the 120 inch screen

		Unit: mm (inches)															
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°	
[E] Xlens	3279 (129 1/8)	3297 (130 1/4)	3316 (130 1/8)	3330 (130 1/4)	3336 (131 1/8)	3341 (131 1/4)	3344 (131 1/2)	3347 (131 3/4)	3350 (131 7/8)	3351 (132 1/8)	3351 (132 1/4)	3351 (132 1/2)	3351 (132 3/4)	3350 (132 7/8)	3348 (132 1/4)	3346 (132 1/8)	
[B] Ylens	791 (31 1/4)	701 (27 1/4)	643 (25 1/8)	585 (23 1/4)	526 (20 3/4)	468 (18 1/4)	410 (16 1/4)	351 (14 1/4)	293 (12 1/4)	234 (9 3/4)	176 (7)	117 (4 1/4)	59 (2 1/4)	0 (0)	-59 (-2 1/4)	-117 (-4 1/4)	
[D] TD	3373 (132 1/8)	3371 (132 1/4)	3369 (132 1/8)	3367 (132 1/4)	3365 (132 1/2)	3363 (132 3/4)	3361 (132 7/8)	3359 (133 1/8)	3357 (133 1/4)	3356 (133 1/2)	3354 (133 3/4)	3352 (133 7/8)	3351 (134 1/8)	3350 (134 1/4)	3350 (134 1/2)	3350 (134 3/4)	
[C] dVoff	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	

When using the 130 inch screen

When using the 130 inch screen																	Unit: mm (inches)		
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°			
[E] Xlens	3570	3589	3600	3610	3618	3625	3632	3637	3641	3644	3647	3648	3649	3648	3647	3645			
	(140 1/8)	(141 1/4)	(141 3/8)	(142 1/4)	(142 1/2)	(142 3/4)	(143 1/8)	(143 1/4)	(143 1/2)	(143 3/4)	(143 7/8)	(144 1/8)	(144 1/4)	(143 3/4)	(143 1/2)	(143 1/8)			
[B] Ylens	861	763	700	637	573	510	446	382	319	255	191	127	64	0	-64	-127			
	(34 1/4)	(30 1/4)	(27 1/4)	(25 1/4)	(22 1/4)	(20 1/4)	(17 1/4)	(15 1/4)	(12 1/4)	(10 1/4)	(7 1/4)	(5 1/4)	(3 1/4)	(2 1/4)	(1 1/4)	(-1 1/4)			
[D] TD	3673	3670	3668	3666	3664	3661	3659	3657	3655	3653	3652	3650	3649	3648	3647	3647			
	(144 1/8)	(144 1/4)	(144 1/2)	(144 3/4)	(144 7/8)	(145 1/8)	(145 1/4)	(145 1/2)	(145 3/4)	(145 7/8)	(146 1/8)	(146 1/4)	(146 1/2)	(146 3/4)	(146 7/8)	(147 1/8)			
[C] dVoff	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0			
	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)			

When using the 140 inch screen

		Unit: mm (inches)														
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°
[E] Xlens	3861	3882	3894	3904	3913	3921	3927	3933	3938	3941	3944	3945	3946	3946	3944	3942
	(152 1/8)	(152 3/4)	(153 1/8)	(153 1/4)	(153 1/2)	(154 1/8)	(154 1/4)	(154 1/2)	(154 3/4)	(155 1/8)	(155 1/4)	(155 1/2)	(155 3/4)	(155 7/8)	(155 15/16)	(155 1/2)
[B] Ylens	932	825	757	688	620	551	482	413	345	276	207	138	69	0	-69	-138
	(36 1/4)	(32 1/4)	(29 1/4)	(27 1/4)	(24 1/4)	(21 1/4)	(19 1/4)	(16 1/4)	(13 1/4)	(10 1/4)	(8 1/4)	(5 1/4)	(3 1/4)	(2 1/4)	(1 1/4)	(-1 1/4)
[D] TD	3972	3969	3967	3965	3962	3959	3957	3955	3953	3951	3949	3948	3947	3946	3945	3944
	(155 1/8)	(155 1/4)	(155 1/2)	(155 3/4)	(156 1/8)	(156 1/4)	(156 1/2)	(156 3/4)	(156 7/8)	(157 1/8)	(157 1/4)	(157 1/2)	(157 3/4)	(157 7/8)	(158 1/8)	(158 1/4)
[C] dVoff	0	0	0	0	0	4	9	15	20	26	31	37	42	48	54	65
	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)

List of the Projection Distance by Angle of Optical Axis

When using the 150 inch screen																Unit: mm (inches)			
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°			
[E] Xlens	4166 (164 1/8)	4188 (165 1/8)	4201 (165 3/8)	4212 (166 1/8)	4220 (166 3/8)	4237 (167 1/8)	4243 (167 3/8)	4248 (167 5/8)	4252 (167 7/8)	4255 (167 9/8)	4257 (167 11/8)	4257 (167 13/8)	4257 (167 15/8)	4257 (167 17/8)	4257 (167 19/8)	4255 (167 21/8)			
[B] Ylens	1005 (39 3/8)	890 (35 1/8)	817 (32 1/4)	743 (29 3/8)	669 (26 3/8)	595 (23 1/2)	520 (20 1/2)	446 (17 1/2)	372 (14 1/2)	297 (11 3/4)	223 (9 1/4)	149 (6 3/4)	74 (3 1/2)	0 (-3 1/2)	-74 (-5 1/2)	-149 (-10 1/2)			
[D] TD	4285 (168 1/8)	4282 (168 3/8)	4280 (168 5/8)	4277 (168 7/8)	4275 (168 9/8)	4272 (168 11/8)	4269 (168 13/8)	4267 (168 15/8)	4265 (168 17/8)	4263 (168 19/8)	4261 (168 21/8)	4259 (168 23/8)	4258 (168 25/8)	4257 (168 27/8)	4256 (168 29/8)	4255 (168 31/8)			
[C] dVoff	0 (0)	0 (0)	0 (0)	0 (0)	5 (1 1/2)	11 (4 1/8)	16 (6 1/8)	22 (8 1/4)	28 (10 3/4)	34 (12 5/8)	40 (15 1/4)	46 (17 3/4)	52 (19 3/4)	58 (21 3/4)	64 (23 3/4)	70 (25 3/4)			
When using the 160 inch screen																Unit: mm (inches)			
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°			
[E] Xlens	4444 (175)	4467 (176 1/8)	4481 (177 1/8)	4493 (177 3/8)	4503 (177 5/8)	4512 (177 7/8)	4520 (177 9/8)	4526 (177 11/8)	4532 (177 13/8)	4536 (177 15/8)	4539 (177 17/8)	4540 (177 19/8)	4541 (177 21/8)	4541 (177 23/8)	4539 (177 25/8)	4536 (177 27/8)			
[B] Ylens	1072 (42 1/2)	950 (37 1/2)	871 (34 1/4)	792 (31 1/4)	713 (28 1/2)	634 (25 1/2)	555 (22 1/2)	476 (19 1/2)	397 (16 1/2)	317 (13 1/4)	238 (10 3/4)	159 (6 3/4)	79 (3 1/2)	0 (-3 1/2)	-79 (-6 3/4)	-159 (-10 3/4)			
[D] TD	4571 (180 1/8)	4567 (179 3/8)	4565 (179 5/8)	4562 (179 7/8)	4559 (179 9/8)	4556 (179 11/8)	4554 (179 13/8)	4551 (179 15/8)	4549 (179 17/8)	4547 (179 19/8)	4545 (179 21/8)	4542 (179 23/8)	4541 (179 25/8)	4540 (179 27/8)	4539 (179 29/8)	4536 (179 31/8)			
[C] dVoff	0 (0)	0 (0)	0 (0)	0 (0)	5 (1 1/2)	12 (4 1/2)	18 (6 3/4)	24 (9 1/4)	30 (11 1/4)	36 (13 3/4)	43 (15 3/4)	49 (17 3/4)	55 (19 3/4)	62 (21 3/4)	68 (23 3/4)	74 (25 3/4)			
When using the 170 inch screen																Unit: mm (inches)			
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°			
[E] Xlens	4717 (185 1/8)	4742 (186 1/8)	4756 (187 1/8)	4769 (187 3/8)	4780 (187 5/8)	4790 (187 7/8)	4798 (187 9/8)	4805 (187 11/8)	4810 (187 13/8)	4815 (187 15/8)	4818 (187 17/8)	4820 (187 19/8)	4820 (187 21/8)	4820 (187 23/8)	4818 (187 25/8)	4815 (187 27/8)			
[B] Ylens	1139 (44 1/4)	1008 (39 1/4)	925 (36 1/4)	841 (33 1/4)	757 (30 1/2)	673 (27 1/2)	589 (24 1/2)	505 (21 1/2)	421 (18 1/2)	337 (15 1/4)	253 (12 1/4)	168 (9 1/4)	84 (4 3/4)	0 (-4 3/4)	-84 (-10 3/4)	-168 (-15 1/4)			
[D] TD	4852 (191 1/8)	4848 (190 3/8)	4845 (190 5/8)	4843 (190 7/8)	4837 (190 9/8)	4834 (190 11/8)	4831 (190 13/8)	4829 (190 15/8)	4826 (190 17/8)	4824 (190 19/8)	4823 (190 21/8)	4821 (190 23/8)	4820 (190 25/8)	4819 (190 27/8)	4818 (190 29/8)	4815 (190 31/8)			
[C] dVoff	0 (0)	0 (0)	0 (0)	0 (0)	6 (2 1/4)	12 (4 1/2)	19 (6 3/4)	25 (9 1/4)	32 (11 1/4)	39 (13 3/4)	45 (15 3/4)	52 (17 3/4)	59 (19 3/4)	65 (21 3/4)	72 (23 3/4)	79 (25 3/4)			
When using the 180 inch screen																Unit: mm (inches)			
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°			
[E] Xlens	4993 (196 1/8)	5020 (197 1/8)	5035 (197 3/8)	5049 (197 5/8)	5060 (197 7/8)	5070 (197 9/8)	5079 (197 11/8)	5086 (197 13/8)	5092 (197 15/8)	5097 (197 17/8)	5100 (197 19/8)	5102 (197 21/8)	5103 (197 23/8)	5102 (197 25/8)	5100 (197 27/8)	5097 (197 29/8)			
[B] Ylens	1205 (47 1/4)	1067 (42 1/4)	979 (38 1/4)	890 (35 1/4)	802 (32 1/4)	713 (29 1/2)	624 (26 1/2)	535 (23 1/2)	446 (20 1/2)	356 (17 1/4)	267 (14 1/4)	178 (10 3/4)	89 (5 3/4)	0 (-5 3/4)	-89 (-10 3/4)	-178 (-15 1/4)			
[D] TD	5137 (202 1/8)	5132 (202 3/8)	5130 (202 5/8)	5127 (202 7/8)	5123 (202 9/8)	5120 (202 11/8)	5117 (202 13/8)	5114 (202 15/8)	5112 (202 17/8)	5109 (202 19/8)	5107 (202 21/8)	5105 (202 23/8)	5104 (202 25/8)	5102 (202 27/8)	5101 (202 29/8)	5100 (202 31/8)			
[C] dVoff	0 (0)	0 (0)	0 (0)	0 (0)	6 (2 1/4)	13 (4 1/2)	20 (6 3/4)	27 (9 1/4)	34 (11 1/4)	41 (13 3/4)	48 (15 3/4)	55 (17 3/4)	62 (19 3/4)	69 (21 3/4)	76 (23 3/4)	84 (25 3/4)			



Others



Others

When using the 190 inch screen																Unit: mm (inches)			
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°			
[E] Xlens	5268 (207 1/8)	5297 (208 1/8)	5313 (209 1/8)	5327 (209 3/8)	5339 (209 5/8)	5349 (210 1/8)	5359 (210 3/8)	5366 (210 5/8)	5372 (210 7/8)	5377 (210 9/8)	5381 (210 11/8)	5383 (210 13/8)	5384 (210 15/8)	5383 (210 17/8)	5381 (210 19/8)	5378 (210 21/8)			
[B] Ylens	1272 (50 1/4)	1126 (44 3/4)	1033 (40 3/4)	939 (37 1/4)	846 (33 3/4)	752 (30 1/4)	658 (26 3/4)	564 (23 1/4)	470 (19 3/4)	376 (16 1/4)	282 (12 3/4)	188 (9 1/4)	94 (4 3/4)	0 (-4 3/4)	-94 (-9 1/4)	-188 (-13 3/4)			
[D] TD	5419 (213 1/8)	5415 (213 3/8)	5412 (213 5/8)	5409 (213 7/8)	5406 (213 9/8)	5402 (213 11/8)	5399 (213 13/8)	5396 (213 15/8)	5393 (213 17/8)	5388 (213 19/8)	5386 (213 21/8)	5385 (213 23/8)	5385 (213 25/8)	5383 (213 27/8)	5382 (213 29/8)	5381 (213 31/8)			
[C] dVoff	0 (0)	0 (0)	0 (0)	0 (0)	6 (2 1/4)	14 (5 1/2)	21 (8 1/4)	28 (10 3/4)	36 (12 5/8)	43 (15 1/4)	51 (17 3/4)	58 (20 3/4)	65 (22 3/4)	73 (24 3/4)	81 (26 3/4)	88 (28 3/4)			
When using the 200 inch screen																Unit: mm (inches)			
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°			
[E] Xlens	5543 (218 1/8)	5573 (219 1/8)	5590 (220 1/8)	5605 (220 3/8)	5618 (220 5/8)	5629 (220 7/8)	5638 (220 9/8)	5646 (220 11/8)	5653 (220 13/8)	5658 (220 15/8)	5662 (220 17/8)	5664 (220 19/8)	5665 (220 21/8)	5664 (220 23/8)	5662 (220 25/8)	5658 (220 27/8)			
[B] Ylens	1338 (52 3/4)	1185 (46 3/4)	1087 (42 1/4)	988 (38 1/4)	890 (34 1/4)	791 (30 1/4)	692 (26 3/4)	593 (23 1/4)	495 (19 3/4)	396 (16 1/4)	297 (12 3/4)	198 (9 1/4)	99 (4 3/4)	0 (-4 3/4)	-99 (-9 1/4)	-198 (-13 3/4)			
[D] TD	5702 (224 1/8)	5697 (224 3/8)	5694 (224 5/8)	5691 (224 7/8)	5688 (224 9/8)	5684 (224 11/8)	5680 (224 13/8)	5677 (224 15/8)	5672 (224 17/8)	5669 (224 19/8)	5667 (224 21/8)	5665 (224 23/8)	5664 (224 25/8)	5663 (224 27/8)	5662 (224 29/8)	5662 (224 31/8)			
[C] dVoff	0 (0)	0 (0)	0 (0)	0 (0)	7 (2 1/2)	14 (5 1/2)	22 (8 1/4)	30 (11 1/4)	38 (13 3/4)	45 (15 3/4)	53 (17 3/4)	61 (19 3/4)	69 (21 3/4)	77 (23 3/4)	85 (25 3/4)	93 (27 3/4)			
When using the 210 inch screen																Unit: mm (inches)			
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°			
[E] Xlens	5816 (229 1/8)	5847 (230 1/8)	5865 (231 1/8)	5881 (231 3/8)	5894 (231 5/8)	5906 (231 7/8)	5916 (231 9/8)	5924 (231 11/8)	5931 (231 13/8)	5937 (231 15/8)	5941 (231 17/8)	5944 (231 19/8)	5945 (231 21/8)	5944 (231 23/8)	5941 (231 25/8)	5937 (231 27/8)			
[B] Ylens	1404 (55 1/4)	1243 (49)	1140 (45 1/4)	1037 (41 1/4)	934 (37 1/4)	830 (33 1/4)	726 (29 1/4)	623 (25 1/4)	519 (21 1/4)	415 (17 1/4)	311 (13 1/4)	208 (10 1/4)	104 (4 3/4)	0 (-4 3/4)	-104 (-9 1/4)	-208 (-13 3/4)			
[D] TD	5963 (235 1/8)	5978 (235 3/8)	5975 (235 5/8)	5972 (235 7/8)	5968 (235 9/8)	5964 (235 11/8)	5960 (235 13/8)	5957 (235 15/8)	5954 (235 17/8)	5949 (235 19/8)	5947 (235 21/8)	5945 (235 23/8)	5944 (235 25/8)	5943 (235 27/8)	5942 (235 29/8)	5941 (235 31/8)			
[C] dVoff	0 (0)	0 (0)	0 (0)	0 (0)	7 (2 1/2)	15 (4 1/2)	23 (6 3/4)	31 (8 1/4)	39 (10 3/4)	47 (12 5/8)	56 (15 1/4)	64 (17 3/4)	72 (19 3/4)	81 (21 3/4)	89 (23 3/4)	97 (25 3/4)			
When using the 220 inch screen																Unit: mm (inches)			
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1°	0°	-1°	-2°			
[E] Xlens	6003 (239 1/8)	6126 (241 1/8)	6144 (241 3/8)	6161 (241 5/8)	6175 (241 7/8)	6187 (241 9/8)	6197 (241 11/8)	6206 (241 13/8)	6213 (241 15/8)	6223 (241 17/8)	6226 (241 19/8)	6228 (241 21/8)	6229 (241 23/8)	6226 (241 25/8)	6223 (241 27/8)	6219 (241 29/8)			
[B] Ylens	1471 (58 1/2)	1302 (52 1/4)	1194 (47 1/4)	1066 (43 1/4)	978 (39 1/4)	870 (35 1/4)	761 (31 1/4)	652 (27 1/4)	544 (23 1/4)	435 (19 1/4)	326 (15 1/4)	217 (11 1/4)	109 (4 3/4)	0 (-4 3/4)	-109 (-9 1/4)	-217 (-13 3/4)			
[D] TD	6298 (258 1/8)	6259 (256 3/8)	6256 (256 5/8)	6252 (256 7/8)	6248 (256 9/8)	6244 (256 11/8)	6240 (256 13/8)	6237 (256 15/8)	6234 (256 17/8)	6232 (256 19/8)	6229 (256 21/8)	6227 (256 23/8)	6226 (256 25/8)	6224 (256 27/8)	6223 (256 29/8)	6223 (256 31/8)			
[C] dVoff	0 (0)	0 (0)	0 (0)	0 (0)	7 (2 1/2)	16 (4 1/2)	25 (6 3/4)	33 (8 1/4)	41 (9 3/4)	50 (11 3/4)	59 (13 3/4)	67 (15 3/4)	76 (17 3/4)	84 (19 3/4)	93 (21 3/4)	102 (23 3/4)			

List of the Projection Distance by Angle of Optical Axis

When using the 230 inch screen													Unit: mm (inches)
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1° 0° -1° -2°
[E] X lens	6345 (248 1/4)	6390 (251 1/4)	6399 (252 1/4)	6416 (253 1/4)	6431 (253 1/4)	6443 (254 1/4)	6454 (254 1/4)	6463 (254 1/4)	6471 (255 1/4)	6477 (255 1/4)	6481 (255 1/4)	6484 (255 1/4)	6481 (255 1/4)
[B] Y lens	1533 (60 1/4)	1356 (53 1/4)	1244 (49 1/4)	1131 (44 1/4)	1019 (40 1/4)	906 (36 1/4)	793 (32 1/4)	679 (28 1/4)	566 (24 1/4)	453 (20 1/4)	340 (16 1/4)	226 (12 1/4)	113 (9 1/4)
[D] TD	6528 (257)	6522 (256 1/2)	6519 (256 1/4)	6515 (256 1/4)	6511 (256 1/4)	6507 (256 1/4)	6503 (256 1/4)	6499 (256 1/4)	6496 (256 1/4)	6493 (256 1/4)	6490 (256 1/4)	6488 (256 1/4)	6481 (255 1/4)
[C] d/Off	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	7 (1/16)	16 (1/8)	25 (1/4)	34 (1/2)	43 (1/2)	52 (1 1/4)	61 (1 1/4)	79 (1 3/4)

When using the 240 inch screen													Unit: mm (inches)
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1° 0° -1° -2°
[E] X lens	6600 (259 1/4)	6655 (262 1/4)	6673 (262 1/4)	6689 (263 1/4)	6702 (263 1/4)	6713 (264 1/4)	6723 (264 1/4)	6730 (264 1/4)	6737 (265 1/4)	6741 (265 1/4)	6744 (265 1/4)	6747 (265 1/4)	6737 (265 1/4)
[B] Y lens	1594 (62 1/4)	1410 (55 1/4)	1294 (51 1/4)	1177 (46 1/4)	1059 (41 1/4)	942 (37 1/4)	824 (32 1/4)	707 (27 1/4)	589 (23 1/4)	471 (19 1/4)	353 (14 1/4)	236 (9 1/4)	118 (7 1/4)
[D] TD	6789 (267 1/4)	6784 (267 1/4)	6772 (266 1/4)	6768 (266 1/4)	6763 (266 1/4)	6756 (266 1/4)	6750 (266 1/4)	6746 (266 1/4)	6741 (266 1/4)	6737 (266 1/4)	6733 (266 1/4)	6729 (266 1/4)	6721 (265 1/4)
[C] d/Off	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	7 (1/16)	17 (1/8)	26 (1/4)	35 (1/2)	44 (1/2)	54 (1 1/4)	63 (1 1/4)	73 (1 3/4)

When using the 250 inch screen													Unit: mm (inches)
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1° 0° -1° -2°
[E] X lens	6868 (270 1/4)	6905 (271 1/4)	6926 (272 1/4)	6944 (273 1/4)	6960 (274 1/4)	6974 (275 1/4)	6986 (275 1/4)	6996 (276 1/4)	7004 (276 1/4)	7010 (276 1/4)	7015 (276 1/4)	7017 (276 1/4)	7010 (276 1/4)
[B] Y lens	1659 (65 1/4)	1468 (57 1/4)	1346 (53 1/4)	1225 (48 1/4)	1102 (43 1/4)	980 (38 1/4)	858 (33 1/4)	735 (29 1/4)	613 (24 1/4)	490 (20 1/4)	368 (15 1/4)	245 (10 1/4)	123 (7 1/4)
[D] TD	7065 (278 1/4)	7059 (278 1/4)	7055 (277 1/4)	7047 (277 1/4)	7042 (277 1/4)	7038 (277 1/4)	7034 (277 1/4)	7031 (277 1/4)	7027 (276 1/4)	7022 (276 1/4)	7019 (276 1/4)	7018 (276 1/4)	7015 (276 1/4)
[C] d/Off	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	7 (1/16)	17 (1/8)	27 (1/4)	37 (1/2)	46 (1/2)	56 (1 1/4)	66 (1 1/4)	76 (1 3/4)

When using the 260 inch screen													Unit: mm (inches)
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1° 0° -1° -2°
[E] X lens	7158 (281 1/4)	7197 (283 1/4)	7218 (284 1/4)	7238 (285 1/4)	7254 (285 1/4)	7268 (286 1/4)	7281 (286 1/4)	7291 (287 1/4)	7300 (287 1/4)	7306 (287 1/4)	7311 (287 1/4)	7314 (287 1/4)	7311 (287 1/4)
[B] Y lens	1729 (68 1/4)	1530 (60 1/4)	1403 (55 1/4)	1276 (50 1/4)	1149 (45 1/4)	1022 (40 1/4)	894 (35 1/4)	766 (30 1/4)	639 (25 1/4)	511 (20 1/4)	383 (15 1/4)	255 (10 1/4)	128 (7 1/4)
[D] TD	7364 (290)	7357 (289 1/4)	7353 (289 1/4)	7350 (289 1/4)	7345 (289 1/4)	7340 (289 1/4)	7335 (289 1/4)	7328 (289 1/4)	7324 (289 1/4)	7321 (289 1/4)	7318 (289 1/4)	7316 (289 1/4)	7311 (288 1/4)
[C] d/Off	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	8 (1/16)	18 (1/8)	29 (1/4)	39 (1/2)	48 (1/2)	59 (1 1/4)	69 (1 1/4)	79 (1 3/4)

When using the 270 inch screen													Unit: mm (inches)
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1° 0° -1° -2°
[E] X lens	7445 (293 1/4)	7485 (294 1/4)	7508 (294 1/4)	7528 (295 1/4)	7545 (295 1/4)	7560 (296 1/4)	7572 (296 1/4)	7583 (296 1/4)	7592 (296 1/4)	7604 (296 1/4)	7607 (296 1/4)	7608 (296 1/4)	7604 (295 1/4)
[B] Y lens	1798 (70 1/4)	1591 (62 1/4)	1459 (57 1/4)	1327 (52 1/4)	1195 (47 1/4)	1062 (41 1/4)	930 (36 1/4)	797 (31 1/4)	664 (26 1/4)	531 (21 1/4)	399 (15 1/4)	266 (10 1/4)	133 (7 1/4)
[D] TD	7659 (301 1/4)	7652 (301 1/4)	7648 (301 1/4)	7644 (301 1/4)	7639 (301 1/4)	7634 (301 1/4)	7629 (301 1/4)	7625 (301 1/4)	7621 (301 1/4)	7618 (301 1/4)	7612 (301 1/4)	7609 (301 1/4)	7604 (299 1/4)
[C] d/Off	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	9 (1/16)	19 (1/8)	30 (1/4)	40 (1/2)	51 (1/2)	61 (1 1/4)	72 (1 1/4)	82 (1 3/4)

When using the 280 inch screen													Unit: mm (inches)
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1° 0° -1° -2°
[E] X lens	7726 (304 1/4)	7768 (305 1/4)	7792 (305 1/4)	7813 (306 1/4)	7830 (306 1/4)	7846 (307 1/4)	7859 (307 1/4)	7870 (307 1/4)	7879 (307 1/4)	7887 (307 1/4)	7892 (307 1/4)	7895 (307 1/4)	7892 (306 1/4)
[B] Y lens	1867 (73 1/4)	1651 (65 1/4)	1515 (59 1/4)	1378 (54 1/4)	1240 (48 1/4)	1103 (43 1/4)	965 (38 1/4)	827 (32 1/4)	689 (27 1/4)	552 (21 1/4)	414 (16 1/4)	276 (10 1/4)	138 (7 1/4)
[D] TD	7948 (313)	7942 (312 1/4)	7938 (312 1/4)	7933 (312 1/4)	7928 (312 1/4)	7923 (311 1/4)	7918 (311 1/4)	7914 (311 1/4)	7910 (311 1/4)	7906 (311 1/4)	7903 (311 1/4)	7897 (311 1/4)	7893 (310 1/4)
[C] d/Off	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	9 (1/16)	20 (1/8)	31 (1/4)	42 (1/2)	53 (1 1/4)	64 (1 1/4)	75 (1 3/4)	86 (1 3/4)

When using the 290 inch screen													Unit: mm (inches)
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1° 0° -1° -2°
[E] X lens	8011 (315 1/4)	8055 (317 1/4)	8079 (318 1/4)	8101 (319 1/4)	8119 (320 1/4)	8135 (320 1/4)	8149 (321 1/4)	8161 (321 1/4)	8170 (321 1/4)	8178 (322 1/4)	8183 (322 1/4)	8186 (322 1/4)	8178 (322 1/4)
[B] Y lens	1935 (76 1/4)	1712 (67 1/4)	1570 (61 1/4)	1428 (56 1/4)	1286 (50 1/4)	1143 (45 1/4)	1001 (39 1/4)	858 (33 1/4)	715 (28 1/4)	572 (22 1/4)	429 (17 1/4)	286 (11 1/4)	143 (8 1/4)
[D] TD	8242 (324 1/4)	8235 (324 1/4)	8230 (323 1/4)	8226 (323 1/4)	8220 (323 1/4)	8215 (323 1/4)	8210 (323 1/4)	8206 (323 1/4)	8201 (323 1/4)	8198 (323 1/4)	8194 (323 1/4)	8188 (323 1/4)	8183 (322 1/4)
[C] d/Off	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	10 (1/16)	21 (1/8)	32 (1/4)	44 (1/2)	55 (1 1/4)	66 (1 1/4)	78 (1 3/4)	89 (1 3/4)

When using the 300 inch screen													Unit: mm (inches)
a TA (deg)	13.6°	12°	11°	10°	9°	8°	7°	6°	5°	4°	3°	2°	1° 0° -1° -2°
[E] X lens	8295 (326 1/4)	8340 (328 1/4)	8365 (329 1/4)	8388 (330 1/4)	8406 (331 1/4)	8423 (331 1/4)	8437 (332 1/4)	8449 (332 1/4)	8459 (333 1/4)	8467 (333 1/4)	8472 (333 1/4)	8476 (333 1/4)	8467 (333 1/4)
[B] Y lens	2004 (79 1/4)	1773 (69 1/4)	1626 (64 1/4)	1479 (58 1/4)	1331 (52 1/4)	1184 (46 1/4)	1036 (40 1/4)	888 (35 1/4)	740 (29 1/4)	592 (23 1/4)	444 (17 1/4)	296 (11 1/4)	148 (8 1/4)
[D] TD	8533 (336 1/4)	8526 (335 1/4)	8522 (335 1/4)	8517 (335 1/4)	8511 (335 1/4)	8506 (334 1/4)	8501 (334 1/4)	8496 (334 1/4)	8491 (334 1/4)	8488 (334 1/4)	8484 (334 1/4)	8478 (334 1/4)	8472 (333 1/4)
[C] d/Off	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)	11 (1/16)	22 (1/8)	34 (1/4)	45 (1/2)	57 (1 1/4)	69 (1 1/4)	80 (1 3/4)	92 (1 3/4)



Others



Others

Index


--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

SECTION 2


SERVICE INFORMATION

2-1. CIRCUIT BOARDS LOCATION


2-1-1. Location 1



2-1-2. Location 2




2-1-3. Location 3




2-2. DISASSEMBLY


2-2-1. Hood Removal




2-2-2. Cover Removal



2-2-3. Opening ED Block




2-2-4. DC Board Removal




2-2-5. EC Board Removal

[CAUTION]


When installing the EC bracket, position all of the six toggle switch levers in the same direction.




2-2-6. ED Board Removal




2-2-7. E Board Removal



2-2-8. Remote Commander Removal



2-2-9. CB, CG and CR Blocks Removal




The CG and CR blocks can be removed in the same manner as the CB block.


[CAUTION]
When installing the CB block, fold the top side of the shield cover (CB) in the arrow direction.
[G90E/G90M]

2-2-10. DA, DB, DD, DE and DF Boards Removal

- Remove the CB, CG and CR blocks. (Refer to Section 2-2-9.)




2-2-11. EBH and EBQ Boards Removal




2-2-12. HVB Block and High-voltage Cable Removal


- Remove the picture tube (B) (Refer to Section 2-2-22.)



2-2-13. DC Fan Removal




2-2-14. PA and PD Boards Removal




2-2-15. MD Board Removal


- Remove the PD board. (Refer to Section 2-2-14.)




2-2-16. HVF Block Removal




2-2-17. BA and YA Boards Removal




2-2-18. BC, F and ME Boards Removal



2-2-19. EBB, EBG, EBR and PE Boards Removal




2-2-20. GA and GB Boards Removal




2-2-21. Lens Removal

[CAUTION]
 Removing the arrow-marked screws are strictly inhibited.
 If removed, it may cause liquid spill.



2-2-22. (1) Picture Tube Removal

- Remove the CB, CG and CR blocks.




2-2-22. (2) Picture Tube Installation


- ⑦ Tighten the shield cover (CB).
[G90E/G90M]

[CAUTION]

After installing the picture tubes (B) and (R), move them in the right and left directions in order to tighten the shield cover (CB) without being pulled.



Shield cover (CB)
[G90E/G90M]



[CAUTION]

Make creases of the shield cover (CB) at the bottom.


- ⑥ Install the high-voltage cable and rubber cap.

Rubber cap

High-voltage cable

[CAUTION]

Check that the high-voltage cable is firmly installed.




Install the picture tube (B) in the same manner as the picture tube (R).

Picture tube (B)

⑤ CBR board

Picture tube (G)

Install the picture tube (G) in the steps of ③ to ⑦.



- ① Loosen the four screws.

- ⑧ Tighten the four screws after adjustment.


Two shafts (B)


Two screws
(SW hexagon head screw
M5 x 12)

② Two stay

2-2-23. MA, MB and MC Boards Removal

1. Open the ED block and remove the harness. (Refer to Section 2-2-3 to 2-2-8.)
2. Remove the CB, CG and CR blocks. (Refer to Section 2-2-9.)
3. Remove the EBH and EBQ boards. (Refer to Section 2-2-11.)
4. Remove the DC fan. (Refer to Section 2-2-13.)
5. Remove the BA, F, and ME boards. (Refer to Section 2-2-17.)
6. Remove the BC and F boards. (Refer to Section 2-2-18.)
7. Remove the EBB, EBG, EBR and PE boards. (Refer to Section 2-2-19.)
8. Remove the GA and GB boards. (Refer to Section 2-2-20.)
9. Remove the three picture tubes. (Refer to Section 2-2-22.(1))






1. Remove the case block. (Refer to Section 2-2-23.)
2. Remove the DA, DB, DD, DE and DF boards. (Refer to Section 2-2-10.)
3. Remove the HVB block and high-voltage cable. (Refer to Section 2-2-12.)



2-2-25. Extension Board



2-3. ERROR CODE

2-3-1. Warning Code on 7-Segment LED

Error no.	LED color	Note	Description
01	Green	Main CS incorrect	Check Sum of Main Program is incorrect. Main Program is not written correctly on Flash Memory. Upload Mode starts immediately after this error is displayed.
03	Green	Font CS incorrect	Check Sum of Font Data is incorrect. Upload Mode starts immediately after this error is displayed.
10	Green	Upload mode Start	Displayed when Upload mode starts. (Flash twice.)
11	Green	Upload data from Comm	Mode of uploading data from communication.
12	Green	Upload data to FM	Mode of writing data uploaded from communication on Flash Memory.
18	Green	Transport Error1	Transport Error (Upload Mode)
19	Green	Transport Error2	Transport Error: Start Code Low Byte Error (Upload Mode)
1A	Green	Transport Error3	Transport Error: Packet Length Error (Upload Mode)
1B	Green	Transport Error4	Transport Error: Data Length Error (Upload Mode)
1C	Green	Transport Error5	Transport Error: Header Check Sum Error (Upload Mode)
1D	Green	Transport Error6	Transport Error: Data Check Sum Error (Upload Mode)
1E	Green	Transport Error7	Transport Error: Data End Low Byte Error (Upload Mode)
1F	Green	Transport Error8	Transport Error: Data End High Byte Error (Upload Mode)
20	Green	Transport Error9	Transport Error: Invalid Error (Upload Mode)
21	Green	Transport Error10	Transport Error: Retry Occur (Upload Mode)
24	Green	Session Error	Session Error (Upload Mode)
2F	Green	Return to Normal	Upload Mode is finished. Return to Normal Mode.
30	Green	User NVM format not available !	User Domain NVM is not formatted.
31	Green	User NVM formatting...	User Domain NVM is being formatted.
32	Green	User NVM writing...	Data is being written on User Domain NVM.
33	Green	Service NVM format not available !	Service Domain NVM is not formatted.
34	Green	Service NVM formatting...	Service Domain NVM is being formatted.
35	Green	Service NVM writing...	Data is being written on Service Domain NVM.
36	Green	Factory NVM format not available !	Factory Domain NVM is not formatted.
37	Green	Factory NVM formatting...	Factory Domain NVM is being formatted.
38	Green	Factory NVM writing...	Data is being written on Factory Domain NVM.
3A	Green	Input memory changing...	Displayed when Input signals are considered unstable.
3B	Green	Now Power on delay waiting...	Waiting for ON in the "ON DELAY" mode.
40	Green	Configuring the system	System Setting is being performed.
41	Green	Same DEVICE INDEX for Projector detected	There are other projectors that have the same device index number.
42	Green	Same DEVICE INDEX for Switcher detected	There are other switchers that have the same device index number.
43	Green	Master Switcher not exist	There is no Master Switcher.

When any of these codes is output in the ON condition, the device cannot be in the Standby state.

2-3-2. Protector Code on 7-Segment LED

Error no.	LED color	Note	Description
60	Orange	Unknown	In this mode, the reason why the protect works is unknown. There is no way other than inspecting GA/GB board steadily or checking each protect detection line on YA board.
61	Orange	POW1	This protect works when the 200V line of the power source has dropped. Since this line is used only on PA board, the points to look into are GB/PA/L (it contains the power protect circuit)/M board.
62	Orange	POW2	This protect works when the 115 V line of the power source has dropped. This line is used on PA/PE/ED/CDR/CDG/CDB boards, therefore, the points to look into are these boards and GB, L and M boards. The past experiences tell that the defects were often found at the VIDEO PACK of C board.
63	Orange	POW3	This protect works when the 50 V line of the power source has dropped. This line is used on DC/EBR/EBG/EBB boards. There are two possible modes for which this protect works. One is the case of failure on the OUT circuit of the above boards. This case can be readily found out because the error code of each board is displayed simultaneously. Another case is caused by the excessive Reg/Mg compensation. In this case, it is necessary to look into whether the Reg/Mg compensation wave forms are normal. If they are abnormal, look into DA/DB/DD/DE board or YA board.
64	Orange	POW4	This protect works when the 15 V line of the power source has dropped. This line is used on most of boards. It is rare that this error is displayed alone. The error code is always displayed by any other board at the same time. If the error is displayed alone, look into GB/LM boards.
65	Orange	POL	This protect concerns with the polarity change. As the possible causes of error, the cover for polarity change is open or the connector in this line is disconnected.
66	Orange	H.STOP	This protect works when the horizontal deflection is inactivated. The most possible failure is H.OUT of E board. If not, failures might be found in H. Drive series or the negative power source series. Look into DA/EA/ED/PD board.
67	Orange	V.STOP	This protect works when the vertical deflection is inactivated. In most cases, inspection of DF board will solve the problem.
68	Orange	SUB	This error code comes from DC board. Failures around OUT/Reg might be considered. Refer to the protect items for POW3.
69	Orange	HV	This protect works when the high voltage rises high. Failures of PA board/PB board/HV BLOCK/HV FILTER might be considered. In some cases, the connector of the detection lines of HV BLOCK is disconnected.
6A	Orange	LOT	Failure around L.O.T. of the PE board.
6B	Orange	Ik	This protect works when the current excessively flows to the CRT of any of R, G and B. Since it is for protection from X-ray, it may be hardly activated. If indicated, look into BA board.
6C	Orange	Σ Ik	This protect works when abnormality occurred in the CRT. If no defect is found in the CRT, look into PA/PB boards.
6D	Orange	FAN1	This protect works when any of four FANs attached at the rear of the unit stopped. In some cases, it is caused by the failure of FAN itself. In other cases, the connector is disconnected or the line materials are caught in.
6E	Orange	FAN2	This protect works when the FAN at the far end of PA board stopped.
6F	Orange	LENS	This protect works when the detection line attached to the LENS of any of R, G and B is disconnected. In some unusual cases, it works due to poor connection of the screw.
70	Orange	CRTR	This protect works when the current excessively flows to RED CRT. Look into CAR/CBR/CDR boards. If no defect is found, suspect RED CRT.
71	Orange	CRTG	This protect works when the current excessively flows to GREEN CRT. Look into CAG/CBG/CDG boards. If no defect is found, suspect GREEN CRT.
72	Orange	CRTB	This protect works when the current excessively flows to BLUE CRT. Look into CAB/CBB/CDB boards. If no defect is found, suspect BLUE CRT.
73	Orange	IFBB	This protect works with the defect of the board inserted into INPUT-B.
74	Orange	IFBC	This protect works with the defect of the board inserted into INPUT-C.

Error no.	LED color	Note	Description
80	Orange	BA	This protect works when the power line of BA board has dropped. Since this is included in the secondary troubleshooting for BA board, it does not usually work. However, for this unit, this protect is very sensitive and the error is displayed even with the trifle power drop. In such a case, look into GB board.
81	Orange	DA	This protect works when the power line of DA board has dropped. Since this is included in the secondary troubleshooting for DA board, it does not usually work.
82	Orange	DB	This protect works when the power line of DB board has dropped. Since this is included in the secondary troubleshooting for DB board, it does not usually work.
83	Orange	DD	This protect works when the power line of DD board has dropped. Since this is included in the secondary troubleshooting for DD board, it does not usually work.
84	Orange	DE	This protect works when the power line of DE board has dropped. Since this is included in the secondary troubleshooting for DE board, it does not usually work.
85	Orange	EBR	This error code comes from EBR board. Failures around OUT/Mg might be considered. Refer to the protect items for POW3.
86	Orange	EBG	This error code comes from EBG board. Failures around OUT/Mg might be considered. Refer to the protect items for POW3.
87	Orange	EBB	This error code comes from EBB board. Failures around OUT/Mg might be considered. Refer to the protect items for POW3.
88	Orange/Red	Initialize	Message during initialization. Software does not start up yet.
89	Orange	EBH	This error code comes from EBH board. Failures around OUT/Mg might be considered. Refer to the protect items for POW3.
8A	Orange	EBQ	This error code comes from EBQ board. Failures around OUT/Mg might be considered. Refer to the protect items for POW3.

When any of these codes is output, the device is set in the Standby state once, however it can be set in the ON state again.

2-3-3. Error Code on 7-Segment LED

Error no.	LED color	Note	Description
D0	Red	User NVM format not available !	User Domain NVM cannot be formatted. This NMV device itself might be destroyed.
D1	Red	User NVM write error !	Data cannot be written on User Domain NVM. This NMV device itself might be destroyed.
D2	Red	Service NVM format not available !	Service Domain NVM cannot be formatted. This NMV device itself might be destroyed.
D3	Red	Service NVM write error !	Data cannot be written on Service Domain NVM. This NMV device itself might be destroyed.
D4	Red	Factory NVM format not available !	Factory Domain NVM cannot be formatted. This NMV device itself might be destroyed.
D5	Red	Factory NVM write error !	Data cannot be written on Factory Domain NVM. This NMV device itself might be destroyed.

When any of these codes is displayed, the device cannot be in the ON state.

2-4. MEMORY ACCESS SYSTEM

2-4-1. Memory Structure

There are three memory areas-USER area, SERVICE area, and FACTORY area.

1. USER area

Memory area always used in the market.

Area in which data is saved when automatic saving or when the MEMORY key is pressed.

<Contents of Memory Structure>

SET MEMORY

CH MEMORY

INPUT MEMORY × 150 (Original + Custom)

At shipment, data of the Original Input Memory (No. 0 to 12) when placed on the floor and front projected to a 120-inch screen is memorized in INPUT MEMORY.

2. SERVICE area

Memory area used for backing up data set or adjusted on the market (user area).

<Contents of Memory Structure>

SET MEMORY

CH MEMORY

INPUT MEMORY ×150 (Original + Custom)

Like the USER area, at shipment, data of the Original Input Memory (No. 0 to 12) is memorized in INPUT MEMORY.

3. FACTORY area

Memory area for saving setting and adjustment data adjusted when placed on the floor and front projected to a 120-inch screen in the factory.

The registration data value of INPUT MEMORY of this area is the Standard Data Save reference value.

<Contents of Memory Structure>

SET MEMORY

CH MEMORY

INPUT MEMORY ×13 (Original)

At shipment, the contents of the memory data in each memory area are the same.





Fig. 1 Memory Area and Structure

2-4-2. Various Memory Data

The basic VPH-G90 memory structure and types are as follows.



1. Set Memory

Memory for saving set and adjusted values which the unit has only one of each.

- Setting Memory
Various setting values of the unit.

Items	Contents
Last CH	VIDEO/INPUT-A/INPUT-B/INPUT-C Sw'er
Set Serial No.	Unit's serial number
Operation Timer	Unit's total operating time
CRT Timer	CRT total operating time
USER MODE	Normal/PRO
Status	ON/OFF
Group INDEX	1-99
Device INDEX	0-99
SIRCS RECEIVER	FRONT&REAR/FRONT/REAR/ALL OFF
OSD Language	E/F/G/S/I/J/C
Baud Rate <PJ-COM>	38.4 k/19.2 k/9600
Baud Rate <RS-232C/422A>	38.4 k/19.2 k/9600
INPUT-MEMORY SEARCH MODE	AUTO/MANUAL
ALL WHITE MODE	0-99 min 0 min = All White Mode OFF
POWER SAVING MODE	ON/OFF
DIRECT POWER ON MODE	ON/OFF
ON DELAY MODE	ON/OFF
SCREEN SELECT	Screen B/Screen M
ABG MODE	ON/OFF
Normal Defocus MODE	ON/OFF
5BNC MODE	ON/OFF
PIC. ORBITING MODE	ON/OFF
SCAN LINE SHIFT MODE	ON/OFF
INT. OSC PATTERN	OSC1-OSC9
TEST PATTERN	OFF, TP1-TP13, TPU1-TPU5
COLOR UNIFORMITY MODE	OFF/STANDARD/MANUAL
BRIGHTNESS UNIFORMITY MODE	OFF/STANDARD/MANUAL
ABL LINK MODE	ON/OFF

Table 1. Setting memory

- Reading and writing of set memory other than video memory

Timing	Memory Type	Memory Area
When AC is ON	All set memories (Other than video memory)	Reads data from the set memory of the user area to the area changing various data (RAM), and sets the changes in the unit.

Table 2. Reading of Set Memory (Other than Video Memory) (Load)

Timing	Memory Type	Memory Area
When the MEMORY key is pressed	All set memories (Other than video memory)	Writes data in the area changing various data (RAM) to the set memory of the user area (Save).
When the input ch changes (When input instability is confirmed)		
When the input signal changes (When input instability is confirmed)		
When the mode of the unit changes		
When the power is turned off		

Table 3. Writing of Set Memory (Other than Video Memory) (Save)

- Video Memory

Various data of video memory setting values 1 to 10.

The data types in the respective setting values are the same.

VIDEO MEMORY OFF is inside INPUT MEMORY.

Items	Contents
Video Memory Label	ASCII character
Color Temperature Select	9300/6500/5400/3200/Custom
W/B Adjust Data of Custom	Gain/BiasCoarse/BiasFine/ γ (for Adj R/G/B, Screen Sel)
Dynamic PICTURE	ON/OFF
V.SHIFT Select	WIDE/NARROW
NTSC Setup Select	0/7.5
COMPONENT FORMAT Select	SMPTE.EBU-N10/BETACAM7.5
COMB Filter Select	3D/3Line
DRC Level Select	High/Low
Picture Control Adjust Data	Contrast/Brightness/Color/Hue/Sharpness
RGB SIZE Adjust Data	Hc/Hf/Vc/Vf
RGB SHIFT Adjust Data	Hc/Hf/Vc
Blanking Adjust Data	Top/Bottom/Left/Right TopPhase/TopKey/TopPin Bottom Phase/BottomKey/BottomPin
W/B Custom Adjust Data	By Screen Select Gain R/G/B Bias Coarse/Fine R/G/B γ R/G/B

Table 4. Video Memory

- Reading and Writing of Video Memory Data

Data writing and reading of the video memory (Load/Save) differ according to the selected setting values of Video Memory.

These set and selected values are saved in INPUT-MEMORY.

① Reading (Load)

Timing	Memory Type	Memory Area (from)
When the POWER is turned ON (As soon as the input signal is confirmed)	Video Memory	Reads data from the input memory of the user area to the area changing various data (RAM), and sets the changes in the unit.
When the input signal is input (As soon as the input signal is confirmed)		
When the CH is switched (As soon as the input signal is confirmed)		
When the input signal is changed (As soon as the input signal is confirmed)		
When the video memory setting is set to OFF (SIRCS, communication, etc.)		

Table 5. Reading of Data When Video Memory OFF

<When Video Memory = 1-10>

Timing	Memory Type	Memory Area
When AC is ON	All data of Video Memory 1-10	Reads various data from the input memory of the user area to the area changing data (RAM). Reads the video memory of the user area expanded.
When POWER is ON (As soon as the input signal is confirmed)	Selected video memory	Sets the video memory selected from the area changing data (RAM) in the unit.
When the input signal is input (As soon as the input signal is confirmed)		
When the CH is switched (As soon as the input signal is confirmed)		
When the input signal is changed (As soon as the input signal is confirmed)		
When the video memory setting value is changed (SIRCS, communication, etc.)		

Table 6. Reading of Data When Video Memory 1-10

② Writing (Save)

Basically, the unit writes and saves the data in the user memories at all writing timings.

However, the data will not be written if the MEMORY key is not pressed only when set to Video Memory = OFF and when the input memory is new.

<When Video Memory = OFF>

Timing	Memory Type	Memory Area
When the MEMORY key is pressed	All data when Video Memory is OFF.	Saves the data of the area changing various data (RAM) in the new (custom) input memory of the user area and INPUT-MEMORY of the memory read from.

Table 7. Writing of Data When Video Memory = OFF <When Input-Memory is New>

Timing	Memory Type	Memory Area
When the MEMORY Key is pressed	All data when the video memory is off	Saves the data of the area changing various data (RAM) in the custom input memory of the memory read from of the user area and original memory of the new memory.
When the input Ch is changed (As soon as input instability is confirmed)		
When the input signal is changed (When input instability is confirmed)		
When the mode of the unit is changed		
When the power is turned off		

Table 8. Writing of Data When Video Memory = OFF <When Input-Memory Exists>

<When Video Memory = 1-10>


Timing	Memory Type	Memory Area (to)
When the MEMORY key is pressed	All data of video memory 1-10 (Including video memory that is not selected)	Writes (saves) data of the area changing various data (RAM) in Video-Memory 1-10 in the set memory of the User Area.

Table 9. Writing of Data When Video Memory = 1-10 <When Input-Memory is New>


Timing	Memory Type	Memory Area (to)
When the MEMORY key is pressed	All data of Video Memory 1-10 (Including video memory that is not selected)	Writes (Saves) data of the area changing various data (RAM) in Video-Memory 1-10 in the set memory of the user area.
When the input Ch is changed (When input instability is confirmed)		
When the input signal is changed (When input instability is confirmed)		
When the mode of the unit is changed		
When the power is turned off		

Table 10. Writing of Data When Video Memory = 1-10 <When Input-Memory Exists>

Example : When set to VIDEO MEMORY OFF for an input (Input Memory No. 14)



Example : When set to VIDEO MEMORY 3 for an input (Input Memory No. 14)




- Color Temperature Memory

The Screen B and Screen M of Screen Sel are set with color temperatures 9300 k, 6500 k, 5400 k, and 3200 k. The data of each color temperature consists of GAIN/BIAS/ γ data.


The color temperature setting value custom is the GAIN/BIAS/ γ data in the following memories;

- Input-memory when Video Memory = OFF
- Various video memories when Video Memory = 1-10




The reading and writing of the data of this memory are as shown in “Table 2 Reading of Set Memory (Other than Video Memory) (Load)” and “Table 3 Writing of Set Memory (Other than Video Memory) (Save).”


Example : When set to Color Temperature: 6500K for an input (Input Memory No. 14)



Example : When set to Color Temperature: Custom for an input (Input Memory No. 14)
(When VIDEO MEMORY OFF)



Example : When set to Color Temperature: Custom for an input (Input Memory No. 14)
(When VIDEO MEMORY 3)




- **Uniformity Memory**

Memory which saves the uniformity data.

The unit has one data for the Uniformity mode : OFF and Manual mode each, and data for every screen for the Standard mode.


The setting values of the Uniformity mode are in Setting Memory.



The reading and writing of the data of this memory are as shown in “Table 2 Reading of Set Memory (Other than Video Memory) (Load)” and “Table 3 Writing of Set Memory (Other than Video Memory) (Save).”

- ABL Memory

Stores various data for ABL control.



The reading and writing of the data of this memory are as shown in “Table 2 Reading of Set Memory (Other than Video Memory) (Load)” and “Table 3 Writing of Set Memory (Other than Video Memory) (Save).”

- Device Memory

Items	Contents
PIC.CTRL.DEVICE IC DIRECT CTRL	Various register settings of CXA2101
VPS Limit control	VPS limit data of 3 colors-R, G, B : Adjustments of unit

Table 11. Device Memory

The reading and writing of the data of this memory are as shown in “Table 2 Reading of Set Memory (Other than Video Memory) (Load)” and “Table 3 Writing of Set Memory (Other than Video Memory) (Save).”

2. Ch Memory

Broadly, part of the set memory, but memorizes the values set for every channel collectively.
Contains the channel data on the channels and switchers of the unit.

Items	Contents
VIDEO Input-System	Video (Composite) / S-Video (YC)
INPUT-A Input-System	Video/S-Video/RGB/Component/HDTV-YPBPR/HDTV-GBR
INPUT-B Input-System	Video/S-Video/RGB/Component/HDTV-YPBPR/HDTV-GBR
INPUT-C Input-System	Video/S-Video/RGB/Component/HDTV-YPBPR/HDTV-GBR
Switcher Input-System	Video/S-Video/RGB/Component/HDTV-YPBPR/HDTV-GBR
VIDEO DRC setting	OFF /ON
INPUT-A DRC setting	
INPUT-B DRC setting	
INPUT-C DRC setting	
Switcher DRC setting	
Various information by switcher channel	

Table 12. Ch Memory

[Writing and Reading of Ch Memory]

Timing	Memory Type	Memory Area (from)
When AC is ON	All ch memories (Other than video memory)	Reads the data from the ch memory of the user area to the area changing various data (RAM), and sets the data in the unit.


Table 13. Reading of Ch Memory (Load)

Timing	Memory Type	Memory Area
When the MEMORY key is pressed	All ch memories	Writes data in the area changing various data (RAM) to the ch memory of the user area (Save).
When the input ch changes (When input instability is confirmed)		
When the input signal changes (When input instability is confirmed)		
When the mode of the unit changes		
When the power is turned off		

Table 14. Writing of Ch Memory (Save)

3. INPUT Memory


Memory for storing setting values and adjustment values by input signal.
There are altogether 150 standard input memories.



As shown above, the input memory is divided into original memory and custom memory.
The structure of each memory is basically the same.

• Structure of INPUT Memory

Consists of the identification data for identifying the input signal and setting and adjustment data by input signal.



Items	Contents
CH information <Custom Only>	Input channel selected when the input memory is registered (newly created) : Video/S-Video/INPUT-A/INPUT-B/INPUT-C/Switcher1-1 to 8-8/Other
Input signal type information <Original & Custom>	Signal type information of input signal when the input memory is registered (newly created) : Video, S-Video, Component, RGB, 15 k RGB, HDTV-YPBPR, HDTV-GBR, SDI-4:2:2, DRC, IDTV (Component60), IDTV (notComponent60), INT IDTV
Sync Status information <Custom Only>	Sync status information of input signal when the input memory is registered (newly created) : H/C-Pos/Neg/—, V-Pos/Neg/—, SonG/Neg/—
Input frequency information <Original & Custom>	fH, fV, number of scanning line

Table 15. Input Memory Identification Information Data

Items	Contents	
Video Memory No.	Video Memory setting value set for input signal: OFF, 1 to 10	
Various data when Video Memory is OFF	Video Memory Label	
	Color Temperature Select	
	W/B Adjust Data of Custom	
	Dynamic PICTURE	
	V.SHIFT Select	
	NTSC Setup Select	
	COMPONENT FORMAT Select	
	COMB Filter Select	
	DRC Level Select	
	Picture Control Adjust Data	
	RGB SIZE Adjust Data	
	RGB SHIFT Adjust Data	
	Blanking Adjust Data	
Clamp Select	Clamp pulse selected setting value : Auto, SonG, H/C, HP, Tri-Level Sync	
VIDEO LOCK Select	VIDEO LOCK selected setting value : Nomal, Wide	
SYNC Select	SYNC selected setting value : Auto, SonG/INT, C/EXT C, HV/EXT HV	
SYNC ROUTE	Sync route selection value of RGB signal input to INPUT-A : Auto, Normal, SYNC w VIDEO	
Normal DEFOCUS Select	Defocus mode selected setting value for normal : ON, OFF	
Registration Adjust	CENT	R/G/B, Hc/Hf/Vc/Vf, User/Service (fine), by deflection polarity
	SIZE	R/G/B, Hc/Hf/Vc/Vf/H/V
	LIN	R/G/B, Hc/Hf/Vc/Vf,
	SKEW	R/G/B, Hc/Hf/Vc/Vf
	BOW	R/G/B, Hc/Hf/Vc/Vf
	KEY	R/G/B, H/V/Top/Bottom/Left/Right,
	PIN	R/G/B, H/V/Top/Bottom/Left/Right,
	ZONE	R/G/B, Hc/Hf/Vc/Vf/H/V, Position1-25
Focus Adjust	Mg	R/G/B, All (Position1-9), H-Phase,
	Pole	R/G/B, 2H/2V/4AQP/4DQP/6AHP/6DHP
	AQP	R/G/B, Position1-9
	DQP	R/G/B, Position1-9
	AHP	R/G/B, Position1-9
	DHP	R/G/B, Position1-9
W/B Adjust <Custom>	GAIN	Screen B/M/, R/G/B,
	BIAS	Screen B/M, R/G/B, Coarse/Fine
	γ	Screen B/M, R/G/B

Table 16. Input Memory-Various Setting and Adjustment Data

- Original Memory

Input memory which stores preset and preadjusted data at shipment.

Serves as the memory read from for new input signals of the unit and in internal oscillation modes such as No-INPUT and INT.OSC mode : ON.

<Difference with Custom Memory>

① Identification conditions in identification data of input memory consist of only;

* Input signal type

* Input frequency (For RGB inputs)

The original memory closest to the input signal based on these conditions is therefore selected and the data is loaded.

② In all cases, various data is also saved in the original memory.

③ In all cases, the memory frame is not erased.

[Does not apply to automatic erasure when the input memory becomes full with registrations.]

[Does not apply to erasure of "Delete function" of the input memory editing function.]

No.	fH (kHz)	fV (Hz)	Scanning Lines	Input Signal Type
00	15.73	60.00	262	VIDEO line (NTSC3.58)
01	15.73	60.00	262	RGB
02	24.83	56.40	440	RGB
03	31.47	59.94	525	RGB
04	48.36	60.00	806	RGB
05	63.98	60.02	1066	RGB
06	75.00	60.00	1250	RGB
07	93.75	75.00	1250	RGB
08	106.25	85.00	1250	RGB
09	126.84	60.00	2114	RGB
10	145.00	60.00	2417	RGB
11	31.47	60.00	525	Double speed line DRC (NTSC 3.58)
12	33.75	60.00	562	HDTV line (YPBPR)

Table 17. Original INPUT MEMORY

- Custom Memory

Input memory for the input signal after shipment.

When the number of input memory registrations become 150 (including the 13 original memories), the memory of the custom memory area is replaced from the smallest number.

[Writing and Reading of Input Memory]

The reading and writing (load/save) of data differs between new input signals and existing input signals.

① Data reading (load)

<For new input signals>

When determined as “new input signal” as a result of the differentiation of the input signal, the most appropriate memory (memory with the signal most resembling the input signal <input signal type, and fH>) is determined from the original input memories, and it is read (loaded) in the area for changing various data (RAM).

<For existing input signals>

If a signal with the same identification conditions exist in the custom input memory as a result of differentiation of input signals, it is determined that the input memory for that signal has been already created, that is, it is an existing input signal, and the data of the custom input memory is read (loaded) to the area changing various data (RAM).

Timing
When the POWER is turned ON (As soon as the input signal is confirmed)
When the input signal is input (As soon as the input signal is confirmed)
When the CH is switched (As soon as the input signal is confirmed)
When the input signal is changed (As soon as the input signal is confirmed)
When Video Memory is set to OFF (SIRCS, communication, etc.)

Table 18. Reading of Input Memory (Loading)

<When NO-INPUT>

When determined as NO-INPUT as a result of the differentiation of the input signal, data from the original input memory set in that channel or determined from the input signal type in the board information is read to the area changing various data (RAM) and set in the unit.

Memory loaded from for every input signal type immediately before NO-INPUT

- VIDEO/S-VIDEO/COMPONENT/SDI : Original INPUT Memory No. 0
- RGB (Including 15 kRGB) : Same No. as the oscillation frequency of fH set at INT.OSC pattern of original input memories No. 1 to 10.
- HDTV system (YPBPR, GBR) : Original INPUT Memory No. 12
- Signal set to DRC ON : Original INPUT Memory NO. 11

② Data Writing and Storage (Save)

The writing and storing timing of the data and memory in which the data is written in differ between the new input signal and existing input signal.

<For new input signals>

By pressing the MEMORY Key, the INPUT-MEMORY data “in the area (RAM) changing various data” at that point is written and stored (save) in the new memory set as the custom input memory.

At the same time, the same data is also written and stored in the original input memory from which the data is read from (load).

Timing	Memory Type	Memory Area (to)
When the MEMORY key is pressed	All data in the input memory	New custom input memory of the user area and input memory from which the data is loaded from (original).

Table 19. Writing and Storing of Data in Input Memory <New> (Save)

<For existing input signals>

At all timings for writing and storing data in the unit (save), data of the input memory for the input signals in the area for changing various data (RAM) is collectively written and stored in the custom input memory from which the data is read from (load) of the user area.

Timing	Memory Type	Memory Area (to)
When the MEMORY key is pressed	All data of the input memory	Custom input memory read from of the user area (load) and original input memory read (loaded) when this memory is newly created.
When the input channel is changed (When input instability is confirmed)		
When the input signal is changed (When input instability is confirmed)		
When the mode of the unit is changed		
When the POWER is turned OFF		

Table 20. Writing and Storing of Data in Input Memory <Exist> (Save)

<When NO-INPUT>

At all timings for writing and storing data in the unit (save), data of the input memory for the input signals in the area for changing various data (RAM) is collectively written and stored in the original input memory from which the data is read from (load) of the user area.

<INPUT-Memory No. in which the data is written and stored :>

When the input memory load/save is Auto :

Until the number of registrations of the custom input memory becomes max. (150 — 13), assigned automatically to unused memories starting from the smallest memory number in order.

When the number of registrations of the custom input memory is max, new input memories are created by overwriting from No. 13.

Data cannot be written when the input memory written in is protected ;

In this case, take note that adjustments will be possible.

At the same time, when the memory key is pressed, an OSD message indicating that data cannot be written will be displayed.

If all input memories are protected, since there is no memory to save the data, an error message will be displayed when determined as new data.

When the protect of several input memories is canceled, the data to be newly registered will be written in the memory with the smallest number.

When input memory load and save is manual :

The memory of the input memory No. specified will be the input memory for the new input signal.


Data cannot be saved when the input memory saved in is protected ;

In this case, take note that adjustments will be possible.


At the same time, when the memory key is pressed, an OSD message indicating that data cannot be saved will be displayed.

If all input memories are protected, since there is no memory to save the data, an error message will be displayed when determined as new data.


Example : When the input signal is new to the unit (fH = 31.5 kHz)
 State in which data is already registered to input memory No. 13



Example : When the input signal was previously input to a different channel (fH = 31.5 kHz: No. 13) to the unit
State in which data is already registered to input memory No. 13



Example : When the input signal has already been input to the unit (fH = 31.5 kHz: No. 13)
 State in which data is already registered to input memory No. 14



2-5. MEMORY DATA RESET

Refer to page 139 of the installation manual.


SECTION 3 SET-UP ADJUSTMENTS

3-1. PRECAUTIONS UPON ADJUSTMENT

1. When the CRT (a cathode-ray tube) has been replaced, fix the DY (deflection yoke) to the funnel and decide the position of the neck assembly before beginning adjustments.
2. When the power is turn off, the service mode is canceled.

3-2. ATTACHING THE NECK ASSEMBLY


1. Fix DY to the CRT funnel, then fix the Magnet Focus Coil.
2. Tentatively secure the 2-pole and 4-pole magnet assembly in contact with the Magnet Focus Coil.
3. Attach the CB board.



3-3. ADJUSTING CONDITIONS


3-3-1. Projecting System

Place the unit on a table which satisfies the projection conditions as shown in the figure.




Inclination Angle at Top and Bottom

(Side view)



Left and Right Tilt of the Unit


(Top view)




3-3-2. CRT Convergence Angle Check

Open the top cover and check that there are adjusting screws in the adjusting holes for 120-inch screen. If there are no adjusting screws in the 120-inch adjusting holes, adjust as follows.


1. Turn on the power of the projector.
2. Set the remote commander to the serviceman adjustment mode. For details, see "Remote Commander" in the instruction manual.
3. Reset the red, green and blue registration data. For details, see "Resetting the Data" in the instruction manual.
4. Observe the screen and confirm the following.
 - The center of the green hatch pattern aligns with the horizontal center of the screen.
 - The centers of the red and blue hatch patterns align at even intervals from the green hatch pattern.
 If the center of the green hatch pattern does not align with the screen center, the projector may not be installed correctly. Re-install it rightly.



5. Loosen the CRT fixing screws (two black screws) used for the red with the use of the supplied tool. Make sure not to remove the screws.



6. Insert the adjusting screws (two gold screws) in the adjusting holes for the 120-inch screen.



When the unit is shipped from a factory, the adjusting screws are screwed into the adjusting holes for 120-inch screen.

7. Tighten the CRT fixing screws (two black screws) used for the red, which were loosened at Step 5.
8. Repeat Steps 5 to 7 to loosen the CRT fixing screws (two black screws) used for the blue, adjust the CRT convergence angle for the blue, then tighten the CRT adjustment screws (two gold screws) used for the blue.

3-4. FOCUS ADJUSTMENT

3-4-1. Preparations

1. Turn ON the MAIN POWER SW, and press the POWER ON key to turn on the power.
2. Press the NORMAL key.
3. Continue pressing the keys as follows.
ENTER key $\Rightarrow$ ENTER key $\Rightarrow$ $\uparrow$ key $\Rightarrow$ $\downarrow$ key $\Rightarrow$ ENTER key $\Rightarrow$
4. Select "YES" on the screen with $\uparrow$ and $\downarrow$ keys, then press the ENTER key.
5. Press the MENU key. "S" is displayed on the screen and the serviceman adjusting mode is set.
6. Keep pressing the RESET key for five seconds.
7. Select "YES" on the screen with $\uparrow$ and $\downarrow$ keys, then press the ENTER key.
8. Select "ALL MEMORY" on the screen with $\uparrow$ and $\downarrow$ keys, then press the ENTER key.
9. Select "FACTORY DATA" on the screen with $\uparrow$ and $\downarrow$ keys, then press the ENTER key.
With the above procedure, the same state as that at the time of factory shipment can be set for the unit, and adjustment can be made for the replaced color.
10. Set INPUT-A to the no-signal state, then select INPUT-A.
11. Select the INT OSC PATTERN from INT. OSC menu with the MENU key, then select P5 (fH = 64 kHz, fV = 60 Hz).

3-4-2. Focus Rough Adjustment


1. Set INPUT-A to the no-signal state, then select INPUT-A.
2. Select the ME pattern, as test pattern, with the PATTERN key.
3. Cut off the colors other than the one to be adjusted with the CUT OFF key and set a single color. Then adjust the lens focus roughly.
4. Press the MG FOCUS key to set the MG FOCUS adjustment mode, then select the ME pattern with the PATTERN key.
5. Press the ALL key to adjust the center focus of R, G and B roughly.
6. Repeat Steps 3 to 5 until the best center focus is attained.

3-4-3. DY Angle Adjustment

Note: Angle adjustment should be made only with DY for the color for which CRT was replaced.

GREEN DY Angle Adjustment

1. Set INPUT-A to the no-signal state, then select INPUT-A.
2. Press the REGISTRATION CENT key and ADJ G key to make the cross-hair pattern appear.
3. Press the CUT OFF key and B key to set green only on the screen.
4. Roughly adjust GREEN DY angle so that the horizontal cross-hair pattern can be parallel to the horizontal line of the screen.
5. Roughly adjust the coil so that the marking section of the GREEN MG FOCUS coil can face up.



6. Adjust the GREEN CENT to the screen center using ↑, ↓, ← and → keys.
7. Roughly adjust the GREEN H.SIZE, H.LIN and V.BOW so that the horizontal line at the center can be straight. In H.SIZE/LIN adjustments, the screen edge or the 30 to 50 mm marks inside the screen serve as the reference.
In order to adjust the DY tilt easily, adjustment is made so that the external lines of the cross-hatch come slightly outside these marks in the H. SIZE adjustment.
8. Press REGISTRATION SKEW on the remote commander to set to the skew adjustment model. Make sure that the "V.SKEW" data on the screen shows "128." Adjust to "128" if it is not so.

9. Adjust GREEN DY angle so that the cross-hair horizontal line can be parallel to the horizontal line of the screen, then tighten the fixing screws.

Note:

- Use a non-magnetized screwdriver to tighten the screws.
- Fix the DY to the CRT funnel.
- Tighten the DY band with the following torque.

Tightening Torque:

80 to 120 N·cm (8.16 to 12.24 kgf·cm).

10. After fixing DY, check that the values of V.SKEW is within the following specification.

Specification: Green: V.SKEW data = 128 ± 5

RED DY Angle Adjustment

11. Adjust RED DY tilt in the same way as the one for GREEN DY (see Steps 1 to 10).

- Press the CUT OFF B key to set the screen to RED and GREEN.
- Use the horizontal lines of GREEN cross-hair pattern as reference of adjustment.

BLUE DY Angle Adjustment


12. Adjust BLUE DY tilt in the same way as the one for GREEN DY (see Steps 1 to 10).

- Press the CUT OFF R or G key.
- Use the horizontal lines of GREEN or RED cross-hair pattern as reference of adjustment.

3-4-4. MG FOCUS Coil Angle Adjustment

BLUE MG FOCUS COIL Angle Adjustment

1. Set INPUT-A to the no-signal state, then select INPUT-A.
2. Select the INT OSC PATTERN from INT. OSC menu with the MENU key, then select P3 (fH = 31.5 kHz, fV = 60 Hz).
3. Press the MG FOCUS key to set to Magnet Focus mode. Press the ADJ B key to set to BLUE adjustment mode, then press the PATTERN key to select the dot (9 × 9) pattern.
4. Press the CUT OFF R and G keys to set BLUE only on the screen.
5. Press the CONTR (+) key to set contrast to the maximum.
6. Press the MG FOCUS key, then press ↑ or ↓ key to select "ALL." Press ← key to set the data of "ALL" to the minimum.
7. Adjust the AQP, DQP, AHP, and DHP so that the dots can be round.
8. Select "ALL" with ↑ or ↓ key, then press ← or → key to set the dots to the minimum.
9. Press the MG FOCUS key to set to DEFOCUS mode. Adjust the COIL angle so that the dot on the screen center can be vertically longer, then fix it.




- Note:**
- Use a non-magnetized screwdriver to tighten the screws.
 - Fix the MG FOCUS Coil at the rear of Sub DY.
 - Tighten the MG FOCUS Coil with the following torque.
Tightening Torque: 80 to 120 N•cm
(8.16 to 12.24 kgf•cm)

10. Press the PATTERN key to select ME Pattern. Select "ALL" with ↑ or ↓ key, then roughly adjust the focus by pressing ← or → key.
11. Press the COUNT (+) or (−) key to set the CONTRAST display on the screen to "80."
12. Keep pressing MEMORY key for 5 seconds or more.
13. Select "YES" on the screen with ↑ and ↓ keys, then press the ENTER key.
14. Select "FOCUS DATA" on the screen with ↑ and ↓ keys, then press the ENTER key.

R/G/B 2P-4P COIL Angle Adjustment

Adjust the angle of 2P-4P coil so that its marking section becomes upward.



3-4-5. 64 kHz Signal Registration Rough Adjustment

1. Set INPUT-A to the no-signal state, then select INPUT-A.
2. Select the INT OSC PATTERN from INT. OSC menu with the MENU key, then select P3 (fH = 64 kHz, fV = 60 Hz).

GREEN Registration Adjustment

3. Press the REGISTRATION CENT key and ADJ G key.
4. Press CUT OFF R and B keys to set GREEN only on the screen.
5. Adjust the GREEN center to the screen center using the ↑, ↓, ← and → keys.
6. Press REGISTRATION SIZE key.
7. Roughly adjust H. SIZE (the horizontal size) with ← and → keys, then V. SIDE (the vertical size) with ↑ and ↓ keys. Adjust the external circumference of the GREEN test signal to the position 30 to 50 mm inside the screen.
8. Press REGISTRATION KEY key.
9. Roughly adjust H. KEY and V. KEY (the horizontal and vertical keystones) using the ↑, ↓, ← and → keys.
10. Press REGISTRATION BOW key.
11. Roughly adjust H. BOW and V. BOW (the horizontal and vertical bows) using the ↑, ↓, ← and → keys.
12. Press REGISTRATION SKEW key.
13. Roughly adjust H. SKEW and V. SKEW (the horizontal and vertical skews) using the ↑, ↓, ← and → keys.
14. Press REGISTRATION PIN key.
15. Roughly adjust H. PIN and V. PIN (the horizontal and vertical pin cushions) using the ↑, ↓, ← and → keys.

RED Registration Adjustment

16. Press the ADJ R key.
17. Press CUT OFF B keys to set RED and GREEN only on the screen.
18. Adjust RED registration in the same way as Steps 5 to 15. Adjust the RED signal to GREEN signal.

BLUE Registration Adjustment

19. Press the ADJ B key.
20. Press CUT OFF R keys to set BLUE and GREEN only on the screen.
21. Adjust BLUE registration in the same way as Steps 5 to 15. Adjust the BLUE signal to GREEN signal.

Saving Registration Data

22. Keep pressing MEMORY key for 5 seconds or more.
23. Select "YES" on the screen with ↑ and ↓ keys, then press the ENTER key.
24. Select "REGISTRATION DATA" on the screen with ↑ and ↓ keys, then press the ENTER key.
25. Press the NORMAL key to exit from the adjustment mode.
26. Press the PATTERN key to output the cross-hatch on the screen, then check that the RED, GREEN and BLUE registration have been adjusted roughly.

3-4-6. RED/GREEN/BLUE Focus Adjustment

1. Set INPUT-A to the no-signal state, then select INPUT-A.
2. Select the INT OSC PATTERN from INT. OSC menu with the MENU key, then select P3 (fH = 31.5 kHz, fV = 60 Hz).

GREEN Focus Adjustment

3. Press the MG FOCUS key and ADJ G key.
4. Press CUT OFF R and B keys to set GREEN only on the screen.
5. Press CONTR (+) key to set the contrast to the maximum.
6. Press PATTERN key to select "Dot (17 × 17) & Hatch (5 × 5)" pattern.
7. Select "ALL" on the screen with ↑ and ↓ keys, then press the ENTER key.
8. Increase the ALL data (+40) with ← and → keys, then output the flare.
9. Select "2PH (2-Pole H)" on the screen with ↑ and ↓ keys, then adjust the dot core to the center of the flare in the horizontal direction with ← and → keys.
10. Select "2PV (2-Pole V)" and adjust the dot core to the center of the flare in the vertical direction.
11. Select "2PH (2-Pole V)" and adjust the dot core to the center of the flare in the vertical direction.
12. Return to "ALL," and decrease the ALL data (−80) to increase the dot size.
13. Select "6PA" and perform adjustment to transform the triangle in the vertical direction of the dot to an ellipse.
14. Select "6PD" and perform adjustment to transform the triangle in the skew direction of the dot to an ellipse.
15. Select "4PA" and perform adjustment to transform the ellipse in the vertical and horizontal directions of the dot to be round.
16. Select "4PD" and perform adjustment to transform the ellipse in the skew direction of the dot to be round.
17. Repeat Steps 9 to 16 until the dot becomes round.

RED Focus Adjustment

18. Press the ADJ R key.
19. Press CUT OFF, G and B keys to set RED only on the screen.
20. Adjust RED centering in the same way as GREEN centering.

BLUE Focus Adjustment

21. Press the ADJ B key.
22. Press CUT OFF, R and G keys to set BLUE only on the screen.
23. Adjust BLUE centering in the same way as GREEN centering.
24. Press CONTR (−) key to set the contrast to "80."
25. Repeat Steps 3 to 23 until the dot becomes round.

Saving Focus Data

26. Keep pressing MEMORY key for 5 seconds or more.
27. Select "YES" on the screen with ↑ and ↓ keys, then press the ENTER key.
28. Select "FOCUS DATA" on the screen with ↑ and ↓ keys, then press the ENTER key.
29. Press the NORMAL key to exit from the adjustment mode.

3-4-7. Zenith Angle Adjustment

1. Input the 64 kHz RGB signal to the INPUT-A connector, then select INPUT-A.
2. Press the MG FOCUS key and ADJ G key.
3. Press CUT OFF R and B keys to set GREEN only on the screen.
4. Press PATTERN key several times and select ME pattern.
5. Roughly adjust the "ALL" for "POSITION No. 1." In succession, roughly adjust the AQP, DQP, AHP, and DHP for "POSITION No. 2" to "POSITION No. 5."
6. Set ME pattern on the screen, and roughly adjust the lens corner focus.


Note: If the center focus is not precisely adjusted, adjust it again. Patterns other than ME pattern are also available.

7. Adjust the lens center focus so that ME pattern at the bottom part of the screen center can be best focused.
8. Look at the top part of the screen center. Rotate the lens center focus to the "Left" and check if a best focus position exists. If so, take the point as "Left."
9. If not, adjust the focus at the bottom part of the screen to the best then look at the top part and rotate the lens focus to the "Right." Check if the best focus point exists. If so, take the point as "Right."
10. Adjust again the focus at the bottom part precisely.
11. Rotate the zenith angle adjustment nut (V) in the same direction as that obtained in Step 8 or Step 9 so that the focus at the top and the bottom can be the same.

[Zenith Angle Adjustment Specification]

Adjust the main lens focus precisely so that the bottom part (or the top part) of the center can be best focused. At this time, the best focus point of the top part (or the bottom part) of the center should be within 20 mm from the screen toward the unit main body.

Note: If the focus point is the far end of the screen, change the measuring points (change from the bottom to the top and vice versa).




12. Adjust the focus at the bottom part precisely, then check that the focus at the top part is within the reference. If not, adjust again in the same way.
13. Perform the H zenith angle adjustment in the same way as above Steps.
14. Adjust the lens center focus so that ME pattern at the left part of the screen center can be best focused.
15. Look at the right part the screen center. Rotate the lens center focus to the "Left" and check if a best focus position exists. If so, take the point as "Left."
16. If not, adjust the focus at the left part of the screen to the best then look at the right part and rotate the lens focus to the "Right." Check if the best focus point exists. If so, take the point as "Right."
17. Adjust again the focus at the left part precisely.
18. Rotate the zenith angle adjustment nut (H) in the same direction as that obtained in Step 15 or Step 16 so that the focus at the right and the left can be the same.

[Zenith Angle Adjustment Specification]

Adjust the main lens focus precisely so that the left part (or the right part) of the center can be best focused. At this time, the best focus point of the right part (or the left part) of the center should be within 20 mm from the screen toward the unit main body.

Note: If the focus point is the far end of the screen, change the measuring points (change from the left to the right and vice versa).



19. Adjust the focus at the left part precisely, then check that the focus at the right part is within the reference. If not, adjust again in the same way.
20. After completion of the above, roughly adjust the lens focus of the screen center again.
21. Adjust RED and BLUE in the same way as GREEN.

3-4-8. HWC (H Width Coil) Adjustment

Note: Perform this adjustment when the E board or deflection yoke has been replaced.

1. Set INPUT-A to the no-signal state, then select INPUT-A.
Select the INT OSC PATTERN from INT. OSC menu with the MENU key, then select P3 (fH = 31.5 kHz, fV = 60 Hz).
2. Press the REGISTRATION CENT key and the ADJ G key to set the CENT GREEN adjustment mode and press the CUT OFF R key and B key to set GREEN only.
3. Adjust the GREEN center to the screen center.
4. Press the REGISTRATION SIZE key to set the SIZE GREEN adjustment mode, adjust the H.SIZE, move the left and right edges of the test pattern near the screen edge. Then press the REGISTRATION LIN key, set the LIN adjustment mode and adjust the linearity.
5. Repeat the SIZE and LIN adjustment to align the left and right edges of the test pattern to the screen edge. (If necessary adjust CENT again.)
6. Press the REGISTRATION CENT key and the ADJ R key to set CENT RED adjustment mode and press the CUT OFF B key to cut off BLUE.
7. Adjust the RED center to the GREEN center.
8. Perform LIN adjustment again to align the RED left and right edges of the test pattern to GREEN.
9. Set the RED H. SIZE data to "128."
10. Press the REGISTRATION CENT key and the ADJ B key to set CENT BLUE adjustment mode and press the CUT OFF R key to cut off RED.
11. Adjust the BLUE center to the GREEN center.
12. Perform LIN adjustment again to align the BLUE left and right edges of the test pattern to GREEN.
13. Set the BLUE H. SIZE data to "128."
14. Adjust RED HWC (LV1), GREEN HWC (LV2) and BLUE HWC (LV3) on the E board and perform adjustment so that any other two colors can be matched to the color with the smallest H SIZE values.

3-4-9. Video Size Adjustment

Note: Perform this adjustment when the E board ED board, or Green deflection yoke has been replaced.

1. Press the INPUT SELECT VIDEO key, input the NTSC monoscope signal and receive the image.
2. Press the CUT OFF R key and the B key to set GREEN only.
3. Press the MG FOCUS key and the ADJ G key to set MG FOCUS GREEN adjustment mode, then adjust the GREEN CENTER FOCUS (Mg-ALL).
4. Press the REGISTRATION CENT key and ADJ G key to set GREEN adjustment mode and adjust the hatch center to the screen center.
5. Press the RGB SHIFT key to set RGB SHIFT adjustment mode, input the monoscope signal and receive the signal.
Further press the CUT OFF R key and the B key to set GREEN only. Adjust the monoscope center to the screen center with SHIFT adjustment.
6. Press the REGISTRATION SIZE key and set the SIZE GREEN adjustment mode. Press the PATTERN key several times to receive the monoscope signal, move the left and right edges of the monoscope near the screen edge, then press the REGISTRATION LIN key to set the LIN adjustment mode and adjust the linearity.
7. Press the CUT OFF R key and the B key to set GREEN only.
8. Repeat the SIZE and LIN adjustment (and CENT adjustment) and adjust the left and right edges of the monoscope to the screen edge.
Note: To change the linearity considerably in H.LIN adjustment, perform the CENT adjustment again.
9. Press RGB SIZE key to set RGB SIZE mode. Adjust H SIZE data (Hc) to Maximum.
10. Press RGB SIZE key to set RGB SIZE mode. Adjust H SIZE data (Hf) to "145."
11. Press the MEMORY key.
12. Adjust RV2 on the EA board, and set the H size of the monoscope to 15.5 ± 0.15 frames.

3-4-10. MG FOCUS Adjustment for 31.5 kHz Signal

1. Set INPUT-A to the no-signal state, then select INPUT-A.
Select the INT OSC PATTERN from INT. OSC menu with the MENU key, then select P3 (fH = 31.5 kHz, fV = 60 Hz).
2. Press the REGISTRATION CENT key and the ADJ G key to set the CENT GREEN adjustment mode and press the CUT OFF key and B key to set GREEN only.
3. Adjust the GREEN center to the screen center (When it has been aligned, adjustment is not needed).
4. Press the REGISTRATION SIZE key to set the SIZE adjustment mode, adjust the H.SIZE and V.SIZE again.
5. Press the PATTERN key to output the cross-hatch pattern, and check that the image distortion has been roughly adjusted. (If not, adjust it again).
6. Press the MG FOCUS key to set the MG Focus adjustment mode, and press the PATTERN key several times to output the ME pattern.
7. Adjust ALL FOCUS at "POSITION No. 1" so that the ME pattern of the center can be focused in the optimum condition.
8. Adjust the GREEN main lens to make the focus of the central part optimum, then fix it.
9. Press the FUNCTION key to set to SPOT SHAPE ADJ mode.
10. Press the PATTERN key to output the dot pattern.
Then press the POSITION (+) key to set to "POSITION No. 2" mode.
11. Move the AQP adjustment mode with ↑ and ↓ keys, then perform adjustment so that the dot can become most rounded.
12. Move the DQP adjustment mode with ↑ and ↓ keys, then perform adjustment so that the dot can become most rounded.
13. Move the AHP adjustment mode with ↑ and ↓ keys, then perform adjustment so that the dot can become most rounded.
14. Move the DHP adjustment mode with ↑ and ↓ keys, then perform adjustment so that the dot can become most rounded.
15. Repeat Steps 11 to 14 several times to adjust the dot to the most rounded conditions while adjusting the tracking.
16. Press the FUNCTION key to finish the SPOT SHAPE ADJ mode.
17. Press the PATTERN key several times to output the ME pattern.

18. Press the POSITION (+) key to set to "POSITION No. 2" mode.
19. Press the MG FOCUS key and the ADJ G key.
20. Press the CUT OFF R key and B key to set GREEN only on the screen.
21. Adjust the focus of the upper ME pattern to the optimum.
22. Move the AQP adjustment mode with ↑ and ↓ keys, adjust the focus of the upper ME pattern to the optimum.
23. Move the DQP adjustment mode with ↑ and ↓ keys, adjust the focus of the upper ME pattern to the optimum.
24. Repeat Steps 21 to 23 several times to adjust the ME pattern to the optimum while adjusting the tracking.
25. Press the POSITION (+) key to set to "POSITION No. 3" mode.
26. Adjust it in the same way as Steps 19 to 24.
27. Adjust "POSITION No. 4" to "POSITION No. 9" in the same way as Steps 25 and 26.
28. Press the MEMORY key to save the adjustment data.
29. Perform the MG FOCUS adjustment of RED and BLUE in the same way as GREEN.
30. Save the data after adjustment.

6		2		8
4		1		5
7		3		9

* The number in the figure indicates the POSITION during AQP, DOP, AHP, and DHP adjustments.

3-4-11. VIDEO Block MG FOCUS Adjustment

1. Press the INPUT SELECT VIDEO key, and receive the NTSC monoscope signal.
2. Press the MG FOCUS key and the ADJ G key to set the GREEN MG FOCUS adjustment mode and press the CUT OFF R key and B key to set GREEN only. Roughly adjust "ALL FOCUS" at POSITION No. 1.
3. Roughly adjust GREEN "CENT," "SIZE," "LIN," "BOW," "SKEW," "PIN" and "KEY."
4. Perform the rough adjustment of RED and BLUE in the same way as Steps 2 and 3.
5. Set the MG FOCUS GREEN adjustment mode again, and press the CUT OFF R key and the B key to set GREEN only.
6. Press the CONTR (+) key and set the contrast to the maximum.
7. Decrease the "ALL" data and increase the dot size.
8. Adjust AQP, DQP, AHP and DHP so that the dot can become dead-round.
9. Return the CONTR data back to "80."
10. Press the POSITION (+) key to set to "POSITION No. 1" mode.
11. Perform the "ALL-FOCUS" adjustment and adjust the focus of the ME pattern to the optimum.
12. Roughly adjust the GREEN centering again.
13. Using the same method as in 3-4-10, "3.15 kHz MG FOCUS Adjustment," adjust the GREEN MG FOCUS, AQP, DQP, AHP and DHP of "POSITION No. 2" to "POSITION No. 9" of the video signal block (15 kHz).
14. Adjust RED and BLUE in the same way as above.

3-4-12. MG FOCUS Adjustment for 64 kHz and 106 kHz Signals

1. Set INPUT-A to the no-signal state, then select INPUT-A. Select the INT OSC PATTERN from INP. OSC menu, then select P5 (fH = 64 kHz, fV = 60 Hz). Perform the same adjustment as Section 3-4-11 "Video Block MG FOCUS Adjustment."
2. Select P8 (fH = 106 kHz, fV = 85 Hz), then perform the same adjustment as Section 3-4-11 "Video Block MG FOCUS Adjustment."

3-4-13. Adjustment of Other Frequencies

Adjustment of the other frequencies are automatically performed by copying the adjusted data in accordance with the next adjustment "3-5. REGISTRATION ADJUSTMENT."

3-5. REGISTRATION ADJUSTMENT

3-5-1. INPUT MEMORY No. 0 Adjustment

1. Input the monoscope signal to VIDEO IN.
2. Press the BLKG key and move the top blanking outside the effective screen with the $\uparrow$ key.
3. Press the POSITION (+) key and move the bottom blanking outside the effective screen with the $\downarrow$ key.
4. Press the POSITION (+) key and move the left blanking outside the effective screen with the $\leftarrow$ key.
5. Press the POSITION (+) key and move the right blanking outside the effective screen with the $\rightarrow$ key.
6. Press the MEMORY key.
7. Press the REGISTRATION CENT key and the ADJ G key to set the GREEN adjustment mode.
8. Adjust the vertical and horizontal lines to the screen center lines using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
9. Press the REGISTRATION SIZE key to adjust the outer circumference of the cross-hair to the position 60 ± 20 mm inside the screen using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
10. Set the modes of LIN, SKEW, BOW, KEY, KEY (TOP/BOTTOM/LEFT/RIGHT), PIN, PIN (TOP/BOTTOM/LEFT/RIGHT) and ZONE, then adjust them to the values within the specification using the arrow keys (up to 21 blocks).

Note:

- For adjusting four corners, use KEY, KEY (TOP/BOTTOM/LEFT/RIGHT), PIN, PIN (TOP/BOTTOM/LEFT/RIGHT). The adjusted value of "POSITION No. 1" – "POSITION No. 9" in ZONE adjustment should be " 128 ± 5 ."

- When the size is deviated during adjustment, adjust it as required.

11. Press the MEMORY key.
 12. Press the REGISTRATION CENT key and the ADJ R key to set the RED adjustment mode, then adjust the vertical and horizontal lines of RED to the GREEN center lines using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
 13. Press the REGISTRATION SIZE key to adjust the outer circumference of the cross-hair to the position 60 ± 20 mm inside the screen using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
 14. Set the modes of LIN, SKEW, BOW, KEY, KEY (TOP/BOTTOM/LEFT/RIGHT), PIN, PIN (TOP/BOTTOM/LEFT/RIGHT) and ZONE, then adjust them to the values within the specification using the arrow keys (up to 21 blocks).
- Note:**
- For adjusting four corners, use KEY, KEY (TOP/BOTTOM/LEFT/RIGHT), PIN, PIN (TOP/BOTTOM/LEFT/RIGHT). The adjusted value of "POSITION No. 6 to "POSITION No. 9" in ZONE adjustment should be " 128 ± 5 ."
 - When the size is deviated during adjustment, adjust it as required.
15. Press the MEMORY key.
 16. Adjust BLUE in the same way.
 17. Copy the adjusted data to INPUT MEMORY No. 1 and INPUT MEMORY No. 2.

3-5-2. INPUT MEMORY No. 3 Adjustment

1. Set INPUT-A to the no-signal state, then select INPUT-A. Select the INT OSC PATTERN from INT. OSC menu with the MENU key, then select P3 (fH = 31.5 kHz, fV = 60 Hz).
 2. Press the BLKG key and move the top blanking outside the effective screen with the $\uparrow$ key.
 3. Press the POSITION (+) key and move the bottom blanking outside the effective screen with the $\downarrow$ key.
 4. Press the POSITION (+) key and move the left blanking outside the effective screen with the $\leftarrow$ key.
 5. Press the POSITION (+) key and move the right blanking outside the effective screen with the $\rightarrow$ key.
 6. Press the MEMORY key.
 7. Press the REGISTRATION CENT key and the ADJ G key to set the GREEN adjustment mode.
 8. Adjust the vertical and horizontal lines to the screen center lines using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
 9. Press the REGISTRATION SIZE key to adjust the outer circumference of the cross-hair to the position 60 ± 20 mm inside the screen using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
 10. Set the modes of LIN, SKEW, BOW, KEY, KEY (TOP/BOTTOM/LEFT/RIGHT), PIN, PIN (TOP/BOTTOM/LEFT/RIGHT) and ZONE, then adjust them to the values within the specification using the arrow keys (up to 21 blocks).
- Note:** When the size is deviated during adjustment, adjust it as required.
11. Press the MEMORY key.
 12. Copy the adjusted data to INPUT MEMORY No. 4, INPUT MEMORY No. 11, and INPUT MEMORY No. 12.

3-5-3. INPUT MEMORY No. 5 Adjustment

1. Set INPUT-A to the no-signal state, then select INPUT-A. Select the INT OSC PATTERN from INT. OSC menu with the MENU key, then select P3 (fH = 64 kHz, fV = 60 Hz).
 2. Press the BLKG key and move the top blanking outside the effective screen with the $\uparrow$ key.
 3. Press the POSITION (+) key and move the bottom blanking outside the effective screen with the $\downarrow$ key.
 4. Press the POSITION (+) key and move the left blanking outside the effective screen with the $\leftarrow$ key.
 5. Press the POSITION (+) key and move the right blanking outside the effective screen with the $\rightarrow$ key.
 6. Press the MEMORY key.
 7. Press the REGISTRATION CENT key and the ADJ G key to set the GREEN adjustment mode.
 8. Adjust the vertical and horizontal lines to the screen center lines using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
 9. Press the REGISTRATION SIZE key to adjust the outer circumference of the cross-hair to the position 60 ± 20 mm inside the screen using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
 10. Set the modes of LIN, SKEW, BOW, KEY, KEY (TOP/BOTTOM/LEFT/RIGHT), PIN, PIN (TOP/BOTTOM/LEFT/RIGHT) and ZONE, then adjust them to the values within the specification using the arrow keys (up to 21 blocks).
- Note:** When the size is deviated during adjustment, adjust it as required.
11. Press the MEMORY key.
 12. Copy the adjusted data to INPUT MEMORY No. 6 and INPUT MEMORY No. 7.

3-5-4. INPUT MEMORY No. 8 Adjustment

1. Set INPUT-A to the no-signal state, then select INPUT-A. Select the INT OSC PATTERN from INT. OSC menu with the MENU key, then select P3 (fH = 106 kHz, fV = 60 Hz).
2. Press the BLKG key and move the top blanking outside the effective screen with the ↑ key.
3. Press the POSITION (+) key and move the bottom blanking outside the effective screen with the ↓ key.
4. Press the POSITION (+) key and move the left blanking outside the effective screen with the ← key.
5. Press the POSITION (+) key and move the right blanking outside the effective screen with the → key.
6. Press the MEMORY key.
7. Press the REGISTRATION CENT key and the ADJ G key to set the GREEN adjustment mode.
8. Adjust the vertical and horizontal lines to the screen center lines using the ↑, ↓, ← and → keys.
9. Press REGISTRATION SIZE key to adjust the outer circumference of the cross-hair to the position 60 ± 20 mm inside the screen using the ↑, ↓, ← and → keys.
10. Set the modes of LIN, SKEW, BOW, KEY, KEY (TOP/BOTTOM/LEFT/RIGHT), PIN, PIN (TOP/BOTTOM/LEFT/RIGHT) and ZONE, then adjust them to the values within the specification using the arrow keys (up to 21 blocks).

Note: When the size is deviated during adjustment, adjust it as required.

11. Press the MEMORY key.
12. Copy the adjusted data to INPUT MEMORY No. 9 and INPUT MEMORY No. 10.

3-5-5. Horizontal/Vertical Reverse Mode Centering Adjustment

1. Turn off the power of the unit.
2. Set S2001 (Horizontal/Vertical Deflection Switch) on the EC Board to the reverse mode.
3. Turn on the power of the unit.
4. Input the NTSC monoscope signal.
5. Press the ON/STANDBY key on the remote commander or the control panel.
6. Check that the horizontal and vertical deflections are reversed.
7. Press the REGISTRATION CENT key and the ADJ G key to set the GREEN adjustment mode.
8. Adjust the horizontal and vertical centering using the ↑, ↓, ← and → keys.
9. Press the MEMORY key.
10. Adjust RED and BLUE in the same way as GREEN.
11. Turn off the main power switch.
12. Return S2001 (Horizontal/Vertical Deflection Switch) on the EC Board to the original settings.

3-6. WHITE BALANCE ADJUSTMENT

3-6-1. Preparations

Equipment required

VPH-G90 (Focus, size, registration, and lens focus had been adjusted completely.)

W/B checker: Philips PM5639/10

Test signal generator: Tektronix TSG-100 or equivalent

Note: If test signal generator is not available, use internal test signal.

Color temperature setting range


9300 °K/6500 °K/5400 °K/3200 °K + 8MPCD

1. Attach a lens-ball of the W/B checker to the lens.
2. Connect a test signal generator.

If there is no test signal generator, use the test signals generate inside the unit. Press the W/B GAIN key, select 100 IRE White, then select 10 IRE with W/B BIAS key.


3. Press the ON/OFF key on the W/B checker.

Buttons on the Display Unit




4. Press the FUNCTION key of the W/B checker, select “White reference” with ▲, ▼ keys, then press the ENTER key.

FUNCTION




5. Select “1: fty. Ref” from the “White reference” menu with ▲, ▼ keys, then press the ENTER key.



6. Press the RGB key, select “R&B/G” with ▲, ▼ keys, then press the ENTER key.


RGB key function



7. Color temperature and bars indications of the W/B checker are as follows:

Color Temp.	R	G	B	x	y
9300	50	100	60	0.283	0.297
6500	60	100	40	0.313	0.329
5400	60	100	30	0.335	0.349
3200	90	100	10	0.427	0.408

Unit: mm



Bars display

3-6-2. Color Temperature Adjustment with a Test Signal Generator

■ Color Temperature 9300 °K Adjustment

1. Turn on the power and warm up for about 20 minutes.
2. Input the 100 IRE White signal to the VIDEO IN connector.
3. Press the W/B GAIN key, and select "9300" with POSITION +/- keys.
4. Press the PATTERN key several times to select the 100 IRE White signal input at VIDEO IN connector.
5. Press the ADJ G key to set the GREEN adjustment mode, and adjust the gain for maximum.
6. Press the STATUS OFF key to erase the characters displayed on the screen.
7. Attach the Lens-ball of the W/B checker to VPH-G90's lens.

[Gain Adjustment (100 IRE)]

Note: Normally, the maximum green bars indication is 200 %; however, it becomes 100 % in GREEN adjustment mode.

8. Press the ADJ B key to set the BLUE adjustment mode.
9. Press the W/B GAIN key. Adjust the blue gain for 60 % with ←, → keys. If not, decrease the green gain with arrow keys.
10. Press the ADJ R key to set the RED adjustment mode. Adjust the red gain for 50 % with ←, → keys.

[Bias Adjustment (10 IRE)]

11. Input the 10 IRE White signal to the VIDEO IN connector.
12. Press the ADJ G key to set the GREEN adjustment mode.
13. Press the W/B BIAS key. Press the CUT OFF R and B keys, then adjust the Y level for 180 % with ←, → keys.
14. Press the ADJ B key to set the BLUE adjustment mode. Adjust the blue gain for 60 % with ←, → keys.
15. Press the ADJ R key to set the RED adjustment mode. Adjust the red gain for 50 % with ←, → keys.
16. Repeat steps 8 to 10 and steps 11 to 15 several times.
17. Press the MEMORY key.
18. Remove the lens-ball attached in step 7.

■ Color Temperature 6500 °K Adjustment

1. Input the 100 IRE White signal to the VIDEO IN connector.
2. Press the W/B GAIN key, and select "6500" with POSITION +/- keys.
3. Press the PATTERN key several times to select the 100 IRE White signal input at VIDEO IN connector.
4. Press the ADJ G key to set the GREEN adjustment mode, and adjust the gain for maximum.
5. Press the STATUS OFF key to erase the characters displayed on the screen.
6. Attach the Lens-ball of the W/B checker to VPH-G90's lens.

[Gain Adjustment (100 IRE)]

Note: Normally, the maximum green bars indication is 200 %; however, it becomes 100 % in GREEN adjustment mode.

7. Press the ADJ B key to set the BLUE adjustment mode.
8. Press the W/B GAIN key. Adjust the blue gain for 40 % with ←, → keys. If not, decrease the green gain with arrow keys.
9. Press the ADJ R key to set the RED adjustment mode. Adjust the red gain for 60 % with ←, → keys.

[Bias Adjustment (10 IRE)]

10. Input the 10 IRE White signal to the VIDEO IN connector.
11. Press the ADJ G key to set the GREEN adjustment mode.
12. Press the W/B BIAS key. Press the CUT OFF R and B keys, then adjust the Y level for 180 % with ←, → keys.
13. Press the ADJ B key to set the BLUE adjustment mode. Adjust the blue gain for 40 % with ←, → keys.
14. Press the ADJ R key to set the RED adjustment mode. Adjust the red gain for 60 % with ←, → keys.
15. Repeat steps 7 to 9 and steps 10 to 14 several times.
16. Press the MEMORY key.
17. Remove the lens-ball attached in step 6.

■ Color Temperature 5400 °K Adjustment

1. Input the 100 IRE White signal to the VIDEO IN connector.
2. Press the W/B GAIN key, and select "5400" with POSITION +/- keys.
3. Press the PATTERN key several times to select the 100 IRE White signal input at VIDEO IN connector.
4. Press the ADJ G key to set the GREEN adjustment mode, and adjust the gain for maximum.
5. Press the STATUS OFF key to erase the characters displayed on the screen.
6. Attach the Lens-ball of the W/B checker to VPH-G90's lens.

[Gain Adjustment (100 IRE)]

Note: Normally, the maximum green bars indication is 200 %; however, it becomes 100 % in GREEN adjustment mode.

7. Press the ADJ B key to set the BLUE adjustment mode.
8. Press the W/B GAIN key. Adjust the blue gain for 30 % with ←, → keys.
9. Press the ADJ R key to set the RED adjustment mode. Adjust the red gain for 60 % with ←, → keys.

[Bias Adjustment (10 IRE)]

10. Input the 10 IRE White signal to the VIDEO IN connector.
11. Press the ADJ G key to set the GREEN adjustment mode.
12. Press the W/B BIAS key. Press the CUT OFF R and B keys, then adjust the Y level for 180 % with ←, → keys.
13. Press the ADJ B key to set the BLUE adjustment mode. Adjust the blue gain for 30 % with ←, → keys.
14. Press the ADJ R key to set the RED adjustment mode. Adjust the red gain for 60 % with ←, → keys.
15. Repeat steps 7 to 9 and steps 10 to 14 several times.
16. Press the MEMORY key.
17. Remove the lens-ball attached in step 6.

■ Color Temperature 3200 °K Adjustment

1. Input the 100 IRE White signal to the VIDEO IN connector.
2. Press the W/B GAIN key, and select "3200" with POSITION +/- keys.
3. Press the PATTERN key several times to select the 100 IRE White signal input at VIDEO IN connector.
4. Press the ADJ R key to set the RED adjustment mode, and adjust the gain for maximum.
5. Press the STATUS OFF key to erase the characters displayed on the screen.
6. Attach the Lens-ball of the W/B checker to VPH-G90's lens.

[Gain Adjustment (100 IRE)]

Note: Normally, the maximum green bars indication is 200 %; however, it becomes 100 % in GREEN adjustment mode.

7. Press the ADJ R key to set the RED adjustment mode.
8. Press the W/B GAIN key. Adjust the red gain for 90 % with ←, → keys.
9. Press the ADJ B key to set the BLUE adjustment mode. Adjust the blue gain for 10 % with ←, → keys.

[Bias Adjustment (10 IRE)]

10. Input the 10 IRE White signal to the VIDEO IN connector.
11. Press the ADJ G key to set the GREEN adjustment mode.
12. Press the W/B BIAS key. Press the CUT OFF R and B keys, then adjust the Y level for 180 % with ←, → keys.
13. Press the ADJ B key to set the BLUE adjustment mode. Adjust the blue gain for 10 % with ←, → keys.
14. Press the ADJ R key to set the RED adjustment mode. Adjust the red gain for 90 % with ←, → keys.
15. Repeat steps 7 to 9 and steps 10 to 14 several times.
16. Press the MEMORY key.
17. Remove the lens-ball attached in step 6.

3-6-3. Color Temperature Adjustment with No Test Signal Generator

■ Color Temperature 9300 °K Adjustment

1. Turn on the power and warm up for about 20 minutes.
2. Press the W/B GAIN key, and select "9300" with POSITION +/- keys.
3. Press the PATTERN key twice to select the internal 100 IRE White signal.
4. Press the ADJ G key to set the GREEN adjustment mode, and adjust the gain for maximum.
5. Press the STATUS OFF key to erase the characters displayed on the screen.
6. Attach the Lens-ball of the W/B checker to VPH-G90's lens.

[Gain Adjustment (100 IRE)]

Note: Normally, the maximum green bars indication is 200 %; however, it becomes 100 % in GREEN adjustment mode.

7. Press the ADJ B key to set the BLUE adjustment mode.
8. Press the W/B GAIN key. Adjust the blue gain for 60 % with ←, → keys. If not, decrease the green gain with arrow keys.
9. Press the ADJ R key to set the RED adjustment mode. Adjust the red gain for 50 % with ←, → keys.

[Bias Adjustment (10 IRE)]

10. Press the ADJ G key to set the GREEN adjustment mode.
11. Press the W/B BIAS key.
12. Press the PATTERN key twice to select the internal 10 IRE White signal.
13. Adjust the Y level for 180 % with ←, → keys.
14. Press the ADJ B key to set the BLUE adjustment mode. Adjust the blue gain for 60 % with ←, → keys.
15. Press the ADJ R key to set the RED adjustment mode. Adjust the red gain for 50 % with ←, → keys.
16. Repeat steps 7 to 9 and steps 10 to 15 several times.
17. Press the MEMORY key.
18. Remove the lens-ball attached in step 6.
19. Perform adjustment of 6500 °K/5400 °K/3200 °K in the same manner of above.

3-7. SIZE/SHIFT BLKG ADJUSTMENT

3-7-1. SIZE/SHIFT/BLKG of Video/HDTV Adjustment


1. Input the monoscope signal to VIDEO IN.
2. Press the INPUT SELECT VIDEO key to project the monoscope signal on the screen.
3. Press the RGB SHIFT key and adjust the center of the monoscope signal to the screen center using the ↑, ↓, ← and → keys.
4. Press the RGB SIZE key and adjust the horizontal and vertical sizes of the monoscope signal using the ↑, ↓, ← and → keys.
5. Press the BLKG key to adjust the screen top blanking to the position 40 ± 10 mm outside the effective screen using ↑ and ↓ keys.
6. Press the MEMORY key.
7. Input the HDTV monoscope signal to INPUT A.
8. Press the MENU key and select Initial Setting 1, then select HDTV-YPBPR from INPUT A.
9. Select INPUT A to project the HDTV monoscope signal on the screen.
10. Press the RGB SHIFT key and adjust the center of the monoscope signal to the screen center using the ↑, ↓, ← and → keys.
11. Press the RGB SIZE key and adjust the horizontal and vertical sizes of the monoscope signal using the ↑, ↓, ← and → keys.
12. Press the BLKG key to adjust the screen top blanking to the position 40 ± 10 mm outside the effective screen using ← and → keys.
13. Press the MEMORY key.
14. Press the MENU key and select Initial Setting 1, then select RGB from INPUT A.

3-7-2. Video Memory SIZE/SHIFT/BLKG Adjustments

1. Input the monoscope signal to VIDEO IN.
2. Press the INPUT SELECT VIDEO key to project the monoscope signal on the screen.
3. Select VIDEO MEMORY 1 using the SWITCHER/VIDEO MEMORY/INDEX changing switch and the SWITCHER/VIDEO MEMORY/INDEX key.
4. Press the RGB SHIFT key and adjust the center of the monoscope signal to the screen center using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
5. Press the RGB SIZE key and adjust the horizontal and vertical sizes of the monoscope signal to 4:3 using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
6. Press the BLKG key to adjust the screen top blanking to the position 40 ± 10 mm outside the effective screen using $\uparrow$ and $\downarrow$ keys.
7. Press the MEMORY key.
8. Store the data of VIDEO MEMORY 1 to VIDEO MEMORY 2 to 5, too.
9. Select VIDEO MEMORY 6.
10. Press the RGB SHIFT key and adjust the center of the monoscope signal to the screen center using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
11. Press the RGB SIZE key and adjust the horizontal and vertical sizes of the monoscope signal to 4:3 using the $\uparrow$, $\downarrow$, $\leftarrow$ and $\rightarrow$ keys.
12. Press the BLKG key to adjust the screen top blanking to the position 40 ± 10 mm outside the effective screen using $\leftarrow$ and $\rightarrow$ keys.
13. Store the data of VIDEO MEMORY 6 to VIDEO MEMORY 7–10, too.

3-8. HIGH VOLTAGE SCREEN DISTORTION ADJUSTMENT

1. Select INPUT A and input the fH = 64 kHz RGB stripe signal to the RGB terminals.
2. Press CONTR (+) and BRIGHT (+) to set the contrast and bright levels to the maximum.
3. Adjust RV1 of the EA board so that the left and right vertical lines of the stripes can be straight.



3-9. PROCEDURE AFTER COMPLETING ADJUSTMENTS

After completing all adjustment, change the dip switch S201-1 on the YA board from “OFF (right)” to “ON (left)” to save the adjustment data in the memory.

SECTION 4

SAFETY RELATED ADJUSTMENT

Note: When the following parts (☒ and ☐ on the schematic diagrams) has been replaced, check and adjust the HV regulation circuit and HV hold down circuit.

PA board

- ☒ components RV100, RV250
- ☐ components C607, C608, C610, C611, C155, C157, C250
R109, R111, R112, R114, R117, R118, R104, R105, R106, R107, R108, R120, R121, R157, R158, R250, R251, R252, R253, R256, R257, R258, R259, R260
RV101, RV150
D252, D253
IC101, IC102, IC100, IC152, IC153, IC250, IC251
L601, L602, L603, L604
PH500

CDR board

- ☒ component RV965
- ☐ components R960, R967, R971, R972, R973, R974, R975, R1007
D960, D965
IC961, IC971, IC990

CDG board

- ☒ component RV965
- ☐ components R960, R967, R971, R972, R973, R974, R975, R1007
D960, D965
IC961, IC971, IC990

CDB board

- ☒ component RV965
- ☐ components R960, R967, R971, R972, R973, R974, R975, R1007
D960, D965
IC961, IC971, IC990

PB board

- ☐ components FBT10, FBT11

BA board


- ☐ components R839, R841, R847, R855, R848, R870, R873, R872, R877, R876
D806
IC804

Note: When the power supply block has been replaced, check that the +B MAX voltage is within 200 ± 2 V.

4-1. PA BOARD HV REGULATOR/HV PROTECTOR ADJUSTMENT


Note: The electric power (+200 V) remains on the PA board for several minutes after even turning off the unit power. When withdrawing PA board from the unit, check that the voltage of TP600 (+200V HV) has dropped. In case of hurry, it may be allowed to discharge with the resistance of approx. $1 \text{ k}\Omega/3 \text{ W}$. In that case, withdraw the PA board after checking the power voltage.

1. Connect the cable from the high voltmeter with the output terminals of the chassis and the CRT (B) on HV block.




2. Input the monoscope signal.
3. Set CONTR to MAX by pressing the CONTR (+) key, then set BRIGHT to MAX by pressing the BRIGHT (+) key.
4. Rotate RV100 (HV.REG) of the PA board slowly to the right (clockwise) and adjust the high voltage to 34 kV.
High voltage specification during HV.PROT adjustment: $34 \pm 0.3 \text{ kV}$
5. Rotate RV250 (HV.PROT) slowly to the left (counterclockwise) and stop when LED (D251) is lit. (In several second HV drops, then the power goes OFF.)
6. Cover RV250 with a rotation stopper cap and apply RVT to fix it.
7. Rotate RV100 to the left a little to turn the power ON.
8. Rotate RV100 slowly to the right and check that the power goes OFF at the high voltage of 34 kV.
* If the specifications are not satisfied, perform Steps 4 to 8 again.
9. Rotate RV100 to the left a little to turn the power ON.
10. Press the MUTING PIC key on the remote commander to set to CUT OFF.

11. Adjust RV100 to set the high voltage to 33 kV.
High voltage adjustment specification (during CUTOFF): 33.0 ± 0.3 kV
12. Turn OFF the power, and cover RV250 with a rotation stopper cap and apply RVT to fix it.
13. Turn ON the power, and check that the high voltage is within the specification.
High voltage adjustment specification (during CUTOFF): 33.0 ± 0.3 kV
14. Check that the high voltage variation when the CONTR and BRIGHT are set to MIN and set to MAX using the remote commander is within the specification.
High voltage variation specification: $+0.2/-0.3$ kV
* If the specifications are not satisfied, perform Steps 10 to 13 again.
* When readjusting RV100 and RV250, replace the VR and rotation stopper caps before readjustment.
15. Set CONTR and BRIGHT to 80 and 50 respectively using the remote commander.



4-2. CRT PROTECTOR ADJUSTMENT

1. Connect a variable current source (3.5 mA to 4.5 mA) between the cathode terminal (pin 8 of CRT socket) of the CBR (CBG and CBB) board and B +12 V line of the CDR (CDG and CDB) board.
2. Connect a pull-up resistor (4.7 k Ω) between pin 3 of CN244 (CN264 and CN284) and +5 V line of the CDR (CDG and CDB) board, then connect an oscilloscope to it.
3. Gradually raise the output of the variable current source, and adjust RV965 of the CAR (CAG and CAB) board so that the waveform on the oscilloscope changes from "High" to "Low" level at 3.9 ± 0.1 mA.



SECTION 5

CIRCUIT ADJUSTMENTS

Perform this section only when the components of each board have been replaced. When the completed board had been replaced, the following adjustments will not be required.

5-1. POWER BLOCK

5-1-1. DC (+) Adjustment

1. Remove the GA board, and connect it back through the extension board.
2. Connect a digital voltmeter to pin 1 and pin 3 of CN11 of the GA board.
3. Adjust RV101 on the GAA board of CN14 side so that the voltage becomes the following specification.
Specification: 375 ± 2 V
4. Connect a digital voltmeter to pin 6 and pin 4 of CN11 of the GA board.
5. Adjust RV101 on the GAA board of CN15 side so that the voltage becomes the following specification.
Specification: 375 ± 2 V

5-1-2. +115 V Adjustment

1. Remove the GB board, and connect it back through the extension board.
2. Connect a digital voltmeter to pin 2 and pin 6 of CN34 of the GB board.
3. Adjust RV403 on the GBB board so that the voltage becomes the following specification.
Specification: 116 ± 0.5 V

5-1-3. +200 V Adjustment

1. Remove the GB board, and connect it back through the extension board.
2. Connect a digital voltmeter to pin 1 and pin 6 of CN34 of the GB board.
3. Adjust RV404 on the GBB board so that the voltage becomes the following specification.
Specification: 200 ± 1.0 V


5-1-4. Oscillating Frequency Adjustment

1. Remove the GB board, and connect it back through the extension board.
2. Connect a frequency counter to the gate terminal of Q6 of the GB board.
3. Adjust RV201 on the GBA board so that the frequency becomes the following specification.
Specification: 85 ± 2 kHz
4. Connect a frequency counter to the gate terminal of Q10 of the GB board.
5. Adjust RV202 on the GBA board so that the frequency becomes the following specification.
Specification: 95 ± 2 kHz
6. Connect a frequency counter to the gate terminal of Q8 of the GB board.
7. Adjust RV402 on the GBB board so that the frequency becomes the following specification.
Specification: 85 ± 2 kHz
8. Connect a frequency counter to the gate terminal of Q12 of the GB board.
7. Adjust RV401 on the GBB board so that the frequency becomes the following specification.
Specification: 100 ± 2 kHz


5-2. BA BOARD ADJUSTMENT

5-2-1. Picture Control Adjustment

1. Connect an oscilloscope to TP1612 of the BA board.
2. Connect a communication controller to the RS-422A connector of the YA board.
Note: Be sure to set this unit and the communication controller to the same baud rate.
3. Turn the power on.
4. Input the NTSC 100 % color bars signal.
5. Change the PICTURE (SUB PICTURE) data of CXA2101Q (IC1600) with a communication controller. Set the level "A (from the pedestal to 100 IRE)" so that it is closest value to 0.700 Vp-p.
6. Change the BRIGHT (SUB BRIGHT) data of CXA2101Q (IC1600) with a communication controller. Set the level "B" so that it is closest value to zero volt.



7. Input the NTSC 75 % color bars signal.
8. Change the SUB-COL (NT3.58EXB OFF) data and SUB-HUE (NT3.58) data of CXA2101Q (IC1600) with a communication controller. Set the levels "A, B, C, and D" so that they are visibly equal in amplitude.




9. Input the SUB-COL (NT3.58EXB OFF) data adjusted in step 8 to SUB-COL (NT3.58EXB ON).
10. Input the PAL 75% color bars signal.
11. Change the SUB-COL (PALEXB OFF) data and SUB-HUE (PAL) data of CXA2101Q (IC1600) with a communication controller. Set the levels "A, B, C, and D" so that they are visibly equal in amplitude.
12. Input the same data as SUB-COL (PAL EXB OFF) adjusted in step 11 to SUB-COL (SECAM EXB OFF), SUB-COL (NT4.43EXB OFF), SUB-COL (PAL-M EXB OFF), SUB-COL (PAL EXB ON), SUB-COL (SECAM EXB ON), SUB-COL (NT4.43 EXB ON), and SUB-COL (PAL-M EXB ON).

13. Input the same data as SUB-HUE (PAL) adjusted in step 11 to SUB-HUE (SECAM), SUB-HUE (4.43), SUB-HUE (PAL-M), SUB-HUE (RGB), SUB-HUE (15kRGB), SUB-HUE (YPbPr), SUB-HUE (RGB), and SUB-HUE (IDTV).
14. Press the MEMORY key.

5-2-2. Signal Level Adjustment


1. Input the 10-STEP signal to VIDEO IN.
2. Set the CONTR and GAIN of each color to maximum position.
3. Connect 75 Ω resistor between pin-A/B/C16 (RED OUT) of connector CN341 on the BA board to ground. Connect 75 Ω resistors between pin-A/B/C18 (GREEN OUT) and ground, and pin-A/B/C20 (BLUE OUT) and ground of connector CN341 on the BA board to ground.
4. Short-circuit between pin-B26 (ABL) of CN 340 on the BA board and ground.
5. Adjust RV502 (R), RV503 (G), and RV504 (B) on the BA board in sequence so that the amplitude of R, G, and B levels become 2 ± 0.05 V.
6. Adjust RV501 on the BA board so that the sync level of GREEN OUT signal becomes the same level as pedestal level. Check to see that the sync levels of RED OUT and BLUE OUT signals are within the pedestal level.



Note: Adjust the sync level so that it becomes the same level as pedestal level. If the sync level fluctuates, stop RV501 where it is stable position.

5-2-3. Analog Test Signal Amplitude Adjustment

1. Press the GAIN key to output the analog test signal.
2. Connect an oscilloscope to pin 4 of IC208 on the BA board.
3. Adjust RV200 on the BA board so that the level of analog signal meets the following specification.



Specification: $B = 0.7 \pm 0.02 \text{ V}$

5-2-4. ABL Adjustment


1. Receive the white signal.
2. Set the CONTR, BRIGHT, and GAIN to the maximum position.
3. Connect a digital voltmeter to base of Q813 on the BA board. Adjust RV800 so that the voltage is $-3.34 \pm 0.05 \text{ V}$.

5-3. CAR/CAG/CAB BOARDS ADJUSTMENT

5-3-1. Preparation Before Adjustments

1. Input the following signal.


Specification	fH:	64 kHz
	fV:	60 Hz
	Amplitude:	$0.7 \pm 0.01 \text{ V}$
	Sync:	off



2. Remove the CAR/CAG/CAB boards and CDR/CDG/CDB board in sequence, and connect it back through the extension board.

5-3-2. Pedestal Level Adjustment

1. Connect an oscilloscope to TP511.
2. Adjust the pedestal level by RV145.





5-3-3. CRT Protector Adjustment

1. Connect a variable current source (3.5 mA to 4.5 mA) between the cathode terminal (pin 8 of CRT socket) of the CBR (CBG and CBB) board and B +12 V line of the CDR (CDG and CDB) board.
2. Connect a pull-up resistor (4.7 kΩ) between pin 3 of CN244 (CN264 and CN284) and +5 V line of the CDR (CDG and CDB) board, then connect an oscilloscope to it.
3. Gradually raise the output of the variable current source, and adjust RV965 of the CAR (CAG and CAB) board so that the waveform on the oscilloscope changes from "High" to "Low" level at $3.9 \pm 0.1 \text{ mA}$.


5-3-4. Cathode Level Adjustment

1. Apply the following voltages to CN244 (CN264 and CN284) of the CDR (CDG and CDB) board:
CN244/CN264/CN284 Pin 1: $+175 \pm 1$ V
CN244/CN264/CN284 Pin 10: $+115 \pm 0.5$ V
2. Connect an oscilloscope to TP1201 on the CBR (CBG and CBB) board, and adjust RV1223 so that the voltage becomes 113 ± 0.5 V.
3. Connect an oscilloscope to base terminal of Q948 on the CDR (CDG and CDB) board, and adjust RV785 on the CAR (CAG and CAB) board so that the peak section of the black level becomes 109 ± 0.5 V.
4. Adjust RV718 so that the amplitude of white peak section becomes 13 ± 0.2 V.




5-3-5. G1 Level Adjustment


1. Connect an oscilloscope to the plus (+) terminal of capacitor C820 on the CDR (CDG and CDB) board, and adjust RV682 so that the black level becomes 12 ± 0.2 V.



2. Connect an oscilloscope to TP891 of the CDR (CDG and CDB) board, and adjust RV623 so that the white peak section of the waveform doesn't clip.



3. Connect an oscilloscope to TP891 on the CDR (CDG and CDB) board. Make sure that the peak section of the waveform clips when turn RV622 on the CAR (CAG and CAB) board counterclockwise. Turn RV622 gradually clockwise and stop it just before the limiter circuit works.



5-3-6. VPS Limiter Adjustment

Note: Be sure to perform this adjustment when increasing Contrast and if there is VPS (Video Peak Saturation) on the screen.

1. Input the signal which contains VPS components.
2. Set the unit in the EXPERT MODE.
3. Set the unit in SERVICE SETTING3/DEVICE CONTROL/VPS LIMITER mode, then press the ENTER key.
4. Cut off the color which is no VPS. If there are VPS on two or three colors, perform adjustment color by color.
5. Set the CONTR to maximum position.
6. Decrease the data value until the VPS disappears.
7. After the adjustment, press the MEMORY key.

5-4. DA/DB/DD BOARDS ADJUSTMENTS

5-4-1. F/V Voltage Adjustment (DA Board)

1. Input the signal of its horizontal frequency (fH) is 64 kHz to R/G/B INPUT connectors.
2. Connect a digital voltmeter to TP104.
3. Adjust RV101 so that the voltage at TP104 is 3 ± 0.05 V.

5-4-2. AFC Adjustment (DA Board)

1. Set the HD OFF switch (S102) to "OFF" position.
2. Input the signal of its horizontal frequency (fH) is 64 kHz to R/G/B INPUT connectors.
3. Adjust RV104 to lock the horizontal sync properly on the screen.
4. Input the signal of its horizontal frequency (fH) is 150 kHz.
5. Adjust RV103 to lock the horizontal sync properly on the screen.
6. Input the video signal to the VIDEO INPUT connector.
7. Adjust RV105 to lock the horizontal sync properly on the screen.
8. Set the HD OFF switch (S102) to "ON" position.
9. Input the 15.75 kHz, 30 kHz, 64 kHz, 100 kHz, and 150 kHz signals in sequence, and make sure that the horizontal sync is locked properly.


5-4-3. V Hold Adjustment (DA Board)

1. Connect a frequency counter or oscilloscope to pin-C11 (V.TRIGGER) of connector CN170 or pin 12 of IC110.
2. Input the signal of its vertical frequency (fV) is 60 Hz to R/G/B INPUT connectors or VIDEO INPUT connector.
3. Set the V SYNC OFF switch (S101) to "OFF" position.
4. Adjust RV102 so that the frequency is 50 Hz (or one vertical period is 20 msec.).
5. Set the V SYNC OFF switch (S101) to "ON" position.
6. Input the 38 Hz, 50 Hz, 60 Hz, 100 Hz, and 150 Hz signals in sequence, and make sure that the vertical sync is locked properly.

5-4-4. H Parabola Waveform Adjustment (DA Board)


1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "240."
3. Set the data value of V SIZE COARSE to "maximum."
4. Connect an oscilloscope to TP402.
5. Adjust RV301 so that A section of a waveform is identical with B section.

Specification: A level = B level



6. Adjust RV302 so that C section of a waveform is 0 ± 0.01 V dc.

Specification: C level = 0 ± 0.01 V dc



7. Repeat steps 5 and 6 until satisfy the specifications.

5-4-5. H SIN Adjustment (DA Board)


1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "240."
3. Set the data value of V SIZE COARSE to "maximum."
4. Connect an oscilloscope to TP403.
5. Adjust RV402 so that A section of a waveform is identical with B section.

Specification: A level = B level

6. Adjust RV403 so that voltage of A and B sections are 0 ± 0.01 V dc.


Specification: A and B voltages = 0 ± 0.01 V dc

7. Repeat steps 5 and 6 until satisfy the specifications.




5-4-6. H SIN x VP Waveform Adjustment (DB Board)

1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "250."
3. Set the data value of V SIZE COARSE to "180."
4. Connect an oscilloscope to TP102.
5. Adjust RV202 so that A section of an envelope waveform is 0 V.



5-4-7. H SIN × V SIN Waveform Adjustment (DB Board)


1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "250."
3. Set the data value of V SIZE COARSE to "180."
4. Connect an oscilloscope to TP101.
5. Adjust RV102 so that A and B sections of a waveform become even with C section as shown in the figure.



6. Adjust RV101 so that C section of a waveform is 0 V.

5-4-8. HS × VS Waveform Adjustment (DB Board)


1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "250."
3. Set the data value of V SIZE COARSE to "180."
4. Connect an oscilloscope to TP104.
5. Adjust RV402 so that A and B sections of a waveform become even with C section as shown in the figure.



6. Adjust RV401 so that C section of a waveform is 0 V.

5-4-9. HP × V SIN Waveform Adjustment (DB Board)


1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "250."
3. Set the data value of V SIZE COARSE to "180."
4. Connect an oscilloscope to TP301.
5. Adjust RV302 so that A section of a waveform become even with B section as shown in the figure.



6. Adjust RV301 so that B section of a waveform is 0 V.

5-4-10. 1/2 SIN1 Waveform Adjustment (DB Board)


1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "250."
3. Set the data value of V SIZE COARSE to "180."
4. Connect an oscilloscope to TP702.
5. Adjust RV703 so that A section of a waveform become even as shown in the figure.



6. Adjust RV704 so that A section is 0 V.

5-4-11. 1/2 SIN2 Waveform Adjustment (DB Board)


1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "250."
3. Set the data value of V SIZE COARSE to "180."
4. Connect an oscilloscope to TP701.
5. Adjust RV701 so that A section of a waveform become even as shown in the figure.



6. Adjust RV702 so that A section is 0 V.

5-4-12. HS x VS Waveform Adjustment (DB Board)


1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "250."
3. Set the data value of V SIZE COARSE to "180."
4. Connect an oscilloscope to TP601.
5. Adjust RV601 so that A section of a waveform become even as shown in the figure.



6. Adjust RV602 so that A section is 0 V.

5-4-13. HP x VS Waveform Adjustment (DB Board)


1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "250."
3. Set the data value of V SIZE COARSE to "180."
4. Connect an oscilloscope to TP602.
5. Adjust RV603 so that A section of a waveform become even as shown in the figure.



6. Adjust RV604 so that A section is 0 V.


5-4-14. B KEY Waveform Adjustment (DB Board)

1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "250."
3. Set the data value of V SIZE COARSE to "180."
4. Connect an oscilloscope to TP502.
5. Adjust RV502 so that A section is 0 V.




5-4-15. T KEY Waveform Adjustment (DB Board)

1. Input the signal of its frequency is 64 kHz.
2. Set the data value of H SIZE COARSE to "250."
3. Set the data value of V SIZE COARSE to "180."
4. Connect an oscilloscope to TP501.
5. Adjust RV501 so that A section is 0 V.



5-4-16. 1/2H Switching Waveform Adjustment (DA/DB Boards)

1. Input the signal of its frequency is 15 kHz.
2. Connect an oscilloscope to TP501 on the DB board.
3. Adjust RV303 on the DA board so that the switching point (A) coincides with 0V cross-point as shown in the figure.



5-4-17. D/A Converter Offset Adjustment (DD Board)

1. Pull out the DB board, then inset the extension board instead. Short-circuit pins B32 and C32 of the extension board's connector with a jumper wire.
2. Short-circuit both ends of capacitors C136 and C342 on the DD board with a jumper wires respectively.
3. Turn on the power.
4. Adjust RV301 so that the voltage at pin-A5 of CN211 is 0 ± 0.01 Vdc.
5. Adjust RV302 so that the voltage at pin-A3 of CN211 is 0 ± 0.01 Vdc.
6. Adjust RV303 so that the voltage at pin-A1 of CN211 is 0 ± 0.01 Vdc.
7. Adjust RV304 so that the voltage at pin-A11 of CN211 is 0 ± 0.01 Vdc.
8. Adjust RV305 so that the voltage at pin-A9 of CN211 is 0 ± 0.01 Vdc.
9. Adjust RV306 so that the voltage at pin-A7 of CN211 is 0 ± 0.01 Vdc.

5-5. VCO OFFSET/LIMITER ADJUSTMENT

Note: The electric power (+200 V) remains on the PA board for several minutes after even turning off the unit power. When withdrawing the PA board from the unit, check that the voltage of TP600 (+200 HV) has dropped. In case of hurry, it may be allowed to discharge with the resistance of approximately 1 k Ω /3 W. In that case, withdraw the PA board after checking the power voltage.

1. Turn off the power of the unit, then disconnect CN87 from the PA board.
2. Connect an oscilloscope to TP152 (HVDRV), and connect a voltmeter to TP151 (VCO IN) on the PA board.
3. Turn on the power of the unit.
4. Adjust RV101 (VCO LIMIT VOL) on the PA board so that the voltage at TP151 is 2.00 $\pm$ 0.01 V.
5. Adjust RV150 (VCO RANGE) on the PA board so that the pulse width at TP152 is 54.5 $\pm$ 0.1 kHz
6. Adjust RV101 (VCO LIMIT VOL) on the PA board so that the voltage at TP151 is 1.70 $\pm$ 0.01 V.
7. Turn off the power of the unit, then remove the oscilloscope and voltmeter from the PA board.
8. Connect CN87 connected in step 1.

5-6. YA BOARD REPLACEMENT

5-6-1. Replacement Procedure

1. Remove the defective YA board
Remove IC233, IC333, and IC334 from the YA board removed, and attach all to the new YA board.
 - * IC233 : Boot program/Uploader program
 - IC333 : User data save
 - IC334 : Factory data save/Service data save/User data back up
2. During this time, be careful of the direction for attaching the ICs, and make sure no pins are bent, etc.
3. Set the rotary switches of the new board to the same value as the old board.
 - * IC233 : Need not be replaced if the Ver. No. on the ROM is the same.
4. Attach the new board to the unit and check operations. If normal, the 7-segment LED on the YB board should change as follows when AC is turned ON.
 - Red : 88 (Approx. 0.5 seconds) $\rightarrow$ Orange : 88 (Approx. 1.0 second) $\rightarrow$ Off
5. If images are displayed correctly when the power is turned on, it means that the board was replaced successfully.
 - $\rightarrow$ Check the software version from the menu, upload the program as necessary if the version is old. Adjust the various data as necessary, and create and save the factory data and service data. (Refer to the next page for details on creating data.)

If the board operations appear abnormal;

- If an error code is displayed, follow the instructions.
- If the 7-segment LED of the YB board does not change from Red : 88.
 - $\rightarrow$ The CPU-bus may be abnormal. Check the short-circuit of each bus line.
- Other problems after turning on the power.
 - $\rightarrow$ Repair the circuit block with abnormal operations (See Block Diagram).

5-6-2. Uploading Program (Emergency Mode)

1. When the 7-segment LED of the YB board changes as follows when the AC is turned ON, the program upload mode will forcibly be set due to the abnormal program data inside. (Emergency mode)
Red : 88 (Approx. 0.5 seconds) → Orange : 88 (Approx. 1.0 seconds) → Green : 10 (blinks twice) → Green : 11 (communication standby)

2. Prepare to upload program.

Preparations : Set the S961 knob to the left.

(RS-232C ↔ RS-422A switch)

Connect the RS-232C controller.

3. Start the uploader software of the RS-232C controller, and start uploading the program data according to the proper procedure.

The 7-segment LED on the YB board changes as follows;

Green : 11 (loading) → Green : 12 (updating) → Green : 11 → Green : 12 → (repeated) → Green : ZF (Aoorix. 0.5 seconds) → Red : 88 (Approx. 0.5 seconds) → Orange : 88 (Approx. 1.0 seconds) → Off

4. Initialization ends after about 11 minutes.

→ If Green : 30 (Lit) lights up on the 7-segment LED of the YB board without going off, it means that the software is requesting initialization of the user SRAM. Press S202 for about 5 seconds in the Green : 30 (lit) state, and the 7-segment LED should change as follows.

Green : 30 → 31 (Approx. 0.1 seconds) → Off

End of initialization

* Take note that initializing the user SRAM erases all user data.


5. Turn on the power and check operations.

5-6-3. Creating Factory Data

To forcibly overwrite current factory data

1. Set S201-(1) to OFF in the AC OFF state.


→ Initial setting for entering the factory mode.



2. Perform AC ON, various adjustments, settings, data saving (user area).

3. In the AC ON state (or Standby state), set S201-(1) to ON.

→ The data will automatically be overwritten when the factory mode is exited.



4. The 7-segment LED changes from 38 lit to off.


* Duration of 38 lit is changed in accordance with data amount adjusted.

5. End of creating data

If data needs to be created again due to program version upgrading and parts replacement (IC334)

1. In the AC OFF state, set S201-(1) to OFF.


→ Initial setting for entering the factory mode.



2. Perform AC ON, various adjustments, settings, data saving (user area).

3. In the AC ON state (or Standby state), set S201-(1) to ON.

→ The data will automatically be overwritten when the factory mode is exited.



4. The 7-segment LED changes as follows;

37 (approx. 90 seconds) → 38 (approx. 40 seconds) → Off

5. End of creating data

5-6-4. Creating Service Data

To forcibly overwrite existing service data

1. Enter the service mode in the AC ON state, and perform various adjustments, settings, data saving (user area).
2. Set the normal state. (Nothing displayed on OSD)
3. Press the ENTER key for about 5 seconds.
→ As the message "Do you save all data as SERVICE DATA?" will be displayed on the OSD, select "YES."
4. The 7-segment LED changes from 35 lit to off.
* Duration of 35 lit is changed in accordance with the data amount adjusted.
5. End of creating data


If data needs to be created again due to program version upgrading and parts replacement (IC334)

1. Enter the service mode in the AC ON state, and perform various adjustments, settings, data saving (user area).
2. Set the normal state. (Nothing displayed on OSD)
3. Press the ENTER key for about 5 seconds.
→ As the message "Do you save all data as SERVICE DATA?" will be displayed on the OSD, select "YES."
4. The 7-segment LED changes as follows;
* 34 (approx. 90 seconds) → 35 (approx. 40 seconds) → Off
5. End of creating data


SECTION 6

SEMICONDUCTORS


AD826AR
MAX3085CSA-TG068




AD835AR
BA05FP-E2
BA09FP-E2
BA033FP-E2
CXA1211M
MAX4121CSA-TE2
MM1112XFF
NJM082BM-T1
NJM2240M
TC7W08F
TC7W241FU-TE12R
μPC393C




BA12FP-E2




CXA1450M
GS4981CTA
LM393PS
LM6361M
NJM2235M-TE2
NJM4200M
SN75157PS-ELL2000
TC4W53F
TC4W53FU
TL082ACP
TL082M
μPC358C
μPC393G2
μPC4558C
μPC4558G2




CXA1470AS
LM1283




CXA1726AM
CXA2119M




CXA1855Q




CXA2016S
TDA9141-N2C
μPC1377C




CXA3069S




CXA1875AM-T4
CXA8038P
MAX8213BCSE-TE2
MB86022PF
MC10H124M
MC74HC4053F
MC74HC4538F
MP7670AS-TE2
PCF8574T-T
SN74HC109ANS
SN74HC157ANS
TC74HC123AF
TC74HC4538AF
TC74VHC123AF
TC74VHC138F
TC74VHC139F
TC74VHC157F




CXD305-127R




CXA2101Q
CXD2024AQ
CXP846P48Q-1-004




CXD2309Q-T6




CXD8773R




DS1245Y-120




EPM7064STC44




EPM7128STC100




HD14538BFP
IDA4665T/V5-118
MC14572UBCP
MC74HC4053F
SN74LS123N
TC4040BP
μPC1394C



ICS1522MT
μPC659AGS-E2



IDT74FCT162245CTPA-TL




IDT71016S15Y-TL




(TOP VIEW)

IDT71024S15Y-TL




(TOP VIEW)

IDT71321SA55J-TL



(TOP VIEW)


LM35DZ




LM675T



LM2576T-12LB03



**LM2990SX
LM2990T-5.0**




**LM7912CT
NJM7912FA**




1:GND
2:OUT
3:IN

**MAX202ECSE-T
SN74HC08AN
SN74HC32ANS
SN74HC125ANS
TC74HCT08AF(EL)
TC74VHC14F
TC74VHC132F**




(TOP VIEW)

MAX489ECSD-TE2




(TOP VIEW)

**MAX4223ESA-TG06
MAX4224ESA-TG06**




(TOP VIEW)

MB90091APF-114




(TOP VIEW)

MBM29F800BA-70PFTN




MC10H125H




(TOP VIEW)

MC10H640FNR2




(TOP VIEW)

**LM2901M
LM324N
M51978P
MC1436CP1
MC1495BP
SN74LS624N
SN74HCU04ANS-E20
TLC2932IPW**



(TOP VIEW)

MC8639A




MARKING SIDE VIEW
•pin 1 ~ N
•Mt(one side, both side)


NJM78L05A



NJM78L12A




NJM79L05UA




NJM79L12A



NJM79M12DLA (TE1)




NJM2533M(TE2)



(TOP VIEW)

PC16552DV



(TOP VIEW)


PQ20VZ5U




**PST574C-T
PST575DMT-T1**




RH5VL43AA-T1



STK392




**SC7S04F
SC7S32F
TA75C558F
TC4S66F
TC7S08F
TC7S66F
TC7S86F-TE85L**




TA78M09F (TE16L)




**TA7812S
TA7820S
μPC2405HF**



**TC7W00F (TE12R)
TC7W04F
TC7WU04F**




**TC74HC541AF(EL)
TC74HCT541AF(EL)
TC74VHC245F**




TL431CLP




TLC5733AIPM




μPC319G2




μPC319G2-E2




μPC814G2-E2




μPC1093J-1-T




μPD6408GF-3BA



μPD65646GJ-252-8EU




μPD65654GC-327-3B6




**2SA1162-G
2SA1462-Y33
2SA1669-TB
2SC2712-YG
2SC3356-(R25)
2SC3545-T43
DTC114EK
DTC144EKA-T146**




**2SA1150-Y
2SA1175-HFE
2SC2785-HFE
DTC144ESA**




FMS1




FMS1A-T148



FMS2



**FMW1
FMW5**




TRANSISTOR, DIODE

IRFP350LF20



2SB734-34
2SD774-34



2SK160-K4
2SK160-K5




1SS184
DAN202K



IRFP460




2SB798-DL
2SC2954
2SD999-CLCK




2SK523-M1




1SS226
DA204K



2SD1878-CA
IRFI9620GS




2SC3356-R24



2SK817



DD50R



2SA1358-Y
2SC3421-Y



2SC4054N




1SS83
DFC15TR
EGP10D
ERA22-08
ERC91-02




2SC4630LS




DTZ-TE-17-2.7B
DTZ-TE-17-3.6B
DTZ-TT-11-3.3B
DTZ10B
DTZ4.7C
MA111
RD5.6SB



2SA1381-E
2SA1406-E
2SA1407-D
2SB772-Q
2SC2688-LK
2SC3503-DE
2SD882-P



2SD1590-L



ESAD39M-06C
F10P40F




2SA1804-RO
2SC4689N-RO
2SC5238-CB




2SJ143
2SK755
2SK929



1SS119-25
11EQS04
D1NL20U-TR
D1NS4
RB441Q-40T-77
RD2.2M-T1B
RD4.7ESB2
RD5.1ESB2
RD5.6ESBS
RD6.2ESB2
RD6.8SB2-T1
RD10ESB2
RD10M-B2
RD11ESB2
RD12ESB2
RD13ESB2
RD15ESB2
RD20ESB2
RD20M-B2
RD30ESB2
RU-1C




D8LC20UR
D10LC20U
D10SC6MR



D10SC6M
DD82RC-SONY



ERC88M-009




FCF10A60




IS2836




MA8039



MVR3368S



PY5504S-1




RBV-2506




RD3.3M-B2
RD4.7M-B2
RD5.1M-B2
RD12M-B1
RD12M-B2
RD15M-T1B2




RD12SB2




SB20-03P



SB30-03P-TD




SLR-54VC12




S16L60



V09G
V11N



1SR154-400TE-25



SECTION 7

EXPLODED VIEWS

NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.

- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by mark $\triangle$ are critical for safety. Replace only with part number specified.


Les composants identifiés par une marque $\triangle$ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

HOOD AND COVER BLOCK

7-1. HOOD AND COVER BLOCK

Ref.No.	Part No.	Description	Remark
1	* X-4036-168-2	HOOD ASSY	2—15
2	4-055-940-01	FASTENER	
3	4-055-953-01	RING, FASTENER	
4	* 4-067-664-01	DOOR, ADJUST	
5	* 4-067-772-01	HOLDER, HANDLE	
6	* 4-067-777-01	HOLDER, SPRING	
7	* 4-067-827-01	SPACER (H)	
8	* 4-067-774-01	HOOK (L), HOOD	
9	* 4-067-773-01	HOOK (R), HOOD	
10	* 4-067-778-01	SPACER, HOOD	
11	* 4-067-826-01	SPRING, EXTENSION	
12	4-314-843-02	SCREW, TAPPING, +4X12	
13	* 4-067-677-02	HINGE, DOOR	
14	* X-4036-165-1	COVER ASSY, COMMANDER	
15	4-069-146-01	HOLDER, HOOD	
16	4-067-823-01	SCREW (+PWH M4X12)	
17	* 4-067-676-01	FILTER, REAR	
18	* 4-067-775-01	HOLDER, REAR FILTER	
19	* 4-067-669-01	COVER, REAR	
20	3-701-810-91	SCREW, TERMINAL	
21	* X-4036-171-1	COVER (R) ASSY, SIDE	
22	* X-4036-170-1	COVER (L) ASSY, SIDE	
23	* 4-067-824-01	SPRING, FRONT	
24	* 4-067-776-01	HOLDER, FRONT	
25	* 4-067-825-01	FILTER, FRONT	
26	* 4-067-670-01	COVER, FRONT	
27	4-067-784-02	LEVER, ADJUST	
28	* 4-068-518-01	GASKET (RS)	

- ◇ : 7-682-663-09 +PSW4 × 12
 ⊕ : 7-682-964-01 +PSW4 × 14
 ● : 7-685-648-79 +BVTP3 × 12
 ⊕ : 7-685-660-79 +BVTP4 × 10




ED BLOCK

7-2. ED BLOCK

Ref.No.	Part No.	Description	Remark
51	1-418-090-11	REMOTE COMMANDER	
52	4-033-713-01	SCREW (+PWH M4X10), PREVENTION	
53	* 4-067-780-02	COVER, EC	
54	* 4-067-831-01	SPRING, EC	
55	* 4-056-414-01	BUSHING, SQUARE	
56	* X-4036-166-1	BRACKET ASSY, ED	57—62
57	* 4-067-841-01	HANDLE	
58	* 4-067-692-01	COVER (T), DC	
59	* 4-067-680-01	COVER (T), E	
60	* 4-067-788-01	LOCK, P	
61	* 4-067-787-01	STOPPER	
62	* 4-067-779-01	HINGE	
63	4-382-854-11	SCREW (M3X10), P, SW (+)	
64	* A-1346-772-A	E COMPL	
65	* 4-067-662-01	COVER (B), E	
66	* A-1346-771-A	ED COMPL	
67	* 4-067-678-01	LEVER, EC	
68	* 4-067-693-01	BRACKET, EC	
69	* A-1343-549-A	EC MOUNT	
70	1-771-559-11	SWITCH, TOGGLE	
71	1-771-560-11	SWITCH, TOGGLE	
72	* 4-067-679-02	COVER (B), EC	
73	* A-1346-773-A	DC COMPL	
74	* 4-067-690-01	COVER (B), DC	
75	* 4-068-518-01	GASKET (RS)	
76	* 4-068-519-01	GASKET (RT)	


- : 7-685-648-79 +BVTP3 × 12
- : 7-685-659-79 +BVTP4 × 8
- ▲ : 7-685-646-79 +BVTP3 × 8



HVF BLOCK

7-3. HVF BLOCK


- △ : 7-682-950-01 +PSW3 × 12
 ■ : 7-685-659-79 +BVTP4 × 8
 ▲ : 7-685-646-79 +BVTP3 × 8
 * : 7-685-768-01 +PTT4 × 30



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
101	△*A-1484-094-A	HVF (L) BLOCK ASSY	102—107	111	*4-067-653-01	COVER (R), FBT	
102	*4-067-652-01	HOLDER (L), FBT		112	1-900-242-16	CONNECTOR ASSY, HV (5)	
103	*4-067-649-01	COVER (L), FBT		113	△*A-1484-093-A	HVF (R) BLOCK ASSY	105—110
104	1-900-242-15	CONNECTOR ASSY, HV (4)		114	4-033-713-01	SCREW (+PWH M4X10), PREVENTION	
105	△1-453-108-32	DC BLOCK, HIGH-VOLTAGE		115	*A-1304-152-A	MD MOUNT	
106	4-373-137-01	CAP (Z), RUBBER		116	*A-1390-889-A	NB MOUNT	
107	△X-4033-245-1	TRANSFORMER ASSY, FLYBACK (FBT10, FBT11) (NX3031//J1S) (L=300)		117	*4-360-309-11	SUPPORT, PC BOARD	
108	△X-4034-326-1	TRANSFORMER ASSY, FLYBACK (L) (FBT11) (NX3031//J1W) (L=330)		118	*A-1195-144-A	PD COMPL	
109	△X-4034-325-1	TRANSFORMER ASSY, FLYBACK (R) (FBT10) (NX3031//J1X) (L=270)		119	*4-067-764-01	COVER (PA)	
110	*4-067-654-01	HOLDER (R), FBT		120	*A-1195-143-A	PA COMPL	
				121	4-057-640-01	COVER, VOLUME	
				122	*4-067-800-02	HOLDER (PA), FAN	
				123	1-763-229-11	FAN, DC	

7-4. CHASSIS BLOCK 1

☆ : 7-684-024-04 N4
 ☼ : 7-682-970-09 +PSW4 × 40
 ◆ : 7-682-962-01 +PSW4 × 10




Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
151	* 4-067-710-01	COVER (D), SHIELD		161	* 4-067-819-01	SPACER (CED)	
152	* A-1346-777-A	DF COMPL		162	* 4-067-705-01	SHIELD (TP), C	
153	* A-1346-776-A	DE COMPL		163	3-701-809-31	SCREW, TERMINAL (M3X3)	
154	* A-1346-775-A	DD COMPL		164	* 4-068-520-01	GASKET (C)	
155	* A-1346-778-A	DB COMPL		165	4-033-713-01	SCREW (+PWH M4X10), PREVENTION	
156	* A-1346-774-A	DA COMPL		166	* 4-067-706-01	HOLDER (C)	
157	* A-1343-563-A	EBH MOUNT		167	* A-1335-105-A	CR COMPL	
158	* 3-703-141-00	HOLDER, PWB		168	* A-1335-106-A	CG COMPL	
159	* A-1343-562-A	EBQ MOUNT		169	* A-1335-107-A	CB COMPL	
160	4-382-854-11	SCREW (M3X10), P, SW (+)		170	* 4-067-691-02	HOLDER, FAN	
				171	1-763-199-11	FAN, DC	

REAR BLOCK

7-5. REAR BLOCK

Ref.No.	Part No.	Description	Remark
201	* A-1195-142-A	PE COMPL	
202	* 3-701-903-11	HOLDER, PC BOARD	
203	* 3-703-141-00	HOLDER, PWB	
204	* A-1346-781-A	EBB COMPL	
205	* A-1346-780-A	EBG COMPL	
206	* A-1346-779-A	EBR COMPL	
207	* A-1316-410-A	GA COMPL	208
208	* A-1311-704-A	GAA MOUNT	
209	* A-1316-411-A	GB COMPL	210—212
210	* A-1311-707-A	GBB MOUNT	
211	* A-1311-687-A	GC MOUNT	
212	* A-1311-706-A	GBA MOUNT	
213	* A-1390-888-A	NA MOUNT	
214	* 4-067-709-01	COVER (EB)	
215	3-701-810-91	SCREW, TERMINAL	
216	4-382-854-11	SCREW (M3X10), P, SW (+)	
217	* 4-067-714-01	COVER (G)	
218	△1-251-263-11	INLET, AC	
219	△1-771-602-11	SWITCH, AC POWER	
220	* 4-067-726-01	PANEL (F), REAR	
221	* A-1245-597-A	F COMPL (G90E/G90M)	222,223
221	* A-1245-598-A	F COMPL (G90U)	222,223
222	△1-533-576-11	FUSE, TIME-LAG ((UL)ET) (G90E/G90M)	
222	△1-533-694-11	FUSE, GLASS ((UL)ET) (10A/250V) (G90U)	
223	1-533-702-11	HOLDER, FUSE (G90E/G90M)	
223	* 1-533-703-11	HOLDER, FUSE (G90U)	
224	* A-1304-153-A	ME MOUNT	
225	* 4-067-814-01	PANEL (BC), REAR	
226	4-396-203-01	SCREW (+B M3X12), PREVENTION	
227	4-035-771-01	PLATE, BLIND	
228	4-353-708-00	HOOK, FINGER	
229	* A-1131-355-A	BC MOUNT	
230	* A-1135-958-A	BB COMPL	
231	* A-1135-957-B	BA COMPL	
232	* A-1394-911-A	YA COMPL	
233	* 4-067-638-01	PANEL (BY), REAR (G90E)	
233	* 4-067-638-11	PANEL (BY), REAR (G90M/G90U)	
234	4-067-813-01	SCREW (P), SPECIAL	
235	3-728-267-01	COVER, 3.5 JACK	
236	* 4-067-810-01	WINDOW, INDICATE	
237	* A-1131-365-A	BD MOUNT (G90M/G90U)	
238	* 4-316-015-00	HOLDER, WIRE	

- : 7-682-949-01 +PSW3 × 10
- ▽ : 7-682-248-09 +K3 × 8
- : 7-682-961-01 +PSW4 × 8
- ▲ : 7-685-646-79 +BVTP3 × 8
- ▼ : 7-685-246-19 +KTP3 × 8
- ◆ : 7-682-962-01 +PSW4 × 10
- ★ : 7-682-903-19 +PWH3 × 6




PICTURE TUBE BLOCK

7-6. PICTURE TUBE BLOCK

Ref.No.	Part No.	Description	Remark
251	△4-049-735-61	LENS (HD-10)	
252	△A-1501-413-A	COUPLING (B) ASSY, CRT (V903)	
253	△A-1501-412-A	COUPLING (G) ASSY, CRT (V902)	
254	△A-1501-411-A	COUPLING (R) ASSY, CRT (V901)	
255	4-067-704-02	SPACER (DY)	
256	△1-451-478-11	DEFLECTION YOKE	
257	4-050-317-01	WEDGE	
258	1-452-964-11	MAGNET, FOCUS	
259	1-416-876-11	COIL, 2-4 P	
260	* A-1331-860-A	CBB MOUNT	
261	* A-1331-859-A	CBG MOUNT	
262	* A-1331-858-A	CBR MOUNT	
263	* 4-067-769-11	STAY (CRT)	
264	* 4-067-769-21	STAY (CRT)	
265	* 4-067-769-01	STAY (CRT)	
266	4-056-110-11	SCREW, SW HEXAGON HEAD M5X12	
267	△A-1484-095-A	HVB BLOCK ASSY	
268	* 4-067-702-01	HOLDER (HVR)	
269	3-701-474-02	LOCK, PURSE	


- : 7-682-961-01 +PSW4 × 8
- ◇ : 7-682-663-09 +PSW4 × 12
- : 7-685-659-79 +BVTP4 × 8
- ◆ : 7-682-962-01 +PSW4 × 10
- ▲ : 7-685-646-79 +BVTP3 × 8



CHASSIS BLOCK


7-7. CHASSIS BLOCK 2

◆ : 7-682-962-01 +PSW4 × 10
 ■ : 7-685-659-79 +BVTP4 × 8



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
301	*4-360-309-11	SUPPORT, PC BOARD		306	4-055-970-21	RAIL (S), PC BOARD GUIDE	
302	*A-1304-148-A	M MOUNT		307	4-056-020-01	RAIL, PA	
303	*A-1390-887-A	L MOUNT		308	*4-056-414-01	BUSHING, SQUARE	
304	*4-958-674-31	SPACER, MINIATURE CARD		309	*A-1304-150-A	MB MOUNT	
305	4-055-970-11	RAIL (S), PC BOARD GUIDE		310	*A-1304-151-A	MC MOUNT	
				311	*A-1304-149-A	MA MOUNT	

7-8. BASE BLOCK



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
351	* X-4036-167-2	BASE ASSY	352—361	357	* 4-067-684-02	HANDLE (R)	
352	* 4-067-646-01	BRACKET (BT), CRT		358	* 4-067-685-02	HANDLE (L)	
353	* 4-067-763-01	BRACKET (PS), CRT		359	4-056-020-01	RAIL, PA	
354	* 4-056-414-01	BUSHING, SQUARE		360	4-055-970-21	RAIL (S), PC BOARD GUIDE	
355	* 4-067-686-01	HANDLE (MR)		361	* 4-067-785-01	ADJUSTOR (M12)	
356	* 4-067-687-01	HANDLE (ML)		362	3-703-319-01	PURSE LOCK (DIA.15)	

SECTION 8

ELECTRICAL PARTS LIST

NOTE:

The components identified by mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

RESISTORS

- All resistors are in ohms
- F: nonflammable

When indicating parts by reference number, please include the board name.

CAPACITORS

PF: $\mu\mu\text{F}$

- There are some cases the reference number on one board overlaps on the other board. Therefore, when ordering parts by the reference number, please include the board name.
- The components identified by $\boxtimes$ in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
	* A-1131-355-A BC MOUNTED PC BOARD *****			R510	1-216-025-91	RES,CHIP 100 5% 1/10W	
	<CAPACITOR>			R511	1-216-065-91	RES,CHIP 4.7K 5% 1/10W	
C500	1-126-791-11	ELECT 10μF 20% 16V			<RELAY>		
C501	1-126-791-11	ELECT 10μF 20% 16V		RY500	1-515-716-11	RELAY (TQ2-5V)	
C502	1-126-786-11	ELECT 47μF 20% 16V		RY501	1-515-716-11	RELAY (TQ2-5V)	
C503	1-164-004-11	CERAMIC CHIP 0.1μF 10% 25V		RY502	1-515-716-11	RELAY (TQ2-5V)	
C505	1-164-004-11	CERAMIC CHIP 0.1μF 10% 25V		RY503	1-515-716-11	RELAY (TQ2-5V)	
	<CONNECTOR>			RY504	1-515-716-11	RELAY (TQ2-5V)	
C507	1-126-786-11	ELECT 47μF 20% 16V		RY505	1-515-716-11	RELAY (TQ2-5V)	
C512	1-126-791-11	ELECT 10μF 20% 16V		RY506	1-515-716-11	RELAY (TQ2-5V)	
C513	1-126-791-11	ELECT 10μF 20% 16V		RY507	1-515-716-11	RELAY (TQ2-5V)	
	<DIODE>			*****			
CN380	* 1-778-891-11 CONNECTOR, BOARD TO BOARD				* A-1131-365-A BD MOUNTED PC BOARD (G90M/G90U) *****		
	<IC>				<CONNECTOR>		
D500	8-719-801-78	DIODE 1SS184		CN400	* 1-564-510-11 PLUG, CONNECTOR 7P		
D501	8-719-801-78	DIODE 1SS184			<DIODE>		
D502	8-719-801-78	DIODE 1SS184		D101	8-719-110-17	DIODE RD10ESB2	
D503	8-719-801-78	DIODE 1SS184		D102	8-719-110-17	DIODE RD10ESB2	
D504	8-719-801-78	DIODE 1SS184		D103	8-719-110-17	DIODE RD10ESB2	
	<COIL>				<JACK>		
IC500	8-759-242-64	IC TC4W53F		J101	1-566-981-21	CONNECTOR, ROUND TYPE 4P	
IC501	8-759-157-17	IC PQ05SZ1U		J102	1-566-980-31	CONNECTOR, ROUND TYPE 4P	
	<TRANSISTOR>				<RESISTOR>		
Q500	8-729-230-49	TRANSISTOR 2SC2712-YG		R101	1-215-394-00	METAL 75 1% 1/4W	
Q501	8-729-230-49	TRANSISTOR 2SC2712-YG		R102	1-215-394-00	METAL 75 1% 1/4W	
Q502	8-729-230-49	TRANSISTOR 2SC2712-YG		R103	1-215-394-00	METAL 75 1% 1/4W	
Q503	8-729-140-75	TRANSISTOR 2SD999-CLCK			<TERMINAL BOARD>		
Q504	8-729-230-49	TRANSISTOR 2SC2712-YG		TB101	* 1-694-488-11 TERMINAL BOARD, I/O		
Q505	8-729-140-75	TRANSISTOR 2SD999-CLCK		TB102	* 1-694-487-11 TERMINAL BOARD, I/O		
Q506	8-729-230-49	TRANSISTOR 2SC2712-YG			*****		
Q507	8-729-230-49	TRANSISTOR 2SC2712-YG			* A-1135-957-B BA COMPLETE PC BOARD *****		
Q508	8-729-900-53	TRANSISTOR DTC114EK			2-280-622-71 SUPPORT (M3), HEXAGON		
	<RESISTOR>				* 4-057-871-01 HOLDER, HEAT SINK (BB)		
R500	1-216-041-00	RES,CHIP 470 5% 1/10W			4-057-872-01 HEAT SINK (BB)		
R501	1-216-041-00	RES,CHIP 470 5% 1/10W			* 4-067-738-01 SHIELD (TP), BA		
R502	1-216-041-00	RES,CHIP 470 5% 1/10W			4-382-854-11 SCREW (M3X10), P, SW (+)		
R503	1-216-065-91	RES,CHIP 4.7K 5% 1/10W			4-382-854-11 SCREW (M3X10), P, SW (+)		
R504	1-216-065-91	RES,CHIP 4.7K 5% 1/10W					
R505	1-216-065-91	RES,CHIP 4.7K 5% 1/10W					
R506	1-216-065-91	RES,CHIP 4.7K 5% 1/10W					
R507	1-216-041-00	RES,CHIP 470 5% 1/10W					
R508	1-216-025-91	RES,CHIP 100 5% 1/10W					
R509	1-216-025-91	RES,CHIP 100 5% 1/10W					

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
<CAPACITOR>				C205	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C206	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C2	1-128-004-11	ELECT CHIP 10μF	20% 16V	C207	1-128-004-11	ELECT CHIP 10μF	20% 16V
C3	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C208	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C4	1-128-453-21	ELECT CHIP 47μF	20% 6.3V	C209	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C5	1-128-453-21	ELECT CHIP 47μF	20% 6.3V	C210	1-126-603-11	ELECT CHIP 4.7μF	20% 16V
C6	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C211	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C7	1-128-453-21	ELECT CHIP 47μF	20% 6.3V	C212	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C8	1-128-453-21	ELECT CHIP 47μF	20% 6.3V	C213	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C9	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C214	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C10	1-128-453-21	ELECT CHIP 47μF	20% 6.3V	C215	1-110-666-11	ELECT CHIP 22μF	20% 6.3V
C11	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C216	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C12	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C218	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C13	1-128-453-21	ELECT CHIP 47μF	20% 6.3V	C219	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C14	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C220	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C15	1-128-004-11	ELECT CHIP 10μF	20% 16V	C221	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C16	1-128-004-11	ELECT CHIP 10μF	20% 16V	C222	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C17	1-128-004-11	ELECT CHIP 10μF	20% 16V	C223	1-128-004-11	ELECT CHIP 10μF	20% 16V
C18	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C224	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C19	1-109-982-11	CERAMIC CHIP 1μF	10% 10V	C225	1-128-004-11	ELECT CHIP 10μF	20% 16V
C20	1-128-004-11	ELECT CHIP 10μF	20% 16V	C226	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C23	1-128-004-11	ELECT CHIP 10μF	20% 16V	C227	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C24	1-128-004-11	ELECT CHIP 10μF	20% 16V	C228	1-128-004-11	ELECT CHIP 10μF	20% 16V
C25	1-126-397-11	ELECT CHIP 33μF	20% 25V	C229	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C26	1-126-394-11	ELECT CHIP 10μF	20% 16V	C230	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C27	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C231	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C28	1-128-004-11	ELECT CHIP 10μF	20% 16V	C232	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C29	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C233	1-126-603-11	ELECT CHIP 4.7μF	20% 16V
C30	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C234	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C31	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C235	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C32	1-128-004-11	ELECT CHIP 10μF	20% 16V	C236	1-110-666-11	ELECT CHIP 22μF	20% 6.3V
C33	1-163-217-11	CERAMIC CHIP 1PF	0.25PF50V	C237	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C34	1-109-982-11	CERAMIC CHIP 1μF	10% 10V	C238	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C37	1-126-397-11	ELECT CHIP 33μF	20% 25V	C239	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C38	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C241	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C40	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C242	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C41	1-163-217-11	CERAMIC CHIP 1PF	0.25PF50V	C243	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C42	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C244	1-128-004-11	ELECT CHIP 10μF	20% 16V
C43	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C245	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C44	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C246	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C47	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C247	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C48	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C248	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C49	1-128-004-11	ELECT CHIP 10μF	20% 16V	C249	1-128-004-11	ELECT CHIP 10μF	20% 16V
C50	1-163-217-11	CERAMIC CHIP 1PF	0.25PF50V	C250	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C51	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C251	1-128-004-11	ELECT CHIP 10μF	20% 16V
C52	1-163-245-11	CERAMIC CHIP 56PF	5% 50V	C252	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C53	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C253	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C54	1-128-004-11	ELECT CHIP 10μF	20% 16V	C254	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C55	1-128-013-11	ELECT CHIP 1μF	20% 50V	C255	1-126-603-11	ELECT CHIP 4.7μF	20% 16V
C56	1-128-004-11	ELECT CHIP 10μF	20% 16V	C256	1-128-004-11	ELECT CHIP 10μF	20% 16V
C57	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C257	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C58	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C258	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C59	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C259	1-110-666-11	ELECT CHIP 22μF	20% 6.3V
C200	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C260	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C201	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C261	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C202	1-128-004-11	ELECT CHIP 10μF	20% 16V	C262	1-128-004-11	ELECT CHIP 10μF	20% 16V
C203	1-128-004-11	ELECT CHIP 10μF	20% 16V	C263	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C204	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C264	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C265	1-128-004-11	ELECT CHIP 10μF	20% 16V	C464	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C266	1-109-982-11	CERAMIC CHIP 1μF	10% 10V	C465	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C267	1-128-004-11	ELECT CHIP 10μF	20% 16V	C466	1-115-857-11	ELECT 0.001F	20% 16V
C269	1-109-982-11	CERAMIC CHIP 1μF	10% 10V	C467	1-115-857-11	ELECT 0.001F	20% 16V
C270	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C470	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C271	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C471	1-163-082-00	CERAMIC CHIP 0.5PF	0.25PF50V
C272	1-128-004-11	ELECT CHIP 10μF	20% 16V	C505	1-124-779-00	ELECT CHIP 10μF	20% 16V
C273	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C509	1-124-779-00	ELECT CHIP 10μF	20% 16V
C274	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C510	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C275	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C511	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C276	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C513	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C277	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C514	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C278	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C515	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C279	1-128-004-11	ELECT CHIP 10μF	20% 16V	C516	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C280	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C517	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C282	1-164-489-11	CERAMIC CHIP 0.22μF	10% 16V	C518	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C284	1-164-489-11	CERAMIC CHIP 0.22μF	10% 16V	C519	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C286	1-164-489-11	CERAMIC CHIP 0.22μF	10% 16V	C520	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C401	1-164-489-11	CERAMIC CHIP 0.22μF	10% 16V	C521	1-163-082-00	CERAMIC CHIP 0.5PF	0.25PF50V
C402	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C555	1-124-779-00	ELECT CHIP 10μF	20% 16V
C403	1-164-489-11	CERAMIC CHIP 0.22μF	10% 16V	C559	1-124-779-00	ELECT CHIP 10μF	20% 16V
C404	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C560	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C405	1-164-489-11	CERAMIC CHIP 0.22μF	10% 16V	C561	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C406	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C563	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C407	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C564	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C408	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C565	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C409	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C570	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C410	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C571	1-163-082-00	CERAMIC CHIP 0.5PF	0.25PF50V
C411	1-126-394-11	ELECT CHIP 10μF	20% 16V	C600	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C412	1-126-204-11	ELECT CHIP 47μF	20% 16V	C601	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C413	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C602	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C414	1-126-204-11	ELECT CHIP 47μF	20% 16V	C603	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C415	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C604	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C416	1-126-204-11	ELECT CHIP 47μF	20% 16V	C605	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C417	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C607	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C418	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C609	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C419	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C610	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C420	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C612	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C421	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C613	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C422	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C614	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C423	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C615	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C424	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C616	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C425	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C617	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C426	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C618	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C427	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C619	1-124-779-00	ELECT CHIP 10μF	20% 16V
C428	1-163-220-11	CERAMIC CHIP 3PF	0.25PF50V	C620	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C429	1-163-220-11	CERAMIC CHIP 3PF	0.25PF50V	C621	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C430	1-163-220-11	CERAMIC CHIP 3PF	0.25PF50V	C622	1-124-779-00	ELECT CHIP 10μF	20% 16V
C431	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C624	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C432	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C625	1-128-393-11	ELECT CHIP 100μF	20% 10V
C433	1-115-857-11	ELECT 0.001F	20% 16V	C627	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C434	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C628	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C435	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C800	1-126-204-11	ELECT CHIP 47μF	20% 16V
C436	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C801	1-128-004-11	ELECT CHIP 10μF	20% 16V
C437	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C802	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C455	1-124-779-00	ELECT CHIP 10μF	20% 16V	C804	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C459	1-124-779-00	ELECT CHIP 10μF	20% 16V	C805	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C460	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C806	1-128-004-11	ELECT CHIP 10μF	20% 16V
C461	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C463	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C808	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1028	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C809	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1029	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C810	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1030	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C1031	1-163-009-11	CERAMIC CHIP 0.001μF	10% 50V
C811	1-163-809-11	CERAMIC CHIP 0.047μF	10% 25V	C1032	1-126-398-11	ELECT CHIP 4.7μF	20% 35V
C813	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C814	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1033	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C815	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1034	1-128-393-11	ELECT CHIP 100μF	20% 10V
C816	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1035	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
				C1036	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C817	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1038	1-163-089-00	CERAMIC CHIP 6PF	0.5PF 50V
C818	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C819	1-128-004-11	ELECT CHIP 10μF	20% 16V	C1039	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C820	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1041	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C821	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1043	1-128-004-11	ELECT CHIP 10μF	20% 16V
				C1044	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V
C822	1-109-982-11	CERAMIC CHIP 1μF	10% 10V	C1045	1-126-204-11	ELECT CHIP 47μF	20% 16V
C823	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C824	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1046	1-126-204-11	ELECT CHIP 47μF	20% 16V
C825	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1047	1-126-204-11	ELECT CHIP 47μF	20% 16V
C826	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1048	1-128-004-11	ELECT CHIP 10μF	20% 16V
				C1049	1-126-204-11	ELECT CHIP 47μF	20% 16V
C827	1-128-013-11	ELECT CHIP 1μF	20% 50V	C1050	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C828	1-110-666-11	ELECT CHIP 22μF	20% 6.3V				
C829	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C1051	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C830	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1052	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C831	1-128-004-11	ELECT CHIP 10μF	20% 16V	C1053	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C1054	1-128-004-11	ELECT CHIP 10μF	20% 16V
C832	1-128-004-11	ELECT CHIP 10μF	20% 16V	C1055	1-128-004-11	ELECT CHIP 10μF	20% 16V
C833	1-128-004-11	ELECT CHIP 10μF	20% 16V				
C834	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1056	1-128-396-11	ELECT CHIP 470μF	20% 10V
C835	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1057	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C836	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1058	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
				C1060	1-126-204-11	ELECT CHIP 47μF	20% 16V
C837	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1061	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C838	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C839	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C1201	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C840	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1202	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C841	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C1203	1-124-779-00	ELECT CHIP 10μF	20% 16V
				C1204	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
C842	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1205	1-124-779-00	ELECT CHIP 10μF	20% 16V
C843	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C844	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1206	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C845	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1208	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C846	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1209	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C1210	1-163-231-11	CERAMIC CHIP 15PF	5% 50V
C1001	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1211	1-128-004-11	ELECT CHIP 10μF	20% 16V
C1003	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V				
C1004	1-124-778-00	ELECT CHIP 22μF	20% 6.3V	C1212	1-128-013-11	ELECT CHIP 1μF	20% 50V
C1005	1-124-778-00	ELECT CHIP 22μF	20% 6.3V	C1213	1-163-133-00	CERAMIC CHIP 470PF	5% 50V
C1006	1-126-395-11	ELECT CHIP 22μF	20% 16V	C1214	1-128-004-11	ELECT CHIP 10μF	20% 16V
				C1215	1-163-102-00	CERAMIC CHIP 24PF	5% 50V
C1007	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C1216	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1011	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V				
C1012	1-124-779-00	ELECT CHIP 10μF	20% 16V	C1217	1-163-102-00	CERAMIC CHIP 24PF	5% 50V
C1013	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C1220	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1014	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C1221	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C1223	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1015	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1224	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1016	1-126-204-11	ELECT CHIP 47μF	20% 16V				
C1017	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1226	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1018	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1229	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1021	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C1231	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C1232	1-128-004-11	ELECT CHIP 10μF	20% 16V
C1022	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1233	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1023	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V				
C1024	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1234	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1026	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C1235	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C1027	1-128-393-11	ELECT CHIP 100μF	20% 10V	C1237	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C1238	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C1239	1-163-131-00	CERAMIC CHIP 390PF	5% 50V	C1427	1-126-204-11	ELECT CHIP 47μF	20% 16V
C1240	1-128-396-11	ELECT CHIP 470μF	20% 10V	C1430	1-126-398-11	ELECT CHIP 4.7μF	20% 35V
C1241	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1431	1-126-398-11	ELECT CHIP 4.7μF	20% 35V
C1242	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1434	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1245	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1435	1-126-204-11	ELECT CHIP 47μF	20% 16V
C1247	1-128-004-11	ELECT CHIP 10μF	20% 16V	C1436	1-126-603-11	ELECT CHIP 4.7μF	20% 35V
C1248	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1439	1-126-603-11	ELECT CHIP 4.7μF	20% 35V
C1249	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1440	1-163-235-11	CERAMIC CHIP 22PF	5% 50V
C1250	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1441	1-126-204-11	ELECT CHIP 47μF	20% 16V
C1252	1-128-004-11	ELECT CHIP 10μF	20% 16V	C1443	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1253	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1445	1-163-009-11	CERAMIC CHIP 0.001μF	10% 50V
C1254	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1446	1-128-004-11	ELECT CHIP 10μF	20% 16V
C1255	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1447	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1256	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1448	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1257	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1449	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1258	1-128-007-11	ELECT CHIP 2.2μF	20% 35V	C1450	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1259	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1451	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1260	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1452	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C1261	1-128-006-11	ELECT CHIP 4.7μF	20% 25V	C1453	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1281	1-124-779-00	ELECT CHIP 10μF	20% 16V	C1454	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1284	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1455	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1285	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1456	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1286	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1457	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1287	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1458	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C1288	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1459	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1289	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1460	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1290	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1478	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1291	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1479	1-128-004-11	ELECT CHIP 10μF	20% 16V
C1292	1-124-779-00	ELECT CHIP 10μF	20% 16V	C1480	1-128-004-11	ELECT CHIP 10μF	20% 16V
C1293	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C1481	1-128-004-11	ELECT CHIP 10μF	20% 16V
C1294	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V	C1483	1-128-004-11	ELECT CHIP 10μF	20% 16V
C1295	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C1484	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1296	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1485	1-128-004-11	ELECT CHIP 10μF	20% 16V
C1297	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C1486	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1401	1-163-224-11	CERAMIC CHIP 7PF	0.25PF50V	C1487	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1402	1-163-809-11	CERAMIC CHIP 0.047μF	10% 25V	C1488	1-128-004-11	ELECT CHIP 10μF	20% 16V
C1403	1-163-089-00	CERAMIC CHIP 6PF	0.5PF 50V	C1489	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1404	1-163-089-00	CERAMIC CHIP 6PF	0.5PF 50V	C1600	1-124-779-00	ELECT CHIP 10μF	20% 16V
C1405	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1601	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1406	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1602	1-126-204-11	ELECT CHIP 47μF	20% 16V
C1407	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1603	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1408	1-163-017-00	CERAMIC CHIP 0.0047μF	10% 50V	C1604	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1409	1-163-133-00	CERAMIC CHIP 470PF	5% 50V	C1605	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1410	1-109-982-11	CERAMIC CHIP 1μF	10% 10V	C1606	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1411	1-164-489-11	CERAMIC CHIP 0.22μF	10% 16V	C1607	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1412	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1608	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1413	1-163-089-00	CERAMIC CHIP 6PF	0.5PF 50V	C1609	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1414	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1610	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1415	1-163-224-11	CERAMIC CHIP 7PF	0.25PF50V	C1611	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1416	1-163-222-11	CERAMIC CHIP 5PF	0.25PF50V	C1612	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1418	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1613	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1419	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1614	1-124-779-00	ELECT CHIP 10μF	20% 16V
C1420	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1615	1-124-779-00	ELECT CHIP 10μF	20% 16V
C1421	1-126-935-11	ELECT 470μF	20% 16V	C1617	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1422	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1619	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1424	1-164-505-11	CERAMIC CHIP 2.2μF	16V	C1620	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1425	1-164-505-11	CERAMIC CHIP 2.2μF	16V	C1621	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C1426	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1622	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C1623	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1801	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1624	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1802	1-126-603-11	ELECT CHIP 4.7μF	20% 16V
C1625	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1803	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1626	1-126-394-11	ELECT CHIP 10μF	20% 16V	C1804	1-164-489-11	CERAMIC CHIP 0.22μF	10% 16V
C1627	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C1805	1-164-489-11	CERAMIC CHIP 0.22μF	10% 16V
C1628	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1806	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1629	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1807	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1630	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1808	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C1631	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1809	1-164-182-11	CERAMIC CHIP 0.0033μF	10% 50V
C1632	1-109-982-11	CERAMIC CHIP 1μF	10% 10V	C1810	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1633	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1811	1-164-489-11	CERAMIC CHIP 0.22μF	10% 16V
C1634	1-163-259-91	CERAMIC CHIP 220PF	5% 50V	C1812	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C1635	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1813	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1636	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1814	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1637	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1816	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1638	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1817	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1639	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1820	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1640	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1822	1-128-004-11	ELECT CHIP 10μF	20% 16V
C1641	1-126-401-11	ELECT CHIP 1μF	20% 50V	C1823	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1642	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1824	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1643	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1827	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C1644	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1828	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1645	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C1829	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1646	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1832	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C1647	1-124-779-00	ELECT CHIP 10μF	20% 16V	C1833	1-128-004-11	ELECT CHIP 10μF	20% 16V
C1648	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1834	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1649	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C1835	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1650	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1836	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1651	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1837	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1652	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C1838	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1653	1-126-204-11	ELECT CHIP 47μF	20% 16V	C1839	1-126-206-11	ELECT CHIP 100μF	20% 6.3V
C1654	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1840	1-124-778-00	ELECT CHIP 22μF	20% 6.3V
C1655	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1841	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1656	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	C2000	1-124-779-00	ELECT CHIP 10μF	20% 16V
C1657	1-126-401-11	ELECT CHIP 1μF	20% 50V	C2001	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1658	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C2002	1-109-982-11	CERAMIC CHIP 1μF	10% 10V
C1659	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C2003	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1670	1-126-204-11	ELECT CHIP 47μF	20% 16V	C2004	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1761	1-164-505-11	CERAMIC CHIP 2.2μF	16V	C2005	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1762	1-164-505-11	CERAMIC CHIP 2.2μF	16V	C2006	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1763	1-164-505-11	CERAMIC CHIP 2.2μF	16V	C2007	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C1764	1-164-505-11	CERAMIC CHIP 2.2μF	16V	C2009	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1765	1-164-505-11	CERAMIC CHIP 2.2μF	16V	C2101	1-126-394-11	ELECT CHIP 10μF	20% 16V
C1766	1-164-505-11	CERAMIC CHIP 2.2μF	16V	C2102	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1767	1-164-505-11	CERAMIC CHIP 2.2μF	16V	C2103	1-126-394-11	ELECT CHIP 10μF	20% 16V
C1768	1-164-505-11	CERAMIC CHIP 2.2μF	16V	C2104	1-126-394-11	ELECT CHIP 10μF	20% 16V
C1769	1-164-505-11	CERAMIC CHIP 2.2μF	16V	C2105	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1770	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C2106	1-126-394-11	ELECT CHIP 10μF	20% 16V
C1771	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C2107	1-128-528-11	ELECT 470μF	20% 25V
C1772	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C2108	1-115-857-11	ELECT 0.001F	20% 16V
C1773	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C2109	1-115-857-11	ELECT 0.001F	20% 16V
C1774	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C2110	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1775	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C2111	1-126-394-11	ELECT CHIP 10μF	20% 16V
C1776	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C2112	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1777	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C2113	1-126-394-11	ELECT CHIP 10μF	20% 16V
C1778	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C2114	1-126-394-11	ELECT CHIP 10μF	20% 16V
C1779	1-128-004-11	ELECT CHIP 10μF	20% 16V	C2115	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C1783	1-128-004-11	ELECT CHIP 10μF	20% 16V	C2116	1-126-394-11	ELECT CHIP 10μF	20% 16V
C1784	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C2117	1-126-394-11	ELECT CHIP 10μF	20% 16V	D811	8-719-801-78	DIODE 1SS184	
C2118	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D812	8-719-801-78	DIODE 1SS184	
C2119	1-126-394-11	ELECT CHIP 10μF	20% 16V				
C2120	1-126-399-11	ELECT CHIP 10μF	20% 35V	D813	8-719-801-78	DIODE 1SS184	
C2121	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D1001	8-719-801-78	DIODE 1SS184	
C2122	1-126-394-11	ELECT CHIP 10μF	20% 16V	D1401	8-719-914-43	DIODE DAN202K	
C2123	1-126-394-11	ELECT CHIP 10μF	20% 16V	D1600	8-719-911-19	DIODE 1SS119-25	
C2124	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D1601	8-719-801-78	DIODE 1SS184	
C2125	1-126-394-11	ELECT CHIP 10μF	20% 16V				
C2126	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D2101	8-719-062-22	DIODE SB30-03P-TD	
C2127	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D2102	8-719-801-78	DIODE 1SS184	
C2207	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D2103	8-719-801-78	DIODE 1SS184	
<CONNECTOR>				D2200	8-719-801-78	DIODE 1SS184	
CN340	* 1-778-891-11	CONNECTOR, BOARD TO BOARD		D2201	8-719-106-70	DIODE RD12M-B1	
CN341	* 1-778-891-11	CONNECTOR, BOARD TO BOARD					
CN346	* 1-565-689-11	HEADER, FLAT CABLE 60P		D2202	8-719-045-99	DIODE RD2.2M-T1B	
CN347	1-562-579-21	RECEPTACLE, CONNECTOR 2P		D2203	8-719-045-99	DIODE RD2.2M-T1B	
CN347	* 1-564-948-21	PIN, CONNECTOR 3P		D2204	8-719-800-76	DIODE 1SS226	
CN348	1-562-579-21	RECEPTACLE, CONNECTOR 2P		D2205	8-719-800-76	DIODE 1SS226	
CN348	* 1-564-948-21	PIN, CONNECTOR 3P		<FERRITE BEAD>			
CN349	1-562-579-21	RECEPTACLE, CONNECTOR 2P		FB1201	1-543-775-11	FERRITE 0μH	
CN349	* 1-564-948-21	PIN, CONNECTOR 3P		FB1202	1-543-775-11	FERRITE 0μH	
CN350	1-562-579-21	RECEPTACLE, CONNECTOR 2P		FB1203	1-543-775-11	FERRITE 0μH	
CN350	* 1-564-948-21	PIN, CONNECTOR 3P		FB1207	1-414-234-22	INDUCTOR CHIP 0μH	
CN351	* 1-564-510-11	PLUG, CONNECTOR 7P		FB1208	1-414-234-22	INDUCTOR CHIP 0μH	
CN352	* 1-564-519-11	PLUG, CONNECTOR 4P					
<DIODE>				FB1210	1-414-234-22	INDUCTOR CHIP 0μH	
D1	8-719-800-76	DIODE 1SS226		FB1212	1-414-234-22	INDUCTOR CHIP 0μH	
D2	8-719-800-76	DIODE 1SS226		FB1213	1-414-234-22	INDUCTOR CHIP 0μH	
D3	8-719-800-76	DIODE 1SS226		FB1215	1-414-234-22	INDUCTOR CHIP 0μH	
D4	8-719-800-76	DIODE 1SS226		<FILTER>			
D5	8-719-801-78	DIODE 1SS184		FL451	1-234-176-21	FERRITE 37μH	
D6	8-719-801-78	DIODE 1SS184		FL501	1-234-176-21	FERRITE 37μH	
D7	8-719-800-76	DIODE 1SS226		FL551	1-234-176-21	FERRITE 37μH	
D8	8-719-801-78	DIODE 1SS184		FL1001	1-239-289-11	FILTER, LOW PASS	
D9	8-719-801-78	DIODE 1SS184		FL1002	1-239-289-11	FILTER, LOW PASS	
D10	8-719-801-78	DIODE 1SS184					
D11	8-719-801-78	DIODE 1SS184		FL1003	1-239-289-11	FILTER, LOW PASS	
D501	8-719-105-46	DIODE RD3.3M-B2		FL1201	1-239-847-11	FILTER, LOW PASS	
D502	8-719-105-46	DIODE RD3.3M-B2		FL1203	1-239-289-11	FILTER, LOW PASS	
D503	8-719-105-46	DIODE RD3.3M-B2		FL1204	1-239-289-11	FILTER, LOW PASS	
D505	8-719-105-73	DIODE RD4.7M-B2		<IC>			
D600	8-719-801-78	DIODE 1SS184		IC1	8-759-431-38	IC MAX4121CSA-TE2	
D601	8-719-801-78	DIODE 1SS184		IC2	8-759-431-38	IC MAX4121CSA-TE2	
D800	8-719-801-78	DIODE 1SS184		IC3	8-759-431-38	IC MAX4121CSA-TE2	
D801	8-719-801-78	DIODE 1SS184		IC4	8-759-981-48	IC TL082M	
D802	8-719-801-78	DIODE 1SS184		IC5	8-759-542-11	IC MAX4223ESA-TG06	
D803	8-719-801-78	DIODE 1SS184					
D804	8-719-801-78	DIODE 1SS184		IC8	8-759-542-11	IC MAX4223ESA-TG06	
D805	8-719-801-78	DIODE 1SS184		IC10	8-759-542-11	IC MAX4223ESA-TG06	
D806	8-719-105-82	DIODE RD5.1M-B2		IC11	8-759-344-12	IC GS4981CTA	
D807	8-719-801-78	DIODE 1SS184		IC12	8-759-092-82	IC SN75157PS-ELL2000	
D808	8-719-801-78	DIODE 1SS184		IC13	8-759-381-53	IC UPC814G2-E2	
D809	8-719-801-78	DIODE 1SS184					
D810	8-719-801-78	DIODE 1SS184		IC200	8-752-052-77	IC CXA1450M	
				IC201	8-759-984-88	IC LM6361M	
				IC202	8-759-431-38	IC MAX4121CSA-TE2	
				IC203	8-759-431-38	IC MAX4121CSA-TE2	
				IC204	8-759-457-54	IC AD835AR-REEL7	
				IC205	8-759-198-34	IC TA75S558F	

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
IC206	8-752-052-77	IC CXA1450M		IC1205	8-759-269-92	IC SN74HCU04ANS-E20	
IC207	8-759-431-38	IC MAX4121CSA-TE2		IC1206	8-759-161-24	IC UPC659AGS-E2	
IC208	8-759-431-38	IC MAX4121CSA-TE2		IC1207	8-759-460-74	IC BA05FP-E2	
IC209	8-759-984-88	IC LM6361M		IC1208	8-759-460-72	IC BA033FP-E2	
				IC1402	8-759-295-47	IC TDA9141-N2C	
IC210	8-759-457-54	IC AD835AR-REEL7					
IC211	8-759-198-34	IC TA75S558F		IC1403	8-759-565-20	IC TDA4665T/V5-118	
IC212	8-752-052-77	IC CXA1450M		IC1404	8-759-335-57	IC MM1112XF	
IC213	8-759-431-38	IC MAX4121CSA-TE2		IC1407	8-759-335-57	IC MM1112XF	
IC214	8-759-431-38	IC MAX4121CSA-TE2		IC1408	8-759-008-45	IC MC74HC4538F	
				IC1409	8-759-344-12	IC GS4981CTA	
IC215	8-759-984-88	IC LM6361M					
IC216	8-759-198-34	IC TA75S558F		IC1410	8-759-242-74	IC TC7W04F	
IC217	8-759-457-54	IC AD835AR-REEL7		IC1411	8-759-234-20	IC TC7S08F	
IC218	8-759-564-49	IC TC7W53FU(TE12R)		IC1413	8-759-242-76	IC TC7W08F	
IC219	8-759-062-66	IC TC7S66F		IC1414	8-759-381-53	IC UPC814G2-E2	
				IC1600	8-752-080-76	IC CXA2101Q	
IC220	8-759-381-53	IC UPC814G2-E2					
IC221	8-759-035-93	IC SC7S32F		IC1602	8-759-242-74	IC TC7W04F	
IC401	8-759-031-84	IC SC7S04F		IC1603	8-759-234-20	IC TC7S08F	
IC402	8-752-075-54	IC CXA3069S		IC1712	8-752-082-49	IC CXA2119M	
IC403	8-759-012-13	IC MC10H125M		IC1801	8-752-073-52	IC CXA2016S	
				IC1802	8-759-926-18	IC SN74HC157ANS	
IC404	8-759-445-85	IC LM1283N					
IC452	8-759-542-11	IC MAX4223ESA-TG06		IC1803	8-759-035-93	IC SC7S32F	
IC502	8-759-542-11	IC MAX4223ESA-TG06		IC1804	8-759-926-18	IC SN74HC157ANS	
IC503	8-759-198-34	IC TA75S558F		IC1805	8-759-195-02	IC TC7S86F-TE85L	
IC504	8-759-198-34	IC TA75S558F		IC1806	8-759-195-02	IC TC7S86F-TE85L	
				IC1807	8-759-564-49	IC TC7W53FU(TE12R)	
IC552	8-759-542-11	IC MAX4223ESA-TG06					
IC600	8-759-251-32	IC NJM4200M		IC1811	8-759-926-18	IC SN74HC157ANS	
IC601	8-759-251-32	IC NJM4200M		IC1813	8-759-439-67	IC TC7W126FU(TE12R)	
IC602	8-759-251-32	IC NJM4200M		IC1814	8-759-242-74	IC TC7W04F	
IC603	8-759-981-48	IC TL082M		IC2000	8-759-175-04	IC PCF8574T-T	
				IC2001	8-752-072-94	IC CXA1875AM-T4	
IC604	8-759-981-48	IC TL082M					
IC605	8-759-981-48	IC TL082M		IC2002	8-759-175-04	IC PCF8574T-T	
IC606	8-759-198-34	IC TA75S558F		IC2003	8-752-072-94	IC CXA1875AM-T4	
IC607	8-759-198-34	IC TA75S558F		IC2004	8-759-175-04	IC PCF8574T-T	
IC608	8-759-198-34	IC TA75S558F		IC2005	8-752-072-94	IC CXA1875AM-T4	
				IC2006	8-759-234-20	IC TC7S08F	
IC609	8-759-326-65	IC MP7670AS-TE2					
IC610	8-759-926-05	IC SN74HC125ANS		IC2101	8-759-460-74	IC BA05FP-E2	
IC611	8-759-326-65	IC MP7670AS-TE2		IC2102	8-759-460-74	IC BA05FP-E2	
IC612	8-759-908-15	IC TL431CLP		IC2103	8-759-391-72	IC LM2576T-12LB03	
IC613	8-759-443-72	IC RH5VL43AA-T1		IC2104	8-759-460-79	IC BA09FP-E2	
				IC2105	8-759-460-79	IC BA09FP-E2	
IC614	8-759-198-34	IC TA75S558F					
IC801	8-759-981-48	IC TL082M		IC2106	8-759-539-89	IC LM2990SX-5.0	
IC802	8-759-981-48	IC TL082M		IC2107	8-759-549-53	IC LM2990SX-12	
IC803	8-759-981-48	IC TL082M		IC2108	8-759-460-74	IC BA05FP-E2	
IC804	8-759-100-93	IC UPC393G2		IC2109	8-759-234-20	IC TC7S08F	
				IC2110	8-759-431-39	IC MAX8213BCSE-TE2	
IC805	8-759-981-48	IC TL082M					
IC807	8-759-198-34	IC TA75S558F		IC2202	8-759-234-20	IC TC7S08F	
IC808	8-759-198-34	IC TA75S558F					
IC809	8-759-198-34	IC TA75S558F					
IC810	8-759-198-34	IC TA75S558F					
IC811	8-759-198-34	IC TA75S558F					
IC812	8-759-198-34	IC TA75S558F					
IC1001	8-759-256-44	IC NJM2235M-TE2					
IC1002	8-752-068-45	IC CXA1855Q					
IC1003	8-752-372-78	IC CXD2024AQ					
IC1004	8-759-711-62	IC NJM2240M					
IC1005	8-759-353-02	IC NJM2533M(TE2)					
IC1006	8-759-256-44	IC NJM2235M-TE2					
IC1202	8-759-473-05	IC UPD424210LE-60-E2					
IC1203	8-759-473-04	IC UPD64081GF-3BA					

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
L1006	1-412-058-11	INDUCTOR CHIP 10μH		Q10	8-729-140-75	TRANSISTOR 2SD999-CLCK	
L1007	1-412-058-11	INDUCTOR CHIP 10μH		Q11	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1201	1-410-200-31	INDUCTOR CHIP 4.7μH		Q12	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1202	1-412-058-11	INDUCTOR CHIP 10μH		Q13	8-729-216-22	TRANSISTOR 2SA1162-G	
L1203	1-414-753-91	INDUCTOR 4.7μH		Q14	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1204	1-414-753-91	INDUCTOR 4.7μH		Q16	8-729-101-07	TRANSISTOR 2SB798-DL	
L1205	1-414-753-91	INDUCTOR 4.7μH		Q18	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1206	1-414-753-91	INDUCTOR 4.7μH		Q19	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1207	1-414-753-91	INDUCTOR 4.7μH		Q20	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1210	1-412-058-11	INDUCTOR CHIP 10μH		Q21	8-729-101-07	TRANSISTOR 2SB798-DL	
L1211	1-412-058-11	INDUCTOR CHIP 10μH		Q22	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1212	1-412-058-11	INDUCTOR CHIP 10μH		Q23	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1213	1-412-058-11	INDUCTOR CHIP 10μH		Q24	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1214	1-412-058-11	INDUCTOR CHIP 10μH		Q25	8-729-216-22	TRANSISTOR 2SA1162-G	
L1215	1-412-058-11	INDUCTOR CHIP 10μH		Q200	1-801-806-11	TRANSISTOR DTC144EKA-T146	
L1216	1-412-058-11	INDUCTOR CHIP 10μH		Q201	8-729-107-31	TRANSISTOR 2SC3545-T43	
L1401	1-414-235-22	INDUCTOR CHIP 0μH		Q202	8-729-116-04	TRANSISTOR 2SK160-K4	
L1402	1-412-058-11	INDUCTOR CHIP 10μH		Q203	8-729-107-31	TRANSISTOR 2SC3545-T43	
L1403	1-414-235-22	INDUCTOR CHIP 0μH		Q204	8-729-116-04	TRANSISTOR 2SK160-K4	
L1404	1-412-058-11	INDUCTOR CHIP 10μH		Q205	8-729-107-31	TRANSISTOR 2SC3545-T43	
L1405	1-412-058-11	INDUCTOR CHIP 10μH		Q206	8-729-116-04	TRANSISTOR 2SK160-K4	
L1406	1-414-756-11	INDUCTOR 47μH		Q207	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1407	1-412-058-11	INDUCTOR CHIP 10μH		Q208	1-801-806-11	TRANSISTOR DTC144EKA-T146	
L1408	1-412-058-11	INDUCTOR CHIP 10μH		Q209	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1409	1-412-058-11	INDUCTOR CHIP 10μH		Q210	1-801-806-11	TRANSISTOR DTC144EKA-T146	
L1410	1-412-058-11	INDUCTOR CHIP 10μH		Q211	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1411	1-412-058-11	INDUCTOR CHIP 10μH		Q212	1-801-806-11	TRANSISTOR DTC144EKA-T146	
L1600	1-412-058-11	INDUCTOR CHIP 10μH		Q213	8-729-230-49	TRANSISTOR 2SC2712-YG	
L1601	1-412-058-11	INDUCTOR CHIP 10μH		Q451	8-729-107-31	TRANSISTOR 2SC3545-T43	
L1602	1-412-058-11	INDUCTOR CHIP 10μH		Q455	8-729-107-31	TRANSISTOR 2SC3545-T43	
L1603	1-412-058-11	INDUCTOR CHIP 10μH		Q456	8-729-107-31	TRANSISTOR 2SC3545-T43	
L1604	1-412-058-11	INDUCTOR CHIP 10μH		Q457	8-729-107-31	TRANSISTOR 2SC3545-T43	
L1708	1-412-058-11	INDUCTOR CHIP 10μH		Q501	8-729-107-31	TRANSISTOR 2SC3545-T43	
L1709	1-412-058-11	INDUCTOR CHIP 10μH		Q505	8-729-107-31	TRANSISTOR 2SC3545-T43	
L1800	1-412-058-11	INDUCTOR CHIP 10μH		Q506	8-729-107-31	TRANSISTOR 2SC3545-T43	
L1801	1-412-058-11	INDUCTOR CHIP 10μH		Q507	8-729-107-31	TRANSISTOR 2SC3545-T43	
L2000	1-412-058-11	INDUCTOR CHIP 10μH		Q551	8-729-107-31	TRANSISTOR 2SC3545-T43	
L2101	1-406-663-21	INDUCTOR 47μH		Q555	8-729-107-31	TRANSISTOR 2SC3545-T43	
L2102	1-406-663-21	INDUCTOR 47μH		Q556	8-729-107-31	TRANSISTOR 2SC3545-T43	
L2103	1-406-663-21	INDUCTOR 47μH		Q557	8-729-107-31	TRANSISTOR 2SC3545-T43	
L2104	1-406-979-11	INDUCTOR 220μH		Q600	1-801-806-11	TRANSISTOR DTC144EKA-T146	
L2105	1-406-979-11	INDUCTOR 220μH		Q601	1-801-806-11	TRANSISTOR DTC144EKA-T146	
L2106	1-406-663-21	INDUCTOR 47μH		Q602	1-801-806-11	TRANSISTOR DTC144EKA-T146	
L2107	1-406-663-21	INDUCTOR 47μH		Q800	8-729-230-49	TRANSISTOR 2SC2712-YG	
L2108	1-406-663-21	INDUCTOR 47μH		Q801	8-729-230-49	TRANSISTOR 2SC2712-YG	
L2109	1-412-533-21	INDUCTOR 47μH		Q802	8-729-230-49	TRANSISTOR 2SC2712-YG	
L2110	1-412-533-21	INDUCTOR 47μH		Q803	8-729-216-22	TRANSISTOR 2SA1162-G	
L2111	1-406-663-21	INDUCTOR 47μH		Q805	8-729-230-49	TRANSISTOR 2SC2712-YG	
<TRANSISTOR>				Q807	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1	8-729-230-49	TRANSISTOR 2SC2712-YG		Q808	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q2	8-729-230-49	TRANSISTOR 2SC2712-YG		Q809	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q3	8-729-216-22	TRANSISTOR 2SA1162-G		Q810	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q4	8-729-230-49	TRANSISTOR 2SC2712-YG		Q811	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q5	8-729-230-49	TRANSISTOR 2SC2712-YG		Q812	8-729-216-22	TRANSISTOR 2SA1162-G	
Q6	8-729-216-22	TRANSISTOR 2SA1162-G		Q813	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q8	8-729-112-65	TRANSISTOR 2SA1462-Y33		Q814	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q9	8-729-230-49	TRANSISTOR 2SC2712-YG		Q815	8-729-230-49	TRANSISTOR 2SC2712-YG	
				Q816	8-729-230-49	TRANSISTOR 2SC2712-YG	

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
Q817	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1415	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1000	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1416	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1001	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1417	8-729-107-31	TRANSISTOR 2SC3545-T43	
Q1002	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1418	8-729-230-49	TRANSISTOR 2SC2712-YG	
				Q1419	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1004	8-729-216-22	TRANSISTOR 2SA1162-G		Q1420	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1005	8-729-216-22	TRANSISTOR 2SA1162-G		Q1421	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1006	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1422	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1007	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1423	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1008	8-729-216-22	TRANSISTOR 2SA1162-G		Q1424	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1009	8-729-216-22	TRANSISTOR 2SA1162-G		Q1425	8-729-903-10	TRANSISTOR FMW1	
Q1010	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1426	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1011	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1427	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1012	8-729-216-22	TRANSISTOR 2SA1162-G		Q1428	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1013	8-729-216-22	TRANSISTOR 2SA1162-G		Q1429	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1014	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1600	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1015	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1601	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q1016	8-729-216-22	TRANSISTOR 2SA1162-G		Q1602	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1017	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1603	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1018	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1604	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1019	8-729-216-22	TRANSISTOR 2SA1162-G		Q1609	8-729-902-96	TRANSISTOR FMS1	
Q1020	8-729-216-22	TRANSISTOR 2SA1162-G		Q1610	8-729-902-96	TRANSISTOR FMS1	
Q1021	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1611	8-729-902-96	TRANSISTOR FMS1	
Q1022	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1709	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1023	8-729-216-22	TRANSISTOR 2SA1162-G		Q1710	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1024	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1711	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1025	8-729-216-22	TRANSISTOR 2SA1162-G		Q1800	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1028	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1801	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1029	8-729-216-22	TRANSISTOR 2SA1162-G		Q1802	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1030	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1803	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1031	1-801-806-11	TRANSISTOR DTC144EKA-T146		Q1804	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1033	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1806	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1201	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1807	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1202	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1808	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1203	8-729-216-22	TRANSISTOR 2SA1162-G		Q1809	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q1204	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1811	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1205	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1812	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1206	8-729-216-22	TRANSISTOR 2SA1162-G		Q1813	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1207	8-729-230-49	TRANSISTOR 2SC2712-YG		Q1814	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1208	8-729-216-22	TRANSISTOR 2SA1162-G		Q1815	8-729-216-22	TRANSISTOR 2SA1162-G	
Q1216	8-729-216-22	TRANSISTOR 2SA1162-G		Q2100	1-801-806-11	TRANSISTOR DTC144EKA-T146	
Q1217	8-729-230-49	TRANSISTOR 2SC2712-YG		Q2101	8-729-900-53	TRANSISTOR DTC114EK	
Q1218	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q1219	8-729-216-22	TRANSISTOR 2SA1162-G					
Q1220	8-729-216-22	TRANSISTOR 2SA1162-G					
Q1221	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q1222	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q1223	8-729-216-22	TRANSISTOR 2SA1162-G					
Q1224	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q1225	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q1226	8-729-216-22	TRANSISTOR 2SA1162-G					
Q1227	8-729-216-22	TRANSISTOR 2SA1162-G					
Q1228	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q1229	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q1230	8-729-216-22	TRANSISTOR 2SA1162-G					
Q1403	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q1404	1-801-806-11	TRANSISTOR DTC144EKA-T146					
Q1405	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q1408	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q1414	8-729-230-49	TRANSISTOR 2SC2712-YG					

<RESISTOR>

R1	1-216-001-00	RES,CHIP	10	5%	1/10W
R2	1-216-001-00	RES,CHIP	10	5%	1/10W
R3	1-216-631-11	METAL CHIP	150	0.50%	1/10W
R4	1-216-631-11	METAL CHIP	150	0.50%	1/10W
R5	1-216-001-00	RES,CHIP	10	5%	1/10W
R6	1-216-089-91	RES,CHIP	47K	5%	1/10W
R7	1-216-089-91	RES,CHIP	47K	5%	1/10W
R8	1-216-631-11	METAL CHIP	150	0.50%	1/10W
R9	1-216-631-11	METAL CHIP	150	0.50%	1/10W
R10	1-216-089-91	RES,CHIP	47K	5%	1/10W
R11	1-216-001-00	RES,CHIP	10	5%	1/10W
R12	1-216-631-11	METAL CHIP	150	0.50%	1/10W
R13	1-216-631-11	METAL CHIP	150	0.50%	1/10W
R14	1-216-001-00	RES,CHIP	10	5%	1/10W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R15	1-216-001-00	RES,CHIP	10 5% 1/10W	R74	1-216-025-91	RES,CHIP	100 5% 1/10W
R16	1-216-089-91	RES,CHIP	47K 5% 1/10W	R75	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W
R17	1-216-089-91	RES,CHIP	47K 5% 1/10W	R76	1-216-025-91	RES,CHIP	100 5% 1/10W
R18	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R77	1-216-041-00	RES,CHIP	470 5% 1/10W
R19	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R78	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R20	1-216-001-00	RES,CHIP	10 5% 1/10W	R79	1-216-013-00	RES,CHIP	33 5% 1/10W
R21	1-216-001-00	RES,CHIP	10 5% 1/10W	R80	1-216-013-00	RES,CHIP	33 5% 1/10W
R22	1-216-001-00	RES,CHIP	10 5% 1/10W	R81	1-216-025-91	RES,CHIP	100 5% 1/10W
R23	1-216-089-91	RES,CHIP	47K 5% 1/10W	R82	1-216-073-00	RES,CHIP	10K 5% 1/10W
R24	1-216-089-91	RES,CHIP	47K 5% 1/10W	R83	1-216-049-91	RES,CHIP	1K 5% 1/10W
R25	1-216-097-91	RES,CHIP	100K 5% 1/10W	R84	1-216-071-00	RES,CHIP	8.2K 5% 1/10W
R26	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R85	1-216-025-91	RES,CHIP	100 5% 1/10W
R27	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R86	1-216-025-91	RES,CHIP	100 5% 1/10W
R28	1-216-073-00	RES,CHIP	10K 5% 1/10W	R87	1-216-073-00	RES,CHIP	10K 5% 1/10W
R29	1-216-025-91	RES,CHIP	100 5% 1/10W	R88	1-216-089-91	RES,CHIP	47K 5% 1/10W
R30	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R89	1-216-025-91	RES,CHIP	100 5% 1/10W
R31	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R90	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R32	1-216-097-91	RES,CHIP	100K 5% 1/10W	R91	1-216-645-11	METAL CHIP	560 0.50% 1/10W
R33	1-216-073-00	RES,CHIP	10K 5% 1/10W	R92	1-216-073-00	RES,CHIP	10K 5% 1/10W
R34	1-216-041-00	RES,CHIP	470 5% 1/10W	R93	1-216-657-11	METAL CHIP	1.8K 0.50% 1/10W
R35	1-216-089-91	RES,CHIP	47K 5% 1/10W	R95	1-216-025-91	RES,CHIP	100 5% 1/10W
R36	1-216-635-11	METAL CHIP	220 0.50% 1/10W	R96	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R37	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R97	1-216-049-91	RES,CHIP	1K 5% 1/10W
R38	1-216-073-00	RES,CHIP	10K 5% 1/10W	R98	1-216-049-91	RES,CHIP	1K 5% 1/10W
R39	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R99	1-216-025-91	RES,CHIP	100 5% 1/10W
R40	1-216-089-91	RES,CHIP	47K 5% 1/10W	R100	1-216-013-00	RES,CHIP	33 5% 1/10W
R41	1-216-001-00	RES,CHIP	10 5% 1/10W	R101	1-216-025-91	RES,CHIP	100 5% 1/10W
R42	1-216-095-00	RES,CHIP	82K 5% 1/10W	R200	1-216-017-91	RES,CHIP	47 5% 1/10W
R43	1-220-259-11	RES,CHIP	150 5% 1/4W	R201	1-216-049-91	RES,CHIP	1K 5% 1/10W
R44	1-216-295-91	SHORT 0		R202	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
R45	1-216-635-11	METAL CHIP	220 0.50% 1/10W	R203	1-216-017-91	RES,CHIP	47 5% 1/10W
R46	1-220-259-11	RES,CHIP	150 5% 1/4W	R204	1-216-017-91	RES,CHIP	47 5% 1/10W
R47	1-216-025-91	RES,CHIP	100 5% 1/10W	R205	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R48	1-216-635-11	METAL CHIP	220 0.50% 1/10W	R206	1-216-017-91	RES,CHIP	47 5% 1/10W
R49	1-216-073-00	RES,CHIP	10K 5% 1/10W	R207	1-216-049-91	RES,CHIP	1K 5% 1/10W
R50	1-216-097-91	RES,CHIP	100K 5% 1/10W	R208	1-216-025-91	RES,CHIP	100 5% 1/10W
R51	1-216-049-91	RES,CHIP	1K 5% 1/10W	R209	1-216-121-91	RES,CHIP	1M 5% 1/10W
R52	1-216-049-91	RES,CHIP	1K 5% 1/10W	R210	1-216-017-91	RES,CHIP	47 5% 1/10W
R53	1-216-001-00	RES,CHIP	10 5% 1/10W	R211	1-216-061-00	RES,CHIP	3.3K 5% 1/10W
R54	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R212	1-216-017-91	RES,CHIP	47 5% 1/10W
R56	1-216-089-91	RES,CHIP	47K 5% 1/10W	R213	1-216-295-91	SHORT 0	
R57	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R214	1-216-089-91	RES,CHIP	47K 5% 1/10W
R58	1-216-049-91	RES,CHIP	1K 5% 1/10W	R215	1-216-025-91	RES,CHIP	100 5% 1/10W
R59	1-220-259-11	RES,CHIP	150 5% 1/4W	R216	1-216-017-91	RES,CHIP	47 5% 1/10W
R60	1-220-259-11	RES,CHIP	150 5% 1/4W	R217	1-216-049-91	RES,CHIP	1K 5% 1/10W
R61	1-216-295-91	SHORT 0		R218	1-216-017-91	RES,CHIP	47 5% 1/10W
R62	1-216-635-11	METAL CHIP	220 0.50% 1/10W	R219	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R63	1-216-001-00	RES,CHIP	10 5% 1/10W	R220	1-216-017-91	RES,CHIP	47 5% 1/10W
R64	1-216-635-11	METAL CHIP	220 0.50% 1/10W	R221	1-216-025-91	RES,CHIP	100 5% 1/10W
R65	1-218-767-11	METAL CHIP	430K 0.50% 1/10W	R222	1-216-049-91	RES,CHIP	1K 5% 1/10W
R66	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R223	1-216-017-91	RES,CHIP	47 5% 1/10W
R67	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R224	1-216-121-91	RES,CHIP	1M 5% 1/10W
R68	1-216-049-91	RES,CHIP	1K 5% 1/10W	R225	1-216-061-00	RES,CHIP	3.3K 5% 1/10W
R69	1-220-259-11	RES,CHIP	150 5% 1/4W	R226	1-216-017-91	RES,CHIP	47 5% 1/10W
R70	1-220-259-11	RES,CHIP	150 5% 1/4W	R227	1-216-089-91	RES,CHIP	47K 5% 1/10W
R71	1-216-295-91	SHORT 0		R228	1-216-295-91	SHORT 0	
R72	1-216-635-11	METAL CHIP	220 0.50% 1/10W	R229	1-216-025-91	RES,CHIP	100 5% 1/10W
R73	1-216-013-00	RES,CHIP	33 5% 1/10W	R230	1-216-017-91	RES,CHIP	47 5% 1/10W

Ref.No.	Part No.	Description	Remark			Ref.No.	Part No.	Description	Remark		
R231	1-216-661-11	METAL CHIP	2.7K	0.50%	1/10W	R419	1-216-045-00	RES,CHIP	680	5%	1/10W
R232	1-216-017-91	RES,CHIP	47	5%	1/10W	R420	1-216-045-00	RES,CHIP	680	5%	1/10W
R233	1-216-025-91	RES,CHIP	100	5%	1/10W	R423	1-216-045-00	RES,CHIP	680	5%	1/10W
R234	1-216-017-91	RES,CHIP	47	5%	1/10W	R424	1-216-045-00	RES,CHIP	680	5%	1/10W
R235	1-216-049-91	RES,CHIP	1K	5%	1/10W	R426	1-216-045-00	RES,CHIP	680	5%	1/10W
R236	1-216-017-91	RES,CHIP	47	5%	1/10W	R427	1-216-017-91	RES,CHIP	47	5%	1/10W
R237	1-216-013-00	RES,CHIP	33	5%	1/10W	R430	1-216-017-91	RES,CHIP	47	5%	1/10W
R238	1-216-049-91	RES,CHIP	1K	5%	1/10W	R431	1-216-017-91	RES,CHIP	47	5%	1/10W
R239	1-216-121-91	RES,CHIP	1M	5%	1/10W	R432	1-216-017-91	RES,CHIP	47	5%	1/10W
R240	1-216-089-91	RES,CHIP	47K	5%	1/10W	R433	1-216-017-91	RES,CHIP	47	5%	1/10W
R241	1-216-061-00	RES,CHIP	3.3K	5%	1/10W	R435	1-216-017-91	RES,CHIP	47	5%	1/10W
R242	1-216-017-91	RES,CHIP	47	5%	1/10W	R436	1-216-017-91	RES,CHIP	47	5%	1/10W
R243	1-216-295-91	SHORT 0				R437	1-216-017-91	RES,CHIP	47	5%	1/10W
R244	1-216-017-91	RES,CHIP	47	5%	1/10W	R438	1-216-017-91	RES,CHIP	47	5%	1/10W
R245	1-216-025-91	RES,CHIP	100	5%	1/10W	R439	1-216-017-91	RES,CHIP	47	5%	1/10W
R246	1-216-067-00	RES,CHIP	5.6K	5%	1/10W	R440	1-216-017-91	RES,CHIP	47	5%	1/10W
R247	1-216-063-91	RES,CHIP	3.9K	5%	1/10W	R441	1-216-017-91	RES,CHIP	47	5%	1/10W
R248	1-216-039-00	RES,CHIP	390	5%	1/10W	R442	1-216-017-91	RES,CHIP	47	5%	1/10W
R249	1-216-017-91	RES,CHIP	47	5%	1/10W	R443	1-216-647-11	METAL CHIP	680	0.50%	1/10W
R250	1-216-013-00	RES,CHIP	33	5%	1/10W	R444	1-216-647-11	METAL CHIP	680	0.50%	1/10W
R251	1-216-017-91	RES,CHIP	47	5%	1/10W	R445	1-216-691-11	METAL CHIP	47K	0.50%	1/10W
R252	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R446	1-216-699-11	METAL CHIP	100K	0.50%	1/10W
R253	1-216-049-91	RES,CHIP	1K	5%	1/10W	R447	1-216-647-11	METAL CHIP	680	0.50%	1/10W
R254	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R448	1-216-647-11	METAL CHIP	680	0.50%	1/10W
R255	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R449	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R256	1-216-017-91	RES,CHIP	47	5%	1/10W	R450	1-216-077-00	RES,CHIP	15K	5%	1/10W
R257	1-216-017-91	RES,CHIP	47	5%	1/10W	R451	1-216-017-91	RES,CHIP	47	5%	1/10W
R258	1-216-017-91	RES,CHIP	47	5%	1/10W	R452	1-216-049-91	RES,CHIP	1K	5%	1/10W
R259	1-216-017-91	RES,CHIP	47	5%	1/10W	R453	1-216-049-91	RES,CHIP	1K	5%	1/10W
R260	1-216-017-91	RES,CHIP	47	5%	1/10W	R454	1-216-049-91	RES,CHIP	1K	5%	1/10W
R261	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R455	1-216-049-91	RES,CHIP	1K	5%	1/10W
R262	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R483	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R263	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R484	1-216-043-91	RES,CHIP	560	5%	1/10W
R273	1-216-085-00	RES,CHIP	33K	5%	1/10W	R485	1-216-624-11	METAL CHIP	75	0.50%	1/10W
R274	1-216-085-00	RES,CHIP	33K	5%	1/10W	R486	1-216-017-91	RES,CHIP	47	5%	1/10W
R275	1-216-085-00	RES,CHIP	33K	5%	1/10W	R487	1-216-659-11	METAL CHIP	2.2K	0.50%	1/10W
R276	1-216-295-91	SHORT 0				R488	1-216-663-11	METAL CHIP	3.3K	0.50%	1/10W
R277	1-216-295-91	SHORT 0				R489	1-216-629-11	METAL CHIP	120	0.50%	1/10W
R278	1-216-295-91	SHORT 0				R491	1-216-295-91	SHORT 0			
R391	1-216-001-00	RES,CHIP	10	5%	1/10W	R492	1-216-089-91	RES,CHIP	47K	5%	1/10W
R392	1-216-659-11	METAL CHIP	2.2K	0.50%	1/10W	R493	1-216-647-11	METAL CHIP	680	0.50%	1/10W
R393	1-216-001-00	RES,CHIP	10	5%	1/10W	R500	1-216-295-91	SHORT 0			
R394	1-216-659-11	METAL CHIP	2.2K	0.50%	1/10W	R501	1-216-017-91	RES,CHIP	47	5%	1/10W
R395	1-216-001-00	RES,CHIP	10	5%	1/10W	R502	1-216-049-91	RES,CHIP	1K	5%	1/10W
R396	1-216-659-11	METAL CHIP	2.2K	0.50%	1/10W	R503	1-216-049-91	RES,CHIP	1K	5%	1/10W
R400	1-216-025-91	RES,CHIP	100	5%	1/10W	R504	1-216-049-91	RES,CHIP	1K	5%	1/10W
R401	1-216-017-91	RES,CHIP	47	5%	1/10W	R505	1-216-049-91	RES,CHIP	1K	5%	1/10W
R402	1-216-025-91	RES,CHIP	100	5%	1/10W	R533	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R403	1-216-017-91	RES,CHIP	47	5%	1/10W	R534	1-216-043-91	RES,CHIP	560	5%	1/10W
R404	1-216-025-91	RES,CHIP	100	5%	1/10W	R535	1-216-624-11	METAL CHIP	75	0.50%	1/10W
R405	1-216-017-91	RES,CHIP	47	5%	1/10W	R536	1-216-025-91	RES,CHIP	100	5%	1/10W
R406	1-216-025-91	RES,CHIP	100	5%	1/10W	R538	1-216-025-91	RES,CHIP	100	5%	1/10W
R408	1-216-017-91	RES,CHIP	47	5%	1/10W	R539	1-216-037-00	RES,CHIP	330	5%	1/10W
R409	1-216-045-00	RES,CHIP	680	5%	1/10W	R540	1-216-025-91	RES,CHIP	100	5%	1/10W
R411	1-216-045-00	RES,CHIP	680	5%	1/10W	R541	1-216-017-91	RES,CHIP	47	5%	1/10W
R413	1-216-045-00	RES,CHIP	680	5%	1/10W	R542	1-216-025-91	RES,CHIP	100	5%	1/10W
R416	1-216-651-11	METAL CHIP	1K	0.50%	1/10W	R543	1-216-037-00	RES,CHIP	330	5%	1/10W
R417	1-216-651-11	METAL CHIP	1K	0.50%	1/10W	R544	1-216-025-91	RES,CHIP	100	5%	1/10W
R418	1-216-651-11	METAL CHIP	1K	0.50%	1/10W						



Ref.No.	Part No.	Description		Remark	Ref.No.	Part No.	Description		Remark
R545	1-216-017-91	RES,CHIP	47	5% 1/10W	R644	1-218-754-11	METAL CHIP	120K	0.50% 1/10W
R547	1-216-017-91	RES,CHIP	47	5% 1/10W	R645	1-218-754-11	METAL CHIP	120K	0.50% 1/10W
R548	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R646	1-218-754-11	METAL CHIP	120K	0.50% 1/10W
R549	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W	R647	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R550	1-216-629-11	METAL CHIP	120	0.50% 1/10W	R648	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R551	1-216-017-91	RES,CHIP	47	5% 1/10W	R649	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R552	1-216-049-91	RES,CHIP	1K	5% 1/10W	R650	1-216-025-91	RES,CHIP	100	5% 1/10W
R553	1-216-049-91	RES,CHIP	1K	5% 1/10W	R651	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R554	1-216-049-91	RES,CHIP	1K	5% 1/10W	R652	1-216-691-11	METAL CHIP	47K	0.50% 1/10W
R555	1-216-049-91	RES,CHIP	1K	5% 1/10W	R653	1-216-025-91	RES,CHIP	100	5% 1/10W
R583	1-216-651-11	METAL CHIP	1K	0.50% 1/10W	R654	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R584	1-216-043-91	RES,CHIP	560	5% 1/10W	R655	1-216-691-11	METAL CHIP	47K	0.50% 1/10W
R585	1-216-624-11	METAL CHIP	75	0.50% 1/10W	R656	1-216-025-91	RES,CHIP	100	5% 1/10W
R586	1-216-025-91	RES,CHIP	100	5% 1/10W	R657	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R587	1-216-295-91	SHORT 0			R658	1-216-691-11	METAL CHIP	47K	0.50% 1/10W
R588	1-216-025-91	RES,CHIP	100	5% 1/10W	R659	1-216-657-11	METAL CHIP	1.8K	0.50% 1/10W
R589	1-216-037-00	RES,CHIP	330	5% 1/10W	R660	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R590	1-216-025-91	RES,CHIP	100	5% 1/10W	R661	1-216-657-11	METAL CHIP	1.8K	0.50% 1/10W
R591	1-216-049-91	RES,CHIP	1K	5% 1/10W	R662	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R592	1-216-025-91	RES,CHIP	100	5% 1/10W	R663	1-216-657-11	METAL CHIP	1.8K	0.50% 1/10W
R593	1-216-017-91	RES,CHIP	47	5% 1/10W	R664	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R594	1-216-647-11	METAL CHIP	680	0.50% 1/10W	R665	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R595	1-216-629-11	METAL CHIP	120	0.50% 1/10W	R666	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R597	1-216-017-91	RES,CHIP	47	5% 1/10W	R667	1-216-671-11	METAL CHIP	6.8K	0.50% 1/10W
R598	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R668	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R599	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W	R669	1-216-671-11	METAL CHIP	6.8K	0.50% 1/10W
R600	1-216-699-11	METAL CHIP	100K	0.50% 1/10W	R670	1-216-671-11	METAL CHIP	6.8K	0.50% 1/10W
R601	1-216-699-11	METAL CHIP	100K	0.50% 1/10W	R671	1-216-671-11	METAL CHIP	6.8K	0.50% 1/10W
R602	1-216-699-11	METAL CHIP	100K	0.50% 1/10W	R672	1-216-655-11	METAL CHIP	1.5K	0.50% 1/10W
R603	1-216-699-11	METAL CHIP	100K	0.50% 1/10W	R673	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
R604	1-216-699-11	METAL CHIP	100K	0.50% 1/10W	R674	1-216-671-11	METAL CHIP	6.8K	0.50% 1/10W
R605	1-216-699-11	METAL CHIP	100K	0.50% 1/10W	R675	1-216-655-11	METAL CHIP	1.5K	0.50% 1/10W
R606	1-216-693-11	METAL CHIP	56K	0.50% 1/10W	R676	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
R607	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W	R680	1-216-671-11	METAL CHIP	6.8K	0.50% 1/10W
R608	1-216-695-11	METAL CHIP	68K	0.50% 1/10W	R681	1-216-655-11	METAL CHIP	1.5K	0.50% 1/10W
R609	1-216-049-91	RES,CHIP	1K	5% 1/10W	R682	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
R610	1-216-693-11	METAL CHIP	56K	0.50% 1/10W	R689	1-216-049-91	RES,CHIP	1K	5% 1/10W
R611	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W	R690	1-216-651-11	METAL CHIP	1K	0.50% 1/10W
R612	1-216-695-11	METAL CHIP	68K	0.50% 1/10W	R691	1-216-025-91	RES,CHIP	100	5% 1/10W
R613	1-216-693-11	METAL CHIP	56K	0.50% 1/10W	R692	1-216-025-91	RES,CHIP	100	5% 1/10W
R614	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W	R693	1-216-025-91	RES,CHIP	100	5% 1/10W
R615	1-216-695-11	METAL CHIP	68K	0.50% 1/10W	R696	1-216-025-91	RES,CHIP	100	5% 1/10W
R617	1-216-687-11	METAL CHIP	33K	0.50% 1/10W	R698	1-216-295-91	SHORT 0		
R619	1-216-687-11	METAL CHIP	33K	0.50% 1/10W	R699	1-216-025-91	RES,CHIP	100	5% 1/10W
R621	1-216-687-11	METAL CHIP	33K	0.50% 1/10W	R700	1-216-295-91	SHORT 0		
R629	1-216-699-11	METAL CHIP	100K	0.50% 1/10W	R701	1-216-025-91	RES,CHIP	100	5% 1/10W
R631	1-216-699-11	METAL CHIP	100K	0.50% 1/10W	R702	1-216-295-91	SHORT 0		
R633	1-216-699-11	METAL CHIP	100K	0.50% 1/10W	R703	1-216-073-00	RES,CHIP	10K	5% 1/10W
R634	1-216-049-91	RES,CHIP	1K	5% 1/10W	R704	1-216-097-91	RES,CHIP	100K	5% 1/10W
R635	1-216-689-11	METAL CHIP	39K	0.50% 1/10W	R705	1-216-033-00	RES,CHIP	220	5% 1/10W
R636	1-216-695-11	METAL CHIP	68K	0.50% 1/10W	R706	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
R637	1-216-695-11	METAL CHIP	68K	0.50% 1/10W	R707	1-216-025-91	RES,CHIP	100	5% 1/10W
R638	1-216-689-11	METAL CHIP	39K	0.50% 1/10W	R708	1-216-025-91	RES,CHIP	100	5% 1/10W
R639	1-216-679-11	METAL CHIP	15K	0.50% 1/10W	R709	1-216-073-00	RES,CHIP	10K	5% 1/10W
R640	1-216-695-11	METAL CHIP	68K	0.50% 1/10W	R710	1-216-073-00	RES,CHIP	10K	5% 1/10W
R641	1-216-689-11	METAL CHIP	39K	0.50% 1/10W	R711	1-216-025-91	RES,CHIP	100	5% 1/10W
R642	1-216-679-11	METAL CHIP	15K	0.50% 1/10W	R712	1-216-025-91	RES,CHIP	100	5% 1/10W
R643	1-216-679-11	METAL CHIP	15K	0.50% 1/10W	R713	1-216-025-91	RES,CHIP	100	5% 1/10W
					R714	1-216-025-91	RES,CHIP	100	5% 1/10W

Ref.No.	Part No.	Description	Remark			Ref.No.	Part No.	Description	Remark		
R715	1-216-025-91	RES,CHIP	100	5%	1/10W	R853	1-216-663-11	METAL CHIP	3.3K	0.50%	1/10W
R716	1-216-025-91	RES,CHIP	100	5%	1/10W	R854	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R717	1-216-025-91	RES,CHIP	100	5%	1/10W	R855	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R718	1-216-699-11	METAL CHIP	100K	0.50%	1/10W	R856	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R719	1-216-699-11	METAL CHIP	100K	0.50%	1/10W	R857	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R720	1-216-699-11	METAL CHIP	100K	0.50%	1/10W	R858	1-216-677-11	METAL CHIP	12K	0.50%	1/10W
R800	1-216-677-11	METAL CHIP	12K	0.50%	1/10W	R859	1-216-691-11	METAL CHIP	47K	0.50%	1/10W
R801	1-216-025-91	RES,CHIP	100	5%	1/10W	R860	1-216-659-11	METAL CHIP	2.2K	0.50%	1/10W
R802	1-216-017-91	RES,CHIP	47	5%	1/10W	R861	1-216-675-11	METAL CHIP	10K	0.50%	1/10W
R803	1-216-661-11	METAL CHIP	2.7K	0.50%	1/10W	R862	1-216-677-11	METAL CHIP	12K	0.50%	1/10W
R804	1-216-673-11	METAL CHIP	8.2K	0.50%	1/10W	R863	1-216-677-11	METAL CHIP	12K	0.50%	1/10W
R805	1-216-683-11	METAL CHIP	22K	0.50%	1/10W	R864	1-216-691-11	METAL CHIP	47K	0.50%	1/10W
R806	1-216-679-11	METAL CHIP	15K	0.50%	1/10W	R866	1-216-675-11	METAL CHIP	10K	0.50%	1/10W
R807	1-216-673-11	METAL CHIP	8.2K	0.50%	1/10W	R867	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R809	1-216-683-11	METAL CHIP	22K	0.50%	1/10W	R868	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R810	1-216-675-11	METAL CHIP	10K	0.50%	1/10W	R869	1-216-001-00	RES,CHIP	10	5%	1/10W
R811	1-216-661-11	METAL CHIP	2.7K	0.50%	1/10W	R870	1-216-603-11	METAL CHIP	10	0.50%	1/10W
R812	1-216-673-11	METAL CHIP	8.2K	0.50%	1/10W	R871	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
R813	1-216-025-91	RES,CHIP	100	5%	1/10W	R872	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
R814	1-216-025-91	RES,CHIP	100	5%	1/10W	R873	1-216-665-11	METAL CHIP	3.9K	0.50%	1/10W
R815	1-216-025-91	RES,CHIP	100	5%	1/10W	R874	1-216-675-11	METAL CHIP	10K	0.50%	1/10W
R816	1-216-673-11	METAL CHIP	8.2K	0.50%	1/10W	R875	1-216-675-11	METAL CHIP	10K	0.50%	1/10W
R817	1-216-669-11	METAL CHIP	5.6K	0.50%	1/10W	R876	1-216-677-11	METAL CHIP	12K	0.50%	1/10W
R818	1-216-663-11	METAL CHIP	3.3K	0.50%	1/10W	R877	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R819	1-218-760-11	METAL CHIP	220K	0.50%	1/10W	R878	1-216-025-91	RES,CHIP	100	5%	1/10W
R820	1-218-760-11	METAL CHIP	220K	0.50%	1/10W	R879	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R821	1-218-760-11	METAL CHIP	220K	0.50%	1/10W	R880	1-216-001-00	RES,CHIP	10	5%	1/10W
R822	1-216-697-91	METAL CHIP	82K	0.50%	1/10W	R881	1-218-760-11	METAL CHIP	220K	0.50%	1/10W
R823	1-216-673-11	METAL CHIP	8.2K	0.50%	1/10W	R882	1-216-073-00	RES,CHIP	10K	5%	1/10W
R824	1-216-675-11	METAL CHIP	10K	0.50%	1/10W	R883	1-216-035-00	RES,CHIP	270	5%	1/10W
R825	1-216-685-11	METAL CHIP	27K	0.50%	1/10W	R884	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R826	1-216-679-11	METAL CHIP	15K	0.50%	1/10W	R885	1-218-758-11	METAL CHIP	180K	0.50%	1/10W
R827	1-216-671-11	METAL CHIP	6.8K	0.50%	1/10W	R886	1-218-764-11	METAL CHIP	330K	0.50%	1/10W
R828	1-216-673-11	METAL CHIP	8.2K	0.50%	1/10W	R887	1-216-691-11	METAL CHIP	47K	0.50%	1/10W
R829	1-216-675-11	METAL CHIP	10K	0.50%	1/10W	R888	1-216-697-91	METAL CHIP	82K	0.50%	1/10W
R830	1-216-025-91	RES,CHIP	100	5%	1/10W	R889	1-216-073-00	RES,CHIP	10K	5%	1/10W
R831	1-216-025-91	RES,CHIP	100	5%	1/10W	R890	1-218-760-11	METAL CHIP	220K	0.50%	1/10W
R832	1-216-675-11	METAL CHIP	10K	0.50%	1/10W	R891	1-216-035-00	RES,CHIP	270	5%	1/10W
R833	1-216-675-11	METAL CHIP	10K	0.50%	1/10W	R892	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R834	1-216-073-00	RES,CHIP	10K	5%	1/10W	R893	1-218-758-11	METAL CHIP	180K	0.50%	1/10W
R835	1-216-659-11	METAL CHIP	2.2K	0.50%	1/10W	R894	1-218-764-11	METAL CHIP	330K	0.50%	1/10W
R836	1-216-677-11	METAL CHIP	12K	0.50%	1/10W	R895	1-216-691-11	METAL CHIP	47K	0.50%	1/10W
R837	1-216-677-11	METAL CHIP	12K	0.50%	1/10W	R896	1-216-691-11	METAL CHIP	47K	0.50%	1/10W
R838	1-216-001-00	RES,CHIP	10	5%	1/10W	R897	1-216-691-11	METAL CHIP	47K	0.50%	1/10W
R839	1-218-760-11	METAL CHIP	220K	0.50%	1/10W	R898	1-216-691-11	METAL CHIP	47K	0.50%	1/10W
R840	1-216-077-00	RES,CHIP	15K	5%	1/10W	R901	1-216-025-91	RES,CHIP	100	5%	1/10W
R841	1-218-760-11	METAL CHIP	220K	0.50%	1/10W	R902	1-216-025-91	RES,CHIP	100	5%	1/10W
R842	1-216-025-91	RES,CHIP	100	5%	1/10W	R903	1-216-025-91	RES,CHIP	100	5%	1/10W
R843	1-218-758-11	METAL CHIP	180K	0.50%	1/10W	R1001	1-216-017-91	RES,CHIP	47	5%	1/10W
R844	1-218-764-11	METAL CHIP	330K	0.50%	1/10W	R1002	1-216-627-11	METAL CHIP	100	0.50%	1/10W
R845	1-216-691-11	METAL CHIP	47K	0.50%	1/10W	R1003	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R846	1-218-760-11	METAL CHIP	220K	0.50%	1/10W	R1004	1-216-055-00	RES,CHIP	1.8K	5%	1/10W
R847	1-218-760-11	METAL CHIP	220K	0.50%	1/10W	R1005	1-216-055-00	RES,CHIP	1.8K	5%	1/10W
R848	1-216-673-11	METAL CHIP	8.2K	0.50%	1/10W	R1006	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R849	1-216-697-91	METAL CHIP	82K	0.50%	1/10W	R1007	1-216-073-00	RES,CHIP	10K	5%	1/10W
R850	1-216-671-11	METAL CHIP	6.8K	0.50%	1/10W	R1008	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R851	1-216-035-00	RES,CHIP	270	5%	1/10W	R1009	1-216-025-91	RES,CHIP	100	5%	1/10W
R852	1-216-073-00	RES,CHIP	10K	5%	1/10W	R1010	1-216-053-00	RES,CHIP	1.5K	5%	1/10W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R1011	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R1076	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
R1013	1-216-017-91	RES,CHIP	47 5% 1/10W	R1077	1-216-025-91	RES,CHIP	100 5% 1/10W
R1014	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R1078	1-216-097-91	RES,CHIP	100K 5% 1/10W
R1015	1-216-025-91	RES,CHIP	100 5% 1/10W	R1079	1-216-051-00	RES,CHIP	1.2K 5% 1/10W
R1016	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R1080	1-216-013-00	RES,CHIP	33 5% 1/10W
R1017	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R1081	1-216-059-00	RES,CHIP	2.7K 5% 1/10W
R1018	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R1082	1-216-025-91	RES,CHIP	100 5% 1/10W
R1019	1-216-025-91	RES,CHIP	100 5% 1/10W	R1083	1-216-025-91	RES,CHIP	100 5% 1/10W
R1020	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R1084	1-216-025-91	RES,CHIP	100 5% 1/10W
R1021	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R1085	1-216-017-91	RES,CHIP	47 5% 1/10W
R1023	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R1086	1-216-025-91	RES,CHIP	100 5% 1/10W
R1024	1-216-025-91	RES,CHIP	100 5% 1/10W	R1087	1-216-033-00	RES,CHIP	220 5% 1/10W
R1025	1-216-051-00	RES,CHIP	1.2K 5% 1/10W	R1088	1-216-029-00	RES,CHIP	150 5% 1/10W
R1026	1-216-025-91	RES,CHIP	100 5% 1/10W	R1089	1-216-025-91	RES,CHIP	100 5% 1/10W
R1027	1-216-017-91	RES,CHIP	47 5% 1/10W	R1091	1-216-089-91	RES,CHIP	47K 5% 1/10W
R1028	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R1092	1-216-061-00	RES,CHIP	3.3K 5% 1/10W
R1029	1-216-025-91	RES,CHIP	100 5% 1/10W	R1093	1-216-049-91	RES,CHIP	1K 5% 1/10W
R1030	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R1094	1-216-089-91	RES,CHIP	47K 5% 1/10W
R1031	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R1095	1-216-017-91	RES,CHIP	47 5% 1/10W
R1032	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R1098	1-216-017-91	RES,CHIP	47 5% 1/10W
R1033	1-216-049-91	RES,CHIP	1K 5% 1/10W	R1099	1-216-017-91	RES,CHIP	47 5% 1/10W
R1034	1-216-049-91	RES,CHIP	1K 5% 1/10W	R1100	1-216-017-91	RES,CHIP	47 5% 1/10W
R1035	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R1101	1-216-017-91	RES,CHIP	47 5% 1/10W
R1036	1-216-049-91	RES,CHIP	1K 5% 1/10W	R1103	1-216-017-91	RES,CHIP	47 5% 1/10W
R1037	1-216-067-00	RES,CHIP	5.6K 5% 1/10W	R1106	1-216-073-00	RES,CHIP	10K 5% 1/10W
R1038	1-216-031-00	RES,CHIP	180 5% 1/10W	R1111	1-216-017-91	RES,CHIP	47 5% 1/10W
R1039	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R1112	1-216-017-91	RES,CHIP	47 5% 1/10W
R1040	1-216-025-91	RES,CHIP	100 5% 1/10W	R1113	1-216-017-91	RES,CHIP	47 5% 1/10W
R1041	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R1118	1-216-017-91	RES,CHIP	47 5% 1/10W
R1042	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R1119	1-216-073-00	RES,CHIP	10K 5% 1/10W
R1043	1-216-025-91	RES,CHIP	100 5% 1/10W	R1120	1-216-073-00	RES,CHIP	10K 5% 1/10W
R1044	1-216-025-91	RES,CHIP	100 5% 1/10W	R1121	1-216-017-91	RES,CHIP	47 5% 1/10W
R1045	1-216-097-91	RES,CHIP	100K 5% 1/10W	R1122	1-216-049-91	RES,CHIP	1K 5% 1/10W
R1046	1-216-051-00	RES,CHIP	1.2K 5% 1/10W	R1123	1-216-017-91	RES,CHIP	47 5% 1/10W
R1047	1-216-059-00	RES,CHIP	2.7K 5% 1/10W	R1124	1-216-071-00	RES,CHIP	8.2K 5% 1/10W
R1048	1-216-013-00	RES,CHIP	33 5% 1/10W	R1125	1-216-059-00	RES,CHIP	2.7K 5% 1/10W
R1049	1-216-049-91	RES,CHIP	1K 5% 1/10W	R1126	1-216-017-91	RES,CHIP	47 5% 1/10W
R1050	1-216-025-91	RES,CHIP	100 5% 1/10W	R1127	1-216-049-91	RES,CHIP	1K 5% 1/10W
R1051	1-216-025-91	RES,CHIP	100 5% 1/10W	R1128	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R1052	1-216-073-00	RES,CHIP	10K 5% 1/10W	R1129	1-216-017-91	RES,CHIP	47 5% 1/10W
R1053	1-216-025-91	RES,CHIP	100 5% 1/10W	R1132	1-216-041-00	RES,CHIP	470 5% 1/10W
R1054	1-216-657-11	METAL CHIP	1.8K 0.50% 1/10W	R1133	1-216-017-91	RES,CHIP	47 5% 1/10W
R1055	1-216-657-11	METAL CHIP	1.8K 0.50% 1/10W	R1200	1-216-017-91	RES,CHIP	47 5% 1/10W
R1056	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R1201	1-216-055-00	RES,CHIP	1.8K 5% 1/10W
R1057	1-216-025-91	RES,CHIP	100 5% 1/10W	R1202	1-216-097-91	RES,CHIP	100K 5% 1/10W
R1058	1-216-025-91	RES,CHIP	100 5% 1/10W	R1203	1-216-017-91	RES,CHIP	47 5% 1/10W
R1059	1-216-025-91	RES,CHIP	100 5% 1/10W	R1204	1-216-021-00	RES,CHIP	68 5% 1/10W
R1063	1-216-073-00	RES,CHIP	10K 5% 1/10W	R1205	1-216-077-00	RES,CHIP	15K 5% 1/10W
R1064	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R1206	1-216-077-00	RES,CHIP	15K 5% 1/10W
R1065	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R1207	1-216-017-91	RES,CHIP	47 5% 1/10W
R1067	1-216-073-00	RES,CHIP	10K 5% 1/10W	R1214	1-216-645-11	METAL CHIP	560 0.50% 1/10W
R1068	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R1215	1-216-049-91	RES,CHIP	1K 5% 1/10W
R1069	1-216-025-91	RES,CHIP	100 5% 1/10W	R1216	1-216-071-00	RES,CHIP	8.2K 5% 1/10W
R1070	1-216-049-91	RES,CHIP	1K 5% 1/10W	R1217	1-216-647-11	METAL CHIP	680 0.50% 1/10W
R1071	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R1218	1-216-025-91	RES,CHIP	100 5% 1/10W
R1072	1-216-071-00	RES,CHIP	8.2K 5% 1/10W	R1219	1-216-295-91	SHORT 0	
R1073	1-216-031-00	RES,CHIP	180 5% 1/10W	R1220	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R1074	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R1221	1-216-067-00	RES,CHIP	5.6K 5% 1/10W
R1075	1-216-651-11	METAL CHIP	1K 0.50% 1/10W				

Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description			Remark
R1222	1-216-043-91	RES,CHIP	560	5%	1/10W	R1323	1-216-671-11	METAL CHIP	6.8K	0.50%	1/10W
R1223	1-216-049-91	RES,CHIP	1K	5%	1/10W	R1325	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R1224	1-216-295-91	SHORT 0				R1326	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R1225	1-216-295-91	SHORT 0				R1327	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R1226	1-216-033-00	RES,CHIP	220	5%	1/10W	R1328	1-216-025-91	RES,CHIP	100	5%	1/10W
R1227	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R1329	1-216-097-91	RES,CHIP	100K	5%	1/10W
R1228	1-216-105-91	RES,CHIP	220K	5%	1/10W	R1330	1-216-051-00	RES,CHIP	1.2K	5%	1/10W
R1229	1-216-041-00	RES,CHIP	470	5%	1/10W	R1331	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R1231	1-216-049-91	RES,CHIP	1K	5%	1/10W	R1401	1-216-017-91	RES,CHIP	47	5%	1/10W
R1232	1-216-025-91	RES,CHIP	100	5%	1/10W	R1406	1-216-089-91	RES,CHIP	47K	5%	1/10W
R1242	1-216-055-00	RES,CHIP	1.8K	5%	1/10W	R1408	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1243	1-216-055-00	RES,CHIP	1.8K	5%	1/10W	R1410	1-216-089-91	RES,CHIP	47K	5%	1/10W
R1244	1-216-055-00	RES,CHIP	1.8K	5%	1/10W	R1412	1-216-025-91	RES,CHIP	100	5%	1/10W
R1245	1-216-055-00	RES,CHIP	1.8K	5%	1/10W	R1416	1-216-089-91	RES,CHIP	47K	5%	1/10W
R1253	1-216-017-91	RES,CHIP	47	5%	1/10W	R1419	1-216-033-00	RES,CHIP	220	5%	1/10W
R1259	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	R1420	1-216-083-00	RES,CHIP	27K	5%	1/10W
R1260	1-216-041-00	RES,CHIP	470	5%	1/10W	R1421	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1265	1-216-025-91	RES,CHIP	100	5%	1/10W	R1422	1-216-091-00	RES,CHIP	56K	5%	1/10W
R1266	1-216-055-00	RES,CHIP	1.8K	5%	1/10W	R1423	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R1267	1-216-055-00	RES,CHIP	1.8K	5%	1/10W	R1424	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R1270	1-216-017-91	RES,CHIP	47	5%	1/10W	R1425	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1278	1-216-025-91	RES,CHIP	100	5%	1/10W	R1426	1-216-295-91	SHORT 0			
R1279	1-216-025-91	RES,CHIP	100	5%	1/10W	R1433	1-216-025-91	RES,CHIP	100	5%	1/10W
R1280	1-216-025-91	RES,CHIP	100	5%	1/10W	R1435	1-216-025-91	RES,CHIP	100	5%	1/10W
R1281	1-216-121-91	RES,CHIP	1M	5%	1/10W	R1436	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1284	1-216-025-91	RES,CHIP	100	5%	1/10W	R1437	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1285	1-216-025-91	RES,CHIP	100	5%	1/10W	R1439	1-216-025-91	RES,CHIP	100	5%	1/10W
R1286	1-216-023-00	RES,CHIP	82	5%	1/10W	R1440	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1287	1-216-295-91	SHORT 0				R1441	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1288	1-216-025-91	RES,CHIP	100	5%	1/10W	R1442	1-216-047-91	RES,CHIP	820	5%	1/10W
R1290	1-216-025-91	RES,CHIP	100	5%	1/10W	R1443	1-216-017-91	RES,CHIP	47	5%	1/10W
R1291	1-216-025-91	RES,CHIP	100	5%	1/10W	R1444	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1292	1-216-025-91	RES,CHIP	100	5%	1/10W	R1445	1-216-049-91	RES,CHIP	1K	5%	1/10W
R1293	1-216-025-91	RES,CHIP	100	5%	1/10W	R1447	1-216-089-91	RES,CHIP	47K	5%	1/10W
R1295	1-216-691-11	METAL CHIP	47K	0.50%	1/10W	R1448	1-216-089-91	RES,CHIP	47K	5%	1/10W
R1296	1-216-679-11	METAL CHIP	15K	0.50%	1/10W	R1450	1-216-017-91	RES,CHIP	47	5%	1/10W
R1297	1-216-295-91	SHORT 0				R1451	1-216-017-91	RES,CHIP	47	5%	1/10W
R1298	1-216-295-91	SHORT 0				R1453	1-216-017-91	RES,CHIP	47	5%	1/10W
R1300	1-216-017-91	RES,CHIP	47	5%	1/10W	R1454	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1303	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R1455	1-216-017-91	RES,CHIP	47	5%	1/10W
R1304	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R1456	1-216-063-91	RES,CHIP	3.9K	5%	1/10W
R1305	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R1457	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1306	1-216-017-91	RES,CHIP	47	5%	1/10W	R1458	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R1307	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R1459	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R1308	1-216-677-11	METAL CHIP	12K	0.50%	1/10W	R1460	1-216-017-91	RES,CHIP	47	5%	1/10W
R1309	1-216-049-91	RES,CHIP	1K	5%	1/10W	R1461	1-218-767-11	METAL CHIP	430K	0.50%	1/10W
R1311	1-216-651-11	METAL CHIP	1K	0.50%	1/10W	R1462	1-216-045-00	RES,CHIP	680	5%	1/10W
R1312	1-216-651-11	METAL CHIP	1K	0.50%	1/10W	R1463	1-216-017-91	RES,CHIP	47	5%	1/10W
R1313	1-216-659-11	METAL CHIP	2.2K	0.50%	1/10W	R1464	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1314	1-216-025-91	RES,CHIP	100	5%	1/10W	R1465	1-216-017-91	RES,CHIP	47	5%	1/10W
R1315	1-216-097-91	RES,CHIP	100K	5%	1/10W	R1466	1-216-017-91	RES,CHIP	47	5%	1/10W
R1316	1-216-051-00	RES,CHIP	1.2K	5%	1/10W	R1467	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1317	1-216-059-00	RES,CHIP	2.7K	5%	1/10W	R1468	1-216-101-00	RES,CHIP	150K	5%	1/10W
R1318	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R1469	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R1319	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R1470	1-216-017-91	RES,CHIP	47	5%	1/10W
R1320	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R1471	1-216-017-91	RES,CHIP	47	5%	1/10W
R1321	1-216-017-91	RES,CHIP	47	5%	1/10W	R1472	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R1322	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R1473	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
						R1474	1-216-053-00	RES,CHIP	1.5K	5%	1/10W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R1475	1-216-059-00	RES,CHIP	2.7K 5% 1/10W	R1633	1-216-085-00	RES,CHIP	33K 5% 1/10W
R1476	1-216-059-00	RES,CHIP	2.7K 5% 1/10W	R1634	1-216-037-00	RES,CHIP	330 5% 1/10W
R1477	1-216-097-91	RES,CHIP	100K 5% 1/10W	R1635	1-216-025-91	RES,CHIP	100 5% 1/10W
R1478	1-216-017-91	RES,CHIP	47 5% 1/10W	R1636	1-216-017-91	RES,CHIP	47 5% 1/10W
R1479	1-216-017-91	RES,CHIP	47 5% 1/10W	R1637	1-216-017-91	RES,CHIP	47 5% 1/10W
R1480	1-216-017-91	RES,CHIP	47 5% 1/10W	R1638	1-216-017-91	RES,CHIP	47 5% 1/10W
R1481	1-216-051-00	RES,CHIP	1.2K 5% 1/10W	R1639	1-216-017-91	RES,CHIP	47 5% 1/10W
R1482	1-216-041-00	RES,CHIP	470 5% 1/10W	R1640	1-216-017-91	RES,CHIP	47 5% 1/10W
R1483	1-216-053-00	RES,CHIP	1.5K 5% 1/10W	R1641	1-216-017-91	RES,CHIP	47 5% 1/10W
R1484	1-216-089-91	RES,CHIP	47K 5% 1/10W	R1642	1-216-017-91	RES,CHIP	47 5% 1/10W
R1499	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R1643	1-216-017-91	RES,CHIP	47 5% 1/10W
R1500	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R1644	1-216-017-91	RES,CHIP	47 5% 1/10W
R1501	1-216-643-11	METAL CHIP	470 0.50% 1/10W	R1645	1-216-017-91	RES,CHIP	47 5% 1/10W
R1502	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R1646	1-216-089-91	RES,CHIP	47K 5% 1/10W
R1503	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R1647	1-216-017-91	RES,CHIP	47 5% 1/10W
R1504	1-216-295-91	SHORT 0		R1648	1-216-081-00	RES,CHIP	22K 5% 1/10W
R1505	1-216-089-91	RES,CHIP	47K 5% 1/10W	R1649	1-216-037-00	RES,CHIP	330 5% 1/10W
R1506	1-216-089-91	RES,CHIP	47K 5% 1/10W	R1650	1-216-017-91	RES,CHIP	47 5% 1/10W
R1507	1-216-653-11	METAL CHIP	1.2K 0.50% 1/10W	R1651	1-216-017-91	RES,CHIP	47 5% 1/10W
R1508	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R1652	1-216-067-00	RES,CHIP	5.6K 5% 1/10W
R1509	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R1653	1-216-017-91	RES,CHIP	47 5% 1/10W
R1510	1-216-653-11	METAL CHIP	1.2K 0.50% 1/10W	R1654	1-216-067-00	RES,CHIP	5.6K 5% 1/10W
R1511	1-216-683-11	METAL CHIP	22K 0.50% 1/10W	R1655	1-216-017-91	RES,CHIP	47 5% 1/10W
R1512	1-216-681-11	METAL CHIP	18K 0.50% 1/10W	R1656	1-216-017-91	RES,CHIP	47 5% 1/10W
R1514	1-216-017-91	RES,CHIP	47 5% 1/10W	R1657	1-216-017-91	RES,CHIP	47 5% 1/10W
R1515	1-216-017-91	RES,CHIP	47 5% 1/10W	R1658	1-216-295-91	SHORT 0	
R1516	1-216-017-91	RES,CHIP	47 5% 1/10W	R1659	1-216-295-91	SHORT 0	
R1517	1-216-017-91	RES,CHIP	47 5% 1/10W	R1660	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R1600	1-216-025-91	RES,CHIP	100 5% 1/10W	R1661	1-216-049-91	RES,CHIP	1K 5% 1/10W
R1601	1-216-025-91	RES,CHIP	100 5% 1/10W	R1662	1-247-807-31	CARBON	100 5% 1/4W
R1602	1-216-083-00	RES,CHIP	27K 5% 1/10W	R1663	1-216-017-91	RES,CHIP	47 5% 1/10W
R1603	1-216-089-91	RES,CHIP	47K 5% 1/10W	R1730	1-216-049-91	RES,CHIP	1K 5% 1/10W
R1604	1-216-133-00	RES,CHIP	3.3M 5% 1/10W	R1731	1-216-049-91	RES,CHIP	1K 5% 1/10W
R1605	1-216-039-00	RES,CHIP	390 5% 1/10W	R1732	1-216-049-91	RES,CHIP	1K 5% 1/10W
R1606	1-216-039-00	RES,CHIP	390 5% 1/10W	R1785	1-216-017-91	RES,CHIP	47 5% 1/10W
R1607	1-216-017-91	RES,CHIP	47 5% 1/10W	R1786	1-216-017-91	RES,CHIP	47 5% 1/10W
R1608	1-216-017-91	RES,CHIP	47 5% 1/10W	R1787	1-216-017-91	RES,CHIP	47 5% 1/10W
R1609	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R1788	1-216-017-91	RES,CHIP	47 5% 1/10W
R1610	1-216-041-00	RES,CHIP	470 5% 1/10W	R1789	1-216-017-91	RES,CHIP	47 5% 1/10W
R1612	1-216-041-00	RES,CHIP	470 5% 1/10W	R1790	1-216-017-91	RES,CHIP	47 5% 1/10W
R1614	1-216-041-00	RES,CHIP	470 5% 1/10W	R1791	1-216-017-91	RES,CHIP	47 5% 1/10W
R1616	1-216-017-91	RES,CHIP	47 5% 1/10W	R1792	1-216-017-91	RES,CHIP	47 5% 1/10W
R1617	1-216-017-91	RES,CHIP	47 5% 1/10W	R1793	1-216-017-91	RES,CHIP	47 5% 1/10W
R1618	1-216-017-91	RES,CHIP	47 5% 1/10W	R1794	1-216-017-91	RES,CHIP	47 5% 1/10W
R1619	1-216-017-91	RES,CHIP	47 5% 1/10W	R1795	1-216-017-91	RES,CHIP	47 5% 1/10W
R1620	1-216-683-11	METAL CHIP	22K 0.50% 1/10W	R1796	1-216-017-91	RES,CHIP	47 5% 1/10W
R1621	1-216-089-91	RES,CHIP	47K 5% 1/10W	R1797	1-216-017-91	RES,CHIP	47 5% 1/10W
R1622	1-216-077-00	RES,CHIP	15K 5% 1/10W	R1798	1-216-017-91	RES,CHIP	47 5% 1/10W
R1623	1-216-017-91	RES,CHIP	47 5% 1/10W	R1800	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R1624	1-216-017-91	RES,CHIP	47 5% 1/10W	R1801	1-216-017-91	RES,CHIP	47 5% 1/10W
R1625	1-216-017-91	RES,CHIP	47 5% 1/10W	R1802	1-216-049-91	RES,CHIP	1K 5% 1/10W
R1626	1-216-017-91	RES,CHIP	47 5% 1/10W	R1803	1-216-001-00	RES,CHIP	10 5% 1/10W
R1627	1-216-081-00	RES,CHIP	22K 5% 1/10W	R1804	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
R1628	1-216-037-00	RES,CHIP	330 5% 1/10W	R1805	1-216-017-91	RES,CHIP	47 5% 1/10W
R1629	1-216-017-91	RES,CHIP	47 5% 1/10W	R1806	1-216-017-91	RES,CHIP	47 5% 1/10W
R1630	1-216-017-91	RES,CHIP	47 5% 1/10W	R1807	1-216-025-91	RES,CHIP	100 5% 1/10W
R1631	1-216-691-11	METAL CHIP	47K 0.50% 1/10W	R1808	1-216-097-91	RES,CHIP	100K 5% 1/10W
R1632	1-216-089-91	RES,CHIP	47K 5% 1/10W	R1809	1-216-097-91	RES,CHIP	100K 5% 1/10W

Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description			Remark
R1810	1-216-097-91	RES,CHIP	100K	5%	1/10W	R2005	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1811	1-216-097-91	RES,CHIP	100K	5%	1/10W	R2006	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1812	1-216-085-00	RES,CHIP	33K	5%	1/10W	R2007	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1813	1-216-033-00	RES,CHIP	220	5%	1/10W	R2009	1-216-025-91	RES,CHIP	100	5%	1/10W
R1814	1-216-001-00	RES,CHIP	10	5%	1/10W	R2011	1-216-025-91	RES,CHIP	100	5%	1/10W
R1815	1-216-017-91	RES,CHIP	47	5%	1/10W	R2012	1-216-017-91	RES,CHIP	47	5%	1/10W
R1816	1-216-017-91	RES,CHIP	47	5%	1/10W	R2013	1-216-017-91	RES,CHIP	47	5%	1/10W
R1817	1-216-699-11	METAL CHIP	100K	0.50%	1/10W	R2015	1-216-017-91	RES,CHIP	47	5%	1/10W
R1818	1-216-049-91	RES,CHIP	1K	5%	1/10W	R2016	1-216-017-91	RES,CHIP	47	5%	1/10W
R1819	1-216-677-11	METAL CHIP	12K	0.50%	1/10W	R2017	1-216-025-91	RES,CHIP	100	5%	1/10W
R1820	1-216-049-91	RES,CHIP	1K	5%	1/10W	R2018	1-216-025-91	RES,CHIP	100	5%	1/10W
R1821	1-216-017-91	RES,CHIP	47	5%	1/10W	R2019	1-216-017-91	RES,CHIP	47	5%	1/10W
R1822	1-216-017-91	RES,CHIP	47	5%	1/10W	R2020	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1823	1-216-017-91	RES,CHIP	47	5%	1/10W	R2021	1-216-017-91	RES,CHIP	47	5%	1/10W
R1824	1-216-017-91	RES,CHIP	47	5%	1/10W	R2022	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1827	1-216-017-91	RES,CHIP	47	5%	1/10W	R2023	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1828	1-216-017-91	RES,CHIP	47	5%	1/10W	R2024	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1829	1-216-017-91	RES,CHIP	47	5%	1/10W	R2025	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1834	1-216-073-00	RES,CHIP	10K	5%	1/10W	R2026	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1835	1-216-063-91	RES,CHIP	3.9K	5%	1/10W	R2027	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1836	1-216-067-00	RES,CHIP	5.6K	5%	1/10W	R2028	1-216-025-91	RES,CHIP	100	5%	1/10W
R1837	1-216-061-00	RES,CHIP	3.3K	5%	1/10W	R2029	1-216-025-91	RES,CHIP	100	5%	1/10W
R1838	1-216-017-91	RES,CHIP	47	5%	1/10W	R2030	1-216-017-91	RES,CHIP	47	5%	1/10W
R1840	1-216-017-91	RES,CHIP	47	5%	1/10W	R2031	1-216-025-91	RES,CHIP	100	5%	1/10W
R1841	1-216-045-00	RES,CHIP	680	5%	1/10W	R2032	1-216-025-91	RES,CHIP	100	5%	1/10W
R1842	1-216-017-91	RES,CHIP	47	5%	1/10W	R2033	1-216-017-91	RES,CHIP	47	5%	1/10W
R1843	1-216-017-91	RES,CHIP	47	5%	1/10W	R2034	1-216-025-91	RES,CHIP	100	5%	1/10W
R1844	1-216-017-91	RES,CHIP	47	5%	1/10W	R2035	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1846	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R2036	1-216-025-91	RES,CHIP	100	5%	1/10W
R1847	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	R2037	1-216-017-91	RES,CHIP	47	5%	1/10W
R1848	1-216-017-91	RES,CHIP	47	5%	1/10W	R2038	1-216-017-91	RES,CHIP	47	5%	1/10W
R1849	1-216-017-91	RES,CHIP	47	5%	1/10W	R2039	1-216-017-91	RES,CHIP	47	5%	1/10W
R1850	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R2040	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1852	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	R2041	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1853	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	R2042	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1854	1-216-059-00	RES,CHIP	2.7K	5%	1/10W	R2043	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1856	1-216-097-91	RES,CHIP	100K	5%	1/10W	R2044	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1857	1-216-017-91	RES,CHIP	47	5%	1/10W	R2045	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1858	1-216-017-91	RES,CHIP	47	5%	1/10W	R2046	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1859	1-216-017-91	RES,CHIP	47	5%	1/10W	R2047	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1860	1-216-017-91	RES,CHIP	47	5%	1/10W	R2048	1-216-025-91	RES,CHIP	100	5%	1/10W
R1861	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R2049	1-216-025-91	RES,CHIP	100	5%	1/10W
R1862	1-216-017-91	RES,CHIP	47	5%	1/10W	R2050	1-216-025-91	RES,CHIP	100	5%	1/10W
R1863	1-216-017-91	RES,CHIP	47	5%	1/10W	R2051	1-216-025-91	RES,CHIP	100	5%	1/10W
R1864	1-216-017-91	RES,CHIP	47	5%	1/10W	R2052	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1865	1-216-017-91	RES,CHIP	47	5%	1/10W	R2056	1-216-017-91	RES,CHIP	47	5%	1/10W
R1866	1-216-017-91	RES,CHIP	47	5%	1/10W	R2057	1-216-017-91	RES,CHIP	47	5%	1/10W
R1867	1-216-041-00	RES,CHIP	470	5%	1/10W	R2058	1-216-017-91	RES,CHIP	47	5%	1/10W
R1868	1-216-049-91	RES,CHIP	1K	5%	1/10W	R2059	1-216-073-00	RES,CHIP	10K	5%	1/10W
R1869	1-216-049-91	RES,CHIP	1K	5%	1/10W	R2060	1-216-017-91	RES,CHIP	47	5%	1/10W
R1870	1-216-017-91	RES,CHIP	47	5%	1/10W	R2061	1-216-017-91	RES,CHIP	47	5%	1/10W
R1871	1-216-061-00	RES,CHIP	3.3K	5%	1/10W	R2062	1-216-017-91	RES,CHIP	47	5%	1/10W
R1872	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R2063	1-216-017-91	RES,CHIP	47	5%	1/10W
R1873	1-216-049-91	RES,CHIP	1K	5%	1/10W	R2064	1-216-017-91	RES,CHIP	47	5%	1/10W
R2000	1-216-073-00	RES,CHIP	10K	5%	1/10W	R2103	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2001	1-216-073-00	RES,CHIP	10K	5%	1/10W	R2104	1-216-695-11	METAL CHIP	68K	0.50%	1/10W
R2002	1-216-073-00	RES,CHIP	10K	5%	1/10W	R2105	1-216-687-11	METAL CHIP	33K	0.50%	1/10W
R2003	1-216-073-00	RES,CHIP	10K	5%	1/10W	R2106	1-216-699-11	METAL CHIP	100K	0.50%	1/10W
R2004	1-216-073-00	RES,CHIP	10K	5%	1/10W						



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R2107	1-216-699-11	METAL CHIP 100K	0.50% 1/10W	TP451	1-535-757-11	CHIP, CHECKER	
R2108	1-216-678-11	METAL CHIP 13K	0.50% 1/10W	TP501	1-535-757-11	CHIP, CHECKER	
R2109	1-216-689-11	METAL CHIP 39K	0.50% 1/10W	TP551	1-535-757-11	CHIP, CHECKER	
R2110	1-216-699-11	METAL CHIP 100K	0.50% 1/10W	TP800	1-535-757-11	CHIP, CHECKER	
R2111	1-216-025-91	RES,CHIP 100	5% 1/10W	TP801	1-535-757-11	CHIP, CHECKER	
R2112	1-216-699-11	METAL CHIP 100K	0.50% 1/10W	TP802	1-535-757-11	CHIP, CHECKER	
R2113	1-216-699-11	METAL CHIP 100K	0.50% 1/10W	TP803	1-535-757-11	CHIP, CHECKER	
R2114	1-216-295-91	SHORT 0		TP804	1-535-757-11	CHIP, CHECKER	
R2115	1-216-681-11	METAL CHIP 18K	0.50% 1/10W	TP1000	1-535-757-11	CHIP, CHECKER	
R2118	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	TP1001	1-535-757-11	CHIP, CHECKER	
R2200	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	TP1002	1-535-757-11	CHIP, CHECKER	
R2201	1-216-025-91	RES,CHIP 100	5% 1/10W	TP1005	1-535-757-11	CHIP, CHECKER	
R2202	1-216-025-91	RES,CHIP 100	5% 1/10W	TP1007	1-535-757-11	CHIP, CHECKER	
R2203	1-216-025-91	RES,CHIP 100	5% 1/10W	TP1010	1-535-757-11	CHIP, CHECKER	
R2204	1-216-049-91	RES,CHIP 1K	5% 1/10W	TP1011	1-535-757-11	CHIP, CHECKER	
R2208	1-216-089-91	RES,CHIP 47K	5% 1/10W	TP1012	1-535-757-11	CHIP, CHECKER	
R2216	1-216-295-91	SHORT 0		TP1013	1-535-757-11	CHIP, CHECKER	
R2217	1-216-295-91	SHORT 0		TP1014	1-535-757-11	CHIP, CHECKER	
<RESISTOR BLOCK>				TP1015	1-535-757-11	CHIP, CHECKER	
RB2000	1-236-908-11	NETWORK RESISTOR (CHIP) 10K		TP1200	1-535-757-11	CHIP, CHECKER	
RB2001	1-236-908-11	NETWORK RESISTOR (CHIP) 10K		TP1201	1-535-757-11	CHIP, CHECKER	
RB2002	1-236-908-11	NETWORK RESISTOR (CHIP) 10K		TP1202	1-535-757-11	CHIP, CHECKER	
<VARIABLE RESISTOR>				TP1400	1-535-757-11	CHIP, CHECKER	
RV200	1-238-801-11	RES, ADJ, CERMET 5K		TP1401	1-535-757-11	CHIP, CHECKER	
RV501	1-238-803-11	RES, ADJ, CERMET 20K		TP1402	1-535-757-11	CHIP, CHECKER	
RV502	1-238-803-11	RES, ADJ, CERMET 20K		TP1403	1-535-757-11	CHIP, CHECKER	
RV503	1-238-803-11	RES, ADJ, CERMET 20K		TP1405	1-535-757-11	CHIP, CHECKER	
RV504	1-238-803-11	RES, ADJ, CERMET 20K		TP1406	1-535-757-11	CHIP, CHECKER	
RV800	1-238-803-11	RES, ADJ, CERMET 20K		TP1407	1-535-757-11	CHIP, CHECKER	
<RELAY>				TP1601	1-535-757-11	CHIP, CHECKER	
RY1	1-515-716-11	RELAY (TQ2-5V)		TP1602	1-535-757-11	CHIP, CHECKER	
RY2	1-515-716-11	RELAY (TQ2-5V)		TP1603	1-535-757-11	CHIP, CHECKER	
RY3	1-515-716-11	RELAY (TQ2-5V)		TP1604	1-535-757-11	CHIP, CHECKER	
RY4	1-515-716-11	RELAY (TQ2-5V)		TP1605	1-535-757-11	CHIP, CHECKER	
RY800	1-515-716-11	RELAY (TQ2-5V)		TP1606	1-535-757-11	CHIP, CHECKER	
RY1600	1-515-911-11	RELAY		TP1610	1-535-757-11	CHIP, CHECKER	
<SWITCH>				TP1611	1-535-757-11	CHIP, CHECKER	
S1	1-570-865-11	SWITCH, SLIDE		TP1612	1-535-757-11	CHIP, CHECKER	
<TERMINAL BOARD>				TP1613	1-535-757-11	CHIP, CHECKER	
TB1	1-694-481-11	TERMINAL BOARD ASSY, I/O		TP1614	1-535-757-11	CHIP, CHECKER	
TB2	1-694-483-11	TERMINAL BOARD ASSY, I/O		TP1615	1-535-757-11	CHIP, CHECKER	
<TEST PIN>				TP1616	1-535-757-11	CHIP, CHECKER	
TP1	1-535-757-11	CHIP, CHECKER		TP1618	1-535-757-11	CHIP, CHECKER	
TP2	1-535-757-11	CHIP, CHECKER		TP1619	1-535-757-11	CHIP, CHECKER	
TP3	1-535-757-11	CHIP, CHECKER		TP1620	1-535-757-11	CHIP, CHECKER	
TP4	1-535-757-11	CHIP, CHECKER		TP1621	1-535-757-11	CHIP, CHECKER	
TP5	1-535-757-11	CHIP, CHECKER		TP1622	1-535-757-11	CHIP, CHECKER	
				TP1623	1-535-757-11	CHIP, CHECKER	
				TP1624	1-535-757-11	CHIP, CHECKER	
				TP1625	1-535-757-11	CHIP, CHECKER	
				TP1800	1-535-757-11	CHIP, CHECKER	
				TP1801	1-535-757-11	CHIP, CHECKER	
				TP1802	1-535-757-11	CHIP, CHECKER	
				TP1804	1-535-757-11	CHIP, CHECKER	
				TP1805	1-535-757-11	CHIP, CHECKER	
				TP1806	1-535-757-11	CHIP, CHECKER	
				TP1807	1-535-757-11	CHIP, CHECKER	
				TP1809	1-535-757-11	CHIP, CHECKER	
				TP1810	1-535-757-11	CHIP, CHECKER	

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
TP1811	1-535-757-11	CHIP, CHECKER		C310	1-163-038-91	CERAMIC CHIP 0.1μF	25V
TP1812	1-535-757-11	CHIP, CHECKER		C311	1-163-038-91	CERAMIC CHIP 0.1μF	25V
TP1814	1-535-757-11	CHIP, CHECKER		C312	1-126-204-11	ELECT CHIP 47μF	20% 16V
TP1815	1-535-757-11	CHIP, CHECKER		C313	1-163-038-91	CERAMIC CHIP 0.1μF	25V
TP2101	1-535-757-11	CHIP, CHECKER		C314	1-163-038-91	CERAMIC CHIP 0.1μF	25V
TP2102	1-535-757-11	CHIP, CHECKER		C315	1-163-038-91	CERAMIC CHIP 0.1μF	25V
TP2103	1-535-757-11	CHIP, CHECKER		C316	1-126-204-11	ELECT CHIP 47μF	20% 16V
TP2104	1-535-757-11	CHIP, CHECKER		C317	1-126-204-11	ELECT CHIP 47μF	20% 16V
TP2106	1-535-757-11	CHIP, CHECKER		C318	1-163-038-91	CERAMIC CHIP 0.1μF	25V
TP2111	1-535-757-11	CHIP, CHECKER		C319	1-163-038-91	CERAMIC CHIP 0.1μF	25V
TP2112	1-535-757-11	CHIP, CHECKER		C320	1-126-204-11	ELECT CHIP 47μF	20% 16V
<CRYSTAL>				C321	1-163-038-91	CERAMIC CHIP 0.1μF	25V
X1201	1-767-606-11	VIBRATOR, CRYSTAL		C322	1-163-038-91	CERAMIC CHIP 0.1μF	25V
X1401	1-760-191-11	VIBRATOR, CRYSTAL		C323	1-163-038-91	CERAMIC CHIP 0.1μF	25V
X1402	1-760-191-11	VIBRATOR, CRYSTAL		C324	1-163-038-91	CERAMIC CHIP 0.1μF	25V
X1403	1-579-973-11	VIBRATOR, CRYSTAL		C325	1-126-204-11	ELECT CHIP 47μF	20% 16V
*****				C326	1-124-779-00	ELECT CHIP 10μF	20% 16V
* A-1135-958-A BB COMPLETE PC BOARD				C328	1-163-038-91	CERAMIC CHIP 0.1μF	25V
*****				C329	1-163-038-91	CERAMIC CHIP 0.1μF	25V
<CAPACITOR>				C330	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C1	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C331	1-124-779-00	ELECT CHIP 10μF	20% 16V
C2	1-126-204-11	ELECT CHIP 47μF	20% 16V	C333	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C4	1-126-204-11	ELECT CHIP 47μF	20% 16V	C334	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C5	1-126-204-11	ELECT CHIP 47μF	20% 16V	C335	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C6	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C336	1-126-204-11	ELECT CHIP 47μF	20% 16V
C8	1-126-204-11	ELECT CHIP 47μF	20% 16V	C337	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C9	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C338	1-124-779-00	ELECT CHIP 10μF	20% 16V
C10	1-126-204-11	ELECT CHIP 47μF	20% 16V	C339	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C106	1-126-204-11	ELECT CHIP 47μF	20% 16V	C340	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C112	1-124-779-00	ELECT CHIP 10μF	20% 16V	C341	1-126-204-11	ELECT CHIP 47μF	20% 16V
C113	1-124-779-00	ELECT CHIP 10μF	20% 16V	C342	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C120	1-126-204-11	ELECT CHIP 47μF	20% 16V	C343	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C121	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C344	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C122	1-124-779-00	ELECT CHIP 10μF	20% 16V	C345	1-126-204-11	ELECT CHIP 47μF	20% 16V
C123	1-126-204-11	ELECT CHIP 47μF	20% 16V	C346	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C124	1-124-779-00	ELECT CHIP 10μF	20% 16V	C347	1-126-204-11	ELECT CHIP 47μF	20% 16V
C125	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C348	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C126	1-124-779-00	ELECT CHIP 10μF	20% 16V	C349	1-163-133-00	CERAMIC CHIP 470PF	5% 50V
C127	1-124-779-00	ELECT CHIP 10μF	20% 16V	C350	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C128	1-124-779-00	ELECT CHIP 10μF	20% 16V	C351	1-126-204-11	ELECT CHIP 47μF	20% 16V
C129	1-124-779-00	ELECT CHIP 10μF	20% 16V	C352	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C130	1-163-259-91	CERAMIC CHIP 220PF	5% 50V	C353	1-126-204-11	ELECT CHIP 47μF	20% 16V
C300	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C354	1-164-005-11	CERAMIC CHIP 0.47μF	16V
C301	1-126-204-11	ELECT CHIP 47μF	20% 16V	C355	1-126-204-11	ELECT CHIP 47μF	20% 16V
C302	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C356	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C303	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C357	1-126-603-11	ELECT CHIP 4.7μF	20% 35V
C304	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C359	1-163-259-91	CERAMIC CHIP 220PF	5% 50V
C305	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C361	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C306	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C362	1-126-204-11	ELECT CHIP 47μF	20% 16V
C307	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C363	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C308	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C364	1-126-204-11	ELECT CHIP 47μF	20% 16V
C309	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C500	1-163-038-91	CERAMIC CHIP 0.1μF	25V
				C501	1-163-038-91	CERAMIC CHIP 0.1μF	25V
				C502	1-163-038-91	CERAMIC CHIP 0.1μF	25V
				C503	1-126-204-11	ELECT CHIP 47μF	20% 16V
				C504	1-163-038-91	CERAMIC CHIP 0.1μF	25V
				C505	1-163-038-91	CERAMIC CHIP 0.1μF	25V
				C506	1-163-038-91	CERAMIC CHIP 0.1μF	25V
				C507	1-163-038-91	CERAMIC CHIP 0.1μF	25V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C508	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C933	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C509	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C934	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C510	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C935	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C511	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C936	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C512	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C937	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C513	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C938	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C514	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C939	1-126-204-11	ELECT CHIP 47μF	20% 16V
C515	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C940	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C516	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C941	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C517	1-163-038-91	CERAMIC CHIP 0.1μF	25V	C942	1-163-038-91	CERAMIC CHIP 0.1μF	25V
C518	1-163-038-91	CERAMIC CHIP 0.1μF	25V	<CONNECTOR>			
C519	1-126-204-11	ELECT CHIP 47μF	20% 16V	CN360	1-565-784-11	HEADDER, FLAT CABLE 60P	
C700	1-163-038-91	CERAMIC CHIP 0.1μF	25V	<DIODE>			
C701	1-163-038-91	CERAMIC CHIP 0.1μF	25V	D300	8-719-422-12	DIODE MA8039	
C702	1-126-204-11	ELECT CHIP 47μF	20% 16V	<FERRITE BEAD>			
C703	1-163-038-91	CERAMIC CHIP 0.1μF	25V	FB100	1-414-234-22	INDUCTOR CHIP 0μH	
C704	1-163-038-91	CERAMIC CHIP 0.1μF	25V	FB101	1-414-234-22	INDUCTOR CHIP 0μH	
C705	1-163-038-91	CERAMIC CHIP 0.1μF	25V	FB102	1-414-234-22	INDUCTOR CHIP 0μH	
C706	1-163-038-91	CERAMIC CHIP 0.1μF	25V	FB103	1-414-234-22	INDUCTOR CHIP 0μH	
C707	1-163-038-91	CERAMIC CHIP 0.1μF	25V	FB104	1-414-234-22	INDUCTOR CHIP 0μH	
C708	1-163-038-91	CERAMIC CHIP 0.1μF	25V	FB105	1-414-234-22	INDUCTOR CHIP 0μH	
C709	1-163-038-91	CERAMIC CHIP 0.1μF	25V	<FILTER>			
C710	1-163-038-91	CERAMIC CHIP 0.1μF	25V	FL100	1-233-505-21	FILTER, LOW PASS	
C711	1-163-038-91	CERAMIC CHIP 0.1μF	25V	FL101	1-233-504-21	FILTER, LOW PASS	
C712	1-163-038-91	CERAMIC CHIP 0.1μF	25V	FL102	1-233-504-21	FILTER, LOW PASS	
C713	1-163-038-91	CERAMIC CHIP 0.1μF	25V	FL900	1-233-876-11	FILTER, LOW PASS	
C900	1-124-779-00	ELECT CHIP 10μF	20% 16V	FL901	1-233-876-11	FILTER, LOW PASS	
C901	1-163-038-91	CERAMIC CHIP 0.1μF	25V	FL902	1-233-878-11	FILTER, LOW PASS	
C902	1-124-779-00	ELECT CHIP 10μF	20% 16V	<IC>			
C903	1-124-779-00	ELECT CHIP 10μF	20% 16V	IC1	8-752-072-94	IC CXA1875AM-T4	
C904	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC2	8-759-460-74	IC BA05FP-E2	
C905	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC3	8-759-460-72	IC BA033FP-E2	
C906	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC4	8-752-072-94	IC CXA1875AM-T4	
C907	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC106	8-759-485-79	IC TC7SET08FU(TE85L)	
C908	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC107	8-759-485-79	IC TC7SET08FU(TE85L)	
C909	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC300	8-759-447-90	IC TLC5733AIPM	
C910	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC301	8-759-467-20	IC CXD8675R	
C911	1-124-779-00	ELECT CHIP 10μF	20% 16V	IC302	8-759-295-09	IC TLC2932IPW	
C912	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC303	8-759-239-55	IC TC74HC123AF	
C913	1-124-779-00	ELECT CHIP 10μF	20% 16V	IC304	8-759-430-32	IC TLC2933IPW-E20	
C914	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC500	8-752-386-52	IC CXD2070Q	
C915	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC501	8-759-422-80	IC MN47V77ST1	
C916	1-124-779-00	ELECT CHIP 10μF	20% 16V	IC502	8-759-422-80	IC MN47V77ST1	
C917	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC700	8-752-384-06	IC CXD2062Q	
C918	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC701	8-759-393-55	IC MC74F244MEL	
C919	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC702	8-759-393-55	IC MC74F244MEL	
C920	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC900	8-752-053-21	IC CXA1211M	
C921	1-163-038-91	CERAMIC CHIP 0.1μF	25V	IC901	8-752-053-21	IC CXA1211M	
C922	1-126-204-11	ELECT CHIP 47μF	20% 16V				
C923	1-163-038-91	CERAMIC CHIP 0.1μF	25V				
C924	1-163-038-91	CERAMIC CHIP 0.1μF	25V				
C925	1-163-038-91	CERAMIC CHIP 0.1μF	25V				
C926	1-163-038-91	CERAMIC CHIP 0.1μF	25V				
C927	1-163-038-91	CERAMIC CHIP 0.1μF	25V				
C928	1-163-038-91	CERAMIC CHIP 0.1μF	25V				
C929	1-163-038-91	CERAMIC CHIP 0.1μF	25V				
C930	1-163-038-91	CERAMIC CHIP 0.1μF	25V				
C931	1-163-038-91	CERAMIC CHIP 0.1μF	25V				
C932	1-163-038-91	CERAMIC CHIP 0.1μF	25V				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
IC902	8-752-386-47	IC CXD2071R			<RESISTOR>		
IC903	8-752-053-21	IC CXA1211M		R1	1-216-446-00	METAL OXIDE 18 5% 2W F	
				R2	1-216-073-00	RES,CHIP 10K 5% 1/10W	
				R3	1-216-073-00	RES,CHIP 10K 5% 1/10W	
	<COIL>			R4	1-216-049-91	RES,CHIP 1K 5% 1/10W	
				R5	1-216-025-91	RES,CHIP 100 5% 1/10W	
L2	1-412-533-21	INDUCTOR 47μH		R6	1-216-025-91	RES,CHIP 100 5% 1/10W	
L3	1-412-533-21	INDUCTOR 47μH		R7	1-216-446-00	METAL OXIDE 18 5% 2W F	
L5	1-412-058-11	INDUCTOR CHIP 10μH		R14	1-216-025-91	RES,CHIP 100 5% 1/10W	
L102	1-414-754-11	INDUCTOR 10μH		R15	1-216-025-91	RES,CHIP 100 5% 1/10W	
L103	1-414-754-11	INDUCTOR 10μH		R16	1-216-049-91	RES,CHIP 1K 5% 1/10W	
L300	1-414-754-11	INDUCTOR 10μH		R17	1-216-073-00	RES,CHIP 10K 5% 1/10W	
L301	1-414-754-11	INDUCTOR 10μH		R18	1-216-025-91	RES,CHIP 100 5% 1/10W	
L302	1-414-754-11	INDUCTOR 10μH		R19	1-216-073-00	RES,CHIP 10K 5% 1/10W	
L303	1-414-757-11	INDUCTOR 100μH		R20	1-216-073-00	RES,CHIP 10K 5% 1/10W	
L304	1-414-754-11	INDUCTOR 10μH		R21	1-216-073-00	RES,CHIP 10K 5% 1/10W	
L305	1-414-754-11	INDUCTOR 10μH		R22	1-216-073-00	RES,CHIP 10K 5% 1/10W	
L306	1-414-754-11	INDUCTOR 10μH		R23	1-216-073-00	RES,CHIP 10K 5% 1/10W	
L307	1-414-754-11	INDUCTOR 10μH		R101	1-216-025-91	RES,CHIP 100 5% 1/10W	
L308	1-414-757-11	INDUCTOR 100μH		R102	1-216-025-91	RES,CHIP 100 5% 1/10W	
L309	1-414-757-11	INDUCTOR 100μH		R108	1-216-025-91	RES,CHIP 100 5% 1/10W	
L310	1-414-757-11	INDUCTOR 100μH		R113	1-216-669-11	METAL CHIP 5.6K 0.50% 1/10W	
L311	1-414-757-11	INDUCTOR 100μH		R118	1-216-053-00	RES,CHIP 1.5K 5% 1/10W	
L312	1-414-754-11	INDUCTOR 10μH		R119	1-216-645-11	METAL CHIP 560 0.50% 1/10W	
L500	1-414-754-11	INDUCTOR 10μH		R120	1-216-075-00	RES,CHIP 12K 5% 1/10W	
L501	1-414-754-11	INDUCTOR 10μH		R121	1-216-079-00	RES,CHIP 18K 5% 1/10W	
L700	1-414-754-11	INDUCTOR 10μH		R122	1-216-295-91	SHORT 0	
L701	1-414-754-11	INDUCTOR 10μH		R123	1-216-025-91	RES,CHIP 100 5% 1/10W	
L702	1-414-754-11	INDUCTOR 10μH		R124	1-216-049-91	RES,CHIP 1K 5% 1/10W	
L900	1-414-754-11	INDUCTOR 10μH		R125	1-216-645-11	METAL CHIP 560 0.50% 1/10W	
L901	1-414-754-11	INDUCTOR 10μH		R128	1-216-669-11	METAL CHIP 5.6K 0.50% 1/10W	
				R129	1-216-075-00	RES,CHIP 12K 5% 1/10W	
				R130	1-216-053-00	RES,CHIP 1.5K 5% 1/10W	
Q103	8-729-230-49	TRANSISTOR 2SC2712-YG		R131	1-216-295-91	SHORT 0	
Q104	8-729-230-49	TRANSISTOR 2SC2712-YG		R132	1-216-025-91	RES,CHIP 100 5% 1/10W	
Q105	8-729-230-49	TRANSISTOR 2SC2712-YG		R135	1-216-049-91	RES,CHIP 1K 5% 1/10W	
Q106	8-729-230-49	TRANSISTOR 2SC2712-YG		R136	1-216-645-11	METAL CHIP 560 0.50% 1/10W	
Q107	8-729-230-49	TRANSISTOR 2SC2712-YG		R138	1-216-669-11	METAL CHIP 5.6K 0.50% 1/10W	
Q108	8-729-230-49	TRANSISTOR 2SC2712-YG		R139	1-216-075-00	RES,CHIP 12K 5% 1/10W	
Q111	8-729-230-49	TRANSISTOR 2SC2712-YG		R140	1-216-053-00	RES,CHIP 1.5K 5% 1/10W	
Q112	8-729-230-49	TRANSISTOR 2SC2712-YG		R142	1-216-079-00	RES,CHIP 18K 5% 1/10W	
Q113	8-729-230-49	TRANSISTOR 2SC2712-YG		R143	1-216-295-91	SHORT 0	
Q300	8-729-216-22	TRANSISTOR 2SA1162-G		R144	1-216-025-91	RES,CHIP 100 5% 1/10W	
Q301	8-729-216-22	TRANSISTOR 2SA1162-G		R145	1-216-079-00	RES,CHIP 18K 5% 1/10W	
Q302	8-729-216-22	TRANSISTOR 2SA1162-G		R146	1-216-049-91	RES,CHIP 1K 5% 1/10W	
Q303	8-729-230-49	TRANSISTOR 2SC2712-YG		R153	1-216-085-00	RES,CHIP 33K 5% 1/10W	
Q304	8-729-230-49	TRANSISTOR 2SC2712-YG		R154	1-216-025-91	RES,CHIP 100 5% 1/10W	
Q305	8-729-230-49	TRANSISTOR 2SC2712-YG		R155	1-216-089-91	RES,CHIP 47K 5% 1/10W	
Q306	8-729-216-22	TRANSISTOR 2SA1162-G		R156	1-216-025-91	RES,CHIP 100 5% 1/10W	
Q900	8-729-230-49	TRANSISTOR 2SC2712-YG		R157	1-216-049-91	RES,CHIP 1K 5% 1/10W	
Q901	8-729-216-22	TRANSISTOR 2SA1162-G		R158	1-216-025-91	RES,CHIP 100 5% 1/10W	
Q902	8-729-216-22	TRANSISTOR 2SA1162-G		R159	1-216-085-00	RES,CHIP 33K 5% 1/10W	
Q903	8-729-230-49	TRANSISTOR 2SC2712-YG		R160	1-216-025-91	RES,CHIP 100 5% 1/10W	
Q904	8-729-216-22	TRANSISTOR 2SA1162-G		R161	1-216-089-91	RES,CHIP 47K 5% 1/10W	
Q905	8-729-230-49	TRANSISTOR 2SC2712-YG		R162	1-216-025-91	RES,CHIP 100 5% 1/10W	
				R163	1-216-049-91	RES,CHIP 1K 5% 1/10W	
				R164	1-216-085-00	RES,CHIP 33K 5% 1/10W	
				R165	1-216-025-91	RES,CHIP 100 5% 1/10W	

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R166	1-216-025-91	RES,CHIP	100 5% 1/10W	R503	1-216-295-91	SHORT 0	
R167	1-216-089-91	RES,CHIP	47K 5% 1/10W	R505	1-216-295-91	SHORT 0	
R168	1-216-025-91	RES,CHIP	100 5% 1/10W	R506	1-216-295-91	SHORT 0	
				R508	1-216-295-91	SHORT 0	
R169	1-216-049-91	RES,CHIP	1K 5% 1/10W	R700	1-216-639-11	METAL CHIP 330	0.50% 1/10W
R300	1-216-025-91	RES,CHIP	100 5% 1/10W				
R301	1-216-295-91	SHORT 0		R701	1-216-639-11	METAL CHIP 330	0.50% 1/10W
R302	1-216-295-91	SHORT 0		R702	1-216-647-11	METAL CHIP 680	0.50% 1/10W
R303	1-216-621-11	METAL CHIP 56	0.50% 1/10W	R703	1-216-647-11	METAL CHIP 680	0.50% 1/10W
				R901	1-216-295-91	SHORT 0	
R304	1-216-621-11	METAL CHIP 56	0.50% 1/10W	R902	1-216-295-91	SHORT 0	
R305	1-216-621-11	METAL CHIP 56	0.50% 1/10W				
R306	1-216-621-11	METAL CHIP 56	0.50% 1/10W	R905	1-216-295-91	SHORT 0	
R307	1-216-091-00	RES,CHIP 56K	5% 1/10W	R906	1-216-049-91	RES,CHIP 1K	5% 1/10W
R308	1-216-077-00	RES,CHIP 15K	5% 1/10W	R908	1-216-025-91	RES,CHIP 100	5% 1/10W
				R909	1-216-025-91	RES,CHIP 100	5% 1/10W
R309	1-216-624-11	METAL CHIP 75	0.50% 1/10W	R910	1-216-295-91	SHORT 0	
R310	1-216-077-00	RES,CHIP 15K	5% 1/10W				
R311	1-216-623-11	METAL CHIP 68	0.50% 1/10W	R911	1-216-295-91	SHORT 0	
R312	1-216-624-11	METAL CHIP 75	0.50% 1/10W	R913	1-216-049-91	RES,CHIP 1K	5% 1/10W
R313	1-216-037-00	RES,CHIP 330	5% 1/10W	R914	1-216-049-91	RES,CHIP 1K	5% 1/10W
				R915	1-216-049-91	RES,CHIP 1K	5% 1/10W
R314	1-216-081-00	RES,CHIP 22K	5% 1/10W	R916	1-216-049-91	RES,CHIP 1K	5% 1/10W
R315	1-216-623-11	METAL CHIP 68	0.50% 1/10W				
R316	1-216-621-11	METAL CHIP 56	0.50% 1/10W	R917	1-216-049-91	RES,CHIP 1K	5% 1/10W
R317	1-216-621-11	METAL CHIP 56	0.50% 1/10W	R918	1-216-061-00	RES,CHIP 3.3K	5% 1/10W
R318	1-216-621-11	METAL CHIP 56	0.50% 1/10W	R919	1-216-663-11	METAL CHIP 3.3K	0.50% 1/10W
				R920	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
R319	1-216-621-11	METAL CHIP 56	0.50% 1/10W	R921	1-216-635-11	METAL CHIP 220	0.50% 1/10W
R320	1-216-025-91	RES,CHIP 100	5% 1/10W				
R321	1-216-037-00	RES,CHIP 330	5% 1/10W	R922	1-216-635-11	METAL CHIP 220	0.50% 1/10W
R322	1-216-025-91	RES,CHIP 100	5% 1/10W	R923	1-216-634-11	METAL CHIP 200	0.50% 1/10W
R323	1-216-295-91	SHORT 0		R924	1-216-053-00	RES,CHIP 1.5K	5% 1/10W
				R925	1-216-635-11	METAL CHIP 220	0.50% 1/10W
R324	1-216-037-00	RES,CHIP 330	5% 1/10W	R926	1-216-635-11	METAL CHIP 220	0.50% 1/10W
R325	1-216-097-91	RES,CHIP 100K	5% 1/10W				
R326	1-216-025-91	RES,CHIP 100	5% 1/10W	R927	1-216-634-11	METAL CHIP 200	0.50% 1/10W
R327	1-216-037-00	RES,CHIP 330	5% 1/10W	R928	1-216-053-00	RES,CHIP 1.5K	5% 1/10W
R328	1-216-037-00	RES,CHIP 330	5% 1/10W	R929	1-216-635-11	METAL CHIP 220	0.50% 1/10W
				R930	1-216-635-11	METAL CHIP 220	0.50% 1/10W
R329	1-216-077-00	RES,CHIP 15K	5% 1/10W	R931	1-216-634-11	METAL CHIP 200	0.50% 1/10W
R330	1-216-295-91	SHORT 0					
R331	1-216-295-91	SHORT 0		R932	1-216-053-00	RES,CHIP 1.5K	5% 1/10W
R332	1-216-066-00	RES,CHIP 5.1K	5% 1/10W				
R335	1-216-665-11	METAL CHIP 3.9K	0.50% 1/10W				
R336	1-216-049-91	RES,CHIP 1K	5% 1/10W				
R337	1-216-057-00	RES,CHIP 2.2K	5% 1/10W				
R338	1-216-295-91	SHORT 0					
R340	1-216-073-00	RES,CHIP 10K	5% 1/10W				
R341	1-216-061-00	RES,CHIP 3.3K	5% 1/10W				
R342	1-216-047-91	RES,CHIP 820	5% 1/10W				
R343	1-216-049-91	RES,CHIP 1K	5% 1/10W				
R344	1-216-117-00	RES,CHIP 680K	5% 1/10W				
R345	1-216-117-00	RES,CHIP 680K	5% 1/10W				
R346	1-216-062-00	RES,CHIP 3.6K	5% 1/10W				
R347	1-216-025-91	RES,CHIP 100	5% 1/10W				
R348	1-216-113-00	RES,CHIP 470K	5% 1/10W				
R349	1-216-025-91	RES,CHIP 100	5% 1/10W				
R350	1-216-651-11	METAL CHIP 1K	0.50% 1/10W				
R352	1-216-113-00	RES,CHIP 470K	5% 1/10W				
R353	1-216-081-00	RES,CHIP 22K	5% 1/10W				
R354	1-216-033-00	RES,CHIP 220	5% 1/10W				
R355	1-216-057-00	RES,CHIP 2.2K	5% 1/10W				
R357	1-216-061-00	RES,CHIP 3.3K	5% 1/10W				
R500	1-216-295-91	SHORT 0					

<VARIABLE RESISTOR>

RV900 1-241-764-11 RES, ADJ, CERMET 10K
RV901 1-241-764-11 RES, ADJ, CERMET 10K
RV902 1-241-764-11 RES, ADJ, CERMET 10K

* A-1190-327-A PB MOUNTED PC BOARD

1-202-826-00 SOLID 4.7K 10% 1/2W
1-202-826-00 SOLID 4.7K 10% 1/2W
1-202-826-00 SOLID 4.7K 20% 1/2W
1-202-826-00 SOLID 4.7K 20% 1/2W
1-202-826-00 SOLID 4.7K 20% 1/2W

1-202-826-00 SOLID 4.7K 20% 1/2W
4-042-892-01 CAP, MV
4-042-892-01 CAP, MV
* 7-322-065-72 RUBBER, RTV (SE-9168) (130G)
* 7-322-065-72 RUBBER, RTV (SE-9168) (130G)

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
	8-719-054-69	DIODE ESJA09-12T3.5		C506	1-126-929-11	ELECT 4700μF 20% 10V	
	8-719-054-69	DIODE ESJA09-12T3.5		C507	1-126-929-11	ELECT 4700μF 20% 10V	
	8-719-058-28	DIODE DHM3UB120-T		C508	1-123-024-21	ELECT 33μF 160V	
	8-719-058-28	DIODE DHM3UB120-T					
	<CONNECTOR>						
CN241	* 1-564-506-11	PLUG, CONNECTOR 3P		C509	1-126-964-11	ELECT 10μF 20% 50V	
CN241	* 1-564-506-11	PLUG, CONNECTOR 3P		C511	1-136-169-00	FILM 0.22μF 5% 50V	
	<FLYBACK TRANSFORMER>			C515	1-136-613-11	FILM 0.0068μF 3% 2KV	
				C516	1-137-370-11	FILM 0.01μF 5% 50V	
FBT10	△X-4033-245-1	TRANSFORMER ASSY, FLYBACK (L) (NX3031//J1S) (L=300)		C517	1-126-964-11	ELECT 10μF 20% 50V	
	△X-4034-325-1	TRANSFORMER ASSY, FLYBACK (R) (NX3031//J1X) (L=270)					
FBT11	△X-4033-245-1	TRANSFORMER ASSY, FLYBACK (R) (NX3031//J1S) (L=300)		C518	1-102-244-00	CERAMIC 220PF 10% 500V	
	△X-4034-326-1	TRANSFORMER ASSY, FLYBACK (L) (NX3031//J1W) (L=330)		C519	1-136-103-00	FILM 0.1μF 5% 200V	
	<NEON LAMP>			C520	1-126-929-11	ELECT 4700μF 20% 10V	
NL10	1-519-108-99	LAMP, NEON		C521	1-136-085-00	FILM 0.016μF 3% 2KV	
NL10	1-519-108-99	LAMP, NEON		C523	1-126-964-11	ELECT 10μF 20% 50V	
NL11	1-519-108-99	LAMP, NEON					
NL11	1-519-108-99	LAMP, NEON		C527	1-163-021-91	CERAMIC CHIP 0.01μF 10% 50V	
*****				C528	1-126-960-11	ELECT 1μF 20% 50V	
	* A-1195-142-A PE COMPLETE PC BOARD			C529	1-126-964-11	ELECT 10μF 20% 50V	
		*****		C532	1-163-021-91	CERAMIC CHIP 0.01μF 10% 50V	
	4-382-854-11	SCREW (M3X10), P, SW (+)		C541	1-107-662-11	ELECT 22μF 20% 250V	
	* 7-322-065-72	RUBBER, RTV (SE-9168) (130G)		C542	1-107-651-11	ELECT 4.7μF 20% 250V	
	<CAPACITOR>			C543	1-107-651-11	ELECT 4.7μF 20% 250V	
C2	1-107-906-11	ELECT 10μF 20% 50V		<CONNECTOR>			
C4	1-164-004-11	CERAMIC CHIP 0.1μF 10% 25V		CN99	* 1-564-710-11	PIN, CONNECTOR (SMALL TYPE) 8P	
C5	1-107-909-11	ELECT 47μF 20% 50V		CN100	* 1-564-711-11	PIN, CONNECTOR (SMALL TYPE) 9P	
C9	1-107-906-11	ELECT 10μF 20% 50V		CN101	* 1-564-711-11	PIN, CONNECTOR (ULTRA SMALL)9P	
C13	1-107-906-11	ELECT 10μF 20% 50V		CN102	* 1-564-706-11	PIN, CONNECTOR (SMALL TYPE) 4P	
				CN103	* 1-508-766-00	PIN, CONNECTOR (5MM PITCH) 4P	
C14	1-126-935-11	ELECT 470μF 20% 16V					
C16	1-164-489-11	CERAMIC CHIP 0.22μF 10% 16V		CN104	* 1-564-506-11	PLUG, CONNECTOR 3P	
C19	1-126-795-11	ELECT 10μF 20% 50V		CN105	* 1-564-506-11	PLUG, CONNECTOR 3P	
C20	1-104-666-11	ELECT 220μF 20% 25V		CN106	* 1-564-506-11	PLUG, CONNECTOR 3P	
C21	1-104-666-11	ELECT 220μF 20% 25V		CN107	* 1-564-506-11	PLUG, CONNECTOR 3P	
				<DIODE>			
C22	1-104-666-11	ELECT 220μF 20% 25V		D4	8-719-801-78	DIODE 1SS184	
C23	1-104-666-11	ELECT 220μF 20% 25V		D6	8-719-801-78	DIODE 1SS184	
C24	1-126-942-61	ELECT 1000μF 20% 25V		D500	8-719-801-78	DIODE 1SS184	
C25	1-126-942-61	ELECT 1000μF 20% 25V		D501	8-719-900-95	DIODE V09G	
C26	1-126-942-61	ELECT 1000μF 20% 25V		D502	8-719-801-78	DIODE 1SS184	
C27	1-126-942-61	ELECT 1000μF 20% 25V		D503	8-719-979-58	DIODE EGP10D	
C500	1-126-943-11	ELECT 2200μF 20% 25V		D504	8-719-979-58	DIODE EGP10D	
C501	1-126-933-11	ELECT 100μF 20% 16V		D505	8-719-054-86	DIODE ERC88M-009	
C502	1-126-969-11	ELECT 220μF 20% 50V		D506	8-719-054-86	DIODE ERC88M-009	
C503	1-126-933-11	ELECT 100μF 20% 16V		D508	8-719-900-95	DIODE V09G	
C504	1-104-665-11	ELECT 100μF 20% 25V		D511	8-719-901-19	DIODE V11N	
C505	1-126-969-11	ELECT 220μF 20% 50V		D512	8-719-054-86	DIODE ERC88M-009	
				D513	8-719-801-78	DIODE 1SS184	
				D514	8-719-801-78	DIODE 1SS184	
				D515	8-719-801-78	DIODE 1SS184	
				D516	8-719-801-78	DIODE 1SS184	
				D517	8-719-801-78	DIODE 1SS184	
				D518	8-719-801-78	DIODE 1SS184	
				D519	8-719-801-78	DIODE 1SS184	
				D522	8-719-801-78	DIODE 1SS184	
				D524	8-719-801-78	DIODE 1SS184	
				D525	8-719-979-58	DIODE EGP10D	
				D526	8-719-900-95	DIODE V09G	
				D527	8-719-801-78	DIODE 1SS184	

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
		<FERRITE BEAD>					
FB500	1-410-396-41	FERRITE 0.45μH		R12	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
FB501	1-410-396-41	FERRITE 0.45μH		R16	1-216-049-91	RES,CHIP 1K	5% 1/10W
				R17	1-216-073-00	RES,CHIP 10K	5% 1/10W
				R22	1-216-647-11	METAL CHIP 680	0.50% 1/10W
		<IC>					
IC2	8-759-947-34	IC LM35DZ		R24	1-216-451-11	METAL OXIDE 120	5% 2W F
IC3	8-759-100-96	IC UPC4558G2		R25	1-216-067-00	RES,CHIP 5.6K	5% 1/10W
IC5	8-759-908-15	IC TL431CLP		R34	1-215-886-11	METAL OXIDE 100	5% 2W F
IC6	8-759-100-96	IC UPC4558G2		R36	1-216-067-00	RES,CHIP 5.6K	5% 1/10W
IC500	8-759-231-58	IC TA7812S		R40	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
IC501	8-759-929-65	IC LM7912CT		R41	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
IC504	8-759-100-96	IC UPC4558G2		R46	1-216-049-91	RES,CHIP 1K	5% 1/10W
IC505	8-759-100-96	IC UPC4558G2		R47	1-216-089-91	RES,CHIP 47K	5% 1/10W
				R48	1-216-049-91	RES,CHIP 1K	5% 1/10W
				R49	1-216-049-91	RES,CHIP 1K	5% 1/10W
		<COIL>					
L500	1-412-533-21	INDUCTOR 47μH		R50	1-216-049-91	RES,CHIP 1K	5% 1/10W
L501	1-412-533-21	INDUCTOR 47μH		R51	1-216-049-91	RES,CHIP 1K	5% 1/10W
L502	1-412-533-21	INDUCTOR 47μH		R52	1-216-105-91	RES,CHIP 220K	5% 1/10W
				R53	1-216-105-91	RES,CHIP 220K	5% 1/10W
				R54	1-216-105-91	RES,CHIP 220K	5% 1/10W
		<TRANSISTOR>					
Q3	8-729-140-97	TRANSISTOR 2SB734-34		R55	1-216-105-91	RES,CHIP 220K	5% 1/10W
Q5	8-729-033-97	TRANSISTOR 2SB1566E		R56	1-215-908-00	METAL OXIDE 33	5% 3W F
Q6	1-801-806-11	TRANSISTOR DTC144EKA-T146		R57	1-215-908-00	METAL OXIDE 33	5% 3W F
Q7	1-801-806-11	TRANSISTOR DTC144EKA-T146		R58	1-215-908-00	METAL OXIDE 33	5% 3W F
Q8	1-801-806-11	TRANSISTOR DTC144EKA-T146		R59	1-215-908-00	METAL OXIDE 33	5% 3W F
Q9	1-801-806-11	TRANSISTOR DTC144EKA-T146		R61	1-216-049-91	RES,CHIP 1K	5% 1/10W
Q10	1-801-806-11	TRANSISTOR DTC144EKA-T146		R62	1-216-059-00	RES,CHIP 2.7K	5% 1/10W
Q500	8-729-821-87	TRANSISTOR 2SD1878-CA		R63	1-216-368-11	METAL OXIDE 0.82	5% 2W F
Q502	8-729-802-71	TRANSISTOR 2SA1407-D		R64	1-216-669-11	METAL CHIP 5.6K	0.50% 1/10W
Q503	1-801-806-11	TRANSISTOR DTC144EKA-T146		R65	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
Q504	8-729-119-80	TRANSISTOR 2SC2688-LK		R66	1-216-681-11	METAL CHIP 18K	0.50% 1/10W
Q505	8-729-230-49	TRANSISTOR 2SC2712-YG		R500	1-260-294-11	CARBON 1.5	5% 1/2W
Q507	8-729-216-22	TRANSISTOR 2SA1162-G		R501	1-216-025-91	RES,CHIP 100	5% 1/10W
Q508	8-729-230-49	TRANSISTOR 2SC2712-YG		R504	1-249-417-11	CARBON 1K	5% 1/4W F
Q509	8-729-031-68	TRANSISTOR 2SC4630LS		R505	1-215-923-00	METAL OXIDE 10K	5% 3W F
Q510	8-729-216-22	TRANSISTOR 2SA1162-G		R506	1-216-073-00	RES,CHIP 10K	5% 1/10W
Q511	8-729-230-49	TRANSISTOR 2SC2712-YG		R507	1-216-353-00	METAL OXIDE 2.2	5% 1W F
Q513	8-729-031-68	TRANSISTOR 2SC4630LS		R508	1-216-041-00	RES,CHIP 470	5% 1/10W
Q514	8-729-216-22	TRANSISTOR 2SA1162-G		R511	1-249-420-11	CARBON 1.8K	5% 1/4W F
Q515	8-729-230-49	TRANSISTOR 2SC2712-YG		R512	1-216-097-91	RES,CHIP 100K	5% 1/10W
Q516	8-729-230-49	TRANSISTOR 2SC2712-YG		R513	1-260-300-11	CARBON 4.7	5% 1/2W
Q519	8-729-031-68	TRANSISTOR 2SC4630LS		R514	1-260-300-11	CARBON 4.7	5% 1/2W
Q521	8-729-216-22	TRANSISTOR 2SA1162-G		R515	1-216-049-91	RES,CHIP 1K	5% 1/10W
Q522	8-729-230-49	TRANSISTOR 2SC2712-YG		R517	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
Q524	8-729-801-88	TRANSISTOR 2SA1381-E		R518	1-249-417-11	CARBON 1K	5% 1/4W F
Q525	8-729-230-49	TRANSISTOR 2SC2712-YG		R519	1-260-300-11	CARBON 4.7	5% 1/2W
		<RESISTOR>		R521	1-220-824-11	CARBON 270K	5% 1/2W
R1	1-216-025-91	RES,CHIP 100	5% 1/10W	R522	1-220-824-11	CARBON 270K	5% 1/2W
R2	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W	R523	1-220-824-11	CARBON 270K	5% 1/2W
R3	1-216-685-11	METAL CHIP 27K	0.50% 1/10W	R525	1-220-824-11	CARBON 270K	5% 1/2W
R4	1-216-055-00	RES,CHIP 1.8K	5% 1/10W	R526	1-220-824-11	CARBON 270K	5% 1/2W
R5	1-216-049-91	RES,CHIP 1K	5% 1/10W	R527	1-220-824-11	CARBON 270K	5% 1/2W
R6	1-216-049-91	RES,CHIP 1K	5% 1/10W	R528	1-216-073-00	RES,CHIP 10K	5% 1/10W
				R529	1-220-824-11	CARBON 270K	5% 1/2W
				R530	1-220-824-11	CARBON 270K	5% 1/2W
				R531	1-220-824-11	CARBON 270K	5% 1/2W
				R532	1-216-089-91	RES,CHIP 47K	5% 1/10W
				R533	1-216-089-91	RES,CHIP 47K	5% 1/10W
				R534	1-219-743-11	CARBON 100	5% 1/2W
				R538	1-216-089-91	RES,CHIP 47K	5% 1/10W

Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description		Remark
R539	1-219-752-11	CARBON	100K	5%	1/2W	TP505	* 1-537-864-11	PIN, POST		
R540	1-216-073-00	RES,CHIP	10K	5%	1/10W					
R541	1-216-089-91	RES,CHIP	47K	5%	1/10W					
R542	1-216-025-91	RES,CHIP	100	5%	1/10W					
R543	1-216-061-00	RES,CHIP	3.3K	5%	1/10W					

R544	1-216-025-91	RES,CHIP	100	5%	1/10W			* A-1195-143-A PA COMPLETE PC BOARD		
R545	1-216-089-91	RES,CHIP	47K	5%	1/10W			*****		
R546	1-216-093-91	RES,CHIP	68K	5%	1/10W					
R547	1-216-065-91	RES,CHIP	4.7K	5%	1/10W			3-701-809-31 SCREW, TERMINAL (M3X8)		
R548	1-216-097-91	RES,CHIP	100K	5%	1/10W			4-056-081-01 HOLDER (EBA), TR		
								* 4-353-708-00 HOOK, FINGER		
R549	1-216-097-91	RES,CHIP	100K	5%	1/10W			4-382-854-11 SCREW (M3X10), P, SW (+)		
R550	1-216-073-00	RES,CHIP	10K	5%	1/10W					
R551	1-216-113-00	RES,CHIP	470K	5%	1/10W					
R552	1-216-073-00	RES,CHIP	10K	5%	1/10W			<CAPACITOR>		
R555	1-219-743-11	CARBON	100	5%	1/2W					
						C1	1-126-933-11	ELECT	100μF	20% 16V
R556	1-219-752-11	CARBON	100K	5%	1/2W	C2	1-126-943-11	ELECT	2200μF	20% 25V
R557	1-216-089-91	RES,CHIP	47K	5%	1/10W	C3	1-126-933-11	ELECT	100μF	20% 16V
R558	1-216-061-00	RES,CHIP	3.3K	5%	1/10W	C4	1-104-665-11	ELECT	100μF	20% 25V
R559	1-216-089-91	RES,CHIP	47K	5%	1/10W	C10	1-126-942-61	ELECT	1000μF	20% 25V
R560	1-216-073-00	RES,CHIP	10K	5%	1/10W					
						C11	1-104-666-11	ELECT	220μF	20% 25V
R561	1-216-073-00	RES,CHIP	10K	5%	1/10W	C100	1-126-968-11	ELECT	100μF	20% 50V
R562	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C101	1-126-968-11	ELECT	100μF	20% 50V
R563	1-216-113-00	RES,CHIP	470K	5%	1/10W	C102	1-126-964-11	ELECT	10μF	20% 50V
R569	1-219-743-11	CARBON	100	5%	1/2W	C103	1-137-366-11	FILM	0.0022μF	5% 50V
R570	1-219-752-11	CARBON	100K	5%	1/2W					
						C104	1-137-366-11	FILM	0.0022μF	5% 50V
R571	1-216-089-91	RES,CHIP	47K	5%	1/10W	C105	1-130-471-00	FILM	0.001μF	5% 50V
R572	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C106	1-126-767-11	ELECT	1000μF	20% 16V
R573	1-216-061-00	RES,CHIP	3.3K	5%	1/10W	C107	1-126-767-11	ELECT	1000μF	20% 16V
R574	1-216-089-91	RES,CHIP	47K	5%	1/10W	C108	1-130-471-00	FILM	0.001μF	5% 50V
R575	1-216-073-00	RES,CHIP	10K	5%	1/10W					
						C109	1-136-169-00	FILM	0.22μF	5% 50V
R576	1-216-097-91	RES,CHIP	100K	5%	1/10W	C110	1-102-978-00	CERAMIC	220PF	5% 50V
R578	1-216-097-91	RES,CHIP	100K	5%	1/10W	C111	1-136-169-00	FILM	0.22μF	5% 50V
R579	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C150	1-104-664-11	ELECT	47μF	20% 16V
R580	1-216-073-00	RES,CHIP	10K	5%	1/10W	C151	1-126-933-11	ELECT	100μF	20% 16V
R581	1-216-077-00	RES,CHIP	15K	5%	1/10W					
						C152	1-126-933-11	ELECT	100μF	20% 16V
R582	1-216-113-00	RES,CHIP	470K	5%	1/10W	C153	1-136-169-00	FILM	0.22μF	5% 50V
R588	1-249-429-11	CARBON	10K	5%	1/4W F	C154	1-101-004-00	CERAMIC	0.01μF	50V
R589	1-216-049-91	RES,CHIP	1K	5%	1/10W	C155	1-102-123-00	CERAMIC	0.0033μF	10% 50V
R590	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C156	1-101-004-00	CERAMIC	0.01μF	50V
R591	1-216-049-91	RES,CHIP	1K	5%	1/10W					
						C157	1-102-116-00	CERAMIC	680PF	10% 50V
R616	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C158	1-137-366-11	FILM	0.0022μF	5% 50V
						C159	1-137-366-11	FILM	0.0022μF	5% 50V
	<SPARK GAP>					C160	1-102-002-00	CERAMIC	680PF	10% 500V
						C200	1-126-964-11	ELECT	10μF	20% 50V
SG1	1-519-504-11	GAP, DISCHARGE				C201	1-126-964-11	ELECT	10μF	20% 50V
						C202	1-126-963-11	ELECT	4.7μF	20% 50V
	<TRANSFORMER>					C203	1-126-963-11	ELECT	4.7μF	20% 50V
						C204	1-126-964-11	ELECT	10μF	20% 50V
						C205	1-101-004-00	CERAMIC	0.01μF	50V
T500	1-437-078-00	TRANSFORMER, HORIZONTAL DRIVE				C250	1-136-169-00	FILM	0.22μF	5% 50V
T501	1-433-521-11	TRANSFORMER, FERRITE (LOT)				C251	1-126-967-11	ELECT	47μF	20% 50V
						C252	1-126-964-11	ELECT	10μF	20% 50V
	<TEST PIN>					C253	1-101-004-00	CERAMIC	0.01μF	50V
						C300	1-104-664-11	ELECT	47μF	20% 16V
TP500	* 1-537-864-11	PIN, POST				C301	1-104-664-11	ELECT	47μF	20% 16V
TP501	* 1-537-864-11	PIN, POST				C302	1-107-906-11	ELECT	10μF	20% 16V
TP502	* 1-537-864-11	PIN, POST				C303	1-102-973-00	CERAMIC	100PF	5% 50V
TP503	* 1-537-864-11	PIN, POST				C500	1-126-933-11	ELECT	100μF	20% 16V
TP504	* 1-537-864-11	PIN, POST				C501	1-126-949-11	ELECT	220μF	20% 35V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C502	1-126-948-11	ELECT	100μF 20% 35V	D602	8-719-110-53	DIODE RD20ESB2	
C503	1-104-665-11	ELECT	100μF 20% 25V	D603	8-719-900-95	DIODE V09G	
C504	1-136-153-00	FILM	0.01μF 5% 50V	D604	8-719-110-53	DIODE RD20ESB2	
C505	1-128-551-11	ELECT	22μF 20% 25V	D605	8-719-110-53	DIODE RD20ESB2	
C506	1-162-318-11	CERAMIC	0.001μF 10% 500V	D606	8-719-900-95	DIODE V09G	
C507	1-126-948-11	ELECT	100μF 20% 35V	D607	8-719-110-53	DIODE RD20ESB2	
C508	1-102-129-00	CERAMIC	0.01μF 10% 50V	D608	8-719-110-53	DIODE RD20ESB2	
C509	1-102-129-00	CERAMIC	0.01μF 10% 50V	D609	8-719-059-41	DIODE DD82RC-SONY	
C600	1-127-684-11	ELECT MELF	820μF 20% 250V	D610	8-719-059-41	DIODE DD82RC-SONY	
C601	1-127-684-11	ELECT MELF	820μF 20% 250V				
C602	1-127-684-11	ELECT MELF	820μF 20% 250V			<FERRITE BEAD>	
C603	1-127-684-11	ELECT MELF	820μF 20% 250V				
C604	1-136-165-00	FILM	0.1μF 5% 50V	FB600	1-410-396-41	FERRITE 0.45μH	
C605	1-136-165-00	FILM	0.1μF 5% 50V	FB601	1-410-396-41	FERRITE 0.45μH	
C606	1-136-165-00	FILM	0.1μF 5% 50V	FB602	1-410-396-41	FERRITE 0.45μH	
C607	△1-117-845-11	FILM	16000PF 3% 1.5KV	FB603	1-410-396-41	FERRITE 0.45μH	
C608	△1-117-845-11	FILM	16000PF 3% 1.5KV	FB604	1-410-396-41	FERRITE 0.45μH	
C609	1-129-718-00	FILM	0.022μF 5% 630V	FB605	1-410-396-41	FERRITE 0.45μH	
C610	△1-136-729-11	FILM	1.5μF 5% 400V			<IC>	
C611	△1-136-729-11	FILM	1.5μF 5% 400V	IC1	8-759-231-58	IC TA7812S	
C612	1-104-999-11	FILM	0.1μF 5% 200V	IC2	8-759-929-65	IC LM7912CT	
C613	1-104-999-11	FILM	0.1μF 5% 200V	IC100	8-759-908-15	IC TL431CLP	
		<CONNECTOR>		IC101	8-759-503-91	IC TL082ACP	
CN86	*1-564-712-11	PIN, CONNECTOR (SMALL TYPE)10P		IC102	8-759-503-91	IC TL082ACP	
CN87	*1-564-509-11	PLUG, CONNECTOR 6P		IC150	8-759-103-93	IC UPC393C	
CN88	*1-564-508-11	PLUG, CONNECTOR 5P		IC151	8-759-708-05	IC NJM78L05A	
CN89	*1-750-916-11	PIN, CONNECTOR(DY)(PC BOARD)8P		IC152	8-759-906-24	IC SN74LS624N	
CN90	*1-750-916-11	PIN, CONNECTOR(DY)(PC BOARD)8P		IC153	8-759-901-23	IC SN74LS123N	
CN91	*1-564-506-11	PLUG, CONNECTOR 3P		IC154	8-759-336-45	IC PST574C-T	
CN93	*1-564-506-11	PLUG, CONNECTOR 3P		IC200	8-759-103-93	IC UPC393C	
		<DIODE>		IC250	8-759-908-15	IC TL431CLP	
D1	8-719-911-19	DIODE 1SS119-25		IC251	8-759-103-93	IC UPC393C	
D2	8-719-900-95	DIODE V09G		IC300	8-759-503-91	IC TL082ACP	
D3	8-719-911-19	DIODE 1SS119-25		IC301	8-759-503-91	IC TL082ACP	
D100	8-719-911-19	DIODE 1SS119-25		IC302	8-759-145-58	IC UPC4558C	
D101	8-719-110-36	DIODE RD13ESB2		IC500	8-759-708-12	IC NJM78L12A	
D102	8-719-110-36	DIODE RD13ESB2				<COIL>	
D103	8-719-911-19	DIODE 1SS119-25		L1	1-406-663-21	INDUCTOR 47μH	
D104	8-719-911-19	DIODE 1SS119-25		L2	1-406-663-21	INDUCTOR 47μH	
D105	8-719-911-19	DIODE 1SS119-25		L500	1-406-663-21	INDUCTOR 47μH	
D150	8-719-911-19	DIODE 1SS119-25		L600	1-406-973-21	INDUCTOR 22μH	
D151	8-719-911-19	DIODE 1SS119-25		L601	△1-416-872-11	INDUCTOR 420μH	
D152	8-719-911-19	DIODE 1SS119-25		L602	△1-416-872-11	INDUCTOR 420μH	
D200	8-719-911-19	DIODE 1SS119-25		L603	△1-416-872-11	INDUCTOR 420μH	
D201	8-719-911-19	DIODE 1SS119-25		L604	△1-416-872-11	INDUCTOR 420μH	
D202	8-719-109-85	DIODE RD5.1ESB2		L605	1-406-656-21	INDUCTOR 3.3μH	
D250	8-719-110-36	DIODE RD13ESB2		L606	1-406-656-21	INDUCTOR 3.3μH	
D251	8-719-027-19	DIODE MVR3368S				<PHOTO COUPLER>	
D252	8-719-911-19	DIODE 1SS119-25		PH500	8-749-014-92	IC TLP558	
D253	8-719-911-19	DIODE 1SS119-25					
D300	8-719-110-22	DIODE RD11ESB2					
D301	8-719-110-22	DIODE RD11ESB2					
D500	8-719-911-19	DIODE 1SS119-25					
D600	8-719-900-95	DIODE V09G					
D601	8-719-110-53	DIODE RD20ESB2					

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
		<TRANSISTOR>		R121	1-215-443-00	METAL 8.2K 1%	1/4W
Q10	8-729-030-02	TRANSISTOR DTC144ESA		R122	1-249-429-11	CARBON 10K 5%	1/4W
Q11	8-729-030-02	TRANSISTOR DTC144ESA		R123	1-249-425-11	CARBON 4.7K 5%	1/4W
Q100	8-729-119-78	TRANSISTOR 2SC2785-HFE		R150	1-249-429-11	CARBON 10K 5%	1/4W
Q150	8-729-119-76	TRANSISTOR 2SA1175-HFE		R151	1-247-863-91	CARBON 22K 5%	1/4W
Q151	8-729-119-76	TRANSISTOR 2SA1175-HFE					
Q152	8-729-119-76	TRANSISTOR 2SA1175-HFE		R152	1-249-420-11	CARBON 1.8K 5%	1/4W
Q153	8-729-119-78	TRANSISTOR 2SC2785-HFE		R153	1-249-425-11	CARBON 4.7K 5%	1/4W
Q154	8-729-119-78	TRANSISTOR 2SC2785-HFE		R154	1-216-450-00	METAL OXIDE 82 5%	2W F
Q155	8-729-119-78	TRANSISTOR 2SC2785-HFE		R155	1-215-441-00	METAL 6.8K 1%	1/4W
Q200	8-729-119-78	TRANSISTOR 2SC2785-HFE		R156	1-215-441-00	METAL 6.8K 1%	1/4W
Q201	8-729-119-78	TRANSISTOR 2SC2785-HFE					
Q202	8-729-119-78	TRANSISTOR 2SC2785-HFE		R157	1-215-457-00	METAL 33K 1%	1/4W
Q203	8-729-119-78	TRANSISTOR 2SC2785-HFE		R158	1-215-459-00	METAL 39K 1%	1/4W
Q204	8-729-119-78	TRANSISTOR 2SC2785-HFE		R159	1-249-429-11	CARBON 10K 5%	1/4W
Q250	8-729-040-55	TRANSISTOR 2SK1482-T		R160	1-249-417-11	CARBON 1K 5%	1/4W
Q251	8-729-030-02	TRANSISTOR DTC144ESA		R161	1-249-437-11	CARBON 47K 5%	1/4W
Q252	8-729-030-02	TRANSISTOR DTC144ESA					
Q500	8-729-119-78	TRANSISTOR 2SC2785-HFE		R162	1-249-441-11	CARBON 100K 5%	1/4W
Q501	8-729-119-76	TRANSISTOR 2SA1175-HFE		R163	1-249-437-11	CARBON 47K 5%	1/4W
Q502	8-729-119-78	TRANSISTOR 2SC2785-HFE		R164	1-249-441-11	CARBON 100K 5%	1/4W
Q503	8-729-207-82	TRANSISTOR 2SC3421-Y		R165	1-249-429-11	CARBON 10K 5%	1/4W
Q504	8-729-207-89	TRANSISTOR 2SA1358-Y		R166	1-249-425-11	CARBON 4.7K 5%	1/4W
Q505	8-729-207-82	TRANSISTOR 2SC3421-Y					
Q506	8-729-207-89	TRANSISTOR 2SA1358-Y		R167	1-249-417-11	CARBON 1K 5%	1/4W
Q507	8-729-207-82	TRANSISTOR 2SC3421-Y		R200	1-215-469-00	METAL 100K 1%	1/4W
Q508	8-729-207-89	TRANSISTOR 2SA1358-Y		R201	1-215-467-00	METAL 82K 1%	1/4W
Q600	8-729-045-55	TRANSISTOR 2SK2349-CB		R202	1-215-469-00	METAL 100K 1%	1/4W
Q601	8-729-045-55	TRANSISTOR 2SK2349-CB		R203	1-247-863-91	CARBON 22K 5%	1/4W
Q602	8-729-045-55	TRANSISTOR 2SK2349-CB					
		<RESISTOR>		R204	1-249-429-11	CARBON 10K 5%	1/4W
R10	1-247-887-00	CARBON 220K 5%	1/4W	R205	1-215-469-00	METAL 100K 1%	1/4W
R11	1-249-429-11	CARBON 10K 5%	1/4W	R206	1-215-467-00	METAL 82K 1%	1/4W
R12	1-249-429-11	CARBON 10K 5%	1/4W	R207	1-215-469-00	METAL 100K 1%	1/4W
R13	1-247-807-31	CARBON 100 5%	1/4W	R208	1-247-863-91	CARBON 22K 5%	1/4W
R14	1-215-908-00	METAL OXIDE 33 5%	3W F				
R100	1-249-429-11	CARBON 10K 5%	1/4W	R209	1-249-429-11	CARBON 10K 5%	1/4W
R101	1-249-417-11	CARBON 1K 5%	1/4W	R210	1-249-437-11	CARBON 47K 5%	1/4W
R102	1-249-417-11	CARBON 1K 5%	1/4W	R211	1-249-436-11	CARBON 39K 5%	1/4W
R103	1-215-447-00	METAL 12K 1%	1/4W	R212	1-249-440-11	CARBON 82K 5%	1/4W
R104	1-215-447-00	METAL 12K 1%	1/4W	R213	1-249-441-11	CARBON 100K 5%	1/4W
R105	1-215-455-00	METAL 27K 1%	1/4W				
R106	1-215-456-00	METAL 30K 1%	1/4W	R214	1-249-441-11	CARBON 100K 5%	1/4W
R107	1-215-445-00	METAL 10K 1%	1/4W	R215	1-249-439-11	CARBON 68K 5%	1/4W
R108	1-249-411-11	CARBON 330 5%	1/4W	R216	1-247-863-91	CARBON 22K 5%	1/4W
R109	1-247-807-31	CARBON 100 5%	1/4W	R217	1-249-425-11	CARBON 4.7K 5%	1/4W
R110	1-249-437-11	CARBON 47K 5%	1/4W	R218	1-249-425-11	CARBON 4.7K 5%	1/4W
R111	1-249-417-11	CARBON 1K 5%	1/4W				
R112	1-249-417-11	CARBON 1K 5%	1/4W	R219	1-247-807-31	CARBON 100 5%	1/4W
R114	1-249-431-11	CARBON 15K 5%	1/4W	R250	1-249-417-11	CARBON 1K 5%	1/4W
R115	1-247-903-00	CARBON 1M 5%	1/4W	R251	1-215-441-00	METAL 6.8K 1%	1/4W
R116	1-249-439-11	CARBON 68K 5%	1/4W	R252	1-215-431-00	METAL 2.7K 1%	1/4W
R117	1-249-417-11	CARBON 1K 5%	1/4W	R253	1-249-429-11	CARBON 10K 5%	1/4W
R118	1-249-417-11	CARBON 1K 5%	1/4W				
R119	1-249-413-11	CARBON 470 5%	1/4W	R254	1-249-441-11	CARBON 100K 5%	1/4W
R120	1-215-465-00	METAL 68K 1%	1/4W	R255	1-249-417-11	CARBON 1K 5%	1/4W
				R256	1-249-429-11	CARBON 10K 5%	1/4W
				R257	1-249-441-11	CARBON 100K 5%	1/4W
				R258	1-249-429-11	CARBON 10K 5%	1/4W
				R259	1-249-429-11	CARBON 10K 5%	1/4W
				R260	1-249-425-11	CARBON 4.7K 5%	1/4W
				R261	1-249-429-11	CARBON 10K 5%	1/4W
				R262	1-247-807-31	CARBON 100 5%	1/4W
				R300	1-249-417-11	CARBON 1K 5%	1/4W
				R301	1-215-453-00	METAL 22K 1%	1/4W
				R302	1-249-417-11	CARBON 1K 5%	1/4W
				R303	1-215-453-00	METAL 22K 1%	1/4W
				R304	1-215-445-00	METAL 10K 1%	1/4W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R305	1-215-437-00	METAL	4.7K 1% 1/4W	TP600	* 1-537-864-11	PIN, POST	
R306	1-215-445-00	METAL	10K 1% 1/4W	TP601	* 1-537-864-11	PIN, POST	
R307	1-215-437-00	METAL	4.7K 1% 1/4W	*****			
R308	1-215-445-00	METAL	10K 1% 1/4W	* A-1195-144-A PD COMPLETE PC BOARD			
R309	1-249-437-11	CARBON	47K 5% 1/4W	*****			
R310	1-249-417-11	CARBON	1K 5% 1/4W	4-382-854-11 SCREW (M3X10), P, SW (+)			
R311	1-247-863-91	CARBON	22K 5% 1/4W	4-393-406-01 SHEET (R), RADIATION			
R312	1-249-417-11	CARBON	1K 5% 1/4W	<CAPACITOR>			
R313	1-249-435-11	CARBON	33K 5% 1/4W	C500	1-126-943-11	ELECT	2200μF 20% 25V
R314	1-249-417-11	CARBON	1K 5% 1/4W	C501	1-126-933-11	ELECT	100μF 20% 16V
R315	1-249-417-11	CARBON	1K 5% 1/4W	C502	1-126-964-11	ELECT	10μF 20% 50V
R316	1-247-807-31	CARBON	100 5% 1/4W	C510	1-126-960-11	ELECT	1μF 20% 50V
R500	1-216-455-11	METAL OXIDE	560 5% 2W F	C514	1-101-004-00	CERAMIC	0.01μF 50V
R501	1-249-417-11	CARBON	1K 5% 1/4W	C522	1-101-004-00	CERAMIC	0.01μF 50V
R502	1-249-417-11	CARBON	1K 5% 1/4W	C524	1-102-973-00	CERAMIC	100PF 5% 50V
R503	1-249-417-11	CARBON	1K 5% 1/4W	C525	1-102-973-00	CERAMIC	100PF 5% 50V
R504	1-249-417-11	CARBON	1K 5% 1/4W	C526	1-102-973-00	CERAMIC	100PF 5% 50V
R505	1-216-435-11	METAL OXIDE	2.7K 5% 1W F	C530	1-126-963-11	ELECT	4.7μF 20% 50V
R506	1-247-727-11	CARBON	10 5% 1/2W F	C531	1-101-004-00	CERAMIC	0.01μF 50V
R507	1-249-401-11	CARBON	47 5% 1/4W	C533	1-136-165-00	FILM	0.1μF 5% 50V
R508	1-249-401-11	CARBON	47 5% 1/4W	C534	1-136-165-00	FILM	0.1μF 5% 50V
R509	1-249-401-11	CARBON	47 5% 1/4W	C535	1-136-165-00	FILM	0.1μF 5% 50V
R600	1-216-448-11	METAL OXIDE	39 5% 2W F	C536	1-123-024-21	ELECT	33μF 160V
R601	1-215-869-11	METAL OXIDE	1K 5% 1W F	C537	1-123-024-21	ELECT	33μF 160V
R602	1-216-448-11	METAL OXIDE	39 5% 2W F	C538	1-102-973-00	CERAMIC	100PF 5% 50V
R603	1-215-869-11	METAL OXIDE	1K 5% 1W F	C539	1-101-004-00	CERAMIC	0.01μF 50V
R604	1-216-448-11	METAL OXIDE	39 5% 2W F	C540	1-136-153-00	FILM	0.01μF 5% 50V
R605	1-215-869-11	METAL OXIDE	1K 5% 1W F	C544	1-136-153-00	FILM	0.01μF 5% 50V
R606	1-215-906-11	METAL OXIDE	15 5% 3W F	C545	1-109-889-11	ELECT	1μF 20% 50V
R607	1-215-906-11	METAL OXIDE	15 5% 3W F	C546	1-130-471-00	FILM	0.001μF 5% 50V
R608	1-215-906-11	METAL OXIDE	15 5% 3W F	C547	1-126-933-11	ELECT	100μF 20% 16V
R609	1-215-906-11	METAL OXIDE	15 5% 3W F	C548	1-126-933-11	ELECT	100μF 20% 16V
R610	1-215-906-11	METAL OXIDE	15 5% 3W F	C549	1-136-165-00	FILM	0.1μF 5% 50V
R612	1-214-880-00	METAL	4.7K 1% 1/2W	C550	1-101-004-00	CERAMIC	0.01μF 50V
R613	1-214-880-00	METAL	4.7K 1% 1/2W	C551	1-126-960-11	ELECT	1μF 20% 50V
R614	△1-202-933-61	FUSIBLE	0.1 10% 1/2W F	C552	1-125-538-11	ELECT(BLOCK)	1000μF 20% 200V
R615	△1-202-933-61	FUSIBLE	0.1 10% 1/2W F	C553	1-136-159-00	FILM	0.033μF 5% 50V
R616	△1-202-933-61	FUSIBLE	0.1 10% 1/2W F	C554	1-102-973-00	CERAMIC	100PF 5% 50V
R617	△1-202-933-61	FUSIBLE	0.1 10% 1/2W F	C555	1-126-964-11	ELECT	10μF 20% 50V
R618	△1-202-933-61	FUSIBLE	0.1 10% 1/2W F	C556	1-136-153-00	FILM	0.01μF 5% 50V
R619	△1-202-933-61	FUSIBLE	0.1 10% 1/2W F	C557	1-126-965-11	ELECT	22μF 20% 50V
<VARIABLE RESISTOR>				<CONNECTOR>			
RV100	△	RES, ADJ, CERMET 20K		CN96	* 1-564-706-11	PIN, CONNECTOR (SMALL TYPE) 4P	
RV101	1-238-802-11	RES, ADJ, CERMET 10K		CN97	* 1-508-786-00	PIN, CONNECTOR (5MM PITCH) 2P	
RV150	1-238-802-11	RES, ADJ, CERMET 10K		CN98	* 1-564-705-11	PIN, CONNECTOR (SMALL TYPE) 3P	
RV250	△	RES, ADJ, CERMET 1K		<DIODE>			
<TEST PIN>				D500	8-719-911-19	DIODE 1SS119-25	
TP1	* 1-537-864-11	PIN, POST		D501	8-719-900-95	DIODE V09G	
TP2	* 1-537-864-11	PIN, POST		D520	8-719-911-19	DIODE 1SS119-25	
TP3	* 1-537-864-11	PIN, POST		D521	8-719-911-19	DIODE 1SS119-25	
TP103	* 1-537-864-11	PIN, POST					
TP150	* 1-537-864-11	PIN, POST					
TP151	* 1-537-864-11	PIN, POST					
TP152	* 1-537-864-11	PIN, POST					
TP300	* 1-537-864-11	PIN, POST					

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
D523	8-719-911-19	DIODE 1SS119-25		R554	1-249-417-11	CARBON 1K	5% 1/4W
D527	8-719-043-14	DIODE ESAD39M-06C		R564	1-247-807-31	CARBON 100	5% 1/4W
D528	8-719-911-19	DIODE 1SS119-25		R565	1-249-436-11	CARBON 39K	5% 1/4W
D529	8-719-911-19	DIODE 1SS119-25		R566	1-249-436-11	CARBON 39K	5% 1/4W
D530	8-719-911-19	DIODE 1SS119-25		R567	1-249-436-11	CARBON 39K	5% 1/4W
D531	8-719-110-36	DIODE RD13ESB2		R568	1-249-429-11	CARBON 10K	5% 1/4W
		<FERRITE BEAD>		R577	1-249-417-11	CARBON 1K	5% 1/4W
FB502	1-410-396-41	FERRITE 0.45μH		R584	1-247-807-31	CARBON 100	5% 1/4W
FB503	1-410-396-41	FERRITE 0.45μH		R585	1-249-426-11	CARBON 5.6K	5% 1/4W
FB504	1-410-396-41	FERRITE 0.45μH		R586	1-249-413-11	CARBON 470	5% 1/4W
FB505	1-410-396-41	FERRITE 0.45μH		R587	1-249-417-11	CARBON 1K	5% 1/4W
		<IC>		R589	1-249-399-11	CARBON 33	5% 1/4W
IC500	8-759-231-58	IC TA7812S		R590	1-249-425-11	CARBON 4.7K	5% 1/4W
IC502	8-759-240-40	IC TC4040BP		R591	1-215-445-00	METAL 10K	1% 1/4W
IC503	8-759-045-72	IC MC14572UBCP		R592	1-247-895-91	CARBON 470K	5% 1/4W
IC506	8-759-103-93	IC UPC393C		R593	1-247-863-91	CARBON 22K	5% 1/4W
IC507	8-759-100-75	IC UPC1394C		R594	1-215-866-11	METAL OXIDE 330	5% 1W F
		<COIL>		R595	1-249-421-11	CARBON 2.2K	5% 1/4W
L500	1-412-533-21	INDUCTOR 47μH		R596	1-247-863-91	CARBON 22K	5% 1/4W
L503	1-406-664-21	INDUCTOR 68μH		R597	1-249-431-11	CARBON 15K	5% 1/4W
L504	1-410-686-11	INDUCTOR 1mH		R598	1-215-445-00	METAL 10K	1% 1/4W
L505	1-411-566-11	INDUCTOR 1mH		R599	1-249-420-11	CARBON 1.8K	5% 1/4W
		<TRANSISTOR>		R600	1-247-863-91	CARBON 22K	5% 1/4W
Q501	8-729-119-78	TRANSISTOR 2SC2785-HFE		R601	1-249-429-11	CARBON 10K	5% 1/4W
Q506	8-729-119-76	TRANSISTOR 2SA1175-HFE		R602	1-247-863-91	CARBON 22K	5% 1/4W
Q512	8-729-119-76	TRANSISTOR 2SA1175-HFE		R603	1-249-425-11	CARBON 4.7K	5% 1/4W
Q517	8-729-030-02	TRANSISTOR DTC144ESA		R604	1-249-429-11	CARBON 10K	5% 1/4W
Q518	8-729-119-78	TRANSISTOR 2SC2785-HFE		R605	1-249-426-11	CARBON 5.6K	5% 1/4W
Q520	8-729-030-02	TRANSISTOR DTC144ESA		R606	1-249-429-11	CARBON 10K	5% 1/4W
Q523	8-729-119-76	TRANSISTOR 2SA1175-HFE		R607	1-216-381-11	METAL OXIDE 0.22	5% 3W F
Q525	8-729-119-76	TRANSISTOR 2SA1175-HFE		R608	1-216-381-11	METAL OXIDE 0.22	5% 3W F
Q526	8-729-033-57	TRANSISTOR IRFP350LF20		R609	1-249-429-11	CARBON 10K	5% 1/4W
Q527	8-729-119-78	TRANSISTOR 2SC2785-HFE		R610	1-249-429-11	CARBON 10K	5% 1/4W
Q528	8-729-140-96	TRANSISTOR 2SD774-34		R611	1-249-429-11	CARBON 10K	5% 1/4W
Q529	8-729-140-97	TRANSISTOR 2SB734-34		R612	1-249-441-11	CARBON 100K	5% 1/4W
Q530	8-729-105-74	TRANSISTOR 2SK523-M1		R613	1-249-425-11	CARBON 4.7K	5% 1/4W
		<RESISTOR>		R614	1-249-425-11	CARBON 4.7K	5% 1/4W
R501	1-249-437-11	CARBON 47K	5% 1/4W	R615	1-249-401-11	CARBON 47	5% 1/4W F
R502	1-249-437-11	CARBON 47K	5% 1/4W	R616	1-249-417-11	CARBON 1K	5% 1/4W
R503	1-247-863-91	CARBON 22K	5% 1/4W			<TRANSFORMER>	
R504	1-249-437-11	CARBON 47K	5% 1/4W	T502	1-424-290-11	TRANSFORMER, DRIVE	
R505	1-249-429-11	CARBON 10K	5% 1/4W			<TEST PIN>	
R506	1-249-421-11	CARBON 2.2K	5% 1/4W	TP500	* 1-537-864-11	PIN, POST	
R507	1-249-429-11	CARBON 10K	5% 1/4W	TP501	* 1-537-864-11	PIN, POST	
R516	1-249-417-11	CARBON 1K	5% 1/4W	TP503	* 1-537-864-11	PIN, POST	
R520	1-247-843-11	CARBON 3.3K	5% 1/4W	TP504	* 1-537-864-11	PIN, POST	
R524	1-249-417-11	CARBON 1K	5% 1/4W	TP505	* 1-537-864-11	PIN, POST	
R535	1-249-425-11	CARBON 4.7K	5% 1/4W			<CRYSTAL>	
R536	1-247-903-00	CARBON 1M	5% 1/4W	X500	1-578-768-11	VIBLATOR, CERAMIC	
R553	1-247-843-11	CARBON 3.3K	5% 1/4W				



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
*****				L3	△1-431-161-11	TRANSFORMER, LINE FILTER	
* A-1245-598-A F COMPLETE PC BOARD				L4	△1-403-675-11	INDUCTOR 34μH	
*****				L9	△1-403-675-11	INDUCTOR 34μH	
* 4-353-708-00 HOOK, FINGER				L10	△1-431-160-11	TRANSFORMER, LINE FILTER	
<CAPACITOR>				L11	△1-431-161-11	TRANSFORMER, LINE FILTER	
C1	△1-104-706-51	FILM	0.22μF 20% 250V	L12	△1-403-675-11	INDUCTOR 34μH	
C2	△1-104-708-51	FILM	0.47μF 20% 250V	<RESISTOR>			
C4	△1-117-699-51	CERAMIC	0.001μF 99% 250V	R1	△1-202-961-11	CEMENTED 1.8 5% 10W	
C5	△1-117-699-51	CERAMIC	0.001μF 99% 250V	R2	△1-202-961-11	CEMENTED 1.8 5% 10W	
C7	△1-107-533-51	FILM	1μF 20% 250V	R3	△1-202-961-11	CEMENTED 1.8 5% 10W	
C8	△1-104-706-51	FILM	0.22μF 20% 250V	R4	△1-217-780-11	FUSIBLE 1 5% 5W F	
C9	△1-104-706-51	FILM	0.22μF 20% 250V	R5	△1-220-827-91	REGISTER 560K 5% 1/2W	
C10	△1-117-699-51	CERAMIC	0.001μF 99% 250V	R16	△1-202-961-11	CEMENTED 1.8 5% 10W	
C12	△1-117-699-51	CERAMIC	0.001μF 99% 250V	R17	△1-202-961-11	CEMENTED 1.8 5% 10W	
C34	△1-104-706-51	FILM	0.22μF 20% 250V	R18	△1-202-961-11	CEMENTED 1.8 5% 10W	
C35	△1-104-708-51	FILM	0.47μF 20% 250V	R19	△1-217-780-11	FUSIBLE 1 5% 5W F	
C37	△1-117-699-51	CERAMIC	0.001μF 99% 250V	R20	△1-220-827-91	REGISTER 560K 5% 1/2W	
C38	△1-117-699-51	CERAMIC	0.001μF 99% 250V	<RELAY>			
C40	△1-107-533-51	FILM	1μF 20% 250V	RY1	△1-515-450-21	RELAY, POWER	
C41	△1-104-706-51	FILM	0.22μF 20% 250V	RY3	△1-515-450-21	RELAY, POWER	
C42	△1-104-706-51	FILM	0.22μF 20% 250V	<VARISTOR>			
C43	△1-117-699-51	CERAMIC	0.001μF 99% 250V	VDR2	△1-809-581-11	VARISTOR	
C45	△1-117-699-51	CERAMIC	0.001μF 99% 250V	VDR6	△1-809-581-11	VARISTOR	
<CONNECTOR>				*****			
CN1	* 1-535-419-00	TAB, FASTEN (PCB)		* A-1304-148-A M MOUNTED PC BOARD			
CN2	* 1-778-891-11	CONNECTOR, BOARD TO BOARD		*****			
CN3	* 1-535-419-00	TAB, FASTEN (PCB)		<CONNECTOR>			
CN4	* 1-535-419-00	TAB, FASTEN (PCB)		CN508	* 1-785-520-11	PIN, CONNECTOR (PC BOARD) 22P	
CN5	* 1-535-419-00	TAB, FASTEN (PCB)		CN509	* 1-785-516-11	PIN, CONNECTOR (PC BOARD) 10P	
CN6	* 1-535-419-00	TAB, FASTEN (PCB)		CN510	* 1-785-515-11	PIN, CONNECTOR (PC BOARD) 8P	
<DIODE>				CN511	* 1-785-518-11	CONNECTOR, BOARD TO BOARD 15P	
D1	△8-719-921-20	DIODE 1SS119-25		CN512	* 1-785-530-11	PIN, CONNECTOR (PC BOARD) 10P	
D4	△8-719-921-20	DIODE 1SS119-25		CN513	* 1-785-532-11	PIN, CONNECTOR (PC BOARD) 14P	
<FUSE>				CN514	* 1-695-904-11	PIN, CONNECTOR (PC BOARD) 20P	
F1	△1-533-694-11	FUSE (10A/250V) (G90U/G90M)		CN515	* 1-785-532-11	PIN, CONNECTOR (PC BOARD) 14P	
	* 1-533-701-11	HOLDER, FUSE		CN516	* 1-695-904-11	PIN, CONNECTOR (PC BOARD) 20P	
	* 1-533-703-11	CAP, FUSE (G90U/G90M)		CN517	* 1-785-530-11	PIN, CONNECTOR (PC BOARD) 10P	
F1	△1-533-576-11	FUSE, TIME-LAG ((UL)ET) (G90E)		CN518	* 1-785-520-11	PIN, CONNECTOR (PC BOARD) 22P	
	* 1-533-701-11	HOLDER, FUSE		CN519	* 1-785-519-11	PIN, CONNECTOR (PC BOARD) 24P	
	* 1-533-702-11	CAP, FUSE (G90E)		CN520	* 1-785-533-11	PIN, CONNECTOR (PC BOARD) 16P	
F3	△1-533-694-11	FUSE (10A/250V) (G90U/G90M)		CN521	* 1-564-507-11	PLUG, CONNECTOR 4P	
	* 1-533-701-11	HOLDER, FUSE		CN522	* 1-695-904-11	PIN, CONNECTOR (PC BOARD) 20P	
	* 1-533-703-11	CAP, FUSE (G90U/G90M)		CN523	* 1-785-532-11	PIN, CONNECTOR (PC BOARD) 14P	
F3	△1-533-576-11	FUSE, TIME-LAG ((UL)ET) (G90E)		CN524	* 1-785-519-11	PIN, CONNECTOR (PC BOARD) 24P	
	* 1-533-701-11	HOLDER, FUSE		CN525	* 1-785-520-11	PIN, CONNECTOR (PC BOARD) 22P	
	* 1-533-702-11	CAP, FUSE (G90E)		CN526	* 1-695-904-11	PIN, CONNECTOR (PC BOARD) 20P	
<COIL>				CN527	* 1-785-521-11	PIN, CONNECTOR (PC BOARD) 32P	
L1	△1-403-675-11	INDUCTOR 34μH		CN528	* 1-785-531-11	PIN, CONNECTOR (PC BOARD) 12P	
L2	△1-431-160-11	TRANSFORMER, LINE FILTER					

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
CN529	* 1-785-530-11	PIN, CONNECTOR (PC BOARD) 10P		*****			
CN530	* 1-695-904-11	PIN, CONNECTOR (PC BOARD) 20P		* A-1304-150-A MB MOUNTED PC BOARD			
CN531	* 1-785-520-11	PIN, CONNECTOR (PC BOARD) 22P		*****			
CN532	* 1-785-531-11	PIN, CONNECTOR (PC BOARD) 12P		<CONNECTOR>			
CN533	* 1-785-519-11	PIN, CONNECTOR (PC BOARD) 24P		CN701 * 1-778-891-11 CONNECTOR, BOARD TO BOARD			
CN535	* 1-785-530-11	PIN, CONNECTOR (PC BOARD) 10P		*****			
CN536	* 1-785-530-11	PIN, CONNECTOR (PC BOARD) 10P		* A-1304-151-A MC MOUNTED PC BOARD			
CN537	* 1-785-530-11	PIN, CONNECTOR (PC BOARD) 10P		*****			
<FERRITE BEAD>				<CONNECTOR>			
FB501	1-410-396-41	FERRITE 0.45μH		CN703 * 1-778-891-11 CONNECTOR, BOARD TO BOARD			
FB502	1-410-396-41	FERRITE 0.45μH		*****			
FB503	1-410-396-41	FERRITE 0.45μH		* A-1304-152-A MD MOUNTED PC BOARD			
FB504	1-410-396-41	FERRITE 0.45μH		*****			
FB505	1-410-396-41	FERRITE 0.45μH		CN711 * 1-564-522-11 PLUG, CONNECTOR 7P			
FB506	1-410-396-41	FERRITE 0.45μH		CN712 * 1-564-521-11 PLUG, CONNECTOR 6P			
FB507	1-410-396-41	FERRITE 0.45μH		CN713 * 1-564-520-11 PLUG, CONNECTOR 5P			
FB508	1-410-396-41	FERRITE 0.45μH		CN714 * 1-564-518-11 PLUG, CONNECTOR 3P			
FB509	1-410-396-41	FERRITE 0.45μH		*****			
FB510	1-410-396-41	FERRITE 0.45μH		* A-1304-153-A ME MOUNTED PC BOARD			
FB511	1-410-396-41	FERRITE 0.45μH		*****			
FB512	1-410-396-41	FERRITE 0.45μH		<CAPACITOR>			
FB513	1-410-396-41	FERRITE 0.45μH		C101 Δ1-126-960-91 ELECT 1μF 20% 50V			
<RESISTOR>				<CONNECTOR>			
R1	1-216-398-11	METAL OXIDE 5.6	5% 3W F	CN2 * 1-766-917-11 PIN,CONNECTOR (DY)(PC BOARD)5P			
R2	1-216-398-11	METAL OXIDE 5.6	5% 3W F	CN3 * 1-564-519-11 PLUG, CONNECTOR 4P			
R3	1-216-398-11	METAL OXIDE 5.6	5% 3W F	<TRANSISTOR>			
R4	1-216-398-11	METAL OXIDE 5.6	5% 3W F	Q101 Δ8-729-140-99 TRANSISTOR 2SB734-34			
R5	1-216-398-11	METAL OXIDE 5.6	5% 3W F	Q102 Δ8-729-423-33 TRANSISTOR 2SC2785-HFE			
R6	1-216-398-11	METAL OXIDE 5.6	5% 3W F	<RESISTOR>			
R7	1-216-398-11	METAL OXIDE 5.6	5% 3W F	R101 Δ1-215-884-71 METAL OXIDE 47 5% 2W F			
R8	1-216-398-11	METAL OXIDE 5.6	5% 3W F	R102 Δ1-215-884-71 METAL OXIDE 47 5% 2W F			
R9	1-216-398-11	METAL OXIDE 5.6	5% 3W F	R103 Δ1-247-819-91 CARBON 330 5% 1/4W			
R10	1-216-483-11	METAL OXIDE 2.7K	5% 3W F	R104 Δ1-247-839-91 CARBON 2.2K 5% 1/4W			
R11	1-216-483-11	METAL OXIDE 2.7K	5% 3W F	R105 Δ1-247-855-91 CARBON 10K 5% 1/4W			
*****				R106 Δ1-247-855-91 CARBON 10K 5% 1/4W			
* A-1304-149-A MA MOUNTED PC BOARD				<JACK>			
*****				J1 1-568-547-11 JACK, MINIATUER PIN			
<CONNECTOR>				J2 1-568-547-11 JACK, MINIATUER PIN			
CN600	* 1-778-891-11	CONNECTOR, BOARD TO BOARD		J3 1-568-547-11 JACK, MINIATUER PIN			
CN601	* 1-778-891-11	CONNECTOR, BOARD TO BOARD					



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark

	* A-1316-410-A GA COMPLETE PC BOARD (Include GAA Mounted PC BOARD) *****				<IC>		
	4-034-094-01	SHEET, INSULATOR		IC101	8-759-458-28	IC UC2854N	
	* 4-067-811-01	HOLDER (G)		IC102	8-759-135-80	IC UPC358C	
	4-382-854-11	SCREW (M3X10), P, SW (+)			<COIL>		
	7-685-648-79	SCREW +BVTP 3X12 TYPE2 N-S		L2	1-403-675-11	INDUCTOR 34μH	
	<CAPACITOR>			L3	1-403-675-11	INDUCTOR 34μH	
C1	1-117-228-11	FILM	2.2μF 10% 450V	L5	1-416-874-11	INDUCTOR 420μH	
C2	1-117-228-11	FILM	2.2μF 10% 450V	L6	1-416-874-11	INDUCTOR 420μH	
C3	1-117-228-11	FILM	2.2μF 10% 450V		<TRANSISTOR>		
C4	1-117-228-11	FILM	2.2μF 10% 450V	Q1	8-729-041-01	TRANSISTOR 2SK2198	
C5	1-107-913-11	ELECT	470μF 20% 50V	Q2	8-729-041-01	TRANSISTOR 2SK2198	
C6	1-125-601-11	ELECT(BLOCK)	470μF 20% 450V	Q3	8-729-188-23	TRANSISTOR 2SD882-P	
C7	1-125-601-11	ELECT(BLOCK)	470μF 20% 450V	Q4	8-729-177-22	TRANSISTOR 2SB772-Q	
C8	△ 1-104-706-51	FILM	0.22μF 20% 250V	Q5	8-729-041-01	TRANSISTOR 2SK2198	
C21	1-117-228-11	FILM	2.2μF 10% 450V	Q6	8-729-188-23	TRANSISTOR 2SD882-P	
C22	1-117-228-11	FILM	2.2μF 10% 450V	Q7	8-729-177-22	TRANSISTOR 2SB772-Q	
C23	1-117-228-11	FILM	2.2μF 10% 450V	Q8	8-729-188-23	TRANSISTOR 2SD882-P	
C24	1-117-228-11	FILM	2.2μF 10% 450V	Q9	8-729-177-22	TRANSISTOR 2SB772-Q	
C25	1-107-913-11	ELECT	470μF 20% 50V	Q21	8-729-041-01	TRANSISTOR 2SK2198	
C26	1-125-601-11	ELECT(BLOCK)	470μF 20% 450V	Q22	8-729-041-01	TRANSISTOR 2SK2198	
C27	1-125-601-11	ELECT(BLOCK)	470μF 20% 450V	Q23	8-729-188-23	TRANSISTOR 2SD882-P	
C28	△ 1-104-706-51	FILM	0.22μF 20% 250V	Q24	8-729-177-22	TRANSISTOR 2SB772-Q	
	<CONNECTOR>			Q25	8-729-041-01	TRANSISTOR 2SK2198	
CN10	* 1-766-917-11	PIN,CONNECTOR (DY)(PC BOARD)5P		Q26	8-729-188-23	TRANSISTOR 2SD882-P	
CN11	* 1-785-514-11	PIN, CONNECTOR (PC BOARD) 6P		Q27	8-729-177-22	TRANSISTOR 2SB772-Q	
CN12	* 1-564-506-11	PLUG, CONNECTOR 3P		Q28	8-729-188-23	TRANSISTOR 2SD882-P	
CN13	* 1-564-506-11	PLUG, CONNECTOR 3P		Q29	8-729-177-22	TRANSISTOR 2SB772-Q	
CN14	* 1-785-518-11	CONNECTOR, BOARD TO BOARD 15P			<RESISTOR>		
CN15	* 1-785-518-11	CONNECTOR, BOARD TO BOARD 15P		R1	1-249-405-11	CARBON 100 5% 1/4W F	
	<DIODE>			R2	1-215-904-11	METAL OXIDE 100K 5% 2W F	
D1	△ 8-719-060-53	DIODE RBV-2506		R3	1-219-718-11	CEMENTED 0.1 10% 5W	
D4	8-719-044-70	DIODE S16L60		R4	1-219-718-11	CEMENTED 0.1 10% 5W	
D5	8-719-510-02	DIODE D1NS4		R5	1-219-718-11	CEMENTED 0.1 10% 5W	
D6	8-719-510-02	DIODE D1NS4		R6	1-249-421-11	CARBON 2.2K 5% 1/4W	
D7	8-719-510-02	DIODE D1NS4		R7	1-249-401-11	CARBON 47 5% 1/4W	
D21	△ 8-719-060-53	DIODE RBV-2506		R8	1-249-421-11	CARBON 2.2K 5% 1/4W	
D24	8-719-044-70	DIODE S16L60		R9	1-249-421-11	CARBON 2.2K 5% 1/4W	
D25	8-719-510-02	DIODE D1NS4		R10	1-249-381-11	CARBON 1 5% 1/4W F	
D26	8-719-510-02	DIODE D1NS4		R11	1-249-381-11	CARBON 1 5% 1/4W F	
D27	8-719-510-02	DIODE D1NS4		R12	1-249-381-11	CARBON 1 5% 1/4W F	
	<FERRITE BEAD>			R13	1-249-401-11	CARBON 47 5% 1/4W	
FB1	1-410-396-41	FERRITE 0.45μH		R14	1-249-401-11	CARBON 47 5% 1/4W F	
FB2	1-410-396-41	FERRITE 0.45μH		R15	1-249-401-11	CARBON 47 5% 1/4W F	
FB3	1-410-396-41	FERRITE 0.45μH		R16	1-249-401-11	CARBON 47 5% 1/4W F	
FB4	1-410-396-41	FERRITE 0.45μH		R17	1-249-401-11	CARBON 47 5% 1/4W	
FB5	1-410-396-41	FERRITE 0.45μH		R20	1-215-904-11	METAL OXIDE 100K 5% 2W F	
FB6	1-410-396-41	FERRITE 0.45μH		R21	1-215-904-11	METAL OXIDE 100K 5% 2W F	
				R22	1-215-904-11	METAL OXIDE 100K 5% 2W F	
				R41	1-249-405-11	CARBON 100 5% 1/4W F	
				R43	1-219-718-11	CEMENTED 0.1 10% 5W	
				R44	1-219-718-11	CEMENTED 0.1 10% 5W	

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R45	1-219-718-11	CEMENTED	0.1 10% 5W	<RESISTOR>			
R46	1-249-421-11	CARBON	2.2K 5% 1/4W	R101	1-260-132-11	CARBON	560K 5% 1/2W
R47	1-249-401-11	CARBON	47 5% 1/4W	R102	1-260-131-11	CARBON	470K 5% 1/2W
R48	1-249-421-11	CARBON	2.2K 5% 1/4W	R103	1-216-097-91	RES,CHIP	100K 5% 1/10W
R49	1-249-421-11	CARBON	2.2K 5% 1/4W	R104	1-216-081-00	RES,CHIP	22K 5% 1/10W
R50	1-249-381-11	CARBON	1 5% 1/4W F	R105	1-260-132-11	CARBON	560K 5% 1/2W
R51	1-249-381-11	CARBON	1 5% 1/4W F	R106	1-260-131-11	CARBON	470K 5% 1/2W
R52	1-249-381-11	CARBON	1 5% 1/4W F	R107	1-216-105-91	RES,CHIP	220K 5% 1/10W
R53	1-249-401-11	CARBON	47 5% 1/4W	R108	1-216-073-00	RES,CHIP	10K 5% 1/10W
R54	1-249-401-11	CARBON	47 5% 1/4W F	R109	1-216-073-00	RES,CHIP	10K 5% 1/10W
R55	1-249-401-11	CARBON	47 5% 1/4W F	R110	1-216-077-00	RES,CHIP	15K 5% 1/10W
R56	1-249-401-11	CARBON	47 5% 1/4W F	R111	1-216-665-11	METAL CHIP	3.9K 0.50% 1/10W
R57	1-249-401-11	CARBON	47 5% 1/4W	R112	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
<THERMAL SWITCH>				R113	1-216-073-00	RES,CHIP	10K 5% 1/10W
TS1	1-692-110-11	SWITCH, THERMAL GUARD		R114	1-216-081-00	RES,CHIP	22K 5% 1/10W
TS3	1-692-110-11	SWITCH, THERMAL GUARD		R115	1-216-121-91	RES,CHIP	1M 5% 1/10W
*****				R116	1-216-665-11	METAL CHIP	3.9K 0.50% 1/10W
* A-1311-704-A GAA MOUNTED PC BOARD				R117	1-216-101-00	RES,CHIP	150K 5% 1/10W
*****				R118	1-216-097-91	RES,CHIP	100K 5% 1/10W
<CAPACITOR>				R119	1-216-679-11	METAL CHIP	15K 0.50% 1/10W
C101	1-136-165-00	FILM	0.1μF 5% 50V	R120	1-216-097-91	RES,CHIP	100K 5% 1/10W
C102	1-137-194-81	FILM	0.47μF 5% 50V	R121	1-216-089-91	RES,CHIP	47K 5% 1/10W
C103	1-136-169-00	FILM	0.22μF 5% 50V	R123	1-249-381-11	CARBON	1 5% 1/4W
C104	1-164-004-11	CERAMIC CHIP	0.1μF 10% 25V	R124	1-216-113-00	RES,CHIP	470K 5% 1/10W
C105	1-164-004-11	CERAMIC CHIP	0.1μF 10% 25V	R125	1-215-475-00	METAL	180K 1% 1/4W
C106	1-164-004-11	CERAMIC CHIP	0.1μF 10% 25V	R126	1-215-475-00	METAL	180K 1% 1/4W
C107	1-163-263-11	CERAMIC CHIP	330PF 5% 50V	R127	1-215-475-00	METAL	180K 1% 1/4W
C108	1-163-009-11	CERAMIC CHIP	0.001μF 10% 50V	R128	1-215-425-00	METAL	1.5K 1% 1/4W
C109	1-163-251-11	CERAMIC CHIP	100PF 5% 50V	R129	1-216-674-11	METAL CHIP	9.1K 0.50% 1/10W
C110	1-164-004-11	CERAMIC CHIP	0.1μF 10% 25V	<VARIABLE RESISTOR>			
C111	1-163-009-11	CERAMIC CHIP	0.001μF 10% 50V	RV101	1-241-783-11	RES, ADJ, CARBON	2.2K
C112	1-164-004-11	CERAMIC CHIP	0.1μF 10% 25V	*****			
<CONNECTOR>				* A-1316-411-A GB COMPLETE PC BOARD			
CN16	* 1-785-517-11	CONNECTOR, BOARD TO BOARD 13P		(Include GC, CBA, GBB Mounted PC BOARD)			
<DIODE>				*****			
D101	8-719-063-73	DIODE D1NL20U-TR		4-034-094-01 SHEET, INSULATOR			
D102	8-719-510-02	DIODE D1NS4		* 4-067-811-01 HOLDER (G)			
D103	8-719-510-02	DIODE D1NS4		4-382-854-11 SCREW (M3X10), P, SW (+)			
D104	8-719-033-53	DIODE RD6.8SB2-T1		* 7-322-065-72 RUBBER, RTV (SE-9168) (130G)			
D105	8-719-050-84	DIODE RB441Q-40T-77		7-685-648-79 SCREW +BVTP 3X12 TYPE2 N-S			
D107	8-719-914-43	DIODE DAN202K		<CAPACITOR>			
<TRANSISTOR>				C1	1-164-645-11	CERAMIC	1000PF 10% 50V
Q101	8-729-216-22	TRANSISTOR 2SA1162-G		C2	1-136-169-00	FILM	0.22μF 5% 50V
				C3	1-115-834-11	ELECT	220μF 20% 50V
				C4	1-164-645-11	CERAMIC	1000PF 10% 50V
				C5	1-136-165-00	FILM	0.1μF 5% 50V
				C6	1-136-169-00	FILM	0.22μF 5% 50V
				C7	1-115-834-11	ELECT	220μF 20% 50V
				C8	1-115-744-51	ELECT	0.0039F 20% 10V
				C9	1-115-744-51	ELECT	0.0039F 20% 10V
				C10	1-107-943-11	ELECT	10μF 20% 160V



Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description	Remark
C11	1-107-792-11	CERAMIC	100PF	5%	1KV	CN24	* 1-564-506-11	PLUG, CONNECTOR 3P	
C12	1-104-652-11	ELECT	470μF	20%	10V	CN25	* 1-564-506-11	PLUG, CONNECTOR 3P	
C13	1-115-814-11	ELECT	1000μF	20%	35V	CN26	* 1-774-249-11	CONNECTOR, BOARD TO BOARD 10P	
C14	1-128-526-11	ELECT	100μF	20%	25V				
C15	1-136-203-11	FILM	0.01μF	10%	630V	CN27	* 1-774-249-11	CONNECTOR, BOARD TO BOARD 10P	
						CN28	* 1-774-248-11	CONNECTOR, BOARD TO BOARD 8P	
C17	1-117-227-11	FILM	1μF	10%	450V	CN29	* 1-774-248-11	CONNECTOR, BOARD TO BOARD 8P	
C18	1-117-228-11	FILM	2.2μF	10%	450V	CN30	* 1-774-248-11	CONNECTOR, BOARD TO BOARD 8P	
C19	1-107-792-11	CERAMIC	100PF	5%	1KV	CN31	* 1-774-248-11	CONNECTOR, BOARD TO BOARD 8P	
C20	1-115-792-11	ELECT	0.0022F	20%	25V				
C21	1-115-792-11	ELECT	0.0022F	20%	25V	CN32	* 1-774-248-11	CONNECTOR, BOARD TO BOARD 8P	
						CN33	* 1-774-248-11	CONNECTOR, BOARD TO BOARD 8P	
C24	1-128-526-11	ELECT	100μF	20%	25V	CN34	* 1-785-515-11	PIN, CONNECTOR (PC BOARD) 8P	
C25	1-107-792-11	CERAMIC	100PF	5%	1KV	CN35	* 1-785-516-11	PIN, CONNECTOR (PC BOARD) 10P	
C26	1-117-644-21	FILM	10000PF	3%	1.2KV				
C27	1-115-789-11	ELECT	0.001F	20%	25V				
C29	1-115-789-11	ELECT	0.001F	20%	25V		<DIODE>		
C31	1-128-526-11	ELECT	100μF	20%	25V	D1	1-807-911-11	DIODE F10P40F	
C32	1-117-644-21	FILM	10000PF	3%	1.2KV	D2	8-719-050-18	DIODE D4SBL20U	
C35	1-115-744-51	ELECT	0.0039F	20%	10V	D3	8-719-510-09	DIODE D10SC6M	
C36	1-115-744-51	ELECT	0.0039F	20%	10V	D4	1-807-911-11	DIODE F10P40F	
C37	1-104-652-11	ELECT	470μF	20%	10V	D5	8-719-050-18	DIODE D4SBL20U	
C38	1-115-741-11	ELECT	0.0022F	20%	10V	D6	8-719-063-73	DIODE D1NL20U-TR	
C39	1-104-652-11	ELECT	470μF	20%	10V	D7	8-719-030-48	DIODE 1JH46-TPA3	
C40	1-107-792-11	CERAMIC	100PF	5%	1KV	D8	8-719-030-48	DIODE 1JH46-TPA3	
C41	1-115-814-11	ELECT	1000μF	20%	35V	D9	8-719-055-40	DIODE FCQ30A04	
C42	1-117-228-11	FILM	2.2μF	10%	450V	D10	8-719-988-31	DIODE D10SC6MR	
C43	1-124-347-00	ELECT	100μF	20%	160V	D11	8-719-911-19	DIODE 1SS119-25	
C44	1-124-347-00	ELECT	100μF	20%	160V	D12	1-807-911-11	DIODE F10P40F	
C47	1-107-910-11	ELECT	100μF	20%	35V	D13	8-719-210-29	DIODE F10P10Q	
C48	1-117-648-11	FILM	15000PF	3%	1.2KV	D14	8-719-988-31	DIODE D10SC6MR	
C49	1-117-648-11	FILM	15000PF	3%	1.2KV	D15	8-719-054-38	DIODE FCF10A60	
C50	1-107-910-11	ELECT	100μF	20%	35V	D17	8-719-510-39	DIODE D10LC20U	
C51	1-117-228-11	FILM	2.2μF	10%	450V	D20	8-719-063-73	DIODE D1NL20U-TR	
C52	1-107-792-11	CERAMIC	100PF	5%	1KV	D23	8-719-063-73	DIODE D1NL20U-TR	
C53	1-111-152-51	ELECT	0.001F	20%	63V				
C54	1-111-152-51	ELECT	0.001F	20%	63V		<FERRITE BEAD>		
C57	1-107-932-11	ELECT	47μF	20%	63V				
C58	1-107-792-11	CERAMIC	100PF	5%	1KV	FB1	1-410-396-41	FERRITE 0.45μH	
C59	1-111-152-51	ELECT	0.001F	20%	63V	FB2	1-410-396-41	FERRITE 0.45μH	
C60	1-111-152-51	ELECT	0.001F	20%	63V	FB3	1-410-396-41	FERRITE 0.45μH	
C63	1-107-932-11	ELECT	47μF	20%	63V	FB4	1-410-396-41	FERRITE 0.45μH	
						FB5	1-410-396-41	FERRITE 0.45μH	
C64	1-117-648-11	FILM	15000PF	3%	1.2KV				
C65	1-117-648-11	FILM	15000PF	3%	1.2KV				
C66	1-117-228-11	FILM	2.2μF	10%	450V		<IC>		
C67	1-107-792-11	CERAMIC	100PF	5%	1KV				
C69	1-107-792-11	CERAMIC	100PF	5%	1KV	IC1	8-759-231-61	IC TA7820S	
						IC2	8-759-231-61	IC TA7820S	
C70	1-117-648-11	FILM	15000PF	3%	1.2KV	IC3	8-759-198-31	IC UPC1093J-1-T	
C71	1-117-648-11	FILM	15000PF	3%	1.2KV	IC4	8-759-198-31	IC UPC1093J-1-T	
C72	1-125-611-11	ELECT(BLOCK)	1000μF	20%	250V				
C74	1-107-961-91	ELECT	10μF	20%	250V				
C76	1-128-526-11	ELECT	100μF	20%	25V		<COIL>		
C79	1-136-165-00	FILM	0.1μF	5%	50V	L1	1-406-703-11	INDUCTOR 3.3μH	
C80	1-115-741-11	ELECT	0.0022F	20%	10V	L2	1-412-537-31	INDUCTOR 100μH	
C100	1-102-074-00	CERAMIC	0.001μF	10%	50V	L3	1-406-667-11	INDUCTOR 220μH	
C101	1-102-074-00	CERAMIC	0.001μF	10%	50V	L4	1-406-703-11	INDUCTOR 3.3μH	
						L5	1-406-703-11	INDUCTOR 3.3μH	

Ref.No.	Part No.	Description	Remark				Ref.No.	Part No.	Description	Remark			
L10	1-406-703-11	INDUCTOR 3.3μH					R31	1-216-361-00	METAL OXIDE 0.22	5%	2W	F	
L11	1-406-703-11	INDUCTOR 3.3μH					R32	1-249-414-11	CARBON 560	5%	1/4W		
L12	1-406-979-11	INDUCTOR 220μH					R33	△1-220-778-21	FUSIBLE 0.1	10%	1/2W	F	
L13	1-406-973-21	INDUCTOR 22μH					R34	1-249-425-11	CARBON 4.7K	5%	1/4W		
L14	1-406-703-11	INDUCTOR 3.3μH					R35	1-249-425-11	CARBON 4.7K	5%	1/4W		
L15	1-406-979-11	INDUCTOR 220μH					R36	1-249-415-11	CARBON 680	5%	1/4W		
L16	1-406-703-11	INDUCTOR 3.3μH					R37	1-216-361-00	METAL OXIDE 0.22	5%	2W	F	
L17	1-406-703-11	INDUCTOR 3.3μH					R38	1-216-361-00	METAL OXIDE 0.22	5%	2W	F	
		<PHOTO COUPLER>					R39	△1-220-778-21	FUSIBLE 0.1	10%	1/2W	F	
PH1	8-749-010-64	PHOTO COUPLER PC123F2					R40	1-249-425-11	CARBON 4.7K	5%	1/4W		
		<TRANSISTOR>					R41	1-249-425-11	CARBON 4.7K	5%	1/4W		
Q1	8-729-140-97	TRANSISTOR 2SB734-34					R42	1-216-361-00	METAL OXIDE 0.22	5%	2W	F	
Q2	8-729-140-97	TRANSISTOR 2SB734-34					R43	1-216-361-00	METAL OXIDE 0.22	5%	2W	F	
Q3	8-729-119-76	TRANSISTOR 2SA1175-HFE					R44	1-216-361-00	METAL OXIDE 0.22	5%	2W	F	
Q4	8-729-036-34	TRANSISTOR 2SK2605					R45	1-249-415-11	CARBON 680	5%	1/4W		
Q5	8-729-046-01	TRANSISTOR 2SK2475-CB					R46	1-215-893-11	METAL OXIDE 1.5K	5%	2W	F	
Q6	8-729-046-01	TRANSISTOR 2SK2475-CB					R47	1-215-893-11	METAL OXIDE 1.5K	5%	2W	F	
Q7	8-729-926-54	TRANSISTOR IRFP460					R48	1-215-904-11	METAL OXIDE 100K	5%	2W	F	
Q8	8-729-926-54	TRANSISTOR IRFP460					R49	1-215-409-00	METAL 330	1%	1/4W		
Q9	8-729-926-54	TRANSISTOR IRFP460					R50	1-215-431-00	METAL 2.7K	1%	1/4W		
Q10	8-729-926-54	TRANSISTOR IRFP460					R51	1-249-429-11	CARBON 10K	5%	1/4W		
Q11	8-729-926-54	TRANSISTOR IRFP460					R52	1-249-417-11	CARBON 1K	5%	1/4W		
Q12	8-729-926-54	TRANSISTOR IRFP460					R53	1-215-475-00	METAL 180K	1%	1/4W		
		<RESISTOR>					R54	1-215-475-00	METAL 180K	1%	1/4W		
R1	1-249-421-11	CARBON 2.2K	5%	1/4W			R55	1-215-475-00	METAL 180K	1%	1/4W		
R2	1-249-429-11	CARBON 10K	5%	1/4W			R56	1-215-409-00	METAL 330	1%	1/4W		
R3	1-215-896-00	METAL OXIDE 4.7K	5%	2W	F		R57	1-215-431-00	METAL 2.7K	1%	1/4W		
R4	1-215-863-11	METAL OXIDE 100	5%	1W	F		R58	1-249-421-11	CARBON 2.2K	5%	1/4W		
R6	1-249-421-11	CARBON 2.2K	5%	1/4W			R59	1-247-843-11	CARBON 3.3K	5%	1/4W		
R7	1-249-429-11	CARBON 10K	5%	1/4W					<TRANSFORMER>				
R9	1-249-377-11	CARBON 0.47	5%	1/4W	F		T1	1-433-522-11	TRANSFORMER, CONVERTER (PIT)				
R10	1-215-475-00	METAL 180K	1%	1/4W			T2	1-433-523-11	TRANSFORMER, CONVERTER (PIT)				
R11	1-215-475-00	METAL 180K	1%	1/4W			T3	1-433-517-11	TRANSFORMER, CONVERTER (PIT)				
R12	1-215-904-11	METAL OXIDE 100K	5%	2W	F		T4	1-433-518-11	TRANSFORMER, CONVERTER (PIT)				
							T5	1-433-519-11	TRANSFORMER, CONVERTER (PIT)				
R13	1-215-904-11	METAL OXIDE 100K	5%	2W	F				*****				
R14	△1-220-926-21	FUSIBLE 0.47	10%	1/2W	F				* A-1311-687-A GC MOUNTED PC BOARD				
R15	1-215-904-11	METAL OXIDE 100K	5%	2W	F				*****				
R16	1-215-904-11	METAL OXIDE 100K	5%	2W	F				<CAPACITOR>				
R17	1-215-904-11	METAL OXIDE 100K	5%	2W	F		C1	1-163-021-91	CERAMIC CHIP 0.01μF	10%	50V		
R18	1-215-475-00	METAL 180K	1%	1/4W			C2	1-126-162-11	ELECT 3.3μF	20%	50V		
R19	1-249-429-11	CARBON 10K	5%	1/4W			C3	1-164-004-11	CERAMIC CHIP 0.1μF	10%	25V		
R20	1-217-152-00	METAL 0.33	10%	2W			C4	1-164-004-11	CERAMIC CHIP 0.1μF	10%	25V		
R21	△1-220-778-21	FUSIBLE 0.1	10%	1/2W	F		C5	1-126-162-11	ELECT 3.3μF	20%	50V		
R22	1-249-425-11	CARBON 4.7K	5%	1/4W			C6	1-163-021-91	CERAMIC CHIP 0.01μF	10%	50V		
R23	1-249-425-11	CARBON 4.7K	5%	1/4W			C7	1-164-004-11	CERAMIC CHIP 0.1μF	10%	25V		
R24	1-216-361-00	METAL OXIDE 0.22	5%	2W	F		C8	1-164-004-11	CERAMIC CHIP 0.1μF	10%	25V		
R25	1-216-361-00	METAL OXIDE 0.22	5%	2W	F		C9	1-163-021-91	CERAMIC CHIP 0.01μF	10%	50V		
R26	1-219-413-11	CARBON 470K	5%	1/4W			C10	1-163-135-00	CERAMIC CHIP 560PF	5%	50V		
R27	△1-220-778-21	FUSIBLE 0.1	10%	1/2W	F		C11	1-163-021-91	CERAMIC CHIP 0.01μF	10%	50V		
R28	1-249-425-11	CARBON 4.7K	5%	1/4W			C12	1-163-009-11	CERAMIC CHIP 0.001μF	10%	50V		
R29	1-249-425-11	CARBON 4.7K	5%	1/4W			C13	1-136-169-00	FILM 0.22μF	5%	50V		
R30	1-216-361-00	METAL OXIDE 0.22	5%	2W	F								

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C14	1-137-194-81	FILM	0.47μF 5% 50V	R10	1-216-073-00	RES,CHIP	10K 5% 1/10W
C15	1-119-772-11	ELECT	47μF 20% 35V	R11	1-247-807-31	CARBON	100 5% 1/4W
				R12	1-216-073-00	RES,CHIP	10K 5% 1/10W
C18	1-119-772-11	ELECT	47μF 20% 35V	R13	1-216-073-00	RES,CHIP	10K 5% 1/10W
C19	1-164-004-11	CERAMIC CHIP	0.1μF 10% 25V	R14	1-216-049-91	RES,CHIP	1K 5% 1/10W
C20	1-136-165-00	FILM	0.1μF 5% 50V	R15	1-216-077-00	RES,CHIP	15K 5% 1/10W
C21	1-136-153-00	FILM	0.01μF 5% 50V	R17	1-216-073-00	RES,CHIP	10K 5% 1/10W
C22	1-163-021-91	CERAMIC CHIP	0.01μF 10% 50V	R18	1-216-073-00	RES,CHIP	10K 5% 1/10W
C23	1-163-021-91	CERAMIC CHIP	0.01μF 10% 50V	R19	1-216-085-00	RES,CHIP	33K 5% 1/10W
C24	1-164-004-11	CERAMIC CHIP	0.1μF 10% 25V	R20	1-216-049-91	RES,CHIP	1K 5% 1/10W
C25	1-163-021-91	CERAMIC CHIP	0.01μF 10% 50V	R21	1-216-049-91	RES,CHIP	1K 5% 1/10W
C100	1-163-021-91	CERAMIC CHIP	0.01μF 10% 50V	R22	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
<CONNECTOR>				R23	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
CN42	* 1-774-246-11	CONNECTOR, BOARD TO BOARD 10P		R24	1-216-049-91	RES,CHIP	1K 5% 1/10W
CN43	* 1-774-246-11	CONNECTOR, BOARD TO BOARD 10P		R25	1-216-049-91	RES,CHIP	1K 5% 1/10W
<DIODE>				R26	1-215-478-00	METAL	240K 1% 1/4W
D1	8-719-109-85	DIODE RD5.1ESB2		R27	1-215-479-00	METAL	270K 1% 1/4W
D2	8-719-914-43	DIODE DAN202K		R28	1-215-484-00	METAL	430K 1% 1/4W
D3	8-719-914-43	DIODE DAN202K		R29	1-215-484-00	METAL	430K 1% 1/4W
D4	8-719-914-43	DIODE DAN202K		R30	1-216-049-91	RES,CHIP	1K 5% 1/10W
D5	8-719-914-43	DIODE DAN202K		R31	1-216-089-91	RES,CHIP	47K 5% 1/10W
D9	8-719-063-73	DIODE D1NL20U-TR		R32	1-216-105-91	RES,CHIP	220K 5% 1/10W
D12	8-719-110-53	DIODE RD20ESB2		R33	1-216-073-00	RES,CHIP	10K 5% 1/10W
<IC>				R34	1-216-609-11	RES,CHIP	18 5% 1/10W
IC1	8-759-198-31	IC UPC1093J-1-T		R35	1-216-097-91	RES,CHIP	100K 5% 1/10W
IC2	8-759-198-31	IC UPC1093J-1-T		R36	1-216-005-00	RES,CHIP	15 5% 1/10W
IC3	8-759-916-16	IC SN74HC08AN		R37	1-216-081-00	RES,CHIP	22K 5% 1/10W
IC4	8-759-912-77	IC LM324N		R38	1-216-079-00	RES,CHIP	18K 5% 1/10W
IC5	8-759-637-30	IC M51978P		R39	1-216-049-91	RES,CHIP	1K 5% 1/10W
IC6	8-759-135-80	IC UPC358C		R41	1-216-049-91	RES,CHIP	1K 5% 1/10W
<PHOTO COUPLER>				R43	1-216-049-91	RES,CHIP	1K 5% 1/10W
PH1	8-749-010-64	PHOTO COUPLER PC123F2		R44	1-216-049-91	RES,CHIP	1K 5% 1/10W
PH3	8-749-010-64	PHOTO COUPLER PC123F2		R45	1-216-049-91	RES,CHIP	1K 5% 1/10W
PH4	8-749-010-64	PHOTO COUPLER PC123F2		R46	1-216-049-91	RES,CHIP	1K 5% 1/10W
PH5	8-749-010-64	PHOTO COUPLER PC123F2		R47	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
<TRANSISTOR>				R48	1-216-656-11	METAL CHIP	1.6K 0.50% 1/10W
Q1	8-729-230-49	TRANSISTOR 2SC2712-YG		R49	1-216-049-91	RES,CHIP	1K 5% 1/10W
Q2	8-729-216-22	TRANSISTOR 2SA1162-G		R50	1-216-113-00	RES,CHIP	470K 5% 1/10W
Q3	8-729-230-49	TRANSISTOR 2SC2712-YG		R51	1-216-049-91	RES,CHIP	1K 5% 1/10W
Q4	8-729-230-49	TRANSISTOR 2SC2712-YG		R52	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
<RESISTOR>				R53	1-216-049-91	RES,CHIP	1K 5% 1/10W
R2	1-216-073-00	RES,CHIP	10K 5% 1/10W	R54	1-216-654-11	METAL CHIP	1.3K 0.50% 1/10W
R3	1-216-049-91	RES,CHIP	1K 5% 1/10W	R55	1-249-405-11	CARBON	100 5% 1/4W F
R4	1-216-073-00	RES,CHIP	10K 5% 1/10W	R56	1-249-393-11	CARBON	10 5% 1/4W F
R5	1-216-073-00	RES,CHIP	10K 5% 1/10W	R57	1-249-405-11	CARBON	100 5% 1/4W F
R7	1-216-049-91	RES,CHIP	1K 5% 1/10W	R58	1-249-405-11	CARBON	100 5% 1/4W F
R8	1-216-073-00	RES,CHIP	10K 5% 1/10W	R59	1-249-405-11	CARBON	100 5% 1/4W F
R9	1-216-073-00	RES,CHIP	10K 5% 1/10W	R61	1-216-067-00	RES,CHIP	5.6K 5% 1/10W
				R62	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
				R63	1-216-049-91	RES,CHIP	1K 5% 1/10W
				R64	1-216-049-91	RES,CHIP	1K 5% 1/10W
				R65	1-215-469-00	METAL	100K 1% 1/4W
				R66	1-215-471-00	METAL	120K 1% 1/4W
				R67	1-216-085-00	RES,CHIP	33K 5% 1/10W
				R68	1-249-381-11	CARBON	1 5% 1/4W F
				R69	1-216-049-91	RES,CHIP	1K 5% 1/10W
				R70	1-216-073-00	RES,CHIP	10K 5% 1/10W
				R100	1-216-073-00	RES,CHIP	10K 5% 1/10W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
		<VARIABLE RESISTOR>		D206	8-719-210-21	DIODE 11EQS04	
RV1	1-238-543-11	RES, ADJ, CARBON 470		D207	8-719-210-21	DIODE 11EQS04	
*****				D208	8-719-210-21	DIODE 11EQS04	
				D209	8-719-914-43	DIODE DAN202K	
				D210	8-719-914-43	DIODE DAN202K	
				D211	8-719-110-31	DIODE RD12ESB2	
				D212	8-719-110-31	DIODE RD12ESB2	
				D213	8-719-063-73	DIODE D1NL20U-TR	
				D214	8-719-063-73	DIODE D1NL20U-TR	
				D215	8-719-063-73	DIODE D1NL20U-TR	
				D216	8-719-063-73	DIODE D1NL20U-TR	
		<CAPACITOR>				<IC>	
C201	1-163-133-00	CERAMIC CHIP 470PF	5% 50V	IC201	8-759-298-87	IC CXA8038P	
C202	1-163-133-00	CERAMIC CHIP 470PF	5% 50V	IC202	8-759-298-87	IC CXA8038P	
C203	1-136-165-00	FILM 0.1μF	5% 50V	IC203	8-759-135-80	IC UPC358C	
C204	1-136-165-00	FILM 0.1μF	5% 50V	IC204	8-759-198-31	IC UPC1093J-1-T	
C205	1-137-194-81	FILM 0.47μF	5% 50V			<PHOTO COUPLER>	
C206	1-137-194-81	FILM 0.47μF	5% 50V	PH201	8-749-010-64	PHOTO COUPLER PC123F2	
C207	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	PH202	8-749-010-64	PHOTO COUPLER PC123F2	
C208	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V			<TRANSISTOR>	
C209	1-163-133-00	CERAMIC CHIP 470PF	5% 50V	Q201	8-729-205-02	TRANSISTOR 2SA1150-Y	
C210	1-163-133-00	CERAMIC CHIP 470PF	5% 50V	Q202	8-729-205-02	TRANSISTOR 2SA1150-Y	
C211	1-163-133-00	CERAMIC CHIP 470PF	5% 50V	Q203	8-729-205-02	TRANSISTOR 2SA1150-Y	
C212	1-163-133-00	CERAMIC CHIP 470PF	5% 50V	Q204	8-729-205-02	TRANSISTOR 2SA1150-Y	
C213	1-163-133-00	CERAMIC CHIP 470PF	5% 50V	Q205	8-729-140-96	TRANSISTOR 2SD774-34	
C214	1-163-133-00	CERAMIC CHIP 470PF	5% 50V				
C215	1-163-263-11	CERAMIC CHIP 330PF	5% 50V	Q206	8-729-140-96	TRANSISTOR 2SD774-34	
C216	1-163-263-11	CERAMIC CHIP 330PF	5% 50V			<RESISTOR>	
C217	1-136-165-00	FILM 0.1μF	5% 50V	R201	1-247-791-91	CARBON 22 5% 1/4W	
C218	1-136-165-00	FILM 0.1μF	5% 50V	R202	1-247-791-91	CARBON 22 5% 1/4W	
C219	1-164-161-11	CERAMIC CHIP 0.0022μF	10% 50V	R203	1-216-061-00	RES,CHIP 3.3K 5% 1/10W	
C220	1-164-161-11	CERAMIC CHIP 0.0022μF	10% 50V	R204	1-216-061-00	RES,CHIP 3.3K 5% 1/10W	
C221	1-164-161-11	CERAMIC CHIP 0.0022μF	10% 50V	R205	1-216-033-00	RES,CHIP 220 5% 1/10W	
C222	1-164-161-11	CERAMIC CHIP 0.0022μF	10% 50V	R206	1-216-033-00	RES,CHIP 220 5% 1/10W	
C223	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	R207	1-216-097-91	RES,CHIP 100K 5% 1/10W	
C224	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	R208	1-216-097-91	RES,CHIP 100K 5% 1/10W	
C225	1-137-194-81	FILM 0.47μF	5% 50V	R209	1-216-057-00	RES,CHIP 2.2K 5% 1/10W	
C226	1-137-194-81	FILM 0.47μF	5% 50V	R210	1-216-057-00	RES,CHIP 2.2K 5% 1/10W	
C227	1-126-951-11	ELECT 470μF	20% 35V	R211	1-216-057-00	RES,CHIP 2.2K 5% 1/10W	
C228	1-126-951-11	ELECT 470μF	20% 35V	R212	1-216-057-00	RES,CHIP 2.2K 5% 1/10W	
C229	1-163-017-00	CERAMIC CHIP 0.0047μF	10% 50V	R213	1-216-065-91	RES,CHIP 4.7K 5% 1/10W	
C230	1-163-017-00	CERAMIC CHIP 0.0047μF	10% 50V	R214	1-216-065-91	RES,CHIP 4.7K 5% 1/10W	
C231	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	R215	1-216-065-91	RES,CHIP 4.7K 5% 1/10W	
C232	1-119-772-91	ELECT MELF 47μF	20% 35V	R216	1-216-065-91	RES,CHIP 4.7K 5% 1/10W	
C233	1-137-368-11	FILM 0.0047μF	5% 50V	R217	1-216-065-91	RES,CHIP 4.7K 5% 1/10W	
C234	1-136-153-00	FILM 0.01μF	5% 50V	R218	1-216-065-91	RES,CHIP 4.7K 5% 1/10W	
		<CONNECTOR>		R219	1-216-065-91	RES,CHIP 4.7K 5% 1/10W	
CN36	* 1-774-245-11	CONNECTOR, BOARD TO BOARD 8P		R220	1-216-065-91	RES,CHIP 4.7K 5% 1/10W	
CN37	* 1-774-245-11	CONNECTOR, BOARD TO BOARD 8P		R221	1-249-389-11	CARBON 4.7 5% 1/4W F	
CN38	* 1-774-245-11	CONNECTOR, BOARD TO BOARD 8P		R222	1-216-049-91	RES,CHIP 1K 5% 1/10W	
		<DIODE>		R223	1-249-389-11	CARBON 4.7 5% 1/4W F	
D201	8-719-050-84	DIODE RB441Q-40T-77		R224	1-216-049-91	RES,CHIP 1K 5% 1/10W	
D202	8-719-050-84	DIODE RB441Q-40T-77					
D203	8-719-050-84	DIODE RB441Q-40T-77					
D204	8-719-050-84	DIODE RB441Q-40T-77					
D205	8-719-210-21	DIODE 11EQS04					

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R227	1-249-389-11	CARBON 4.7 5%	1/4W F	C418	1-136-165-00	FILM 0.1μF 5%	50V
R228	1-249-389-11	CARBON 4.7 5%	1/4W F	C419	1-164-161-11	CERAMIC CHIP 0.0022μF 10%	50V
R229	1-216-079-00	RES,CHIP 18K 5%	1/10W	C420	1-164-161-11	CERAMIC CHIP 0.0022μF 10%	50V
R230	1-216-065-91	RES,CHIP 4.7K 5%	1/10W	C421	1-164-161-11	CERAMIC CHIP 0.0022μF 10%	50V
R231	1-216-077-00	RES,CHIP 15K 5%	1/10W	C422	1-164-161-11	CERAMIC CHIP 0.0022μF 10%	50V
R232	1-216-065-91	RES,CHIP 4.7K 5%	1/10W	C423	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V
R233	1-216-057-00	RES,CHIP 2.2K 5%	1/10W	C424	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V
R234	1-216-057-00	RES,CHIP 2.2K 5%	1/10W	C425	1-137-194-81	FILM 0.47μF 5%	50V
R237	1-216-057-00	RES,CHIP 2.2K 5%	1/10W	C426	1-137-194-81	FILM 0.47μF 5%	50V
R238	1-216-057-00	RES,CHIP 2.2K 5%	1/10W	C427	1-126-951-11	ELECT 470μF 20%	35V
R239	1-216-113-00	RES,CHIP 470K 5%	1/10W	C428	1-126-951-11	ELECT 470μF 20%	35V
R240	1-216-081-00	RES,CHIP 22K 5%	1/10W	C429	1-163-017-00	CERAMIC CHIP 0.0047μF 10%	50V
R241	1-216-057-00	RES,CHIP 2.2K 5%	1/10W	C430	1-163-017-00	CERAMIC CHIP 0.0047μF 10%	50V
R242	1-216-089-91	RES,CHIP 47K 5%	1/10W	C431	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V
R243	1-216-671-11	METAL CHIP 6.8K 0.50%	1/10W	C432	1-119-772-91	ELECT MELF 47μF 20%	35V
R245	1-215-459-00	METAL 39K 1%	1/4W	C433	1-136-356-11	FILM 470PF 5%	50V
R247	1-216-049-91	RES,CHIP 1K 5%	1/10W	C434	1-136-356-11	FILM 470PF 5%	50V
R248	1-216-657-11	METAL CHIP 1.8K 0.50%	1/10W	<CONNECTOR>			
R249	1-216-049-91	RES,CHIP 1K 5%	1/10W	CN39	* 1-774-245-11	CONNECTOR, BOARD TO BOARD 8P	
R250	1-216-073-00	RES,CHIP 10K 5%	1/10W	CN40	* 1-774-245-11	CONNECTOR, BOARD TO BOARD 8P	
R251	1-216-651-11	METAL CHIP 1K 0.50%	1/10W	CN41	* 1-774-245-11	CONNECTOR, BOARD TO BOARD 8P	
<VARIABLE RESISTOR>				<DIODE>			
RV201	1-241-784-11	RES, ADJ, CARBON 4.7K		D401	8-719-050-84	DIODE RB441Q-40T-77	
RV202	1-241-784-11	RES, ADJ, CARBON 4.7K		D402	8-719-050-84	DIODE RB441Q-40T-77	
RV203	1-238-543-11	RES, ADJ, CARBON 470		D403	8-719-050-84	DIODE RB441Q-40T-77	
RV204	1-238-543-11	RES, ADJ, CARBON 470		D404	8-719-050-84	DIODE RB441Q-40T-77	
<TRANSFORMER>				D405	8-719-210-21	DIODE 11EQS04	
T201	1-429-741-11	TRANSFORMER, DRIVE		D406	8-719-210-21	DIODE 11EQS04	
T202	1-429-741-11	TRANSFORMER, DRIVE		D407	8-719-210-21	DIODE 11EQS04	
*****				D408	8-719-210-21	DIODE 11EQS04	
* A-1311-707-A GBB MOUNTED PC BOARD				D409	8-719-914-43	DIODE DAN202K	
*****				D410	8-719-914-43	DIODE DAN202K	
<CAPACITOR>				D411	8-719-110-31	DIODE RD12ESB2	
C401	1-163-133-00	CERAMIC CHIP 470PF 5%	50V	D412	8-719-110-31	DIODE RD12ESB2	
C402	1-163-133-00	CERAMIC CHIP 470PF 5%	50V	D413	8-719-063-73	DIODE D1NL20U-TR	
C403	1-136-165-00	FILM 0.1μF 5%	50V	D414	8-719-063-73	DIODE D1NL20U-TR	
C404	1-136-165-00	FILM 0.1μF 5%	50V	<IC>			
C405	1-137-194-81	FILM 0.47μF 5%	50V	IC401	8-759-298-87	IC CXA8038P	
C406	1-137-194-81	FILM 0.47μF 5%	50V	IC402	8-759-298-87	IC CXA8038P	
C407	1-163-021-91	CERAMIC CHIP 0.01μF 10%	50V	IC403	8-759-135-80	IC UPC358C	
C408	1-163-021-91	CERAMIC CHIP 0.01μF 10%	50V	IC404	8-759-198-31	IC UPC1093J-1-T	
C409	1-163-133-00	CERAMIC CHIP 470PF 5%	50V	<PHOTO COUPLER>			
C410	1-163-133-00	CERAMIC CHIP 470PF 5%	50V	PH401	8-749-010-64	PHOTO COUPLER PC123F2	
C411	1-163-133-00	CERAMIC CHIP 470PF 5%	50V	PH402	8-749-010-64	PHOTO COUPLER PC123F2	
C412	1-163-133-00	CERAMIC CHIP 470PF 5%	50V	<TRANSISTOR>			
C413	1-163-133-00	CERAMIC CHIP 470PF 5%	50V	Q401	8-729-205-02	TRANSISTOR 2SA1150-Y	
C414	1-163-133-00	CERAMIC CHIP 470PF 5%	50V	Q402	8-729-205-02	TRANSISTOR 2SA1150-Y	
C415	1-163-263-11	CERAMIC CHIP 330PF 5%	50V	Q403	8-729-205-02	TRANSISTOR 2SA1150-Y	
C416	1-163-263-11	CERAMIC CHIP 330PF 5%	50V	Q404	8-729-205-02	TRANSISTOR 2SA1150-Y	
C417	1-136-171-00	FILM 0.33μF 5%	50V	Q405	8-729-140-96	TRANSISTOR 2SD774-34	

Ref.No.	Part No.	Description	Remark				Ref.No.	Part No.	Description	Remark			
Q406	8-729-140-96	TRANSISTOR 2SD774-34					RV404	1-241-783-11	RES, ADJ, CARBON 2.2K				
	<RESISTOR>						<TRANSFORMER>						
R401	1-247-791-91	CARBON	22	5%	1/4W		T401	1-429-741-11	TRANSFORMER, DRIVE				
R402	1-247-791-91	CARBON	22	5%	1/4W		T402	1-429-741-11	TRANSFORMER, DRIVE				
R403	1-216-061-00	RES,CHIP	3.3K	5%	1/10W	*****							
R404	1-216-061-00	RES,CHIP	3.3K	5%	1/10W								
R405	1-216-033-00	RES,CHIP	220	5%	1/10W								
R406	1-216-033-00	RES,CHIP	220	5%	1/10W	* A-1331-858-A CBR MOUNTED PC BOARD *****							
R407	1-216-097-91	RES,CHIP	100K	5%	1/10W								
R408	1-216-097-91	RES,CHIP	100K	5%	1/10W								
R409	1-216-057-00	RES,CHIP	2.2K	5%	1/10W								
R410	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	<CAPACITOR>							
R411	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	C2001	1-162-114-00	CERAMIC	0.0047μF	2KV			
R412	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	C2002	1-162-117-00	CERAMIC	100PF	10%	500V		
R413	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C2003	1-162-114-00	CERAMIC	0.0047μF	2KV			
R414	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C2004	1-162-114-00	CERAMIC	0.0047μF	2KV			
R415	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C2005	1-162-114-00	CERAMIC	0.0047μF	2KV			
R416	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C2008	1-162-117-00	CERAMIC	100PF	10%	500V		
R417	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	<CONNECTOR>							
R418	1-216-065-91	RES,CHIP	4.7K	5%	1/10W								
R419	1-216-065-91	RES,CHIP	4.7K	5%	1/10W								
R420	1-216-065-91	RES,CHIP	4.7K	5%	1/10W								
R421	1-249-389-11	CARBON	4.7	5%	1/4W	F	CN300	* 1-564-507-11	PLUG, CONNECTOR 4P				
R422	1-216-049-91	RES,CHIP	1K	5%	1/10W		CN301	* 1-564-507-11	PLUG, CONNECTOR 4P				
R423	1-249-389-11	CARBON	4.7	5%	1/4W	F	CN302	* 1-564-506-11	PLUG, CONNECTOR 3P				
R424	1-216-049-91	RES,CHIP	1K	5%	1/10W		CN303	* 1-508-784-00	PIN, CONNECTOR (5MM PITCH) 1P				
R427	1-249-389-11	CARBON	4.7	5%	1/4W	F	CN304	1-764-101-11	PIN, CONNECTOR (PC BOARD) 2P				
R428	1-249-389-11	CARBON	4.7	5%	1/4W	F	<FERRITE BEAD>						
R429	1-216-077-00	RES,CHIP	15K	5%	1/10W								
R430	1-216-057-00	RES,CHIP	2.2K	5%	1/10W								
R431	1-216-079-00	RES,CHIP	18K	5%	1/10W								
R432	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	FB2001	1-410-397-21	FERRITE 1.1μH					
						FB2011	1-410-397-21	FERRITE 1.1μH					
						FB2012	1-410-397-21	FERRITE 1.1μH					
R433	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	<JACK>							
R434	1-216-057-00	RES,CHIP	2.2K	5%	1/10W								
R437	1-216-057-00	RES,CHIP	2.2K	5%	1/10W								
R438	1-216-057-00	RES,CHIP	2.2K	5%	1/10W								
R439	1-216-105-91	RES,CHIP	220K	5%	1/10W	J2001	1-451-482-11	SOCKET, CRT					
R440	1-216-105-91	RES,CHIP	220K	5%	1/10W	<COIL>							
R441	1-216-105-91	RES,CHIP	220K	5%	1/10W								
R442	1-216-113-00	RES,CHIP	470K	5%	1/10W								
R443	1-215-484-00	METAL	430K	1%	1/4W								
R444	1-249-405-11	CARBON	100	5%	1/4W	F	L2002	1-414-137-31	INDUCTOR 0.22μH				
						L2004	1-414-137-31	INDUCTOR 0.22μH					
R445	1-215-471-00	METAL	120K	1%	1/4W	<RESISTOR>							
R446	1-215-471-00	METAL	120K	1%	1/4W								
R447	1-216-049-91	RES,CHIP	1K	5%	1/10W								
R448	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W								
R449	1-216-049-91	RES,CHIP	1K	5%	1/10W	R2002	1-219-743-11	CARBON	100	5%	1/2W		
						R2003	1-219-742-11	CARBON	47	5%	1/2W		
						R2005	1-219-752-11	CARBON	100K	5%	1/2W		
R450	1-216-073-00	RES,CHIP	10K	5%	1/10W	R2006	1-219-513-11	CARBON	4.7M	5%	1/2W		
R451	1-216-675-11	METAL CHIP	10K	0.50%	1/10W	R2008	1-219-743-11	CARBON	100	5%	1/2W		
R452	1-215-485-00	METAL	470K	1%	1/4W								
R453	1-249-405-11	CARBON	100	5%	1/4W	F	R2009	1-219-755-11	CARBON	10M	5%	1/2W	
	<VARIABLE RESISTOR>						<SPARK GAP>						
RV401	1-241-784-11	RES, ADJ, CARBON 4.7K					SG2001	1-519-504-11	GAP, DISCHARGE				
RV402	1-241-784-11	RES, ADJ, CARBON 4.7K					SG2002	1-519-422-11	GAP, SPARK				
RV403	1-241-761-11	RES, ADJ, CARBON 1K					SG2003	1-519-504-11	GAP, DISCHARGE				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
SG2009	1-517-422-11	GAP, SPARK		*****			
*****				* A-1331-860-A CBB MOUNTED PC BOARD			
*****				*****			
* A-1331-859-A CBG MOUNTED PC BOARD				<CAPACITOR>			
*****				C2001	1-162-114-00	CERAMIC 0.0047μF 2KV	
				C2002	1-162-117-00	CERAMIC 100PF 10% 500V	
				C2003	1-162-114-00	CERAMIC 0.0047μF 2KV	
				C2004	1-162-114-00	CERAMIC 0.0047μF 2KV	
				C2005	1-162-114-00	CERAMIC 0.0047μF 2KV	
				C2008	1-162-117-00	CERAMIC 100PF 10% 500V	
				<CONNECTOR>			
				CN310	* 1-564-507-11	PLUG, CONNECTOR 4P	
				CN311	* 1-564-507-11	PLUG, CONNECTOR 4P	
				CN312	* 1-564-506-11	PLUG, CONNECTOR 3P	
				CN313	* 1-508-784-00	PIN, CONNECTOR (5MM PITCH) 1P	
				CN314	1-764-101-11	PIN, CONNECTOR (PC BOARD) 2P	
				<FERRITE BEAD>			
				FB2001	1-410-397-21	FERRITE 1.1μH	
				FB2011	1-410-397-21	FERRITE 1.1μH	
				FB2012	1-410-397-21	FERRITE 1.1μH	
				<JACK>			
				J2001	1-451-482-11	SOCKET, CRT	
				<COIL>			
				L2002	1-414-137-31	INDUCTOR 0.22μH	
				L2004	1-414-137-31	INDUCTOR 0.22μH	
				<RESISTOR>			
				R2002	1-219-743-11	CARBON 100 5% 1/2W	
				R2003	1-219-742-11	CARBON 47 5% 1/2W	
				R2005	1-219-752-11	CARBON 100K 5% 1/2W	
				R2006	1-219-513-11	CARBON 4.7M 5% 1/2W	
				R2008	1-219-743-11	CARBON 100 5% 1/2W	
				R2009	1-219-755-11	CARBON 10M 5% 1/2W	
				<SPARK GAP>			
				SG2001	1-519-504-11	GAP, DISCHARGE	
				SG2002	1-519-422-11	GAP, SPARK	
				SG2003	1-519-504-11	GAP, DISCHARGE	
				SG2009	1-517-422-11	GAP, SPARK	

				* A-1331-860-A CBB MOUNTED PC BOARD			

				<CAPACITOR>			
				C2001	1-162-114-00	CERAMIC 0.0047μF 2KV	
				C2002	1-162-117-00	CERAMIC 100PF 10% 500V	
				C2003	1-162-114-00	CERAMIC 0.0047μF 2KV	
				C2004	1-162-114-00	CERAMIC 0.0047μF 2KV	
				C2005	1-162-114-00	CERAMIC 0.0047μF 2KV	
				C2008	1-162-117-00	CERAMIC 100PF 10% 500V	
				<CONNECTOR>			
				CN320	* 1-564-507-11	PLUG, CONNECTOR 4P	
				CN321	* 1-564-507-11	PLUG, CONNECTOR 4P	
				CN322	* 1-564-506-11	PLUG, CONNECTOR 3P	
				CN323	* 1-508-784-00	PIN, CONNECTOR (5MM PITCH) 1P	
				CN324	1-764-101-11	PIN, CONNECTOR (PC BOARD) 2P	
				<FERRITE BEAD>			
				FB2001	1-410-397-21	FERRITE 1.1μH	
				FB2011	1-410-397-21	FERRITE 1.1μH	
				FB2012	1-410-397-21	FERRITE 1.1μH	
				<JACK>			
				J2001	1-451-482-11	SOCKET, CRT	
				<COIL>			
				L2002	1-414-137-31	INDUCTOR 0.22μH	
				L2004	1-414-137-31	INDUCTOR 0.22μH	
				<RESISTOR>			
				R2002	1-219-743-11	CARBON 100 5% 1/2W	
				R2003	1-219-742-11	CARBON 47 5% 1/2W	
				R2005	1-219-752-11	CARBON 100K 5% 1/2W	
				R2006	1-219-513-11	CARBON 4.7M 5% 1/2W	
				R2008	1-219-743-11	CARBON 100 5% 1/2W	
				R2009	1-219-755-11	CARBON 10M 5% 1/2W	
				<SPARK GAP>			
				SG2001	1-519-504-11	GAP, DISCHARGE	
				SG2002	1-519-422-11	GAP, SPARK	
				SG2003	1-519-504-11	GAP, DISCHARGE	
				SG2009	1-517-422-11	GAP, SPARK	

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
*****				C502	1-104-607-11	ELECT CHIP 47μF	20% 16V
* A-1335-105-A CR COMPLETE PC BOARD				C503	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
(Include CAR, CDR Mounted PC BOARD)				C505	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C506	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
3-701-809-31	SCREW, TERMINAL (M3X8)			C511	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
4-057-640-01	COVER, VOLUME			C512	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
* 4-067-812-01	HOLDER (C), TR			C513	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
* 4-067-820-01	HOLDER (VP)			C514	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
* 7-322-065-72	RUBBER, RTV (SE-9168) (130G)			C515	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
7-682-652-09	SCREW +PS 3X16			C516	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
7-682-949-01	SCREW +PSW 3X10			C525	1-126-394-11	ELECT CHIP 10μF	20% 16V
*****				C526	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
CAR MOUNTED PC BOARD				C527	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C540	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
<CAPACITOR>				C551	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C11	1-110-648-11	ELECT CHIP 220μF	20% 25V	C552	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C12	1-128-304-11	ELECT CHIP 330μF	20% 16V	C560	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C15	1-128-361-11	ELECT CHIP 470μF	20% 10V	C561	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C16	1-128-361-11	ELECT CHIP 470μF	20% 10V	C562	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C21	1-110-648-11	ELECT CHIP 220μF	20% 25V	C571	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C22	1-128-304-11	ELECT CHIP 330μF	20% 16V	C572	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C24	1-128-361-11	ELECT CHIP 470μF	20% 10V	C573	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C51	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C591	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C61	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C592	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C71	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C593	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C81	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C594	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C105	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C606	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C106	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	C610	1-104-607-11	ELECT CHIP 47μF	20% 16V
C107	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C611	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C108	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	C612	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C111	1-126-392-11	ELECT CHIP 100μF	20% 6.3V	C617	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C132	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C621	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C135	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C622	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C136	1-126-394-11	ELECT CHIP 10μF	20% 16V	C631	1-126-767-11	ELECT 1000μF	20% 16V
C141	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C632	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C142	1-163-009-11	CERAMIC CHIP 0.001μF	10% 50V	C636	1-163-089-00	CERAMIC CHIP 6PF	0.5PF 50V
C146	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C638	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C151	1-163-017-00	CERAMIC CHIP 0.0047μF	10% 50V	C639	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C152	1-163-017-00	CERAMIC CHIP 0.0047μF	10% 50V	C646	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C153	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C647	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C154	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C648	1-104-607-11	ELECT CHIP 47μF	20% 16V
C171	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C649	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C172	1-135-177-21	TANTAL. CHIP 1μF	20% 16V	C651	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C173	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C652	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C174	1-135-177-21	TANTAL. CHIP 1μF	20% 16V	C655	1-104-607-11	ELECT CHIP 47μF	20% 16V
C441	1-163-001-11	CERAMIC CHIP 220PF	10% 50V	C656	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C444	1-135-177-21	TANTAL. CHIP 1μF	20% 16V	C658	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C445	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C665	1-164-222-11	CERAMIC CHIP 0.22μF	25V
C446	1-163-001-11	CERAMIC CHIP 220PF	10% 50V	C667	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C451	1-163-001-11	CERAMIC CHIP 220PF	10% 50V	C669	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C454	1-135-177-21	TANTAL. CHIP 1μF	20% 16V	C671	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C455	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C672	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C456	1-163-001-11	CERAMIC CHIP 220PF	10% 50V	C681	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C683	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C691	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
				C692	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C698	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
				C699	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
Q510	8-729-129-54	TRANSISTOR 2SC2954		R145	1-216-677-11	METAL CHIP 12K	0.50% 1/10W
Q511	8-729-129-54	TRANSISTOR 2SC2954		R146	1-216-683-11	METAL CHIP 22K	0.50% 1/10W
Q525	8-729-107-31	TRANSISTOR 2SC3545-T43					
Q527	8-729-230-49	TRANSISTOR 2SC2712-YG		R147	1-216-295-91	SHORT 0	
				R148	1-216-049-91	RES,CHIP 1K	5% 1/10W
Q540	8-729-216-22	TRANSISTOR 2SA1162-G		R151	1-216-073-00	RES,CHIP 10K	5% 1/10W
Q551	8-729-129-54	TRANSISTOR 2SC2954		R155	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
Q563	8-729-230-49	TRANSISTOR 2SC2712-YG		R171	1-216-025-91	RES,CHIP 100	5% 1/10W
Q581	8-729-112-65	TRANSISTOR 2SA1462-T1Y33					
Q605	8-729-107-31	TRANSISTOR 2SC3545-T43		R172	1-216-049-91	RES,CHIP 1K	5% 1/10W
				R173	1-216-051-00	RES,CHIP 1.2K	5% 1/10W
Q610	8-729-033-16	TRANSISTOR 2SA1669-TB		R174	1-216-025-91	RES,CHIP 100	5% 1/10W
Q618	8-729-112-65	TRANSISTOR 2SA1462-T1Y33		R180	1-216-025-91	RES,CHIP 100	5% 1/10W
Q625	8-729-143-46	TRANSISTOR 2SC3356-R24		R182	1-216-049-91	RES,CHIP 1K	5% 1/10W
Q631	8-729-143-46	TRANSISTOR 2SC3356-R24					
Q645	8-729-033-16	TRANSISTOR 2SA1669-TB		R183	1-216-049-91	RES,CHIP 1K	5% 1/10W
				R184	1-216-025-91	RES,CHIP 100	5% 1/10W
Q647	8-729-107-31	TRANSISTOR 2SC3545-T43		R441	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
Q651	8-729-143-46	TRANSISTOR 2SC3356-R24		R445	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
Q656	8-729-129-54	TRANSISTOR 2SC2954		R446	1-216-025-91	RES,CHIP 100	5% 1/10W
Q665	8-729-116-05	TRANSISTOR 2SK160-K5					
Q671	8-729-107-31	TRANSISTOR 2SC3545-T43		R447	1-216-001-00	RES,CHIP 10	5% 1/10W
				R448	1-216-025-91	RES,CHIP 100	5% 1/10W
Q691	8-729-143-46	TRANSISTOR 2SC3356-R24		R451	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
Q692	8-729-033-16	TRANSISTOR 2SA1669-TB		R455	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
Q701	8-729-129-54	TRANSISTOR 2SC2954		R456	1-216-025-91	RES,CHIP 100	5% 1/10W
Q721	8-729-143-46	TRANSISTOR 2SC3356-R24					
Q723	8-729-107-31	TRANSISTOR 2SC3545-T43		R457	1-216-001-00	RES,CHIP 10	5% 1/10W
				R458	1-216-025-91	RES,CHIP 100	5% 1/10W
Q726	8-729-129-54	TRANSISTOR 2SC2954		R501	1-216-033-00	RES,CHIP 220	5% 1/10W
Q733	8-729-129-54	TRANSISTOR 2SC2954		R502	1-216-643-11	METAL CHIP 470	0.50% 1/10W
Q736	8-729-033-16	TRANSISTOR 2SA1669-TB		R503	1-216-033-00	RES,CHIP 220	5% 1/10W
Q738	8-729-112-65	TRANSISTOR 2SA1462-T1Y33					
Q741	8-729-112-65	TRANSISTOR 2SA1462-T1Y33		R504	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
				R505	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
Q751	8-729-143-46	TRANSISTOR 2SC3356-R24		R506	1-216-045-00	RES,CHIP 680	5% 1/10W
Q752	8-729-033-16	TRANSISTOR 2SA1669-TB		R507	1-216-045-00	RES,CHIP 680	5% 1/10W
Q781	8-729-116-05	TRANSISTOR 2SK160-K5		R508	1-216-045-00	RES,CHIP 680	5% 1/10W
Q797	8-729-230-49	TRANSISTOR 2SC2712-YG					
				R509	1-216-045-00	RES,CHIP 680	5% 1/10W
				R510	1-216-017-91	RES,CHIP 47	5% 1/10W
				R511	1-216-033-00	RES,CHIP 220	5% 1/10W
				R521	1-216-643-11	METAL CHIP 470	0.50% 1/10W
				R523	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
				R524	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
				R525	1-216-081-00	RES,CHIP 22K	5% 1/10W
				R526	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
				R527	1-216-073-00	RES,CHIP 10K	5% 1/10W
				R540	1-216-033-00	RES,CHIP 220	5% 1/10W
				R541	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
				R542	1-216-071-00	RES,CHIP 8.2K	5% 1/10W
				R551	1-216-051-00	RES,CHIP 1.2K	5% 1/10W
				R552	1-216-075-00	RES,CHIP 12K	5% 1/10W
				R553	1-216-033-00	RES,CHIP 220	5% 1/10W
				R554	1-220-273-11	RES,CHIP 1K	5% 1/10W
				R560	1-216-049-91	RES,CHIP 1K	5% 1/10W
				R561	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
				R562	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
				R563	1-216-033-00	RES,CHIP 220	5% 1/10W
				R564	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W
				R566	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
				R567	1-216-049-91	RES,CHIP 1K	5% 1/10W
				R571	1-216-049-91	RES,CHIP 1K	5% 1/10W
				R572	1-216-049-91	RES,CHIP 1K	5% 1/10W
				R573	1-216-049-91	RES,CHIP 1K	5% 1/10W

<RESISTOR>

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R581	1-216-033-00	RES,CHIP	220 5% 1/10W	R712	1-216-635-11	METAL CHIP	220 0.50% 1/10W
R591	1-216-017-91	RES,CHIP	47 5% 1/10W	R717	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R592	1-216-295-91	SHORT 0		R719	1-216-643-11	METAL CHIP	470 0.50% 1/10W
R593	1-216-295-91	SHORT 0		R720	1-216-635-11	METAL CHIP	220 0.50% 1/10W
R595	1-216-043-91	RES,CHIP	560 5% 1/10W	R721	1-216-017-91	RES,CHIP	47 5% 1/10W
R596	1-216-295-91	SHORT 0		R722	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
R605	1-216-033-00	RES,CHIP	220 5% 1/10W	R723	1-216-025-91	RES,CHIP	100 5% 1/10W
R606	1-216-687-11	METAL CHIP	33K 0.50% 1/10W	R724	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R607	1-216-017-91	RES,CHIP	47 5% 1/10W	R725	1-216-657-11	METAL CHIP	1.8K 0.50% 1/10W
R609	1-216-295-91	SHORT 0		R726	1-216-017-91	RES,CHIP	47 5% 1/10W
R610	1-216-017-91	RES,CHIP	47 5% 1/10W	R727	1-216-017-91	RES,CHIP	47 5% 1/10W
R616	1-216-653-11	METAL CHIP	1.2K 0.50% 1/10W	R731	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R617	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R732	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W
R618	1-216-025-91	RES,CHIP	100 5% 1/10W	R733	1-216-025-91	RES,CHIP	100 5% 1/10W
R619	1-216-631-11	METAL CHIP	150 0.50% 1/10W	R734	1-220-269-11	RES,CHIP	330 5% 1/2W
R621	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R735	1-220-274-11	RES,CHIP	1.2K 5% 1/2W
R622	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R736	1-216-017-91	RES,CHIP	47 5% 1/10W
R625	1-216-033-00	RES,CHIP	220 5% 1/10W	R737	1-220-274-11	RES,CHIP	1.2K 5% 1/2W
R631	1-216-017-91	RES,CHIP	47 5% 1/10W	R738	1-216-033-00	RES,CHIP	220 5% 1/10W
R632	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R739	1-216-653-11	METAL CHIP	1.2K 0.50% 1/10W
R633	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R740	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R635	1-216-641-11	METAL CHIP	390 0.50% 1/10W	R741	1-216-033-00	RES,CHIP	220 5% 1/10W
R636	1-216-635-11	METAL CHIP	220 0.50% 1/10W	R742	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R645	1-216-001-00	RES,CHIP	10 5% 1/10W	R743	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R646	1-216-073-00	RES,CHIP	10K 5% 1/10W	R745	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R647	1-216-033-00	RES,CHIP	220 5% 1/10W	R746	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W
R648	1-216-653-11	METAL CHIP	1.2K 0.50% 1/10W	R751	1-216-017-91	RES,CHIP	47 5% 1/10W
R649	1-216-673-11	METAL CHIP	8.2K 0.50% 1/10W	R752	1-216-017-91	RES,CHIP	47 5% 1/10W
R650	1-216-639-11	METAL CHIP	330 0.50% 1/10W	R753	1-216-001-00	RES,CHIP	10 5% 1/10W
R651	1-216-017-91	RES,CHIP	47 5% 1/10W	R754	1-216-635-11	METAL CHIP	220 0.50% 1/10W
R653	1-216-635-11	METAL CHIP	220 0.50% 1/10W	R755	1-216-635-11	METAL CHIP	220 0.50% 1/10W
R654	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R756	1-216-001-00	RES,CHIP	10 5% 1/10W
R655	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R757	1-216-001-00	RES,CHIP	10 5% 1/10W
R656	1-216-635-11	METAL CHIP	220 0.50% 1/10W	R758	1-220-273-11	RES,CHIP	1K 5% 1/2W
R657	1-216-033-00	RES,CHIP	220 5% 1/10W	R759	1-220-273-11	RES,CHIP	1K 5% 1/2W
R658	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R781	1-216-049-91	RES,CHIP	1K 5% 1/10W
R659	1-216-653-11	METAL CHIP	1.2K 0.50% 1/10W	R782	1-216-121-91	RES,CHIP	1M 5% 1/10W
R661	1-216-049-91	RES,CHIP	1K 5% 1/10W	R783	1-216-049-91	RES,CHIP	1K 5% 1/10W
R665	1-216-121-91	RES,CHIP	1M 5% 1/10W	R784	1-216-677-11	METAL CHIP	12K 0.50% 1/10W
R666	1-216-049-91	RES,CHIP	1K 5% 1/10W	R785	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R667	1-216-073-00	RES,CHIP	10K 5% 1/10W	R786	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R668	1-216-049-91	RES,CHIP	1K 5% 1/10W	R787	1-216-049-91	RES,CHIP	1K 5% 1/10W
R669	1-216-081-00	RES,CHIP	22K 5% 1/10W	R789	1-216-049-91	RES,CHIP	1K 5% 1/10W
R672	1-216-025-91	RES,CHIP	100 5% 1/10W	R791	1-216-073-00	RES,CHIP	10K 5% 1/10W
R675	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R795	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R676	1-216-001-00	RES,CHIP	10 5% 1/10W	R796	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R681	1-216-677-11	METAL CHIP	12K 0.50% 1/10W	R797	1-216-025-91	RES,CHIP	100 5% 1/10W
R683	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W	R798	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
R691	1-216-017-91	RES,CHIP	47 5% 1/10W	R801	1-216-017-91	RES,CHIP	47 5% 1/10W
R692	1-216-017-91	RES,CHIP	47 5% 1/10W	<RESISTOR BLOCK>			
R693	1-216-001-00	RES,CHIP	10 5% 1/10W	RB51	1-233-576-11	RES, CHIP	NETWORK 100
R695	1-216-001-00	RES,CHIP	10 5% 1/10W	RB71	1-233-414-11	RES, CHIP	NETWORK 4.7K (3216)
R696	1-216-001-00	RES,CHIP	10 5% 1/10W	RB72	1-233-576-11	RES, CHIP	NETWORK 100
R698	1-220-273-11	RES,CHIP	1K 5% 1/2W	RB81	1-233-576-11	RES, CHIP	NETWORK 100
R699	1-220-273-11	RES,CHIP	1K 5% 1/2W				
R701	1-216-017-91	RES,CHIP	47 5% 1/10W				
R704	1-216-635-11	METAL CHIP	220 0.50% 1/10W				
R710	1-216-065-91	RES,CHIP	4.7K 5% 1/10W				
R711	1-216-637-11	METAL CHIP	270 0.50% 1/10W				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
<VARIABLE RESISTOR>				C832	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
RV145	1-230-871-11	RES, ADJ, METAL GLAZE 22K		C833	1-102-050-00	CERAMIC 0.01μF	99% 500V
RV622	1-238-785-21	RES, ADJ, CERMET 2K		C834	1-107-961-91	ELECT 10μF	20% 250V
RV623	1-238-783-11	RES, ADJ, CERMET 500		C851	1-110-648-11	ELECT CHIP 220μF	20% 25V
RV682	1-238-786-11	RES, ADJ, CERMET 5K		C852	1-128-304-11	ELECT CHIP 330μF	20% 16V
RV718	1-238-785-21	RES, ADJ, CERMET 2K		C853	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
RV785	1-238-786-11	RES, ADJ, CERMET 5K		C854	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
RV796	1-230-871-11	RES, ADJ, METAL GLAZE 22K		C862	1-128-304-11	ELECT CHIP 330μF	20% 16V
<SWITCH>				C901	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
S796	1-571-674-11	SWITCH, SLIDE		C902	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
<TEST PIN>				C903	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
TP21	1-535-757-11	CHIP, CHECKER		C904	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
TP22	1-535-757-11	CHIP, CHECKER		C905	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
TP23	1-535-757-11	CHIP, CHECKER		C906	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
TP24	1-535-757-11	CHIP, CHECKER		C911	1-124-779-00	ELECT CHIP 10μF	20% 16V
TP34	1-535-757-11	CHIP, CHECKER		C912	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
TP35	1-535-757-11	CHIP, CHECKER		C913	1-163-249-11	CERAMIC CHIP 82PF	5% 50V
TP71	1-535-757-11	CHIP, CHECKER		C914	1-163-235-11	CERAMIC CHIP 22PF	5% 50V
TP72	1-535-757-11	CHIP, CHECKER		C915	1-163-243-11	CERAMIC CHIP 47PF	5% 50V
TP73	1-535-757-11	CHIP, CHECKER		C953	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
TP501	1-535-757-11	CHIP, CHECKER		C954	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
TP511	1-535-757-11	CHIP, CHECKER		C956	1-162-117-00	CERAMIC 100PF	10% 500V
TP691	1-535-757-11	CHIP, CHECKER		C957	1-102-050-00	CERAMIC 0.01μF	99% 500V
TP751	1-535-757-11	CHIP, CHECKER		C958	1-107-943-11	ELECT 10μF	20% 160V
*****				C961	1-102-038-00	CERAMIC 0.001μF	500V
CDR MOUNTED PC BOARD				C962	1-163-275-11	CERAMIC CHIP 0.001μF	5% 50V
*****				C965	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
<CAPACITOR>				C968	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C800	1-128-304-11	ELECT CHIP 330μF	20% 16V	C969	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C801	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C970	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C802	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	C971	1-124-779-00	ELECT CHIP 10μF	20% 16V
C803	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	C973	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C805	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C974	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C811	1-124-779-00	ELECT CHIP 10μF	20% 16V	C977	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C812	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C982	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
C815	1-163-251-11	CERAMIC CHIP 100PF	5% 50V	C991	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C816	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V	C992	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C817	1-163-121-00	CERAMIC CHIP 150PF	5% 50V	C993	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C818	1-162-117-00	CERAMIC 100PF	10% 500V	C995	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
C820	1-107-961-91	ELECT 10μF	20% 250V	C996	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C821	1-102-050-00	CERAMIC 0.01μF	99% 500V	C997	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C822	1-107-943-11	ELECT 10μF	20% 160V	C998	1-164-506-11	CERAMIC CHIP 4.7μF	16V
C823	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C999	1-164-506-11	CERAMIC CHIP 4.7μF	16V
C824	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1000	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C826	1-126-397-11	ELECT CHIP 33μF	20% 25V	C1002	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C827	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1201	1-107-943-11	ELECT 10μF	20% 160V
C828	1-164-506-11	CERAMIC CHIP 4.7μF	16V	C1210	1-107-943-11	ELECT 10μF	20% 160V
C829	1-164-506-11	CERAMIC CHIP 4.7μF	16V	C1211	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C830	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C1212	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
<CONNECTOR>				C1213	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
CN244	* 1-564-726-11	PIN, CONNECTOR (SMALL TYPE) OP		C1214	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
CN245	* 1-564-507-11	PLUG, CONNECTOR 4P		C1215	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
CN246	* 1-564-507-11	PLUG, CONNECTOR 4P		C1221	1-107-943-11	ELECT 10μF	20% 160V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
CN249	* 1-564-518-11	PLUG, CONNECTOR 3P				<COIL>	
CN250	* 1-785-522-11	PIN, CONNECTOR (PC BOARD) 18P					
		<DIODE>					
D801	8-719-800-76	DIODE 1SS226		L801	1-412-533-21	INDUCTOR 47μH	
D806	8-719-978-04	DIODE DTZ-TT11-3.3B		L818	1-414-137-31	INDUCTOR 0.22μH	
D811	8-719-901-83	DIODE 1SS83		L951	1-412-533-21	INDUCTOR 47μH	
D812	8-719-901-83	DIODE 1SS83		L954	1-414-137-31	INDUCTOR 0.22μH	
D820	8-719-800-76	DIODE 1SS226		L955	1-414-137-31	INDUCTOR 0.22μH	
D821	8-719-106-53	DIODE RD10M-B2				<TRANSISTOR>	
D831	8-719-107-24	DIODE RD20M-B2					
D832	8-719-901-83	DIODE 1SS83		Q801	8-729-033-16	TRANSISTOR 2SA1669-TB	
D833	8-719-901-83	DIODE 1SS83		Q802	8-729-112-65	TRANSISTOR 2SA1462-T1Y33	
D841	8-719-901-83	DIODE 1SS83		Q806	8-729-145-13	TRANSISTOR 2SC3356-(R25)	
				Q807	8-729-033-16	TRANSISTOR 2SA1669-TB	
D842	8-719-901-83	DIODE 1SS83		Q815	8-729-116-05	TRANSISTOR 2SK160-K5	
D851	8-719-914-43	DIODE DAN202K					
D861	8-719-914-43	DIODE DAN202K		Q819	8-729-801-88	TRANSISTOR 2SA1381-E	
D901	8-719-800-76	DIODE 1SS226		Q821	8-729-821-02	TRANSISTOR 2SC3503-DE	
D906	8-719-978-04	DIODE DTZ-TT11-3.3B		Q901	8-729-033-16	TRANSISTOR 2SA1669-TB	
				Q902	8-729-112-65	TRANSISTOR 2SA1462-T1Y33	
D941	8-719-901-83	DIODE 1SS83		Q906	8-729-145-13	TRANSISTOR 2SC3356-(R25)	
D942	8-719-901-83	DIODE 1SS83					
D945	8-719-018-98	DIODE 1SS311(TE85L)		Q907	8-729-033-16	TRANSISTOR 2SA1669-TB	
D955	8-719-800-76	DIODE 1SS226		Q948	8-729-804-63	TRANSISTOR 2SA1406-E	
D956	8-719-106-53	DIODE RD10M-B2		Q961	1-801-806-11	TRANSISTOR DTC144EKA-T146	
				Q974	8-729-230-49	TRANSISTOR 2SC2712-YG	
D960	8-719-801-78	DIODE 1SS184		Q1204	8-729-821-02	TRANSISTOR 2SC3503-DE	
D961	8-719-800-76	DIODE 1SS226					
D965	8-719-105-82	DIODE RD5.1M-B2		Q1210	8-729-111-07	TRANSISTOR 2SD1590-L	
D981	8-719-106-53	DIODE RD10M-B2					
D982	8-719-800-76	DIODE 1SS226				<RESISTOR>	
D1001	8-719-976-96	DIODE DTZ4.7C		R801	1-216-017-91	RES,CHIP 47	5% 1/10W
D1211	8-719-800-76	DIODE 1SS226		R802	1-216-033-00	RES,CHIP 220	5% 1/10W
D1215	8-719-106-53	DIODE RD10M-B2		R803	1-216-025-91	RES,CHIP 100	5% 1/10W
				R804	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W
				R805	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
		<FILTER>					
FL1001	1-233-831-11	FILTER, EMI		R806	1-216-017-91	RES,CHIP 47	5% 1/10W
FL1002	1-233-831-11	FILTER, EMI		R807	1-216-017-91	RES,CHIP 47	5% 1/10W
FL1011	1-233-512-21	FERRITE 37μH		R808	1-216-001-00	RES,CHIP 10	5% 1/10W
FL1012	1-233-512-21	FERRITE 37μH		R809	1-216-001-00	RES,CHIP 10	5% 1/10W
FL1013	1-233-512-21	FERRITE 37μH		R810	1-216-001-00	RES,CHIP 10	5% 1/10W
FL1014	1-233-512-21	FERRITE 37μH		R811	1-216-627-11	METAL CHIP 100	0.50% 1/10W
				R814	1-216-619-11	METAL CHIP 47	0.50% 1/10W
				R815	1-249-401-11	CARBON 47	5% 1/4W F
		<IC>		R819	1-216-033-00	RES,CHIP 220	5% 1/10W
				R820	1-216-049-91	RES,CHIP 1K	5% 1/10W
IC801	8-749-014-86	IC VPJ15H					
IC802	8-759-710-78	IC NJM082BM-T1		R821	1-215-485-00	METAL 470K	1% 1/4W
IC851	8-759-460-81	IC BA12FP-E2		R822	1-215-485-00	METAL 470K	1% 1/4W
IC861	8-759-335-28	IC TA78M09F(TE16L)		R823	1-215-461-00	METAL 47K	1% 1/4W
IC901	8-749-014-86	IC VPJ15H		R824	1-216-121-91	RES,CHIP 1M	5% 1/10W
				R825	1-216-025-91	RES,CHIP 100	5% 1/10W
IC902	8-759-381-53	IC UPC814G2-E2		R826	1-216-075-00	RES,CHIP 12K	5% 1/10W
IC961	8-749-011-45	IC NJL5152MD		R827	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
IC971	8-759-710-78	IC NJM082BM-T1		R828	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
IC981	8-759-234-77	IC TC4S66F		R829	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
IC990	8-759-710-78	IC NJM082BM-T1		R830	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
IC998	8-759-710-78	IC NJM082BM-T1		R831	1-215-461-00	METAL 47K	1% 1/4W
IC1211	8-759-198-34	IC TA75S558F		R832	1-249-417-11	CARBON 1K	5% 1/4W
				R833	1-249-417-11	CARBON 1K	5% 1/4W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R841	1-215-477-00	METAL	220K 1% 1/4W	R1211	1-216-049-91	RES,CHIP 1K 5% 1/10W	
R851	1-220-274-11	RES,CHIP	1.2K 5% 1/2W	R1212	1-216-073-00	RES,CHIP 10K 5% 1/10W	
				R1213	1-216-675-11	METAL CHIP 10K 0.50% 1/10W	
R852	1-220-274-11	RES,CHIP	1.2K 5% 1/2W	R1214	1-216-675-11	METAL CHIP 10K 0.50% 1/10W	
R901	1-216-017-91	RES,CHIP	47 5% 1/10W				
R902	1-216-033-00	RES,CHIP	220 5% 1/10W	R1221	1-215-477-00	METAL 220K 1% 1/4W	
R903	1-216-025-91	RES,CHIP	100 5% 1/10W	R1222	1-215-485-00	METAL 470K 1% 1/4W	
R904	1-216-653-11	METAL CHIP	1.2K 0.50% 1/10W	R1223	1-216-699-11	METAL CHIP 100K 0.50% 1/10W	
				R1224	1-216-683-11	METAL CHIP 22K 0.50% 1/10W	
R905	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R906	1-216-017-91	RES,CHIP	47 5% 1/10W				
R907	1-216-017-91	RES,CHIP	47 5% 1/10W				
R908	1-216-001-00	RES,CHIP	10 5% 1/10W				
R909	1-216-001-00	RES,CHIP	10 5% 1/10W				
R910	1-216-001-00	RES,CHIP	10 5% 1/10W				
R911	1-216-627-11	METAL CHIP	100 0.50% 1/10W				
R912	1-216-619-11	METAL CHIP	47 0.50% 1/10W				
R919	1-216-033-00	RES,CHIP	220 5% 1/10W				
R921	1-215-485-00	METAL	470K 1% 1/4W				
R922	1-215-485-00	METAL	470K 1% 1/4W				
R923	1-215-445-00	METAL	10K 1% 1/4W				
R924	1-216-049-91	RES,CHIP	1K 5% 1/10W				
R925	1-216-025-91	RES,CHIP	100 5% 1/10W				
R951	1-220-274-11	RES,CHIP	1.2K 5% 1/2W				
R952	1-220-274-11	RES,CHIP	1.2K 5% 1/2W				
R955	1-249-401-11	CARBON	47 5% 1/4W				
R957	1-215-493-00	METAL	1M 1% 1/4W				
R958	1-219-741-91	CARBON	10 5% 1/2W				
R959	1-219-743-11	CARBON	100 5% 1/2W				
R960	1-216-649-11	METAL CHIP	820 0.50% 1/10W				
R961	1-216-683-11	METAL CHIP	22K 0.50% 1/10W				
R967	1-216-025-91	RES,CHIP	100 5% 1/10W				
R971	1-216-025-91	RES,CHIP	100 5% 1/10W				
R972	1-216-653-11	METAL CHIP	1.2K 0.50% 1/10W				
R973	1-216-653-11	METAL CHIP	1.2K 0.50% 1/10W				
R974	1-216-073-00	RES,CHIP	10K 5% 1/10W				
R975	1-216-045-00	RES,CHIP	680 5% 1/10W				
R976	1-216-675-11	METAL CHIP	10K 0.50% 1/10W				
R977	1-216-073-00	RES,CHIP	10K 5% 1/10W				
R978	1-216-025-91	RES,CHIP	100 5% 1/10W				
R979	1-216-025-91	RES,CHIP	100 5% 1/10W				
R982	1-216-065-91	RES,CHIP	4.7K 5% 1/10W				
R983	1-216-089-91	RES,CHIP	47K 5% 1/10W				
R984	1-216-017-91	RES,CHIP	47 5% 1/10W				
R990	1-216-025-91	RES,CHIP	100 5% 1/10W				
R991	1-216-673-11	METAL CHIP	8.2K 0.50% 1/10W				
R992	1-216-673-11	METAL CHIP	8.2K 0.50% 1/10W				
R993	1-216-049-91	RES,CHIP	1K 5% 1/10W				
R994	1-216-025-91	RES,CHIP	100 5% 1/10W				
R995	1-216-025-91	RES,CHIP	100 5% 1/10W				
R996	1-216-675-11	METAL CHIP	10K 0.50% 1/10W				
R997	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W				
R998	1-216-105-91	RES,CHIP	220K 5% 1/10W				
R999	1-216-049-91	RES,CHIP	1K 5% 1/10W				
R1001	1-216-057-00	RES,CHIP	2.2K 5% 1/10W				
R1007	1-216-619-11	METAL CHIP	47 0.50% 1/10W				
R1201	1-215-439-00	METAL	5.6K 1% 1/4W				
R1202	1-215-455-00	METAL	27K 1% 1/4W				
R1203	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R1204	1-216-025-91	RES,CHIP	100 5% 1/10W				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C16	1-128-361-11	ELECT CHIP 470μF	20% 10V	C592	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C21	1-110-648-11	ELECT CHIP 220μF	20% 25V	C593	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C594	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C22	1-128-304-11	ELECT CHIP 330μF	20% 16V	C606	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C24	1-128-361-11	ELECT CHIP 470μF	20% 10V				
C51	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C610	1-104-607-11	ELECT CHIP 47μF	20% 16V
C61	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C611	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C71	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C612	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C617	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C81	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C621	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C105	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C106	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	C622	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C107	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C631	1-126-767-11	ELECT 1000μF	20% 16V
C108	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	C632	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C636	1-163-089-00	CERAMIC CHIP 6PF	0.5PF 50V
C111	1-126-392-11	ELECT CHIP 100μF	20% 6.3V	C638	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C132	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C135	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C639	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C136	1-126-394-11	ELECT CHIP 10μF	20% 16V	C646	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C141	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V	C647	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C648	1-104-607-11	ELECT CHIP 47μF	20% 16V
C142	1-163-009-11	CERAMIC CHIP 0.001μF	10% 50V	C649	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C146	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C151	1-163-017-00	CERAMIC CHIP 0.0047μF	10% 50V	C651	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C152	1-163-017-00	CERAMIC CHIP 0.0047μF	10% 50V	C652	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C153	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C655	1-104-607-11	ELECT CHIP 47μF	20% 16V
				C656	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C154	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C658	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C171	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C172	1-135-177-21	TANTAL. CHIP 1μF	20% 16V	C665	1-164-222-11	CERAMIC CHIP 0.22μF	25V
C173	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C667	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C174	1-135-177-21	TANTAL. CHIP 1μF	20% 16V	C669	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
				C671	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C441	1-163-001-11	CERAMIC CHIP 220PF	10% 50V	C672	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C444	1-135-177-21	TANTAL. CHIP 1μF	20% 16V				
C445	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C681	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C446	1-163-001-11	CERAMIC CHIP 220PF	10% 50V	C683	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C451	1-163-001-11	CERAMIC CHIP 220PF	10% 50V	C691	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
				C692	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C454	1-135-177-21	TANTAL. CHIP 1μF	20% 16V	C698	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C455	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C456	1-163-001-11	CERAMIC CHIP 220PF	10% 50V	C699	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C502	1-104-607-11	ELECT CHIP 47μF	20% 16V	C701	1-107-781-11	ELECT CHIP 47μF	20% 16V
C503	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C702	1-104-607-11	ELECT CHIP 47μF	20% 16V
				C703	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C505	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C712	1-163-091-00	CERAMIC CHIP 8PF	0.25PF 50V
C506	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C511	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	C718	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C512	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C719	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C513	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C722	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C725	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C514	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C726	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C515	1-104-913-11	TANTAL. CHIP 10μF	10% 16V				
C516	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	C727	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C525	1-126-394-11	ELECT CHIP 10μF	20% 16V	C732	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C526	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C737	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C738	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C527	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C745	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C540	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C551	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C751	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C552	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C752	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C560	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C755	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
				C756	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C561	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C758	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C562	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C571	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C759	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C572	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C760	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C573	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C781	1-164-222-11	CERAMIC CHIP 0.22μF	25V
				C784	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C591	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C785	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C787	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	IC16	8-759-460-74	IC BA05FP-E2	
C789	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	IC22	8-759-549-53	IC LM2990SX-12	
C791	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	IC24	8-759-045-17	IC NJM79L05UA	
C793	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	IC101	8-759-541-88	IC EPM7064STC44-10-PULSE	
C796	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
	<CONNECTOR>			IC102	8-759-564-62	IC MAX4224ESA-TG06	
CN260	* 1-760-388-11	CONNECTOR PIN (SMD) 9 PIN		IC141	8-759-381-53	IC UPC814G2-E2	
CN262	* 1-691-551-11	PIN, CONNECTOR (SMD) 8P		IC171	8-759-392-64	IC AD828AR	
CN263	1-569-516-11	PIN, CONNECTOR 18P		IC560	8-759-710-78	IC NJM082BM-T1	
				IC570	8-759-082-61	IC TC4W53FU	
	<DIODE>			IC595	8-759-542-11	IC MAX4223ESA-TG06	
D12	8-719-914-43	DIODE DAN202K		IC661	8-759-381-53	IC UPC814G2-E2	
D16	8-719-914-43	DIODE DAN202K		IC781	8-759-381-53	IC UPC814G2-E2	
D22	8-719-914-43	DIODE DAN202K					
D24	8-719-914-43	DIODE DAN202K					
D121	8-719-800-76	DIODE 1SS226					
D501	8-719-801-78	DIODE 1SS184					
D511	8-719-801-78	DIODE 1SS184					
D512	8-719-422-12	DIODE MA8039					
D525	8-719-801-78	DIODE 1SS184					
D527	8-719-801-78	DIODE 1SS184					
D581	8-719-801-78	DIODE 1SS184					
D611	8-719-800-76	DIODE 1SS226					
D612	8-719-801-78	DIODE 1SS184					
D615	8-719-800-76	DIODE 1SS226					
D625	8-719-800-76	DIODE 1SS226					
D650	8-719-056-73	DIODE UDZ-TE-17-2.7B					
D651	8-719-800-76	DIODE 1SS226					
D652	8-719-800-76	DIODE 1SS226					
D667	8-719-977-28	DIODE DTZ10B					
D672	8-719-800-76	DIODE 1SS226					
D691	8-719-056-73	DIODE UDZ-TE-17-2.7B					
D710	8-719-801-78	DIODE 1SS184					
D726	8-719-109-93	DIODE RD6.2ESB2					
D737	8-719-800-76	DIODE 1SS226					
D738	8-719-104-34	DIODE 1S2836					
D751	8-719-056-73	DIODE UDZ-TE-17-2.7B					
D787	8-719-977-28	DIODE DTZ10B					
	<FILTER>						
FL11	1-233-512-21	FERRITE 37μH					
FL12	1-233-512-21	FERRITE 37μH					
FL21	1-233-512-21	FERRITE 37μH					
FL101	1-233-512-21	FERRITE 37μH					
FL102	1-233-512-21	FERRITE 37μH					
FL103	1-233-512-21	FERRITE 37μH					
FL104	1-233-512-21	FERRITE 37μH					
FL111	1-233-283-11	FILTER, EMI (SMD)					
FL112	1-233-283-11	FILTER, EMI (SMD)					
FL113	1-233-283-11	FILTER, EMI (SMD)					
FL114	1-233-283-11	FILTER, EMI (SMD)					
	<IC>						
IC12	8-759-460-81	IC BA12FP-E2					

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
Q726	8-729-129-54	TRANSISTOR 2SC2954		R501	1-216-033-00	RES,CHIP 220	5% 1/10W
Q733	8-729-129-54	TRANSISTOR 2SC2954		R502	1-216-643-11	METAL CHIP 470	0.50% 1/10W
Q736	8-729-033-16	TRANSISTOR 2SA1669-TB		R503	1-216-033-00	RES,CHIP 220	5% 1/10W
Q738	8-729-112-65	TRANSISTOR 2SA1462-T1Y33		R504	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q741	8-729-112-65	TRANSISTOR 2SA1462-T1Y33		R505	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
Q751	8-729-143-46	TRANSISTOR 2SC3356-R24		R506	1-216-045-00	RES,CHIP 680	5% 1/10W
Q752	8-729-033-16	TRANSISTOR 2SA1669-TB		R507	1-216-045-00	RES,CHIP 680	5% 1/10W
Q781	8-729-116-05	TRANSISTOR 2SK160-K5		R508	1-216-045-00	RES,CHIP 680	5% 1/10W
Q797	8-729-230-49	TRANSISTOR 2SC2712-YG		R509	1-216-045-00	RES,CHIP 680	5% 1/10W
<RESISTOR>				R510	1-216-017-91	RES,CHIP 47	5% 1/10W
R51	1-216-073-00	RES,CHIP 10K	5% 1/10W	R511	1-216-033-00	RES,CHIP 220	5% 1/10W
R63	1-216-073-00	RES,CHIP 10K	5% 1/10W	R521	1-216-643-11	METAL CHIP 470	0.50% 1/10W
R75	1-216-295-91	SHORT 0		R523	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
R76	1-216-295-91	SHORT 0		R524	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R82	1-216-049-91	RES,CHIP 1K	5% 1/10W	R525	1-216-081-00	RES,CHIP 22K	5% 1/10W
R83	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	R526	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
R84	1-216-025-91	RES,CHIP 100	5% 1/10W	R527	1-216-073-00	RES,CHIP 10K	5% 1/10W
R85	1-216-025-91	RES,CHIP 100	5% 1/10W	R540	1-216-033-00	RES,CHIP 220	5% 1/10W
R101	1-216-631-11	METAL CHIP 150	0.50% 1/10W	R541	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
R102	1-216-631-11	METAL CHIP 150	0.50% 1/10W	R542	1-216-071-00	RES,CHIP 8.2K	5% 1/10W
R103	1-216-017-91	RES,CHIP 47	5% 1/10W	R551	1-216-051-00	RES,CHIP 1.2K	5% 1/10W
R105	1-216-642-11	METAL CHIP 430	0.50% 1/10W	R552	1-216-075-00	RES,CHIP 12K	5% 1/10W
R106	1-216-643-11	METAL CHIP 470	0.50% 1/10W	R553	1-216-033-00	RES,CHIP 220	5% 1/10W
R121	1-216-017-91	RES,CHIP 47	5% 1/10W	R554	1-220-273-11	RES,CHIP 1K	5% 1/2W
R131	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R560	1-216-049-91	RES,CHIP 1K	5% 1/10W
R132	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W	R561	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R133	1-216-033-00	RES,CHIP 220	5% 1/10W	R562	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R135	1-216-647-11	METAL CHIP 680	0.50% 1/10W	R563	1-216-033-00	RES,CHIP 220	5% 1/10W
R136	1-216-647-11	METAL CHIP 680	0.50% 1/10W	R564	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W
R140	1-216-049-91	RES,CHIP 1K	5% 1/10W	R566	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R141	1-216-121-91	RES,CHIP 1M	5% 1/10W	R567	1-216-049-91	RES,CHIP 1K	5% 1/10W
R142	1-216-025-91	RES,CHIP 100	5% 1/10W	R571	1-216-049-91	RES,CHIP 1K	5% 1/10W
R143	1-216-025-91	RES,CHIP 100	5% 1/10W	R572	1-216-049-91	RES,CHIP 1K	5% 1/10W
R145	1-216-677-11	METAL CHIP 12K	0.50% 1/10W	R573	1-216-049-91	RES,CHIP 1K	5% 1/10W
R146	1-216-683-11	METAL CHIP 22K	0.50% 1/10W	R581	1-216-033-00	RES,CHIP 220	5% 1/10W
R147	1-216-295-91	SHORT 0		R591	1-216-017-91	RES,CHIP 47	5% 1/10W
R148	1-216-049-91	RES,CHIP 1K	5% 1/10W	R592	1-216-295-91	SHORT 0	
R151	1-216-073-00	RES,CHIP 10K	5% 1/10W	R593	1-216-295-91	SHORT 0	
R155	1-216-057-00	RES,CHIP 2.2K	5% 1/10W	R595	1-216-043-91	RES,CHIP 560	5% 1/10W
R171	1-216-025-91	RES,CHIP 100	5% 1/10W	R596	1-216-295-91	SHORT 0	
R172	1-216-049-91	RES,CHIP 1K	5% 1/10W	R605	1-216-033-00	RES,CHIP 220	5% 1/10W
R173	1-216-051-00	RES,CHIP 1.2K	5% 1/10W	R606	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
R174	1-216-025-91	RES,CHIP 100	5% 1/10W	R607	1-216-017-91	RES,CHIP 47	5% 1/10W
R180	1-216-025-91	RES,CHIP 100	5% 1/10W	R609	1-216-295-91	SHORT 0	
R182	1-216-049-91	RES,CHIP 1K	5% 1/10W	R610	1-216-017-91	RES,CHIP 47	5% 1/10W
R183	1-216-049-91	RES,CHIP 1K	5% 1/10W	R616	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W
R184	1-216-025-91	RES,CHIP 100	5% 1/10W	R617	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
R441	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	R618	1-216-025-91	RES,CHIP 100	5% 1/10W
R445	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	R619	1-216-631-11	METAL CHIP 150	0.50% 1/10W
R446	1-216-025-91	RES,CHIP 100	5% 1/10W	R621	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
R447	1-216-001-00	RES,CHIP 10	5% 1/10W	R622	1-216-627-11	METAL CHIP 100	0.50% 1/10W
R448	1-216-025-91	RES,CHIP 100	5% 1/10W	R625	1-216-033-00	RES,CHIP 220	5% 1/10W
R451	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	R631	1-216-017-91	RES,CHIP 47	5% 1/10W
R455	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	R632	1-216-627-11	METAL CHIP 100	0.50% 1/10W
R456	1-216-025-91	RES,CHIP 100	5% 1/10W	R633	1-216-627-11	METAL CHIP 100	0.50% 1/10W
R457	1-216-001-00	RES,CHIP 10	5% 1/10W	R635	1-216-641-11	METAL CHIP 390	0.50% 1/10W
R458	1-216-025-91	RES,CHIP 100	5% 1/10W	R636	1-216-635-11	METAL CHIP 220	0.50% 1/10W
				R645	1-216-001-00	RES,CHIP 10	5% 1/10W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R646	1-216-073-00	RES,CHIP 10K	5% 1/10W	R745	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
R647	1-216-033-00	RES,CHIP 220	5% 1/10W	R746	1-216-669-11	METAL CHIP 5.6K	0.50% 1/10W
R648	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W	R751	1-216-017-91	RES,CHIP 47	5% 1/10W
R649	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W	R752	1-216-017-91	RES,CHIP 47	5% 1/10W
R650	1-216-639-11	METAL CHIP 330	0.50% 1/10W	R753	1-216-001-00	RES,CHIP 10	5% 1/10W
R651	1-216-017-91	RES,CHIP 47	5% 1/10W	R754	1-216-635-11	METAL CHIP 220	0.50% 1/10W
R653	1-216-635-11	METAL CHIP 220	0.50% 1/10W	R755	1-216-635-11	METAL CHIP 220	0.50% 1/10W
R654	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R756	1-216-001-00	RES,CHIP 10	5% 1/10W
R655	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R757	1-216-001-00	RES,CHIP 10	5% 1/10W
R656	1-216-635-11	METAL CHIP 220	0.50% 1/10W	R758	1-220-273-11	RES,CHIP 1K	5% 1/2W
R657	1-216-033-00	RES,CHIP 220	5% 1/10W	R759	1-220-273-11	RES,CHIP 1K	5% 1/2W
R658	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W	R781	1-216-049-91	RES,CHIP 1K	5% 1/10W
R659	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W	R782	1-216-121-91	RES,CHIP 1M	5% 1/10W
R661	1-216-049-91	RES,CHIP 1K	5% 1/10W	R783	1-216-049-91	RES,CHIP 1K	5% 1/10W
R665	1-216-121-91	RES,CHIP 1M	5% 1/10W	R784	1-216-677-11	METAL CHIP 12K	0.50% 1/10W
R666	1-216-049-91	RES,CHIP 1K	5% 1/10W	R785	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
R667	1-216-073-00	RES,CHIP 10K	5% 1/10W	R786	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R668	1-216-049-91	RES,CHIP 1K	5% 1/10W	R787	1-216-049-91	RES,CHIP 1K	5% 1/10W
R669	1-216-081-00	RES,CHIP 22K	5% 1/10W	R789	1-216-049-91	RES,CHIP 1K	5% 1/10W
R672	1-216-025-91	RES,CHIP 100	5% 1/10W	R791	1-216-073-00	RES,CHIP 10K	5% 1/10W
R675	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R795	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R676	1-216-001-00	RES,CHIP 10	5% 1/10W	R796	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R681	1-216-677-11	METAL CHIP 12K	0.50% 1/10W	R797	1-216-025-91	RES,CHIP 100	5% 1/10W
R683	1-216-669-11	METAL CHIP 5.6K	0.50% 1/10W	R798	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
R691	1-216-017-91	RES,CHIP 47	5% 1/10W				
R692	1-216-017-91	RES,CHIP 47	5% 1/10W			<RESISTOR BLOCK>	
R693	1-216-001-00	RES,CHIP 10	5% 1/10W	RB51	1-233-576-11	RES, CHIP	NETWORK 100
R695	1-216-001-00	RES,CHIP 10	5% 1/10W	RB71	1-233-414-11	RES, CHIP	NETWORK 4.7K (3216)
R696	1-216-001-00	RES,CHIP 10	5% 1/10W	RB72	1-233-576-11	RES, CHIP	NETWORK 100
R698	1-220-273-11	RES,CHIP 1K	5% 1/2W	RB81	1-233-576-11	RES, CHIP	NETWORK 100
R699	1-220-273-11	RES,CHIP 1K	5% 1/2W				
R701	1-216-017-91	RES,CHIP 47	5% 1/10W			<VARIABLE RESISTOR>	
R704	1-216-635-11	METAL CHIP 220	0.50% 1/10W	RV145	1-230-871-11	RES, ADJ, METAL GLAZE	22K
R710	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	RV622	1-238-785-21	RES, ADJ, CERMET	2K
R711	1-216-637-11	METAL CHIP 270	0.50% 1/10W	RV623	1-238-783-11	RES, ADJ, CERMET	500
R712	1-216-635-11	METAL CHIP 220	0.50% 1/10W	RV682	1-238-786-11	RES, ADJ, CERMET	5K
R717	1-216-627-11	METAL CHIP 100	0.50% 1/10W	RV718	1-238-785-21	RES, ADJ, CERMET	2K
R719	1-216-643-11	METAL CHIP 470	0.50% 1/10W				
R720	1-216-635-11	METAL CHIP 220	0.50% 1/10W	RV785	1-238-786-11	RES, ADJ, CERMET	5K
R721	1-216-017-91	RES,CHIP 47	5% 1/10W	RV796	1-230-871-11	RES, ADJ, METAL GLAZE	22K
R722	1-216-057-00	RES,CHIP 2.2K	5% 1/10W				
R723	1-216-025-91	RES,CHIP 100	5% 1/10W			<TEST PIN>	
R724	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W	TP21	1-535-757-11	CHIP, CHECKER	
R725	1-216-657-11	METAL CHIP 1.8K	0.50% 1/10W	TP22	1-535-757-11	CHIP, CHECKER	
R726	1-216-017-91	RES,CHIP 47	5% 1/10W	TP23	1-535-757-11	CHIP, CHECKER	
R727	1-216-017-91	RES,CHIP 47	5% 1/10W	TP24	1-535-757-11	CHIP, CHECKER	
R731	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W	TP34	1-535-757-11	CHIP, CHECKER	
R732	1-216-669-11	METAL CHIP 5.6K	0.50% 1/10W	TP35	1-535-757-11	CHIP, CHECKER	
R733	1-216-025-91	RES,CHIP 100	5% 1/10W	TP71	1-535-757-11	CHIP, CHECKER	
R734	1-220-269-11	RES,CHIP 330	5% 1/2W	TP72	1-535-757-11	CHIP, CHECKER	
R735	1-220-274-11	RES,CHIP 1.2K	5% 1/2W	TP73	1-535-757-11	CHIP, CHECKER	
R736	1-216-017-91	RES,CHIP 47	5% 1/10W	TP501	1-535-757-11	CHIP, CHECKER	
R737	1-220-274-11	RES,CHIP 1.2K	5% 1/2W				
R738	1-216-033-00	RES,CHIP 220	5% 1/10W	TP511	1-535-757-11	CHIP, CHECKER	
R739	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W	TP691	1-535-757-11	CHIP, CHECKER	
R740	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W	TP751	1-535-757-11	CHIP, CHECKER	
R741	1-216-033-00	RES,CHIP 220	5% 1/10W				
R742	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W				
R743	1-216-651-11	METAL CHIP 1K	0.50% 1/10W				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
*****				C973	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C974	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C977	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C982	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
*****				C991	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C992	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C993	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C995	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
*****				C996	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C997	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C998	1-164-506-11	CERAMIC CHIP 4.7μF	16V
*****				C999	1-164-506-11	CERAMIC CHIP 4.7μF	16V
*****				C1000	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C1002	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C1201	1-107-943-11	ELECT 10μF	20% 160V
*****				C1210	1-107-943-11	ELECT 10μF	20% 160V
*****				C1211	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
*****				C1212	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C1213	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C1214	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C1215	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
*****				C1221	1-107-943-11	ELECT 10μF	20% 160V
*****				<CONNECTOR>			
*****				CN264	* 1-564-726-11	PIN, CONNECTOR (SMALL TYPE)10P	
*****				CN265	* 1-564-507-11	PLUG, CONNECTOR 4P	
*****				CN266	* 1-564-507-11	PLUG, CONNECTOR 4P	
*****				CN269	* 1-564-518-11	PLUG, CONNECTOR 3P	
*****				CN270	* 1-785-522-11	PIN, CONNECTOR (PC BOARD) 18P	
*****				<DIODE>			
*****				D801	8-719-800-76	DIODE 1SS226	
*****				D806	8-719-978-04	DIODE DTZ-TT11-3.3B	
*****				D811	8-719-901-83	DIODE 1SS83	
*****				D812	8-719-901-83	DIODE 1SS83	
*****				D820	8-719-800-76	DIODE 1SS226	
*****				D821	8-719-106-53	DIODE RD10M-B2	
*****				D831	8-719-107-24	DIODE RD20M-B2	
*****				D832	8-719-901-83	DIODE 1SS83	
*****				D833	8-719-901-83	DIODE 1SS83	
*****				D841	8-719-901-83	DIODE 1SS83	
*****				D842	8-719-901-83	DIODE 1SS83	
*****				D851	8-719-914-43	DIODE DAN202K	
*****				D861	8-719-914-43	DIODE DAN202K	
*****				D901	8-719-800-76	DIODE 1SS226	
*****				D906	8-719-978-04	DIODE DTZ-TT11-3.3B	
*****				D941	8-719-901-83	DIODE 1SS83	
*****				D942	8-719-901-83	DIODE 1SS83	
*****				D945	8-719-018-98	DIODE 1SS311(TE85L)	
*****				D955	8-719-800-76	DIODE 1SS226	
*****				D956	8-719-106-53	DIODE RD10M-B2	
*****				D960	8-719-801-78	DIODE 1SS184	
*****				D961	8-719-800-76	DIODE 1SS226	
*****				D965	8-719-105-82	DIODE RD5.1M-B2	
*****				D981	8-719-106-53	DIODE RD10M-B2	
*****				D982	8-719-800-76	DIODE 1SS226	
*****				D1001	8-719-976-96	DIODE DTZ4.7C	
*****				<CAPACITOR>			
C800	1-128-304-11	ELECT CHIP 330μF	20% 16V	*****			
C801	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C802	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	*****			
C803	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	*****			
C805	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C811	1-124-779-00	ELECT CHIP 10μF	20% 16V	*****			
C812	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C815	1-163-251-11	CERAMIC CHIP 100PF	5% 50V	*****			
C816	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V	*****			
C817	1-163-121-00	CERAMIC CHIP 150PF	5% 50V	*****			
C818	1-162-117-00	CERAMIC 100PF	10% 500V	*****			
C820	1-107-961-91	ELECT 10μF	20% 250V	*****			
C821	1-102-050-00	CERAMIC 0.01μF	99% 500V	*****			
C822	1-107-943-11	ELECT 10μF	20% 160V	*****			
C823	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C824	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C826	1-126-397-11	ELECT CHIP 33μF	20% 25V	*****			
C827	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C828	1-164-506-11	CERAMIC CHIP 4.7μF	16V	*****			
C829	1-164-506-11	CERAMIC CHIP 4.7μF	16V	*****			
C830	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C832	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C833	1-102-050-00	CERAMIC 0.01μF	99% 500V	*****			
C834	1-107-961-91	ELECT 10μF	20% 250V	*****			
C851	1-110-648-11	ELECT CHIP 220μF	20% 25V	*****			
C852	1-128-304-11	ELECT CHIP 330μF	20% 16V	*****			
C853	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C854	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	*****			
C862	1-128-304-11	ELECT CHIP 330μF	20% 16V	*****			
C901	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C902	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C903	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C904	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	*****			
C905	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C906	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	*****			
C911	1-124-779-00	ELECT CHIP 10μF	20% 16V	*****			
C912	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C913	1-163-249-11	CERAMIC CHIP 82PF	5% 50V	*****			
C914	1-163-235-11	CERAMIC CHIP 22PF	5% 50V	*****			
C915	1-163-243-11	CERAMIC CHIP 47PF	5% 50V	*****			
C953	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C954	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	*****			
C956	1-162-117-00	CERAMIC 100PF	10% 500V	*****			
C957	1-102-050-00	CERAMIC 0.01μF	99% 500V	*****			
C958	1-107-943-11	ELECT 10μF	20% 160V	*****			
C961	1-102-038-00	CERAMIC 0.001μF	500V	*****			
C962	1-163-275-11	CERAMIC CHIP 0.001μF	5% 50V	*****			
C965	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C968	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C969	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C970	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	*****			
C971	1-124-779-00	ELECT CHIP 10μF	20% 16V	*****			

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
D1211	8-719-800-76	DIODE 1SS226		<RESISTOR>			
D1215	8-719-106-53	DIODE RD10M-B2		R801	1-216-017-91	RES,CHIP 47 5% 1/10W	
<FILTER>				R802	1-216-033-00	RES,CHIP 220 5% 1/10W	
FL1001	1-233-831-11	FILTER, EMI		R803	1-216-025-91	RES,CHIP 100 5% 1/10W	
FL1002	1-233-831-11	FILTER, EMI		R804	1-216-653-11	METAL CHIP 1.2K 0.50% 1/10W	
FL1011	1-233-512-21	FERRITE 37μH		R805	1-216-667-11	METAL CHIP 4.7K 0.50% 1/10W	
FL1012	1-233-512-21	FERRITE 37μH		R806	1-216-017-91	RES,CHIP 47 5% 1/10W	
FL1013	1-233-512-21	FERRITE 37μH		R807	1-216-017-91	RES,CHIP 47 5% 1/10W	
FL1014	1-233-512-21	FERRITE 37μH		R808	1-216-001-00	RES,CHIP 10 5% 1/10W	
<IC>				R809	1-216-001-00	RES,CHIP 10 5% 1/10W	
IC801	8-749-014-86	IC VPJ15H		R810	1-216-001-00	RES,CHIP 10 5% 1/10W	
IC802	8-759-710-78	IC NJM082BM-T1		R811	1-216-627-11	METAL CHIP 100 0.50% 1/10W	
IC851	8-759-460-81	IC BA12FP-E2		R814	1-216-619-11	METAL CHIP 47 0.50% 1/10W	
IC861	8-759-335-28	IC TA78M09F(TE16L)		R815	1-249-401-11	CARBON 47 5% 1/4W F	
IC901	8-749-014-86	IC VPJ15H		R819	1-216-033-00	RES,CHIP 220 5% 1/10W	
IC902	8-759-381-53	IC UPC814G2-E2		R820	1-216-049-91	RES,CHIP 1K 5% 1/10W	
IC961	8-749-011-45	IC NJL5152MD		R821	1-215-485-00	METAL 470K 1% 1/4W	
IC971	8-759-710-78	IC NJM082BM-T1		R822	1-215-485-00	METAL 470K 1% 1/4W	
IC981	8-759-234-77	IC TC4S66F		R823	1-215-461-00	METAL 47K 1% 1/4W	
IC990	8-759-710-78	IC NJM082BM-T1		R824	1-216-121-91	RES,CHIP 1M 5% 1/10W	
IC998	8-759-710-78	IC NJM082BM-T1		R825	1-216-025-91	RES,CHIP 100 5% 1/10W	
IC1211	8-759-198-34	IC TA75S558F		R826	1-216-075-00	RES,CHIP 12K 5% 1/10W	
<COIL>				R827	1-216-667-11	METAL CHIP 4.7K 0.50% 1/10W	
L801	1-412-533-21	INDUCTOR 47μH		R828	1-216-675-11	METAL CHIP 10K 0.50% 1/10W	
L818	1-414-137-31	INDUCTOR 0.22μH		R829	1-216-057-00	RES,CHIP 2.2K 5% 1/10W	
L951	1-412-533-21	INDUCTOR 47μH		R830	1-216-667-11	METAL CHIP 4.7K 0.50% 1/10W	
L954	1-414-137-31	INDUCTOR 0.22μH		R831	1-215-461-00	METAL 47K 1% 1/4W	
L955	1-414-137-31	INDUCTOR 0.22μH		R832	1-249-417-11	CARBON 1K 5% 1/4W	
L956	1-414-137-31	INDUCTOR 0.22μH		R833	1-249-417-11	CARBON 1K 5% 1/4W	
L957	1-414-137-31	INDUCTOR 0.22μH		R841	1-215-477-00	METAL 220K 1% 1/4W	
<TRANSISTOR>				R851	1-220-274-11	RES,CHIP 1.2K 5% 1/2W	
Q801	8-729-033-16	TRANSISTOR 2SA1669-TB		R852	1-220-274-11	RES,CHIP 1.2K 5% 1/2W	
Q802	8-729-112-65	TRANSISTOR 2SA1462-T1Y33		R901	1-216-017-91	RES,CHIP 47 5% 1/10W	
Q806	8-729-145-13	TRANSISTOR 2SC3356-(R25)		R902	1-216-033-00	RES,CHIP 220 5% 1/10W	
Q807	8-729-033-16	TRANSISTOR 2SA1669-TB		R903	1-216-025-91	RES,CHIP 100 5% 1/10W	
Q815	8-729-116-05	TRANSISTOR 2SK160-K5		R904	1-216-653-11	METAL CHIP 1.2K 0.50% 1/10W	
Q819	8-729-801-88	TRANSISTOR 2SA1381-E		R905	1-216-667-11	METAL CHIP 4.7K 0.50% 1/10W	
Q821	8-729-821-02	TRANSISTOR 2SC3503-DE		R906	1-216-017-91	RES,CHIP 47 5% 1/10W	
Q901	8-729-033-16	TRANSISTOR 2SA1669-TB		R907	1-216-017-91	RES,CHIP 47 5% 1/10W	
Q902	8-729-112-65	TRANSISTOR 2SA1462-T1Y33		R908	1-216-001-00	RES,CHIP 10 5% 1/10W	
Q906	8-729-145-13	TRANSISTOR 2SC3356-(R25)		R909	1-216-001-00	RES,CHIP 10 5% 1/10W	
Q907	8-729-033-16	TRANSISTOR 2SA1669-TB		R910	1-216-001-00	RES,CHIP 10 5% 1/10W	
Q948	8-729-804-63	TRANSISTOR 2SA1406-E		R911	1-216-627-11	METAL CHIP 100 0.50% 1/10W	
Q961	1-801-806-11	TRANSISTOR DTC144EKA-T146		R912	1-216-619-11	METAL CHIP 47 0.50% 1/10W	
Q974	8-729-230-49	TRANSISTOR 2SC2712-YG		R919	1-216-033-00	RES,CHIP 220 5% 1/10W	
Q1204	8-729-821-02	TRANSISTOR 2SC3503-DE		R921	1-215-485-00	METAL 470K 1% 1/4W	
Q1210	8-729-111-07	TRANSISTOR 2SD1590-L		R922	1-215-485-00	METAL 470K 1% 1/4W	
				R923	1-215-445-00	METAL 10K 1% 1/4W	
				R924	1-216-049-91	RES,CHIP 1K 5% 1/10W	
				R925	1-216-025-91	RES,CHIP 100 5% 1/10W	
				R951	1-220-274-11	RES,CHIP 1.2K 5% 1/2W	
				R952	1-220-274-11	RES,CHIP 1.2K 5% 1/2W	
				R955	1-249-401-11	CARBON 47 5% 1/4W F	
				R957	1-215-493-00	METAL 1M 1% 1/4W	
				R958	1-219-741-91	CARBON 10 5% 1/2W	
				R959	1-219-743-11	CARBON 100 5% 1/2W	
				R960	1-216-649-11	METAL CHIP 820 0.50% 1/10W	
				R961	1-216-683-11	METAL CHIP 22K 0.50% 1/10W	

[illegible]

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C525	1-126-394-11	ELECT CHIP 10μF	20% 16V	C732	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C526	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C737	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C738	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C527	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C745	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C540	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C551	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C751	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C552	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C752	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
C560	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C755	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
				C756	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C561	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C758	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C562	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C571	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C759	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C572	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C760	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C573	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C781	1-164-222-11	CERAMIC CHIP 0.22μF	25V
				C784	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C591	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C785	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C592	1-104-913-11	TANTAL. CHIP 10μF	10% 16V				
C593	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C787	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C594	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	C789	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C606	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C791	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
				C793	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V
C610	1-104-607-11	ELECT CHIP 47μF	20% 16V	C796	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
C611	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C612	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	<CONNECTOR>			
C617	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	CN280	* 1-760-388-11	CONNECTOR PIN (SMD) 9 PIN	
C621	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	CN282	* 1-691-551-11	PIN, CONNECTOR (SMD) 8P	
				CN283	1-569-516-11	PIN, CONNECTOR 18P	
C622	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C631	1-126-767-11	ELECT 1000μF	20% 16V	<DIODE>			
C632	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D12	8-719-914-43	DIODE DAN202K	
C636	1-163-089-00	CERAMIC CHIP 6PF	0.5PF 50V	D16	8-719-914-43	DIODE DAN202K	
C638	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D22	8-719-914-43	DIODE DAN202K	
				D24	8-719-914-43	DIODE DAN202K	
C639	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	D121	8-719-800-76	DIODE 1SS226	
C646	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C647	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D501	8-719-801-78	DIODE 1SS184	
C648	1-104-607-11	ELECT CHIP 47μF	20% 16V	D511	8-719-801-78	DIODE 1SS184	
C649	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	D512	8-719-422-12	DIODE MA8039	
				D525	8-719-801-78	DIODE 1SS184	
C651	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D527	8-719-801-78	DIODE 1SS184	
C652	1-104-913-11	TANTAL. CHIP 10μF	10% 16V				
C655	1-104-607-11	ELECT CHIP 47μF	20% 16V	D581	8-719-801-78	DIODE 1SS184	
C656	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D611	8-719-800-76	DIODE 1SS226	
C658	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D612	8-719-801-78	DIODE 1SS184	
				D615	8-719-800-76	DIODE 1SS226	
C665	1-164-222-11	CERAMIC CHIP 0.22μF	25V	D625	8-719-800-76	DIODE 1SS226	
C667	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C669	1-107-823-11	CERAMIC CHIP 0.47μF	10% 16V	D650	8-719-056-73	DIODE UDZ-TE-17-2.7B	
C671	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D651	8-719-800-76	DIODE 1SS226	
C672	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D652	8-719-800-76	DIODE 1SS226	
				D667	8-719-977-28	DIODE DTZ10B	
C681	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D672	8-719-800-76	DIODE 1SS226	
C683	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C691	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	D691	8-719-056-73	DIODE UDZ-TE-17-2.7B	
C692	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D710	8-719-801-78	DIODE 1SS184	
C698	1-104-913-11	TANTAL. CHIP 10μF	10% 16V	D726	8-719-109-93	DIODE RD6.2ESB2	
				D737	8-719-800-76	DIODE 1SS226	
C699	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D738	8-719-104-34	DIODE 1S2836	
C701	1-107-781-11	ELECT CHIP 47μF	20% 16V				
C702	1-104-607-11	ELECT CHIP 47μF	20% 16V	D751	8-719-056-73	DIODE UDZ-TE-17-2.7B	
C703	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D787	8-719-977-28	DIODE DTZ10B	
C712	1-163-091-00	CERAMIC CHIP 8PF	0.25PF50V				
				<FILTER>			
C718	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	FL11	1-233-512-21	FERRITE 37μH	
C719	1-104-913-11	TANTAL. CHIP 10μF	10% 16V				
C722	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C725	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C726	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V				
C727	1-104-913-11	TANTAL. CHIP 10μF	10% 16V				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
FL12	1-233-512-21	FERRITE 37μH		Q618	8-729-112-65	TRANSISTOR 2SA1462-T1Y33	
FL21	1-233-512-21	FERRITE 37μH		Q625	8-729-143-46	TRANSISTOR 2SC3356-R24	
FL101	1-233-512-21	FERRITE 37μH		Q631	8-729-143-46	TRANSISTOR 2SC3356-R24	
FL102	1-233-512-21	FERRITE 37μH		Q645	8-729-033-16	TRANSISTOR 2SA1669-TB	
FL103	1-233-512-21	FERRITE 37μH		Q647	8-729-107-31	TRANSISTOR 2SC3545-T43	
FL104	1-233-512-21	FERRITE 37μH		Q651	8-729-143-46	TRANSISTOR 2SC3356-R24	
FL111	1-233-283-11	FILTER, EMI (SMD)		Q656	8-729-129-54	TRANSISTOR 2SC2954	
FL112	1-233-283-11	FILTER, EMI (SMD)		Q665	8-729-116-05	TRANSISTOR 2SK160-K5	
FL113	1-233-283-11	FILTER, EMI (SMD)		Q671	8-729-107-31	TRANSISTOR 2SC3545-T43	
FL114	1-233-283-11	FILTER, EMI (SMD)		Q691	8-729-143-46	TRANSISTOR 2SC3356-R24	
	<IC>			Q692	8-729-033-16	TRANSISTOR 2SA1669-TB	
IC12	8-759-460-81	IC BA12FP-E2		Q701	8-729-129-54	TRANSISTOR 2SC2954	
IC16	8-759-460-74	IC BA05FP-E2		Q721	8-729-143-46	TRANSISTOR 2SC3356-R24	
IC22	8-759-549-53	IC LM2990SX-12		Q723	8-729-107-31	TRANSISTOR 2SC3545-T43	
IC24	8-759-045-17	IC NJM79L05UA		Q726	8-729-129-54	TRANSISTOR 2SC2954	
IC101	8-759-541-88	IC EPM7064STC44-10-PULSE		Q733	8-729-129-54	TRANSISTOR 2SC2954	
IC102	8-759-564-62	IC MAX4224ESA-TG06		Q736	8-729-033-16	TRANSISTOR 2SA1669-TB	
IC141	8-759-381-53	IC UPC814G2-E2		Q738	8-729-112-65	TRANSISTOR 2SA1462-T1Y33	
IC171	8-759-392-64	IC AD828AR		Q741	8-729-112-65	TRANSISTOR 2SA1462-T1Y33	
IC560	8-759-710-78	IC NJM082BM-T1		Q751	8-729-143-46	TRANSISTOR 2SC3356-R24	
IC570	8-759-082-61	IC TC4W53FU		Q752	8-729-033-16	TRANSISTOR 2SA1669-TB	
IC595	8-759-542-11	IC MAX4223ESA-TG06		Q781	8-729-116-05	TRANSISTOR 2SK160-K5	
IC661	8-759-381-53	IC UPC814G2-E2		Q797	8-729-230-49	TRANSISTOR 2SC2712-YG	
IC781	8-759-381-53	IC UPC814G2-E2			<RESISTOR>		
	<JACK>			R51	1-216-073-00	RES,CHIP 10K 5% 1/10W	
J280	1-568-547-11	JACK, MINIATUER PIN		R63	1-216-073-00	RES,CHIP 10K 5% 1/10W	
	<COIL>			R75	1-216-295-91	SHORT 0	
L648	1-412-066-21	INDUCTOR CHIP 220μH		R76	1-216-295-91	SHORT 0	
	<TRANSISTOR>			R82	1-216-049-91	RES,CHIP 1K 5% 1/10W	
Q121	8-729-033-16	TRANSISTOR 2SA1669-TB		R83	1-216-065-91	RES,CHIP 4.7K 5% 1/10W	
Q133	8-729-112-65	TRANSISTOR 2SA1462-T1Y33		R84	1-216-025-91	RES,CHIP 100 5% 1/10W	
Q141	8-729-116-05	TRANSISTOR 2SK160-K5		R85	1-216-025-91	RES,CHIP 100 5% 1/10W	
Q441	8-729-107-31	TRANSISTOR 2SC3545-T43		R101	1-216-631-11	METAL CHIP 150 0.50% 1/10W	
Q446	8-729-107-31	TRANSISTOR 2SC3545-T43		R102	1-216-631-11	METAL CHIP 150 0.50% 1/10W	
Q447	8-729-216-22	TRANSISTOR 2SA1162-G		R103	1-216-017-91	RES,CHIP 47 5% 1/10W	
Q451	8-729-107-31	TRANSISTOR 2SC3545-T43		R105	1-216-642-11	METAL CHIP 430 0.50% 1/10W	
Q456	8-729-107-31	TRANSISTOR 2SC3545-T43		R106	1-216-643-11	METAL CHIP 470 0.50% 1/10W	
Q457	8-729-216-22	TRANSISTOR 2SA1162-G		R121	1-216-017-91	RES,CHIP 47 5% 1/10W	
Q501	8-729-033-16	TRANSISTOR 2SA1669-TB		R131	1-216-659-11	METAL CHIP 2.2K 0.50% 1/10W	
Q502	8-729-112-65	TRANSISTOR 2SA1462-T1Y33		R132	1-216-667-11	METAL CHIP 4.7K 0.50% 1/10W	
Q510	8-729-129-54	TRANSISTOR 2SC2954		R133	1-216-033-00	RES,CHIP 220 5% 1/10W	
Q511	8-729-129-54	TRANSISTOR 2SC2954		R135	1-216-647-11	METAL CHIP 680 0.50% 1/10W	
Q525	8-729-107-31	TRANSISTOR 2SC3545-T43		R136	1-216-647-11	METAL CHIP 680 0.50% 1/10W	
Q527	8-729-230-49	TRANSISTOR 2SC2712-YG		R140	1-216-049-91	RES,CHIP 1K 5% 1/10W	
Q540	8-729-216-22	TRANSISTOR 2SA1162-G		R141	1-216-121-91	RES,CHIP 1M 5% 1/10W	
Q551	8-729-129-54	TRANSISTOR 2SC2954		R142	1-216-025-91	RES,CHIP 100 5% 1/10W	
Q563	8-729-230-49	TRANSISTOR 2SC2712-YG		R143	1-216-025-91	RES,CHIP 100 5% 1/10W	
Q581	8-729-112-65	TRANSISTOR 2SA1462-T1Y33		R145	1-216-677-11	METAL CHIP 12K 0.50% 1/10W	
Q605	8-729-107-31	TRANSISTOR 2SC3545-T43		R146	1-216-683-11	METAL CHIP 22K 0.50% 1/10W	
Q610	8-729-033-16	TRANSISTOR 2SA1669-TB		R147	1-216-295-91	SHORT 0	
				R148	1-216-049-91	RES,CHIP 1K 5% 1/10W	
				R151	1-216-073-00	RES,CHIP 10K 5% 1/10W	
				R155	1-216-057-00	RES,CHIP 2.2K 5% 1/10W	
				R171	1-216-025-91	RES,CHIP 100 5% 1/10W	
				R172	1-216-049-91	RES,CHIP 1K 5% 1/10W	
				R173	1-216-051-00	RES,CHIP 1.2K 5% 1/10W	
				R174	1-216-025-91	RES,CHIP 100 5% 1/10W	

Ref.No.	Part No.	Description	Remark			Ref.No.	Part No.	Description	Remark		
R180	1-216-025-91	RES,CHIP	100	5%	1/10W	R610	1-216-017-91	RES,CHIP	47	5%	1/10W
R182	1-216-049-91	RES,CHIP	1K	5%	1/10W	R616	1-216-653-11	METAL CHIP	1.2K	0.50%	1/10W
						R617	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
R183	1-216-049-91	RES,CHIP	1K	5%	1/10W	R618	1-216-025-91	RES,CHIP	100	5%	1/10W
R184	1-216-025-91	RES,CHIP	100	5%	1/10W						
R441	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R619	1-216-631-11	METAL CHIP	150	0.50%	1/10W
R445	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R621	1-216-659-11	METAL CHIP	2.2K	0.50%	1/10W
R446	1-216-025-91	RES,CHIP	100	5%	1/10W	R622	1-216-627-11	METAL CHIP	100	0.50%	1/10W
						R625	1-216-033-00	RES,CHIP	220	5%	1/10W
R447	1-216-001-00	RES,CHIP	10	5%	1/10W	R631	1-216-017-91	RES,CHIP	47	5%	1/10W
R448	1-216-025-91	RES,CHIP	100	5%	1/10W						
R451	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R632	1-216-627-11	METAL CHIP	100	0.50%	1/10W
R455	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R633	1-216-627-11	METAL CHIP	100	0.50%	1/10W
R456	1-216-025-91	RES,CHIP	100	5%	1/10W	R635	1-216-641-11	METAL CHIP	390	0.50%	1/10W
						R636	1-216-635-11	METAL CHIP	220	0.50%	1/10W
R457	1-216-001-00	RES,CHIP	10	5%	1/10W	R645	1-216-001-00	RES,CHIP	10	5%	1/10W
R458	1-216-025-91	RES,CHIP	100	5%	1/10W						
R501	1-216-033-00	RES,CHIP	220	5%	1/10W	R646	1-216-073-00	RES,CHIP	10K	5%	1/10W
R502	1-216-643-11	METAL CHIP	470	0.50%	1/10W	R647	1-216-033-00	RES,CHIP	220	5%	1/10W
R503	1-216-033-00	RES,CHIP	220	5%	1/10W	R648	1-216-653-11	METAL CHIP	1.2K	0.50%	1/10W
						R649	1-216-673-11	METAL CHIP	8.2K	0.50%	1/10W
R504	1-216-659-11	METAL CHIP	2.2K	0.50%	1/10W	R650	1-216-639-11	METAL CHIP	330	0.50%	1/10W
R505	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W						
R506	1-216-045-00	RES,CHIP	680	5%	1/10W	R651	1-216-017-91	RES,CHIP	47	5%	1/10W
R507	1-216-045-00	RES,CHIP	680	5%	1/10W	R653	1-216-635-11	METAL CHIP	220	0.50%	1/10W
R508	1-216-045-00	RES,CHIP	680	5%	1/10W	R654	1-216-627-11	METAL CHIP	100	0.50%	1/10W
						R655	1-216-627-11	METAL CHIP	100	0.50%	1/10W
R509	1-216-045-00	RES,CHIP	680	5%	1/10W	R656	1-216-635-11	METAL CHIP	220	0.50%	1/10W
R510	1-216-017-91	RES,CHIP	47	5%	1/10W						
R511	1-216-033-00	RES,CHIP	220	5%	1/10W	R657	1-216-033-00	RES,CHIP	220	5%	1/10W
R521	1-216-643-11	METAL CHIP	470	0.50%	1/10W	R658	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
R523	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R659	1-216-653-11	METAL CHIP	1.2K	0.50%	1/10W
						R661	1-216-049-91	RES,CHIP	1K	5%	1/10W
R524	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R665	1-216-121-91	RES,CHIP	1M	5%	1/10W
R525	1-216-081-00	RES,CHIP	22K	5%	1/10W						
R526	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R666	1-216-049-91	RES,CHIP	1K	5%	1/10W
R527	1-216-073-00	RES,CHIP	10K	5%	1/10W	R667	1-216-073-00	RES,CHIP	10K	5%	1/10W
R540	1-216-033-00	RES,CHIP	220	5%	1/10W	R668	1-216-049-91	RES,CHIP	1K	5%	1/10W
						R669	1-216-081-00	RES,CHIP	22K	5%	1/10W
R541	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R672	1-216-025-91	RES,CHIP	100	5%	1/10W
R542	1-216-071-00	RES,CHIP	8.2K	5%	1/10W						
R551	1-216-051-00	RES,CHIP	1.2K	5%	1/10W	R675	1-216-627-11	METAL CHIP	100	0.50%	1/10W
R552	1-216-075-00	RES,CHIP	12K	5%	1/10W	R676	1-216-001-00	RES,CHIP	10	5%	1/10W
R553	1-216-033-00	RES,CHIP	220	5%	1/10W	R681	1-216-677-11	METAL CHIP	12K	0.50%	1/10W
						R683	1-216-669-11	METAL CHIP	5.6K	0.50%	1/10W
R554	1-220-273-11	RES,CHIP	1K	5%	1/2W	R691	1-216-017-91	RES,CHIP	47	5%	1/10W
R560	1-216-049-91	RES,CHIP	1K	5%	1/10W						
R561	1-216-675-11	METAL CHIP	10K	0.50%	1/10W	R692	1-216-017-91	RES,CHIP	47	5%	1/10W
R562	1-216-675-11	METAL CHIP	10K	0.50%	1/10W	R693	1-216-001-00	RES,CHIP	10	5%	1/10W
R563	1-216-033-00	RES,CHIP	220	5%	1/10W	R695	1-216-001-00	RES,CHIP	10	5%	1/10W
						R696	1-216-001-00	RES,CHIP	10	5%	1/10W
R564	1-216-653-11	METAL CHIP	1.2K	0.50%	1/10W	R698	1-220-273-11	RES,CHIP	1K	5%	1/2W
R566	1-216-675-11	METAL CHIP	10K	0.50%	1/10W						
R567	1-216-049-91	RES,CHIP	1K	5%	1/10W	R699	1-220-273-11	RES,CHIP	1K	5%	1/2W
R571	1-216-049-91	RES,CHIP	1K	5%	1/10W	R701	1-216-017-91	RES,CHIP	47	5%	1/10W
R572	1-216-049-91	RES,CHIP	1K	5%	1/10W	R704	1-216-635-11	METAL CHIP	220	0.50%	1/10W
						R710	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R573	1-216-049-91	RES,CHIP	1K	5%	1/10W	R711	1-216-637-11	METAL CHIP	270	0.50%	1/10W
R581	1-216-033-00	RES,CHIP	220	5%	1/10W						
R591	1-216-017-91	RES,CHIP	47	5%	1/10W	R712	1-216-635-11	METAL CHIP	220	0.50%	1/10W
R592	1-216-295-91	SHORT 0				R717	1-216-627-11	METAL CHIP	100	0.50%	1/10W
R593	1-216-295-91	SHORT 0				R719	1-216-643-11	METAL CHIP	470	0.50%	1/10W
						R720	1-216-635-11	METAL CHIP	220	0.50%	1/10W
R595	1-216-043-91	RES,CHIP	560	5%	1/10W	R721	1-216-017-91	RES,CHIP	47	5%	1/10W
R596	1-216-295-91	SHORT 0									
R605	1-216-033-00	RES,CHIP	220	5%	1/10W	R722	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R606	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R723	1-216-025-91	RES,CHIP	100	5%	1/10W
R607	1-216-017-91	RES,CHIP	47	5%	1/10W	R724	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
						R725	1-216-657-11	METAL CHIP	1.8K	0.50%	1/10W
R609	1-216-295-91	SHORT 0				R726	1-216-017-91	RES,CHIP	47	5%	1/10W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R727	1-216-017-91	RES,CHIP	47 5% 1/10W	<TEST PIN>			
R731	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	TP21	1-535-757-11	CHIP, CHECKER	
R732	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W	TP22	1-535-757-11	CHIP, CHECKER	
R733	1-216-025-91	RES,CHIP	100 5% 1/10W	TP23	1-535-757-11	CHIP, CHECKER	
R734	1-220-269-11	RES,CHIP	330 5% 1/2W	TP24	1-535-757-11	CHIP, CHECKER	
R735	1-220-274-11	RES,CHIP	1.2K 5% 1/2W	TP34	1-535-757-11	CHIP, CHECKER	
R736	1-216-017-91	RES,CHIP	47 5% 1/10W	TP35	1-535-757-11	CHIP, CHECKER	
R737	1-220-274-11	RES,CHIP	1.2K 5% 1/2W	TP71	1-535-757-11	CHIP, CHECKER	
R738	1-216-033-00	RES,CHIP	220 5% 1/10W	TP72	1-535-757-11	CHIP, CHECKER	
R739	1-216-653-11	METAL CHIP	1.2K 0.50% 1/10W	TP73	1-535-757-11	CHIP, CHECKER	
R740	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	TP501	1-535-757-11	CHIP, CHECKER	
R741	1-216-033-00	RES,CHIP	220 5% 1/10W	TP511	1-535-757-11	CHIP, CHECKER	
R742	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	TP691	1-535-757-11	CHIP, CHECKER	
R743	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	TP751	1-535-757-11	CHIP, CHECKER	
R745	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	*****			
R746	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W	CDB MOUNTED PC BOARD			
R751	1-216-017-91	RES,CHIP	47 5% 1/10W	*****			
R752	1-216-017-91	RES,CHIP	47 5% 1/10W	<CAPACITOR>			
R753	1-216-001-00	RES,CHIP	10 5% 1/10W	C800	1-128-304-11	ELECT CHIP 330μF	20% 16V
R754	1-216-635-11	METAL CHIP	220 0.50% 1/10W	C801	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R755	1-216-635-11	METAL CHIP	220 0.50% 1/10W	C802	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
R756	1-216-001-00	RES,CHIP	10 5% 1/10W	C803	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
R757	1-216-001-00	RES,CHIP	10 5% 1/10W	C805	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R758	1-220-273-11	RES,CHIP	1K 5% 1/2W	C811	1-124-779-00	ELECT CHIP 10μF	20% 16V
R759	1-220-273-11	RES,CHIP	1K 5% 1/2W	C812	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R781	1-216-049-91	RES,CHIP	1K 5% 1/10W	C815	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
R782	1-216-121-91	RES,CHIP	1M 5% 1/10W	C816	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V
R783	1-216-049-91	RES,CHIP	1K 5% 1/10W	C817	1-163-121-00	CERAMIC CHIP 150PF	5% 50V
R784	1-216-677-11	METAL CHIP	12K 0.50% 1/10W	C818	1-162-117-00	CERAMIC 100PF	10% 500V
R785	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	C820	1-107-961-91	ELECT 10μF	20% 250V
R786	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	C821	1-102-050-00	CERAMIC 0.01μF	99% 500V
R787	1-216-049-91	RES,CHIP	1K 5% 1/10W	C822	1-107-943-11	ELECT 10μF	20% 160V
R789	1-216-049-91	RES,CHIP	1K 5% 1/10W	C823	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R791	1-216-073-00	RES,CHIP	10K 5% 1/10W	C824	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R795	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	C826	1-126-397-11	ELECT CHIP 33μF	20% 25V
R796	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	C827	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R797	1-216-025-91	RES,CHIP	100 5% 1/10W	C828	1-164-506-11	CERAMIC CHIP 4.7μF	16V
R798	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	C829	1-164-506-11	CERAMIC CHIP 4.7μF	16V
<RESISTOR BLOCK>				C830	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
RB51	1-233-576-11	RES, CHIP	NETWORK 100	C832	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
RB71	1-233-414-11	RES, CHIP	NETWORK 4.7K (3216)	C833	1-102-050-00	CERAMIC 0.01μF	99% 500V
RB72	1-233-576-11	RES, CHIP	NETWORK 100	C834	1-107-961-91	ELECT 10μF	20% 250V
RB81	1-233-576-11	RES, CHIP	NETWORK 100	C851	1-110-648-11	ELECT CHIP 220μF	20% 25V
<VARIABLE RESISTOR>				C852	1-128-304-11	ELECT CHIP 330μF	20% 16V
RV145	1-230-871-11	RES, ADJ, METAL GLAZE	22K	C853	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
RV622	1-238-785-21	RES, ADJ, CERMET	2K	C854	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
RV623	1-238-783-11	RES, ADJ, CERMET	500	C862	1-128-304-11	ELECT CHIP 330μF	20% 16V
RV682	1-238-786-11	RES, ADJ, CERMET	5K	C901	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
RV718	1-238-785-21	RES, ADJ, CERMET	2K	C902	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
RV785	1-238-786-11	RES, ADJ, CERMET	5K	C903	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
RV796	1-230-871-11	RES, ADJ, METAL GLAZE	22K	C904	1-104-913-11	TANTAL. CHIP 10μF	10% 16V
<SWITCH>				C905	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
S796	1-571-674-11	SWITCH, SLIDE		C906	1-104-913-11	TANTAL. CHIP 10μF	10% 16V

VPH-G90E/G90M/G90U

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
Q815	8-729-116-05	TRANSISTOR 2SK160-K5		R919	1-216-033-00	RES,CHIP 220	5% 1/10W
Q819	8-729-801-88	TRANSISTOR 2SA1381-E		R921	1-215-485-00	METAL 470K	1% 1/4W
Q821	8-729-821-02	TRANSISTOR 2SC3503-DE		R922	1-215-485-00	METAL 470K	1% 1/4W
Q901	8-729-033-16	TRANSISTOR 2SA1669-TB		R923	1-215-445-00	METAL 10K	1% 1/4W
Q902	8-729-112-65	TRANSISTOR 2SA1462-T1Y33		R924	1-216-049-91	RES,CHIP 1K	5% 1/10W
Q906	8-729-145-13	TRANSISTOR 2SC3356-(R25)		R925	1-216-025-91	RES,CHIP 100	5% 1/10W
Q907	8-729-033-16	TRANSISTOR 2SA1669-TB		R951	1-220-274-11	RES,CHIP 1.2K	5% 1/2W
Q948	8-729-804-63	TRANSISTOR 2SA1406-E		R952	1-220-274-11	RES,CHIP 1.2K	5% 1/2W
Q961	1-801-806-11	TRANSISTOR DTC144EKA-T146		R955	1-249-401-11	CARBON 47	5% 1/4W F
Q974	8-729-230-49	TRANSISTOR 2SC2712-YG		R957	1-215-493-00	METAL 1M	1% 1/4W
Q1204	8-729-821-02	TRANSISTOR 2SC3503-DE		R958	1-219-741-91	CARBON 10	5% 1/2W
Q1210	8-729-111-07	TRANSISTOR 2SD1590-L		R959	1-219-743-11	CARBON 100	5% 1/2W
<RESISTOR>				R960	1-216-649-11	METAL CHIP 820	0.50% 1/10W
R801	1-216-017-91	RES,CHIP 47	5% 1/10W	R961	1-216-683-11	METAL CHIP 22K	0.50% 1/10W
R802	1-216-033-00	RES,CHIP 220	5% 1/10W	R967	1-216-025-91	RES,CHIP 100	5% 1/10W
R803	1-216-025-91	RES,CHIP 100	5% 1/10W	R971	1-216-025-91	RES,CHIP 100	5% 1/10W
R804	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W	R972	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W
R805	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W	R973	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W
R806	1-216-017-91	RES,CHIP 47	5% 1/10W	R974	1-216-073-00	RES,CHIP 10K	5% 1/10W
R807	1-216-017-91	RES,CHIP 47	5% 1/10W	R975	1-216-045-00	RES,CHIP 680	5% 1/10W
R808	1-216-001-00	RES,CHIP 10	5% 1/10W	R976	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R809	1-216-001-00	RES,CHIP 10	5% 1/10W	R977	1-216-073-00	RES,CHIP 10K	5% 1/10W
R810	1-216-001-00	RES,CHIP 10	5% 1/10W	R978	1-216-025-91	RES,CHIP 100	5% 1/10W
R811	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R979	1-216-025-91	RES,CHIP 100	5% 1/10W
R814	1-216-619-11	METAL CHIP 47	0.50% 1/10W	R982	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R815	1-249-401-11	CARBON 47	5% 1/4W F	R983	1-216-089-91	RES,CHIP 47K	5% 1/10W
R819	1-216-033-00	RES,CHIP 220	5% 1/10W	R984	1-216-017-91	RES,CHIP 47	5% 1/10W
R820	1-216-049-91	RES,CHIP 1K	5% 1/10W	R990	1-216-025-91	RES,CHIP 100	5% 1/10W
R821	1-215-485-00	METAL 470K	1% 1/4W	R991	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
R822	1-215-485-00	METAL 470K	1% 1/4W	R992	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
R823	1-215-461-00	METAL 47K	1% 1/4W	R993	1-216-049-91	RES,CHIP 1K	5% 1/10W
R824	1-216-121-91	RES,CHIP 1M	5% 1/10W	R994	1-216-025-91	RES,CHIP 100	5% 1/10W
R825	1-216-025-91	RES,CHIP 100	5% 1/10W	R995	1-216-025-91	RES,CHIP 100	5% 1/10W
R826	1-216-075-00	RES,CHIP 12K	5% 1/10W	R996	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R827	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W	R997	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
R828	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R998	1-216-105-91	RES,CHIP 220K	5% 1/10W
R829	1-216-057-00	RES,CHIP 2.2K	5% 1/10W	R999	1-216-049-91	RES,CHIP 1K	5% 1/10W
R830	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W	R1001	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
R831	1-215-461-00	METAL 47K	1% 1/4W	R1007	1-216-619-11	METAL CHIP 47	0.50% 1/10W
R832	1-249-417-11	CARBON 1K	5% 1/4W	R1201	1-215-439-00	METAL 5.6K	1% 1/4W
R833	1-249-417-11	CARBON 1K	5% 1/4W	R1202	1-215-455-00	METAL 27K	1% 1/4W
R841	1-215-477-00	METAL 220K	1% 1/4W	R1203	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
R851	1-220-274-11	RES,CHIP 1.2K	5% 1/2W	R1204	1-216-025-91	RES,CHIP 100	5% 1/10W
R852	1-220-274-11	RES,CHIP 1.2K	5% 1/2W	R1211	1-216-049-91	RES,CHIP 1K	5% 1/10W
R901	1-216-017-91	RES,CHIP 47	5% 1/10W	R1212	1-216-073-00	RES,CHIP 10K	5% 1/10W
R902	1-216-033-00	RES,CHIP 220	5% 1/10W	R1213	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R903	1-216-025-91	RES,CHIP 100	5% 1/10W	R1214	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R904	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W	R1221	1-215-477-00	METAL 220K	1% 1/4W
R905	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W	R1222	1-215-485-00	METAL 470K	1% 1/4W
R906	1-216-017-91	RES,CHIP 47	5% 1/10W	R1223	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
R907	1-216-017-91	RES,CHIP 47	5% 1/10W	R1224	1-216-683-11	METAL CHIP 22K	0.50% 1/10W
R908	1-216-001-00	RES,CHIP 10	5% 1/10W	<VARIABLE RESISTOR>			
R909	1-216-001-00	RES,CHIP 10	5% 1/10W	RV965	RES, ADJ, CERMET 2K		
R910	1-216-001-00	RES,CHIP 10	5% 1/10W	RV1223	1-238-804-11	RES, ADJ, CERMET 50K	
R911	1-216-627-11	METAL CHIP 100	0.50% 1/10W				
R912	1-216-619-11	METAL CHIP 47	0.50% 1/10W				

Ref.No.	Part No.	Description	Remark			Ref.No.	Part No.	Description	Remark		
*****						C304	1-101-004-00	CERAMIC	0.01μF		50V
* A-1343-549-A EC MOUNTED PC BOARD						C305	1-101-004-00	CERAMIC	0.01μF		50V
*****						C306	1-126-968-11	ELECT	100μF	20%	50V
						C307	1-126-968-11	ELECT	100μF	20%	50V
<CAPACITOR>						C308	1-102-973-00	CERAMIC	100PF	5%	50V
						C309	1-102-973-00	CERAMIC	100PF	5%	50V
C2001	1-136-153-00	FILM	0.01μF	5%	50V	C310	1-101-004-00	CERAMIC	0.01μF		50V
						C311	1-101-004-00	CERAMIC	0.01μF		50V
<CONNECTOR>						C312	1-126-968-11	ELECT	100μF	20%	50V
						C313	1-126-968-11	ELECT	100μF	20%	50V
CN121	1-564-718-11	PIN, CONNECTOR (SMALL TYPE) 2P				<CONNECTOR>					
CN127	1-564-721-11	PIN, CONNECTOR (SMALL TYPE) 5P									
<RESISTOR>						CN130	* 1-564-711-11 PIN, CONNECTOR (SMALL TYPE) 9P				
						CN131	* 1-564-714-11 PIN, CONNECTOR (SMALL TYPE)12P				
						CN132	* 1-564-507-11 PLUG, CONNECTOR 4P				
R2001	1-247-807-31	CARBON	100	5%	1/4W	CN133	* 1-564-507-11 PLUG, CONNECTOR 4P				
R2002	1-247-807-31	CARBON	100	5%	1/4W	CN134	* 1-564-507-11 PLUG, CONNECTOR 4P				
<SWITCH>						<DIODE>					
S2001	1-570-865-11	SWITCH, SLIDE				D100	8-719-911-19 DIODE 1SS119-25				
S2002	1-570-245-11	SWITCH, MICRO				D101	8-719-911-19 DIODE 1SS119-25				
						D102	8-719-911-19 DIODE 1SS119-25				
*****						<IC>					
* A-1343-562-A EBQ MOUNTED PC BOARD						IC100	8-759-103-93 IC UPC393C				
*****						IC200	8-749-924-98 IC STK392-040				
4-067-815-01 SHEET (EBQH), INSULATOR						IC300	8-749-924-98 IC STK392-040				
4-382-854-11 SCREW (M3X10), P, SW (+)						<COIL>					
7-682-651-09 SCREW +PS 3X14						L100	1-406-663-21 INDUCTOR 47μH				
<CAPACITOR>						L101	1-406-663-21 INDUCTOR 47μH				
C100	1-126-968-11	ELECT	100μF	20%	50V	<TRANSISTOR>					
C101	1-126-968-11	ELECT	100μF	20%	50V	Q100	8-729-207-89 TRANSISTOR 2SA1358-Y				
C102	1-107-906-11	ELECT	10μF	20%	50V	Q101	8-729-207-82 TRANSISTOR 2SC3421-Y				
C103	1-107-906-11	ELECT	10μF	20%	50V	Q102	8-729-030-02 TRANSISTOR DTC144ESA				
C104	1-124-242-00	ELECT	33μF	20%	25V	<RESISTOR>					
C105	1-101-004-00	CERAMIC	0.01μF		50V	R100	1-249-413-11 CARBON 470 5% 1/4W				
C200	1-102-973-00	CERAMIC	100PF	5%	50V	R101	1-247-863-91 CARBON 22K 5% 1/4W				
C201	1-102-973-00	CERAMIC	100PF	5%	50V	R102	1-249-429-11 CARBON 10K 5% 1/4W				
C202	1-102-973-00	CERAMIC	100PF	5%	50V	R103	1-249-436-11 CARBON 39K 5% 1/4W				
C203	1-102-973-00	CERAMIC	100PF	5%	50V	R104	1-249-413-11 CARBON 470 5% 1/4W				
C204	1-101-004-00	CERAMIC	0.01μF		50V	R105	1-216-367-11 METAL OXIDE 0.68 5% 2W F				
C205	1-101-004-00	CERAMIC	0.01μF		50V	R106	1-249-429-11 CARBON 10K 5% 1/4W				
C206	1-126-968-11	ELECT	100μF	20%	50V	R107	1-249-429-11 CARBON 10K 5% 1/4W				
C207	1-126-968-11	ELECT	100μF	20%	50V	R108	1-216-367-11 METAL OXIDE 0.68 5% 2W F				
C208	1-102-973-00	CERAMIC	100PF	5%	50V	R109	1-249-435-11 CARBON 33K 5% 1/4W				
C209	1-102-973-00	CERAMIC	100PF	5%	50V	R110	1-249-435-11 CARBON 33K 5% 1/4W				
C210	1-101-004-00	CERAMIC	0.01μF		50V	R111	1-249-435-11 CARBON 33K 5% 1/4W				
C211	1-101-004-00	CERAMIC	0.01μF		50V	R112	1-249-437-11 CARBON 47K 5% 1/4W				
C212	1-126-968-11	ELECT	100μF	20%	50V	R113	1-249-417-11 CARBON 1K 5% 1/4W				
C213	1-126-968-11	ELECT	100μF	20%	50V	R114	1-247-807-31 CARBON 100 5% 1/4W				
C300	1-102-973-00	CERAMIC	100PF	5%	50V						
C301	1-102-973-00	CERAMIC	100PF	5%	50V						
C302	1-102-973-00	CERAMIC	100PF	5%	50V						
C303	1-102-973-00	CERAMIC	100PF	5%	50V						

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R200	1-249-415-11	CARBON	680 5% 1/4W	C607	1-126-968-11	ELECT	100μF 20% 50V
R201	1-249-411-11	CARBON	330 5% 1/4W	C608	1-102-973-00	CERAMIC	100PF 5% 50V
R202	1-249-415-11	CARBON	680 5% 1/4W	C609	1-102-973-00	CERAMIC	100PF 5% 50V
R203	1-249-411-11	CARBON	330 5% 1/4W	C610	1-101-004-00	CERAMIC	0.01μF 50V
R204	1-249-415-11	CARBON	680 5% 1/4W	C611	1-101-004-00	CERAMIC	0.01μF 50V
R205	1-249-411-11	CARBON	330 5% 1/4W	C612	1-126-968-11	ELECT	100μF 20% 50V
R206	1-215-433-00	METAL	3.3K 1% 1/4W	C613	1-126-968-11	ELECT	100μF 20% 50V
R207	1-215-433-00	METAL	3.3K 1% 1/4W	C700	1-102-973-00	CERAMIC	100PF 5% 50V
R208	1-249-405-11	CARBON	100 5% 1/4W F	C701	1-102-973-00	CERAMIC	100PF 5% 50V
R209	1-249-405-11	CARBON	100 5% 1/4W F	C702	1-102-973-00	CERAMIC	100PF 5% 50V
R210	1-216-392-11	METAL OXIDE	1.8 5% 3W F	C703	1-102-973-00	CERAMIC	100PF 5% 50V
R211	1-215-433-00	METAL	3.3K 1% 1/4W	C704	1-101-004-00	CERAMIC	0.01μF 50V
R212	1-216-392-11	METAL OXIDE	1.8 5% 3W F	C705	1-101-004-00	CERAMIC	0.01μF 50V
R213	1-216-392-11	METAL OXIDE	1.8 5% 3W F	C706	1-126-968-11	ELECT	100μF 20% 50V
R214	1-215-911-11	METAL OXIDE	100 5% 3W F	C707	1-126-968-11	ELECT	100μF 20% 50V
R215	1-215-911-11	METAL OXIDE	100 5% 3W F	C708	1-102-973-00	CERAMIC	100PF 5% 50V
R216	1-215-911-11	METAL OXIDE	100 5% 3W F	C709	1-102-973-00	CERAMIC	100PF 5% 50V
R300	1-249-415-11	CARBON	680 5% 1/4W	C710	1-101-004-00	CERAMIC	0.01μF 50V
R301	1-249-411-11	CARBON	330 5% 1/4W	C711	1-101-004-00	CERAMIC	0.01μF 50V
R302	1-249-415-11	CARBON	680 5% 1/4W	C712	1-126-968-11	ELECT	100μF 20% 50V
R303	1-249-411-11	CARBON	330 5% 1/4W	C713	1-126-968-11	ELECT	100μF 20% 50V
R304	1-249-415-11	CARBON	680 5% 1/4W	<CONNECTOR>			
R305	1-249-411-11	CARBON	330 5% 1/4W	CN135	* 1-564-711-11	PIN, CONNECTOR (SMALL TYPE) 9P	
R306	1-215-433-00	METAL	3.3K 1% 1/4W	CN136	* 1-564-714-11	PIN, CONNECTOR (SMALL TYPE) 12P	
R307	1-215-433-00	METAL	3.3K 1% 1/4W	CN137	* 1-564-507-11	PLUG, CONNECTOR 4P	
R308	1-249-405-11	CARBON	100 5% 1/4W F	CN138	* 1-564-507-11	PLUG, CONNECTOR 4P	
R309	1-249-405-11	CARBON	100 5% 1/4W F	CN139	* 1-564-507-11	PLUG, CONNECTOR 4P	
R310	1-216-392-11	METAL OXIDE	1.8 5% 3W F	<DIODE>			
R311	1-215-433-00	METAL	3.3K 1% 1/4W	D500	8-719-911-19	DIODE 1SS119-25	
R312	1-216-392-11	METAL OXIDE	1.8 5% 3W F	D501	8-719-911-19	DIODE 1SS119-25	
R313	1-216-392-11	METAL OXIDE	1.8 5% 3W F	D502	8-719-911-19	DIODE 1SS119-25	
R314	1-215-911-11	METAL OXIDE	100 5% 3W F	<IC>			
R315	1-215-911-11	METAL OXIDE	100 5% 3W F	IC500	8-759-103-93	IC UPC393C	
R316	1-215-911-11	METAL OXIDE	100 5% 3W F	IC600	8-749-924-98	IC STK392-040	
*****				IC700	8-749-924-98	IC STK392-040	
* A-1343-563-A EBH MOUNTED PC BOARD				<COIL>			
*****				L500	1-406-663-21	INDUCTOR 47μH	
4-067-815-01 SHEET (EBQH), INSULATOR				L501	1-406-663-21	INDUCTOR 47μH	
4-382-854-11 SCREW (M3X10), P, SW (+)				<TRANSISTOR>			
7-682-651-09 SCREW +PS 3X14				Q500	8-729-207-89	TRANSISTOR 2SA1358-Y	
<CAPACITOR>				Q501	8-729-207-82	TRANSISTOR 2SC3421-Y	
C500	1-126-968-11	ELECT	100μF 20% 50V	Q502	8-729-030-02	TRANSISTOR DTC144ESA	
C501	1-126-968-11	ELECT	100μF 20% 50V	<RESISTOR>			
C502	1-107-906-11	ELECT	10μF 20% 50V	R500	1-249-413-11	CARBON	470 5% 1/4W
C503	1-107-906-11	ELECT	10μF 20% 50V	R501	1-247-863-91	CARBON	22K 5% 1/4W
C504	1-124-242-00	ELECT	33μF 20% 25V	R502	1-249-429-11	CARBON	10K 5% 1/4W
C505	1-101-004-00	CERAMIC	0.01μF 50V	R503	1-249-436-11	CARBON	39K 5% 1/4W
C600	1-102-973-00	CERAMIC	100PF 5% 50V	R504	1-249-413-11	CARBON	470 5% 1/4W
C601	1-102-973-00	CERAMIC	100PF 5% 50V				
C602	1-102-973-00	CERAMIC	100PF 5% 50V				
C603	1-102-973-00	CERAMIC	100PF 5% 50V				
C604	1-101-004-00	CERAMIC	0.01μF 50V				
C605	1-101-004-00	CERAMIC	0.01μF 50V				
C606	1-126-968-11	ELECT	100μF 20% 50V				

Ref.No.	Part No.	Description	Remark				Ref.No.	Part No.	Description	Remark			
R505	1-216-367-11	METAL OXIDE	0.68	5%	2W	F	C3	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
R506	1-249-429-11	CARBON	10K	5%	1/4W		C4	1-126-964-11	ELECT	10μF	20%	50V	
R507	1-249-429-11	CARBON	10K	5%	1/4W		C5	1-126-964-11	ELECT	10μF	20%	50V	
R508	1-216-367-11	METAL OXIDE	0.68	5%	2W	F							
R509	1-249-435-11	CARBON	33K	5%	1/4W		C6	1-126-960-11	ELECT	1μF	20%	50V	
							C7	1-107-713-11	ELECT	4.7μF	20%	50V	
R510	1-249-435-11	CARBON	33K	5%	1/4W		C8	1-163-251-11	CERAMIC CHIP	100PF	5%	50V	
R511	1-249-435-11	CARBON	33K	5%	1/4W		C9	1-136-165-00	FILM	0.1μF	5%	50V	
R512	1-249-437-11	CARBON	47K	5%	1/4W		C10	1-136-165-00	FILM	0.1μF	5%	50V	
R513	1-249-417-11	CARBON	1K	5%	1/4W								
R514	1-247-807-31	CARBON	100	5%	1/4W		C11	1-109-889-11	ELECT	1μF	20%	50V	
							C12	1-136-159-00	FILM	0.033μF	5%	50V	
R600	1-249-415-11	CARBON	680	5%	1/4W		C13	1-126-933-11	ELECT	100μF	20%	16V	
R601	1-249-411-11	CARBON	330	5%	1/4W		C14	1-126-966-11	ELECT	33μF	20%	16V	
R602	1-249-415-11	CARBON	680	5%	1/4W		C15	1-126-966-11	ELECT	33μF	20%	16V	
R603	1-249-411-11	CARBON	330	5%	1/4W								
R604	1-249-415-11	CARBON	680	5%	1/4W		C16	1-136-165-00	FILM	0.1μF	5%	50V	
							C17	1-126-966-11	ELECT	33μF	20%	16V	
R605	1-249-411-11	CARBON	330	5%	1/4W		C18	1-126-933-11	ELECT	100μF	20%	16V	
R606	1-215-433-00	METAL	3.3K	1%	1/4W		C19	1-136-153-00	FILM	0.01μF	5%	50V	
R607	1-215-433-00	METAL	3.3K	1%	1/4W		C20	1-130-471-00	FILM	0.001μF	5%	50V	
R608	1-249-405-11	CARBON	100	5%	1/4W	F							
R609	1-249-405-11	CARBON	100	5%	1/4W	F	C21	1-126-964-11	ELECT	10μF	20%	50V	
							C22	1-136-153-00	FILM	0.01μF	5%	50V	
R610	1-216-392-11	METAL OXIDE	1.8	5%	3W	F	C23	1-136-153-00	FILM	0.01μF	5%	50V	
R611	1-215-433-00	METAL	3.3K	1%	1/4W		C24	1-126-960-11	ELECT	1μF	20%	50V	
R612	1-216-392-11	METAL OXIDE	1.8	5%	3W	F	C25	1-136-165-00	FILM	0.1μF	5%	50V	
R613	1-216-392-11	METAL OXIDE	1.8	5%	3W	F							
R614	1-215-911-11	METAL OXIDE	100	5%	3W	F	C26	1-126-960-11	ELECT	1μF	20%	50V	
							C27	1-126-960-11	ELECT	1μF	20%	50V	
R615	1-215-911-11	METAL OXIDE	100	5%	3W	F	C29	1-126-960-11	ELECT	1μF	20%	50V	
R616	1-215-911-11	METAL OXIDE	100	5%	3W	F	C30	1-136-153-00	FILM	0.01μF	5%	50V	
R700	1-249-415-11	CARBON	680	5%	1/4W		C31	1-126-964-11	ELECT	10μF	20%	50V	
R701	1-249-411-11	CARBON	330	5%	1/4W								
R702	1-249-415-11	CARBON	680	5%	1/4W		C32	1-126-964-11	ELECT	10μF	20%	50V	
							C34	1-126-964-11	ELECT	10μF	20%	50V	
R703	1-249-411-11	CARBON	330	5%	1/4W		C35	1-126-966-11	ELECT	33μF	20%	16V	
R704	1-249-415-11	CARBON	680	5%	1/4W		C38	1-130-471-00	FILM	0.001μF	5%	50V	
R705	1-249-411-11	CARBON	330	5%	1/4W		C39	1-136-165-00	FILM	0.1μF	5%	50V	
R706	1-215-433-00	METAL	3.3K	1%	1/4W								
R707	1-215-433-00	METAL	3.3K	1%	1/4W		C40	1-136-165-00	FILM	0.1μF	5%	50V	
							C41	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
R708	1-249-405-11	CARBON	100	5%	1/4W	F	C1001	1-104-665-11	ELECT	100μF	20%	25V	
R709	1-249-405-11	CARBON	100	5%	1/4W	F	C1002	1-128-578-11	ELECT	1μF	20%	100V	
R710	1-216-392-11	METAL OXIDE	1.8	5%	3W	F	C1003	1-126-933-11	ELECT	100μF	20%	16V	
R711	1-215-433-00	METAL	3.3K	1%	1/4W								
R712	1-216-392-11	METAL OXIDE	1.8	5%	3W	F	C1004	1-128-582-11	ELECT	10μF	20%	100V	
							C1005	1-128-578-11	ELECT	1μF	20%	100V	
R713	1-216-392-11	METAL OXIDE	1.8	5%	3W	F	C1006	1-128-582-11	ELECT	10μF	20%	100V	
R714	1-215-911-11	METAL OXIDE	100	5%	3W	F	C1007	1-126-933-11	ELECT	100μF	20%	16V	
R715	1-215-911-11	METAL OXIDE	100	5%	3W	F	C1008	1-104-665-11	ELECT	100μF	20%	25V	
R716	1-215-911-11	METAL OXIDE	100	5%	3W	F							
							C1009	1-104-965-11	ELECT	10μF	0	160V	
							C1010	1-136-111-00	FILM	1μF	5%	200V	
							C1011	1-107-746-11	ELECT	10μF	20%	200V	
*****							C1012	1-136-157-00	FILM	0.022μF	5%	50V	
							C1013	1-136-111-00	FILM	1μF	5%	200V	
* A-1346-771-A ED COMPLETE PC BOARD													
(Include EA Mounted PC BOARD)							C1014	1-126-960-11	ELECT	1μF	20%	50V	
*****							C1026	1-136-153-00	FILM	0.01μF	5%	50V	
							C1027	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
3-701-809-31 SCREW, TERMINAL (M3X8)							C1028	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
* 4-067-829-01 HOLDER (EDA), TR							C1033	1-136-153-00	FILM	0.01μF	5%	50V	
* 4-067-830-01 HOLDER (EDB), TR													
							C1036	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
							C1037	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
<CAPACITOR>							C1041	1-136-153-00	FILM	0.01μF	5%	50V	
C1	1-163-031-11	CERAMIC CHIP	0.01μF			50V	C1042	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	
C2	1-163-031-11	CERAMIC CHIP	0.01μF			50V	C1043	1-163-133-00	CERAMIC CHIP	470PF	5%	50V	



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C1047	1-128-563-11	ELECT	100μF 20% 100V	IC4	8-759-100-96	IC UPC4558G2	
C1048	1-128-563-11	ELECT	100μF 20% 100V	IC5	8-759-381-53	IC UPC814G2-E2	
C1049	1-136-153-00	FILM	0.01μF 5% 50V				
<CONNECTOR>				IC6	8-759-300-78	IC HD14538BFP	
CN750	*1-785-517-11	CONNECTOR, BOARD TO BOARD 13P		IC7	8-759-100-96	IC UPC4558G2	
CN751	*1-785-517-11	CONNECTOR, BOARD TO BOARD 13P		IC8	8-759-100-96	IC UPC4558G2	
CN752	*1-785-518-11	CONNECTOR, BOARD TO BOARD 15P		IC9	8-759-100-93	IC UPC393G2	
CN753	*1-785-518-11	CONNECTOR, BOARD TO BOARD 15P		IC12	8-759-100-93	IC UPC393G2	
CN754	*1-564-713-11	PIN, CONNECTOR (SMALL TYPE)11P					
CN755	*1-564-513-11	PLUG, CONNECTOR 10P		IC1001	8-759-231-58	IC TA7812S	
CN756	*1-564-709-11	PIN, CONNECTOR (SMALL TYPE) 7P		IC1002	8-759-929-65	IC LM7912CT	
CN758	*1-785-530-11	PIN, CONNECTOR (PC BOARD) 10P		IC1010	8-759-100-96	IC UPC4558G2	
CN759	*1-785-519-11	PIN, CONNECTOR (PC BOARD) 24P		IC1011	8-759-100-96	IC UPC4558G2	
				IC1013	8-759-100-96	IC UPC4558G2	
<DIODE>				IC1014	8-759-100-96	IC UPC4558G2	
D1	8-719-801-78	DIODE 1SS184		<COIL>			
D2	8-719-801-78	DIODE 1SS184		L1	1-410-067-21	INDUCTOR 4.7mH	
D3	8-719-801-78	DIODE 1SS184		L1001	1-412-533-21	INDUCTOR 47μH	
D4	8-719-801-78	DIODE 1SS184		L1002	1-412-533-21	INDUCTOR 47μH	
D5	8-719-801-78	DIODE 1SS184		L1003	1-412-533-21	INDUCTOR 47μH	
				L1004	1-412-533-21	INDUCTOR 47μH	
D6	8-719-948-45	DIODE ERA22-08		L1005	1-459-104-00	COIL, DUST CORE	
D7	8-719-801-78	DIODE 1SS184		L1006	1-459-104-00	COIL, DUST CORE	
D8	8-719-801-78	DIODE 1SS184		L1007	1-410-680-31	INDUCTOR 330μH	
D9	8-719-801-78	DIODE 1SS184		<TRANSISTOR>			
D10	8-719-801-78	DIODE 1SS184		Q1	8-729-230-49	TRANSISTOR 2SC2712-YG	
D11	8-719-801-78	DIODE 1SS184		Q2	8-729-216-22	TRANSISTOR 2SA1162-G	
D12	8-719-948-45	DIODE ERA22-08		Q3	8-729-116-05	TRANSISTOR 2SK160-K5	
D13	8-719-801-78	DIODE 1SS184		Q4	8-729-230-49	TRANSISTOR 2SC2712-YG	
D1001	8-719-948-45	DIODE ERA22-08		Q5	1-801-806-11	TRANSISTOR DTC144EKA-T146	
D1002	8-719-948-45	DIODE ERA22-08					
D1003	8-719-948-45	DIODE ERA22-08		Q6	8-729-216-22	TRANSISTOR 2SA1162-G	
D1004	8-719-948-45	DIODE ERA22-08		Q7	8-729-116-05	TRANSISTOR 2SK160-K5	
D1005	8-719-911-19	DIODE 1SS119-25		Q8	8-729-230-49	TRANSISTOR 2SC2712-YG	
D1006	8-719-911-19	DIODE 1SS119-25		Q9	8-729-230-49	TRANSISTOR 2SC2712-YG	
D1007	8-719-911-19	DIODE 1SS119-25		Q10	8-729-216-22	TRANSISTOR 2SA1162-G	
D1008	8-719-300-80	DIODE RU-1C		Q11	8-729-230-49	TRANSISTOR 2SC2712-YG	
D1009	8-719-300-80	DIODE RU-1C		Q12	8-729-216-22	TRANSISTOR 2SA1162-G	
D1010	8-719-300-80	DIODE RU-1C		Q13	8-729-216-22	TRANSISTOR 2SA1162-G	
D1011	8-719-948-45	DIODE ERA22-08		Q14	1-801-806-11	TRANSISTOR DTC144EKA-T146	
D1012	8-719-911-19	DIODE 1SS119-25		Q15	8-729-119-80	TRANSISTOR 2SC2688-LK	
D1013	8-719-911-19	DIODE 1SS119-25		Q16	8-729-230-49	TRANSISTOR 2SC2712-YG	
D1014	8-719-300-80	DIODE RU-1C		Q17	8-729-230-49	TRANSISTOR 2SC2712-YG	
D1015	8-719-911-19	DIODE 1SS119-25		Q18	8-729-230-49	TRANSISTOR 2SC2712-YG	
D1016	8-719-911-19	DIODE 1SS119-25		Q19	8-729-216-22	TRANSISTOR 2SA1162-G	
D1017	8-719-110-72	DIODE RD30ESB2		Q20	8-729-230-49	TRANSISTOR 2SC2712-YG	
D1018	8-719-110-72	DIODE RD30ESB2		Q21	8-729-230-49	TRANSISTOR 2SC2712-YG	
<FERRITE BEAD>				Q22	8-729-216-22	TRANSISTOR 2SA1162-G	
FB1000	1-410-396-41	FERRITE 0.45μH		Q1001	8-729-140-96	TRANSISTOR 2SD774-34	
<IC>				Q1003	8-729-140-97	TRANSISTOR 2SB734-34	
IC1	8-759-100-96	IC UPC4558G2		Q1007	8-729-119-80	TRANSISTOR 2SC2688-LK	
IC2	8-759-433-43	IC MC1495BP		Q1009	8-729-119-80	TRANSISTOR 2SC2688-LK	
IC3	8-759-442-21	IC MC1436CP1		Q1010	8-729-905-86	TRANSISTOR 2SC4054N	
				Q1011	8-729-143-42	TRANSISTOR 2SK929	
				Q1012	8-729-905-86	TRANSISTOR 2SC4054N	
				Q1013	8-729-402-03	TRANSISTOR 2SK755	
				Q1014	8-729-802-71	TRANSISTOR 2SA1407-D	

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
	<RESISTOR>			R59	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
R1	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R60	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R2	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R61	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R3	1-216-699-11	METAL CHIP 100K	0.50% 1/10W	R62	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
R4	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R63	1-216-049-91	RES,CHIP 1K	5% 1/10W
R5	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R64	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R6	1-216-049-91	RES,CHIP 1K	5% 1/10W	R65	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R7	1-216-049-91	RES,CHIP 1K	5% 1/10W	R66	1-216-089-91	RES,CHIP 47K	5% 1/10W
R8	1-216-697-91	METAL CHIP 82K	0.50% 1/10W	R67	1-216-097-91	RES,CHIP 100K	5% 1/10W
R10	1-216-687-11	METAL CHIP 33K	0.50% 1/10W	R68	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
R11	1-216-663-11	METAL CHIP 3.3K	0.50% 1/10W	R69	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R12	1-216-061-00	RES,CHIP 3.3K	5% 1/10W	R70	1-216-049-91	RES,CHIP 1K	5% 1/10W
R13	1-216-663-11	METAL CHIP 3.3K	0.50% 1/10W	R71	1-216-049-91	RES,CHIP 1K	5% 1/10W
R14	1-216-651-11	METAL CHIP 1K	0.50% 1/10W	R72	1-216-665-11	METAL CHIP 3.9K	0.50% 1/10W
R15	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R73	1-216-663-11	METAL CHIP 3.3K	0.50% 1/10W
R16	1-216-061-00	RES,CHIP 3.3K	5% 1/10W	R74	1-216-073-00	RES,CHIP 10K	5% 1/10W
R17	1-216-073-00	RES,CHIP 10K	5% 1/10W	R75	1-216-025-91	RES,CHIP 100	5% 1/10W
R18	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R76	1-216-025-91	RES,CHIP 100	5% 1/10W
R19	1-216-073-00	RES,CHIP 10K	5% 1/10W	R77	1-216-049-91	RES,CHIP 1K	5% 1/10W
R20	1-216-687-11	METAL CHIP 33K	0.50% 1/10W	R79	1-216-025-91	RES,CHIP 100	5% 1/10W
R21	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R81	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R22	1-216-677-11	METAL CHIP 12K	0.50% 1/10W	R88	1-216-061-00	RES,CHIP 3.3K	5% 1/10W
R23	1-216-679-11	METAL CHIP 15K	0.50% 1/10W	R89	1-216-097-91	RES,CHIP 100K	5% 1/10W
R24	1-216-663-11	METAL CHIP 3.3K	0.50% 1/10W	R90	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
R25	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	R91	1-216-061-00	RES,CHIP 3.3K	5% 1/10W
R26	1-216-685-11	METAL CHIP 27K	0.50% 1/10W	R92	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R27	1-216-089-91	RES,CHIP 47K	5% 1/10W	R93	1-216-025-91	RES,CHIP 100	5% 1/10W
R28	1-216-073-00	RES,CHIP 10K	5% 1/10W	R94	1-216-097-91	RES,CHIP 100K	5% 1/10W
R29	1-216-073-00	RES,CHIP 10K	5% 1/10W	R96	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R30	1-216-121-91	RES,CHIP 1M	5% 1/10W	R97	1-216-049-91	RES,CHIP 1K	5% 1/10W
R31	1-216-061-00	RES,CHIP 3.3K	5% 1/10W	R98	1-216-685-11	METAL CHIP 27K	0.50% 1/10W
R32	1-216-073-00	RES,CHIP 10K	5% 1/10W	R100	1-216-097-91	RES,CHIP 100K	5% 1/10W
R33	1-216-049-91	RES,CHIP 1K	5% 1/10W	R103	1-216-097-91	RES,CHIP 100K	5% 1/10W
R34	1-216-677-11	METAL CHIP 12K	0.50% 1/10W	R104	1-216-049-91	RES,CHIP 1K	5% 1/10W
R35	1-216-677-11	METAL CHIP 12K	0.50% 1/10W	R105	1-216-669-11	METAL CHIP 5.6K	0.50% 1/10W
R36	1-216-691-11	METAL CHIP 47K	0.50% 1/10W	R107	1-216-105-91	RES,CHIP 220K	5% 1/10W
R37	1-216-061-00	RES,CHIP 3.3K	5% 1/10W	R108	1-216-089-91	RES,CHIP 47K	5% 1/10W
R38	1-216-101-00	RES,CHIP 150K	5% 1/10W	R109	1-216-049-91	RES,CHIP 1K	5% 1/10W
R39	1-216-057-00	RES,CHIP 2.2K	5% 1/10W	R110	1-216-049-91	RES,CHIP 1K	5% 1/10W
R40	1-216-061-00	RES,CHIP 3.3K	5% 1/10W	R113	1-216-013-00	RES,CHIP 33	5% 1/10W
R41	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	R114	1-216-089-91	RES,CHIP 47K	5% 1/10W
R42	1-216-081-00	RES,CHIP 22K	5% 1/10W	R115	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R43	1-216-057-00	RES,CHIP 2.2K	5% 1/10W	R116	1-216-665-11	METAL CHIP 3.9K	0.50% 1/10W
R44	1-216-073-00	RES,CHIP 10K	5% 1/10W	R117	1-216-073-00	RES,CHIP 10K	5% 1/10W
R45	1-216-055-00	RES,CHIP 1.8K	5% 1/10W	R118	1-216-089-91	RES,CHIP 47K	5% 1/10W
R46	1-216-677-11	METAL CHIP 12K	0.50% 1/10W	R119	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
R47	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R120	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
R48	1-216-061-00	RES,CHIP 3.3K	5% 1/10W	R121	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R49	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	R122	1-216-089-91	RES,CHIP 47K	5% 1/10W
R50	1-216-049-91	RES,CHIP 1K	5% 1/10W	R123	1-216-665-11	METAL CHIP 3.9K	0.50% 1/10W
R51	1-216-061-00	RES,CHIP 3.3K	5% 1/10W	R124	1-216-025-91	RES,CHIP 100	5% 1/10W
R52	1-216-057-00	RES,CHIP 2.2K	5% 1/10W	R125	1-216-025-91	RES,CHIP 100	5% 1/10W
R53	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R126	1-216-025-91	RES,CHIP 100	5% 1/10W
R54	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R127	1-216-115-00	RES,CHIP 560K	5% 1/10W
R55	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R1002	1-260-296-11	CARBON 2.2	5% 1/2W
R56	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R1003	1-249-434-11	CARBON 27K	5% 1/4W
R57	1-216-681-11	METAL CHIP 18K	0.50% 1/10W	R1004	1-247-863-91	CARBON 22K	5% 1/4W
R58	1-216-691-11	METAL CHIP 47K	0.50% 1/10W	R1006	1-260-296-11	CARBON 2.2	5% 1/2W



Ref.No.	Part No.	Description	Remark			Ref.No.	Part No.	Description	Remark		
R1007	1-249-434-11	CARBON	27K	5%	1/4W			<TEST PIN>			
R1011	1-247-863-91	CARBON	22K	5%	1/4W						
R1021	1-260-298-51	CARBON	3.3	5%	1/2W	TP1	* 1-537-864-11	PIN, POST			
R1022	1-215-878-00	METAL OXIDE	33K	5%	1W	TP2	* 1-537-864-11	PIN, POST			
R1023	1-215-924-00	METAL OXIDE	15K	5%	3W	TP3	* 1-537-864-11	PIN, POST			
						TP4	* 1-537-864-11	PIN, POST			
						TP5	* 1-537-864-11	PIN, POST			
R1026	1-215-924-00	METAL OXIDE	15K	5%	3W						
R1027	1-215-383-00	METAL	27	1%	1/4W						
R1030	1-215-924-00	METAL OXIDE	15K	5%	3W						
R1031	1-215-383-00	METAL	27	1%	1/4W						
R1032	1-215-421-00	METAL	1K	1%	1/4W						
R1033	1-215-383-00	METAL	27	1%	1/4W			* A-1346-772-A E COMPLETE PC BOARD			
R1036	1-247-807-31	CARBON	100	5%	1/4W			*****			
R1037	1-247-807-31	CARBON	100	5%	1/4W						
R1038	1-249-429-11	CARBON	10K	5%	1/4W			1-923-514-14	TUBE DIA1.6 8MM BLK		
R1039	1-260-298-51	CARBON	3.3	5%	1/2W			3-701-809-31	SCREW, TERMINAL (M3X8)		
								4-056-066-01	HOLDER (C), TR		
R1040	1-249-429-11	CARBON	10K	5%	1/4W			* 4-067-840-01	HOLDER (E), TR		
R1041	1-249-441-11	CARBON	100K	5%	1/4W			4-382-854-11	SCREW (M3X10), P, SW (+)		
R1042	1-215-413-00	METAL	470	1%	1/4W						
R1043	1-215-387-00	METAL	39	1%	1/4W			4-393-406-01	SHEET (R), RADIATION		
R1060	1-216-073-00	RES,CHIP	10K	5%	1/10W			7-682-903-11	SCREW +PWH 3X6		
R1078	1-216-049-91	RES,CHIP	1K	5%	1/10W			<CAPACITOR>			
R1080	1-216-073-00	RES,CHIP	10K	5%	1/10W						
R1081	1-216-053-00	RES,CHIP	1.5K	5%	1/10W						
R1082	1-216-049-91	RES,CHIP	1K	5%	1/10W	C1	1-126-899-11	ELECT	3900μF	20%	16V
R1083	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	C2	1-126-899-11	ELECT	3900μF	20%	16V
						C3	1-126-899-11	ELECT	3900μF	20%	16V
R1084	1-216-073-00	RES,CHIP	10K	5%	1/10W	C15	1-125-649-11	ELECT(BLOCK)	1500μF	20%	200V
R1085	1-216-073-00	RES,CHIP	10K	5%	1/10W	C17	1-126-899-11	ELECT	3900μF	20%	16V
R1086	1-216-073-00	RES,CHIP	10K	5%	1/10W						
R1087	1-216-049-91	RES,CHIP	1K	5%	1/10W	C18	1-126-899-11	ELECT	3900μF	20%	16V
R1088	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	C19	1-126-899-11	ELECT	3900μF	20%	16V
						C20	1-162-116-00	CERAMIC	680PF	10%	2KV
R1093	1-249-425-11	CARBON	4.7K	5%	1/4W	C21	1-109-956-11	ELECT	1μF	20%	200V
R1094	1-249-425-11	CARBON	4.7K	5%	1/4W	C22	1-162-116-00	CERAMIC	680PF	10%	2KV
R1095	1-216-073-00	RES,CHIP	10K	5%	1/10W						
R1099	1-216-049-91	RES,CHIP	1K	5%	1/10W	C23	1-127-686-11	FILM MELF	8.2μF	3%	200V
R1101	1-216-073-00	RES,CHIP	10K	5%	1/10W	C24	1-127-686-11	FILM MELF	8.2μF	3%	200V
						C25	1-127-686-11	FILM MELF	8.2μF	3%	200V
R1102	1-216-073-00	RES,CHIP	10K	5%	1/10W	C26	1-127-686-11	FILM MELF	8.2μF	3%	200V
R1103	1-216-049-91	RES,CHIP	1K	5%	1/10W	C27	1-127-686-11	FILM MELF	8.2μF	3%	200V
R1111	1-216-073-00	RES,CHIP	10K	5%	1/10W						
R1112	1-216-073-00	RES,CHIP	10K	5%	1/10W	C28	1-127-686-11	FILM MELF	8.2μF	3%	200V
R1124	1-216-049-91	RES,CHIP	1K	5%	1/10W	C29	1-127-686-11	FILM MELF	8.2μF	3%	200V
						C30	1-127-686-11	FILM MELF	8.2μF	3%	200V
R1125	1-216-073-00	RES,CHIP	10K	5%	1/10W	C31	1-127-686-11	FILM MELF	8.2μF	3%	200V
R1126	1-216-049-91	RES,CHIP	1K	5%	1/10W	C32	1-127-686-11	FILM MELF	8.2μF	3%	200V
R1127	1-216-073-00	RES,CHIP	10K	5%	1/10W						
R1128	1-216-073-00	RES,CHIP	10K	5%	1/10W	C33	1-127-683-11	FILM MELF	2400PF	3%	2.5KV
R1129	1-216-073-00	RES,CHIP	10K	5%	1/10W	C35	1-107-746-11	ELECT	10μF	20%	200V
						C36	1-126-969-11	ELECT	220μF	20%	50V
R1130	1-216-073-00	RES,CHIP	10K	5%	1/10W	C37	1-101-821-00	CERAMIC	0.0022μF		500V
R1131	1-216-073-00	RES,CHIP	10K	5%	1/10W	C38	1-137-194-81	FILM	0.47μF	5%	50V
R1132	1-216-073-00	RES,CHIP	10K	5%	1/10W						
R1133	1-216-073-00	RES,CHIP	10K	5%	1/10W	C39	1-162-116-00	CERAMIC	680PF	10%	2KV
R1134	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C40	1-102-824-00	CERAMIC	470PF	5%	50V
						C41	1-137-194-81	FILM	0.47μF	5%	50V
R1135	1-216-049-91	RES,CHIP	1K	5%	1/10W	C42	1-107-746-11	ELECT	10μF	20%	200V
						C43	1-127-683-11	FILM MELF	2400PF	3%	2.5KV
		<VARIABLE RESISTOR>				C44	1-127-683-11	FILM MELF	2400PF	3%	2.5KV
						C45	1-127-685-11	FILM MELF	8000PF	3%	2.5KV
RV1	1-238-791-11	RES, ADJ, CERMET 200K				C46	1-126-965-11	ELECT	22μF	20%	50V
RV2	1-238-790-11	RES, ADJ, CERMET 100K									

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
<CONNECTOR>				LV2	1-416-873-11	COIL, HORIZONTAL WIZU	
CN113	* 1-785-519-11	PIN, CONNECTOR (PC BOARD) 24P		LV3	1-416-873-11	COIL, HORIZONTAL WIZU	
CN114	* 1-785-530-11	PIN, CONNECTOR (PC BOARD) 10P		<TRANSISTOR>			
CN116	* 1-764-334-11	PLUG, CONNECTOR 11P		Q2	8-729-142-69	TRANSISTOR 2SK817	
CN117	* 1-785-524-11	PIN, CONNECTOR (PC BOARD) 3P		Q4	8-729-140-96	TRANSISTOR 2SD774-34	
CN118	* 1-785-514-11	PIN, CONNECTOR (PC BOARD) 6P		Q5	8-729-142-68	TRANSISTOR 2SJ143	
CN119	* 1-785-514-11	PIN, CONNECTOR (PC BOARD) 6P		Q6	8-729-142-69	TRANSISTOR 2SK817	
CN120	* 1-785-514-11	PIN, CONNECTOR (PC BOARD) 6P		Q8	8-729-142-68	TRANSISTOR 2SJ143	
CN121	* 1-564-506-11	PLUG, CONNECTOR 3P		Q15	8-729-142-69	TRANSISTOR 2SK817	
<DIODE>				Q16	8-729-142-68	TRANSISTOR 2SJ143	
D15	8-719-110-41	DIODE RD15ESB2		Q17	8-729-046-55	TRANSISTOR 2SK1452	
D16	8-719-110-41	DIODE RD15ESB2		Q18	8-729-046-56	TRANSISTOR 2SJ413	
D17	8-719-110-41	DIODE RD15ESB2		Q19	8-729-119-78	TRANSISTOR 2SC2785-HFE	
D18	8-719-110-41	DIODE RD15ESB2		Q20	8-729-032-26	TRANSISTOR IRFI9620GS	
D19	8-719-911-19	DIODE 1SS119-25		Q22	8-729-033-56	TRANSISTOR 2SC5238-CB	
D20	8-719-110-88	DIODE RD39ESB2		Q23	8-729-033-56	TRANSISTOR 2SC5238-CB	
D21	8-719-948-45	DIODE ERA22-08		<RESISTOR>			
D22	8-719-110-41	DIODE RD15ESB2		R1	1-202-961-11	CEMENTED	1.8 5% 10W
D23	8-719-110-41	DIODE RD15ESB2		R2	1-260-300-11	CARBON	4.7 5% 1/2W
D24	8-719-911-19	DIODE 1SS119-25		R5	1-214-810-00	METAL	5.6 1% 1/2W
D25	8-719-110-41	DIODE RD15ESB2		R8	1-214-810-00	METAL	5.6 1% 1/2W
D26	8-719-110-72	DIODE RD30ESB2		R9	1-247-807-31	CARBON	100 5% 1/4W
D27	8-719-110-72	DIODE RD30ESB2		R10	1-214-810-00	METAL	5.6 1% 1/2W
D28	8-719-911-19	DIODE 1SS119-25		R12	1-247-843-11	CARBON	3.3K 5% 1/4W
D29	8-719-911-19	DIODE 1SS119-25		R13	1-214-810-00	METAL	5.6 1% 1/2W
D30	8-719-911-19	DIODE 1SS119-25		R14	1-247-807-31	CARBON	100 5% 1/4W
D31	8-719-911-19	DIODE 1SS119-25		R15	1-214-810-00	METAL	5.6 1% 1/2W
D32	8-719-901-19	DIODE V11N		R16	1-249-429-11	CARBON	10K 5% 1/4W
D33	8-719-970-89	DIODE DD50R		R17	1-214-810-00	METAL	5.6 1% 1/2W
D34	8-719-970-89	DIODE DD50R		R18	1-216-388-11	METAL OXIDE	0.82 5% 3W F
D35	8-719-920-67	DIODE ERC91-02		R19	1-214-810-00	METAL	5.6 1% 1/2W
D36	8-719-054-88	DIODE DFC15TR		R20	1-214-810-00	METAL	5.6 1% 1/2W
D37	8-719-054-88	DIODE DFC15TR		R24	1-247-807-31	CARBON	100 5% 1/4W
D38	8-719-054-88	DIODE DFC15TR		R25	1-214-810-00	METAL	5.6 1% 1/2W
D39	8-719-054-88	DIODE DFC15TR		R28	1-214-810-00	METAL	5.6 1% 1/2W
D40	8-719-054-88	DIODE DFC15TR		R29	1-247-807-31	CARBON	100 5% 1/4W
D41	8-719-920-67	DIODE ERC91-02		R33	1-214-810-00	METAL	5.6 1% 1/2W
D42	8-719-054-88	DIODE DFC15TR		R34	1-214-810-00	METAL	5.6 1% 1/2W
<IC>				R35	1-216-388-11	METAL OXIDE	0.82 5% 3W F
IC3	8-759-442-21	IC MC1436CP1		R44	1-214-810-00	METAL	5.6 1% 1/2W
<COIL>				R45	1-214-810-00	METAL	5.6 1% 1/2W
L8	1-406-664-21	INDUCTOR 68μH		R46	1-247-807-31	CARBON	100 5% 1/4W
L9	1-406-664-21	INDUCTOR 68μH		R47	1-214-810-00	METAL	5.6 1% 1/2W
L10	1-416-875-11	COIL, HORIZONTAL LINEARITY		R48	1-214-810-00	METAL	5.6 1% 1/2W
L11	1-410-067-21	INDUCTOR 4.7mH		R49	1-247-807-31	CARBON	100 5% 1/4W
L12	1-416-875-11	COIL, HORIZONTAL LINEARITY		R50	1-214-810-00	METAL	5.6 1% 1/2W
L13	1-410-067-21	INDUCTOR 4.7mH		R51	1-214-810-00	METAL	5.6 1% 1/2W
L14	1-416-875-11	COIL, HORIZONTAL LINEARITY		R52	1-216-388-11	METAL OXIDE	0.82 5% 3W F
<VARIABLE COIL>				R53	1-215-911-11	METAL OXIDE	100 5% 3W F
LV1	1-416-873-11	COIL, HORIZONTAL WIZU		R54	1-260-288-11	CARBON	0.47 5% 1/2W
				R55	1-260-288-11	CARBON	0.47 5% 1/2W
				R56	1-215-451-00	METAL	18K 1% 1/4W
				R57	1-249-417-11	CARBON	1K 5% 1/4W
				R58	1-249-417-11	CARBON	1K 5% 1/4W
				R59	1-249-393-11	CARBON	10 5% 1/4W F



Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description			Remark	
R60	1-249-399-11	CARBON	33	5%	1/4W	F	*****					
R61	1-249-437-11	CARBON	47K	5%	1/4W							
R62	1-249-421-11	CARBON	2.2K	5%	1/4W		* A-1346-773-A DC COMPLETE PC BOARD					
R63	1-217-210-11	WIREWOUND	6.8	10%	2W	F	*****					
R64	1-260-340-11	CARBON	10K	5%	1/2W		* 4-056-414-01 BUSHING, SQUARE					
R65	1-202-961-11	CEMENTED	1.8	5%	10W		4-067-833-01 SHEET (DC), INSULATOR					
R66	1-249-399-11	CARBON	33	5%	1/4W	F	4-382-854-11 SCREW (M3X10), P, SW (+)					
							7-682-651-09 SCREW +PS 3X14					
R67	1-215-915-11	METAL OXIDE	470	5%	3W	F	7-682-651-09 SCREW +PS 3X14					
R68	1-249-429-11	CARBON	10K	5%	1/4W							
R69	1-202-961-11	CEMENTED	1.8	5%	10W		7-682-950-01 SCREW +PSW 3X12					
R70	1-249-431-11	CARBON	15K	5%	1/4W							
R71	1-207-688-00	WIREWOUND	220	10%	5W	F	<CAPACITOR>					
R72	1-249-399-11	CARBON	33	5%	1/4W	F	C1	1-162-318-11	CERAMIC	0.001μF	10%	500V
R73	1-249-429-11	CARBON	10K	5%	1/4W		C2	1-162-318-11	CERAMIC	0.001μF	10%	500V
R74	1-249-431-11	CARBON	15K	5%	1/4W		C3	1-162-318-11	CERAMIC	0.001μF	10%	500V
R75	1-249-429-11	CARBON	10K	5%	1/4W		C4	1-162-318-11	CERAMIC	0.001μF	10%	500V
R76	1-249-431-11	CARBON	15K	5%	1/4W		C5	1-162-318-11	CERAMIC	0.001μF	10%	500V
R77	1-249-425-11	CARBON	4.7K	5%	1/4W		C6	1-162-318-11	CERAMIC	0.001μF	10%	500V
R78	1-249-431-11	CARBON	15K	5%	1/4W		C7	1-107-906-11	ELECT	10μF	20%	50V
R79	1-216-400-11	METAL OXIDE	8.2	5%	3W	F	C8	1-101-004-00	CERAMIC	0.01μF		50V
R80	1-219-513-11	CARBON	4.7M	5%	1/2W		C9	1-101-004-00	CERAMIC	0.01μF		50V
R81	1-216-400-11	METAL OXIDE	8.2	5%	3W	F	C10	1-102-050-00	CERAMIC	0.01μF	99%	500V
R82	1-219-513-11	CARBON	4.7M	5%	1/2W		C11	1-102-050-00	CERAMIC	0.01μF	99%	500V
R83	1-216-400-11	METAL OXIDE	8.2	5%	3W	F	C12	1-111-168-91	ELECT	100μF	20%	100V
R84	1-219-513-11	CARBON	4.7M	5%	1/2W		C13	1-102-050-00	CERAMIC	0.01μF	99%	500V
R85	1-215-911-11	METAL OXIDE	100	5%	3W	F	C14	1-102-824-00	CERAMIC	470PF	5%	50V
R86	1-219-513-11	CARBON	4.7M	5%	1/2W		C15	1-101-004-00	CERAMIC	0.01μF		50V
R87	1-216-400-11	METAL OXIDE	8.2	5%	3W	F	C16	1-111-168-91	ELECT	100μF	20%	100V
R88	1-215-451-00	METAL	18K	1%	1/4W		C17	1-101-004-00	CERAMIC	0.01μF		50V
R89	1-215-451-00	METAL	18K	1%	1/4W		C18	1-111-168-91	ELECT	100μF	20%	100V
R90	1-216-400-11	METAL OXIDE	8.2	5%	3W	F	C19	1-102-050-00	CERAMIC	0.01μF	99%	500V
R91	1-215-911-11	METAL OXIDE	100	5%	3W	F	C20	1-111-168-91	ELECT	100μF	20%	100V
R92	1-216-400-11	METAL OXIDE	8.2	5%	3W	F	C21	1-102-852-91	CERAMIC	47PF	5%	50V
R93	1-216-400-11	METAL OXIDE	8.2	5%	3W	F	C22	1-107-926-11	ELECT	2.2μF	20%	100V
R94	1-216-400-11	METAL OXIDE	8.2	5%	3W	F	C23	1-102-824-00	CERAMIC	470PF	5%	50V
R95	1-215-451-00	METAL	18K	1%	1/4W		C24	1-102-852-91	CERAMIC	47PF	5%	50V
R96	1-215-451-00	METAL	18K	1%	1/4W		C25	1-102-824-00	CERAMIC	470PF	5%	50V
R97	1-215-453-00	METAL	22K	1%	1/4W		C26	1-128-526-11	ELECT	100μF	20%	16V
R98	1-215-915-11	METAL OXIDE	470	5%	3W	F	C27	1-102-852-91	CERAMIC	47PF	5%	50V
							C28	1-107-906-11	ELECT	10μF	20%	50V
							C29	1-102-824-00	CERAMIC	470PF	5%	50V
							C30	1-102-824-00	CERAMIC	470PF	5%	50V
RY1	* 1-515-868-11	RELAY					C31	1-102-824-00	CERAMIC	470PF	5%	50V
							C32	1-101-004-00	CERAMIC	0.01μF		50V
							C33	1-101-004-00	CERAMIC	0.01μF		50V
							C34	1-101-004-00	CERAMIC	0.01μF		50V
T1	1-433-524-11	TRANSFORMER, HORIZONTAL DRIVE					C35	1-101-004-00	CERAMIC	0.01μF		50V
T2	1-433-520-11	TRANSFORMER, FERRITE (HOT)					C38	1-102-050-00	CERAMIC	0.01μF	99%	500V
							C39	1-111-168-91	ELECT	100μF	20%	100V
							C40	1-107-906-11	ELECT	10μF	20%	50V
							C43	1-111-171-31	ELECT	220μF	20%	100V
TP1	* 1-537-864-11	PIN, POST					C44	1-128-526-11	ELECT	100μF	20%	16V
TP2	* 1-537-864-11	PIN, POST					C45	1-111-057-11	ELECT	120μF	20%	25V
							C46	1-102-050-00	CERAMIC	0.01μF	99%	500V
							C49	1-111-168-91	ELECT	100μF	20%	100V
							C50	1-102-050-00	CERAMIC	0.01μF	99%	500V
							C51	1-107-906-11	ELECT	10μF	20%	50V

Ref.No.	Part No.	Description				Remark	Ref.No.	Part No.	Description				Remark
C52	1-162-318-11	CERAMIC	0.001μF	10%	500V		L4	1-459-155-00	COIL (WITH CORE) 45μH				
C53	1-162-318-11	CERAMIC	0.001μF	10%	500V								
C54	1-162-318-11	CERAMIC	0.001μF	10%	500V								
C55	1-162-318-11	CERAMIC	0.001μF	10%	500V			<TRANSISTOR>					
C56	1-162-318-11	CERAMIC	0.001μF	10%	500V								
C57	1-162-318-11	CERAMIC	0.001μF	10%	500V		Q1	8-729-030-02	TRANSISTOR DTC144ESA				
C58	1-111-171-31	ELECT	220μF	20%	100V		Q2	8-729-207-82	TRANSISTOR 2SC3421-Y				
C59	1-102-050-00	CERAMIC	0.01μF	99%	500V		Q3	8-729-030-02	TRANSISTOR DTC144ESA				
C60	1-111-168-91	ELECT	100μF	20%	100V		Q7	8-729-207-82	TRANSISTOR 2SC3421-Y				
C61	1-128-526-11	ELECT	100μF	20%	16V		Q11	8-729-207-89	TRANSISTOR 2SA1358-Y				
C62	1-102-050-00	CERAMIC	0.01μF	99%	500V		Q12	8-729-207-82	TRANSISTOR 2SC3421-Y				
C63	1-102-050-00	CERAMIC	0.01μF	99%	500V								
C64	1-111-168-91	ELECT	100μF	20%	100V			<RESISTOR>					
C65	1-102-050-00	CERAMIC	0.01μF	99%	500V		R1	1-249-405-11	CARBON	100	5%	1/4W	F
C66	1-111-168-91	ELECT	100μF	20%	100V		R2	1-249-405-11	CARBON	100	5%	1/4W	F
C67	1-111-168-91	ELECT	100μF	20%	100V		R3	1-249-405-11	CARBON	100	5%	1/4W	F
C68	1-107-926-11	ELECT	2.2μF	20%	100V		R4	1-249-421-11	CARBON	2.2K	5%	1/4W	
C69	1-102-824-00	CERAMIC	470PF	5%	50V		R5	1-247-815-91	CARBON	220	5%	1/4W	
C70	1-102-824-00	CERAMIC	470PF	5%	50V								
C71	1-102-824-00	CERAMIC	470PF	5%	50V		R6	1-247-815-91	CARBON	220	5%	1/4W	
C72	1-102-824-00	CERAMIC	470PF	5%	50V		R7	1-247-815-91	CARBON	220	5%	1/4W	
C73	1-102-852-91	CERAMIC	47PF	5%	50V		R8	1-247-815-91	CARBON	220	5%	1/4W	
C74	1-102-824-00	CERAMIC	470PF	5%	50V		R9	1-247-815-91	CARBON	220	5%	1/4W	
C75	1-102-852-91	CERAMIC	47PF	5%	50V		R10	1-247-815-91	CARBON	220	5%	1/4W	
C76	1-102-824-00	CERAMIC	470PF	5%	50V		R11	1-249-429-11	CARBON	10K	5%	1/4W	
C77	1-102-852-91	CERAMIC	47PF	5%	50V		R12	1-249-429-11	CARBON	10K	5%	1/4W	
							R13	1-247-807-31	CARBON	100	5%	1/4W	
							R14	1-249-437-11	CARBON	47K	5%	1/4W	
							R15	1-247-863-91	CARBON	22K	5%	1/4W	
							R16	1-215-433-00	METAL	3.3K	1%	1/4W	
							R17	1-249-425-11	CARBON	4.7K	5%	1/4W	
							R18	1-215-413-00	METAL	470	1%	1/4W	
							R19	1-249-437-11	CARBON	47K	5%	1/4W	
							R20	1-214-816-00	METAL	10	1%	1/2W	
							R21	1-214-816-00	METAL	10	1%	1/2W	
							R22	1-214-816-00	METAL	10	1%	1/2W	
							R23	1-214-816-00	METAL	10	1%	1/2W	
							R24	1-214-816-00	METAL	10	1%	1/2W	
							R25	1-214-816-00	METAL	10	1%	1/2W	
							R26	1-214-816-00	METAL	10	1%	1/2W	
							R27	1-214-816-00	METAL	10	1%	1/2W	
							R28	1-214-816-00	METAL	10	1%	1/2W	
							R29	1-214-816-00	METAL	10	1%	1/2W	
							R30	1-215-433-00	METAL	3.3K	1%	1/4W	
							R31	1-216-475-11	METAL OXIDE	120	5%	3W	F
							R32	1-247-807-31	CARBON	100	5%	1/4W	
							R33	1-249-429-11	CARBON	10K	5%	1/4W	
							R34	1-247-807-31	CARBON	100	5%	1/4W	
							R35	1-249-434-11	CARBON	27K	5%	1/4W	
							R36	1-215-413-00	METAL	470	1%	1/4W	
							R37	1-249-421-11	CARBON	2.2K	5%	1/4W	
							R38	1-216-475-11	METAL OXIDE	120	5%	3W	F
							R39	1-214-816-00	METAL	10	1%	1/2W	
							R40	1-214-816-00	METAL	10	1%	1/2W	
							R41	1-214-816-00	METAL	10	1%	1/2W	
							R42	1-214-816-00	METAL	10	1%	1/2W	
							R43	1-214-816-00	METAL	10	1%	1/2W	
							R44	1-214-816-00	METAL	10	1%	1/2W	
							R45	1-214-816-00	METAL	10	1%	1/2W	



Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description			Remark
R46	1-214-816-00	METAL	10	1%	1/2W	R126	1-249-429-11	CARBON	10K	5%	1/4W
R47	1-214-816-00	METAL	10	1%	1/2W	R127	1-249-427-11	CARBON	6.8K	5%	1/4W
R48	1-214-816-00	METAL	10	1%	1/2W	R128	1-247-863-91	CARBON	22K	5%	1/4W
R49	1-215-433-00	METAL	3.3K	1%	1/4W	R129	1-249-425-11	CARBON	4.7K	5%	1/4W
R50	1-247-807-31	CARBON	100	5%	1/4W	R130	1-249-434-11	CARBON	27K	5%	1/4W
R51	1-215-413-00	METAL	470	1%	1/4W	R131	1-247-807-31	CARBON	100	5%	1/4W
R52	1-247-807-31	CARBON	100	5%	1/4W	R132	1-247-807-31	CARBON	100	5%	1/4W
R53	1-247-807-31	CARBON	100	5%	1/4W	R133	1-247-807-31	CARBON	100	5%	1/4W
R54	1-247-807-31	CARBON	100	5%	1/4W	R134	1-215-433-00	METAL	3.3K	1%	1/4W
R55	1-249-421-11	CARBON	2.2K	5%	1/4W	R135	1-215-433-00	METAL	3.3K	1%	1/4W
R56	1-249-429-11	CARBON	10K	5%	1/4W	R136	1-215-433-00	METAL	3.3K	1%	1/4W
R57	1-215-433-00	METAL	3.3K	1%	1/4W	R137	1-215-433-00	METAL	3.3K	1%	1/4W
R58	1-215-433-00	METAL	3.3K	1%	1/4W	R138	1-215-413-00	METAL	470	1%	1/4W
R59	1-215-433-00	METAL	3.3K	1%	1/4W	R139	1-215-433-00	METAL	3.3K	1%	1/4W
R60	1-214-816-00	METAL	10	1%	1/2W	R140	1-215-413-00	METAL	470	1%	1/4W
R61	1-214-816-00	METAL	10	1%	1/2W	R141	1-215-433-00	METAL	3.3K	1%	1/4W
R62	1-214-816-00	METAL	10	1%	1/2W	R142	1-215-413-00	METAL	470	1%	1/4W
R63	1-214-816-00	METAL	10	1%	1/2W	R143	1-214-816-00	METAL	10	1%	1/2W
R64	1-214-816-00	METAL	10	1%	1/2W	R144	1-214-816-00	METAL	10	1%	1/2W
R65	1-214-816-00	METAL	10	1%	1/2W	R145	1-214-816-00	METAL	10	1%	1/2W
R66	1-214-816-00	METAL	10	1%	1/2W	R146	1-214-816-00	METAL	10	1%	1/2W
R67	1-214-816-00	METAL	10	1%	1/2W	R147	1-214-816-00	METAL	10	1%	1/2W
R68	1-214-816-00	METAL	10	1%	1/2W	R148	1-214-816-00	METAL	10	1%	1/2W
R69	1-214-816-00	METAL	10	1%	1/2W	R149	1-214-816-00	METAL	10	1%	1/2W
R70	1-249-429-11	CARBON	10K	5%	1/4W	R150	1-214-816-00	METAL	10	1%	1/2W
R71	1-247-863-91	CARBON	22K	5%	1/4W	R151	1-214-816-00	METAL	10	1%	1/2W
R72	1-247-807-31	CARBON	100	5%	1/4W	R152	1-214-816-00	METAL	10	1%	1/2W
R73	1-249-441-11	CARBON	100K	5%	1/4W	R153	1-214-816-00	METAL	10	1%	1/2W
R74	1-249-441-11	CARBON	100K	5%	1/4W	R154	1-214-816-00	METAL	10	1%	1/2W
R75	1-247-903-00	CARBON	1M	5%	1/4W	R155	1-214-816-00	METAL	10	1%	1/2W
R76	1-216-475-11	METAL OXIDE	120	5%	3W F	R156	1-214-816-00	METAL	10	1%	1/2W
R78	1-216-475-11	METAL OXIDE	120	5%	3W F	R157	1-214-816-00	METAL	10	1%	1/2W
R79	1-249-441-11	CARBON	100K	5%	1/4W	R158	1-214-816-00	METAL	10	1%	1/2W
R80	1-249-441-11	CARBON	100K	5%	1/4W	R159	1-214-816-00	METAL	10	1%	1/2W
R84	1-247-903-00	CARBON	1M	5%	1/4W	R160	1-214-816-00	METAL	10	1%	1/2W
R85	1-249-429-11	CARBON	10K	5%	1/4W	R161	1-214-816-00	METAL	10	1%	1/2W
R86	1-247-807-31	CARBON	100	5%	1/4W	R162	1-214-816-00	METAL	10	1%	1/2W
R89	1-247-863-91	CARBON	22K	5%	1/4W	R163	1-214-816-00	METAL	10	1%	1/2W
R90	1-249-421-11	CARBON	2.2K	5%	1/4W	R164	1-214-816-00	METAL	10	1%	1/2W
R95	1-216-475-11	METAL OXIDE	120	5%	3W F	R165	1-214-816-00	METAL	10	1%	1/2W
R96	1-249-413-11	CARBON	470	5%	1/4W	R166	1-214-816-00	METAL	10	1%	1/2W
R97	1-216-386-11	METAL OXIDE	0.56	5%	3W F	R167	1-214-816-00	METAL	10	1%	1/2W
R98	1-216-475-11	METAL OXIDE	120	5%	3W F	R168	1-214-816-00	METAL	10	1%	1/2W
R99	1-216-386-11	METAL OXIDE	0.56	5%	3W F	R169	1-214-816-00	METAL	10	1%	1/2W
R104	1-249-429-11	CARBON	10K	5%	1/4W	R170	1-214-816-00	METAL	10	1%	1/2W
R105	1-249-427-11	CARBON	6.8K	5%	1/4W	R171	1-214-816-00	METAL	10	1%	1/2W
R112	1-249-389-11	CARBON	4.7	5%	1/4W F	R172	1-214-816-00	METAL	10	1%	1/2W
R114	1-249-413-11	CARBON	470	5%	1/4W	R180	1-249-429-11	CARBON	10K	5%	1/4W
R115	1-216-386-11	METAL OXIDE	0.56	5%	3W F	R181	1-249-429-11	CARBON	10K	5%	1/4W
R116	1-249-405-11	CARBON	100	5%	1/4W F						
R117	1-249-405-11	CARBON	100	5%	1/4W F						
R118	1-249-405-11	CARBON	100	5%	1/4W F						
R119	1-247-815-91	CARBON	220	5%	1/4W						
R120	1-247-815-91	CARBON	220	5%	1/4W						
R121	1-247-815-91	CARBON	220	5%	1/4W						
R122	1-247-815-91	CARBON	220	5%	1/4W						
R123	1-247-815-91	CARBON	220	5%	1/4W						
R124	1-247-815-91	CARBON	220	5%	1/4W						
R125	1-216-386-11	METAL OXIDE	0.56	5%	3W F						

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
*****				C154	1-126-964-11	ELECT 10μF 20%	50V
* A-1346-774-A DA COMPLETE PC BOARD				C155	1-126-960-11	ELECT 1μF 20%	50V
*****				C156	1-126-960-11	ELECT 1μF 20%	50V
<CAPACITOR>				C157	1-136-153-00	FILM 0.01μF 5%	50V
C101	1-126-968-11	ELECT 100μF 20%	50V	C158	1-136-153-00	FILM 0.01μF 5%	50V
C102	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V	C159	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C103	1-126-963-11	ELECT 4.7μF 20%	50V	C160	1-126-960-11	ELECT 1μF 20%	50V
C104	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C161	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C105	1-126-964-11	ELECT 10μF 20%	50V	C162	1-126-964-11	ELECT 10μF 20%	50V
C106	1-126-933-11	ELECT 100μF 20%	16V	C163	1-126-934-11	ELECT 220μF 20%	16V
C107	1-163-253-11	CERAMIC CHIP 120PF 5%	50V	C164	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C108	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C165	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
C109	1-126-968-11	ELECT 100μF 20%	50V	C166	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
C110	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V	C167	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C111	1-137-366-11	FILM 0.0022μF 5%	50V	C168	1-126-964-11	ELECT 10μF 20%	50V
C112	1-126-959-11	ELECT 0.47μF 20%	50V	C169	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
C113	1-126-963-11	ELECT 4.7μF 20%	50V	C170	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C114	1-136-159-00	FILM 0.033μF 5%	50V	C171	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C116	1-126-963-11	ELECT 4.7μF 20%	50V	C172	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C117	1-126-933-11	ELECT 100μF 20%	16V	C301	1-126-964-11	ELECT 10μF 20%	50V
C118	1-104-664-11	ELECT 47μF 20%	16V	C302	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C119	1-126-961-11	ELECT 2.2μF 20%	50V	C303	1-126-964-11	ELECT 10μF 20%	50V
C120	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C304	1-164-346-11	CERAMIC CHIP 1μF	16V
C121	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C305	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C122	1-126-961-11	ELECT 2.2μF 20%	50V	C306	1-126-964-11	ELECT 10μF 20%	50V
C123	1-126-960-11	ELECT 1μF 20%	50V	C307	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
C124	1-136-165-00	FILM 0.1μF 5%	50V	C308	1-126-964-11	ELECT 10μF 20%	50V
C125	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C309	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C126	1-126-964-11	ELECT 10μF 20%	50V	C310	1-126-964-11	ELECT 10μF 20%	50V
C127	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C311	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C128	1-137-368-11	FILM 0.0047μF 5%	50V	C312	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C129	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C313	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C130	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C314	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C131	1-137-194-81	FILM 0.47μF 5%	50V	C315	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V
C132	1-126-963-11	ELECT 4.7μF 20%	50V	C316	1-126-964-11	ELECT 10μF 20%	50V
C133	1-137-366-11	FILM 0.0022μF 5%	50V	C317	1-126-964-11	ELECT 10μF 20%	50V
C134	1-126-933-11	ELECT 100μF 20%	16V	C318	1-126-964-11	ELECT 10μF 20%	50V
C135	1-126-960-11	ELECT 1μF 20%	50V	C319	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C136	1-136-165-00	FILM 0.1μF 5%	50V	C320	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C137	1-130-471-00	FILM 0.001μF 5%	50V	C321	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V
C138	1-130-471-00	FILM 0.001μF 5%	50V	C322	1-126-964-11	ELECT 10μF 20%	50V
C139	1-126-965-11	ELECT 22μF 20%	50V	C323	1-126-964-11	ELECT 10μF 20%	50V
C140	1-126-960-11	ELECT 1μF 20%	50V	C324	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C141	1-130-471-00	FILM 0.001μF 5%	50V	C325	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C142	1-126-961-11	ELECT 2.2μF 20%	50V	C326	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C143	1-126-935-11	ELECT 470μF 20%	16V	C327	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C144	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C328	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C145	1-136-157-00	FILM 0.022μF 5%	50V	C329	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C146	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C330	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V
C147	1-126-934-11	ELECT 220μF 20%	16V	C331	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V
C148	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C332	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C149	1-163-259-91	CERAMIC CHIP 220PF 5%	50V	C333	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C150	1-126-961-11	ELECT 2.2μF 20%	50V	C334	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V
C151	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C335	1-164-346-11	CERAMIC CHIP 1μF	16V
C152	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C351	1-126-964-11	ELECT 10μF 20%	50V
C153	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C352	1-163-031-11	CERAMIC CHIP 0.01μF	50V
				C353	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V
				C354	1-163-031-11	CERAMIC CHIP 0.01μF	50V



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C355	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D111	8-719-801-78	DIODE 1SS184	
C356	1-126-964-11	ELECT 10μF	20% 50V	D112	8-719-801-78	DIODE 1SS184	
C357	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D113	8-719-801-78	DIODE 1SS184	
C358	1-126-964-11	ELECT 10μF	20% 50V	D351	8-719-053-18	DIODE 1SR154-400TE-25	
C359	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D352	8-719-053-18	DIODE 1SR154-400TE-25	
C360	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D353	8-719-977-28	DIODE DTZ10B	
C361	1-126-933-11	ELECT 100μF	20% 16V	D354	8-719-056-76	DIODE UDZ-TE-17-3.6B	
C362	1-126-933-11	ELECT 100μF	20% 16V	D355	8-719-158-15	DIODE RD5.6SB	
C364	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D356	8-719-801-78	DIODE 1SS184	
C365	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C366	1-163-031-11	CERAMIC CHIP 0.01μF	50V			<IC>	
C367	1-126-965-11	ELECT 22μF	20% 50V	IC101	8-759-300-78	IC HD14538BFP	
C368	1-126-965-11	ELECT 22μF	20% 50V	IC102	8-759-460-81	IC BA12FP-E2	
C401	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC103	8-759-300-78	IC HD14538BFP	
C402	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC104	8-759-381-53	IC UPC814G2-E2	
C403	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V	IC105	8-759-466-51	IC NJM79M12DLA(TE1)	
C404	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC106	8-749-010-15	IC MC-8639A	
C405	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC107	8-759-381-53	IC UPC814G2-E2	
C406	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC108	8-759-100-93	IC UPC393G2	
C407	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	IC109	8-759-381-53	IC UPC814G2-E2	
C409	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC110	8-759-100-60	IC UPC1377C	
C410	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC112	8-759-381-53	IC UPC814G2-E2	
C411	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC113	8-759-381-53	IC UPC814G2-E2	
C412	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	IC114	8-759-300-78	IC HD14538BFP	
C413	1-126-964-11	ELECT 10μF	20% 50V	IC115	8-759-100-96	IC UPC4558G2	
C414	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC116	8-759-300-78	IC HD14538BFP	
C415	1-126-964-11	ELECT 10μF	20% 50V	IC117	8-759-239-34	IC TC74HC4538AF	
C416	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC301	8-752-068-37	IC CXA1726AM	
C417	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC302	8-759-286-47	IC PC74HC4053D-T	
C418	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC303	8-759-457-55	IC AD835AR-REEL	
C419	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	IC305	8-759-984-88	IC LM6361M	
C425	1-126-960-11	ELECT 1μF	20% 50V	IC306	8-759-381-53	IC UPC814G2-E2	
C451	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC307	8-759-984-88	IC LM6361M	
C452	1-126-933-11	ELECT 100μF	20% 16V	IC308	8-759-925-99	IC SN74HC109ANS	
C453	1-126-933-11	ELECT 100μF	20% 16V	IC309	8-759-421-87	IC UPC319G2-E2	
C454	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC310	8-759-031-84	IC SC7S04F	
C455	1-104-664-11	ELECT 47μF	20% 16V	IC311	8-759-286-47	IC PC74HC4053D-T	
C456	1-126-964-11	ELECT 10μF	20% 50V	IC312	8-759-381-53	IC UPC814G2-E2	
C457	1-136-155-00	FILM 0.015μF	5% 50V	IC313	8-759-381-53	IC UPC814G2-E2	
C458	1-136-159-00	FILM 0.033μF	5% 50V	IC314	8-759-234-20	IC TC7S08F	
C459	1-136-165-00	FILM 0.1μF	5% 50V	IC351	8-759-908-15	IC TL431CLP	
				IC352	8-759-381-53	IC UPC814G2-E2	
				IC353	8-759-460-74	IC BA05FP-E2	
				IC354	8-759-381-53	IC UPC814G2-E2	
				IC355	8-759-539-89	IC LM2990SX-5.0	
				IC401	8-759-984-88	IC LM6361M	
				IC402	8-759-392-64	IC AD828AR	
				IC403	8-759-286-47	IC PC74HC4053D-T	
				IC405	8-759-392-64	IC AD828AR	
				IC406	8-759-457-55	IC AD835AR-REEL	
				IC407	8-759-381-53	IC UPC814G2-E2	
				IC451	8-752-065-69	IC CXA1470AS	
				IC452	8-759-381-53	IC UPC814G2-E2	
						<COIL>	
				L101	1-412-533-21	INDUCTOR 47μH	
				L102	1-412-533-21	INDUCTOR 47μH	

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
L351	1-412-533-21	INDUCTOR 47μH		R111	1-216-101-00	RES,CHIP 150K	5% 1/10W
L352	1-412-533-21	INDUCTOR 47μH		R112	1-216-083-00	RES,CHIP 27K	5% 1/10W
				R113	1-216-033-00	RES,CHIP 220	5% 1/10W
				R114	1-216-049-91	RES,CHIP 1K	5% 1/10W
				R115	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
		<TRANSISTOR>					
Q101	8-729-030-02	TRANSISTOR DTC144ESA		R116	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
Q102	8-729-105-74	TRANSISTOR 2SK523-M1		R117	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
Q103	8-729-230-49	TRANSISTOR 2SC2712-YG		R118	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
Q104	8-729-230-49	TRANSISTOR 2SC2712-YG		R119	1-216-025-91	RES,CHIP 100	5% 1/10W
Q105	8-729-030-02	TRANSISTOR DTC144ESA		R120	1-216-057-00	RES,CHIP 2.2K	5% 1/10W
Q106	8-729-230-49	TRANSISTOR 2SC2712-YG		R121	1-216-041-00	RES,CHIP 470	5% 1/10W
Q107	8-729-230-49	TRANSISTOR 2SC2712-YG		R122	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
Q108	8-729-230-49	TRANSISTOR 2SC2712-YG		R125	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
Q109	8-729-926-23	TRANSISTOR FMW5		R126	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
Q110	8-729-904-04	TRANSISTOR FMS2		R127	1-216-683-11	METAL CHIP 22K	0.50% 1/10W
Q111	8-729-230-49	TRANSISTOR 2SC2712-YG		R128	1-216-089-91	RES,CHIP 47K	5% 1/10W
Q112	8-729-230-49	TRANSISTOR 2SC2712-YG		R129	1-216-089-91	RES,CHIP 47K	5% 1/10W
Q113	8-729-230-49	TRANSISTOR 2SC2712-YG		R130	1-216-089-91	RES,CHIP 47K	5% 1/10W
Q114	8-729-216-22	TRANSISTOR 2SA1162-G		R131	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
Q115	8-729-216-22	TRANSISTOR 2SA1162-G		R132	1-216-095-00	RES,CHIP 82K	5% 1/10W
Q116	8-729-030-02	TRANSISTOR DTC144ESA		R133	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
Q117	8-729-230-49	TRANSISTOR 2SC2712-YG		R134	1-216-049-91	RES,CHIP 1K	5% 1/10W
Q118	8-729-030-02	TRANSISTOR DTC144ESA		R135	1-216-097-91	RES,CHIP 100K	5% 1/10W
Q119	8-729-230-49	TRANSISTOR 2SC2712-YG		R136	1-216-073-00	RES,CHIP 10K	5% 1/10W
Q120	8-729-230-49	TRANSISTOR 2SC2712-YG		R137	1-216-085-00	RES,CHIP 33K	5% 1/10W
Q121	8-729-216-22	TRANSISTOR 2SA1162-G		R138	1-216-073-00	RES,CHIP 10K	5% 1/10W
Q122	8-729-216-22	TRANSISTOR 2SA1162-G		R139	1-216-073-00	RES,CHIP 10K	5% 1/10W
Q123	8-729-230-49	TRANSISTOR 2SC2712-YG		R140	1-216-073-00	RES,CHIP 10K	5% 1/10W
Q124	8-729-216-22	TRANSISTOR 2SA1162-G		R141	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
Q125	8-729-230-49	TRANSISTOR 2SC2712-YG		R142	1-216-013-00	RES,CHIP 33	5% 1/10W
Q126	8-729-230-49	TRANSISTOR 2SC2712-YG		R143	1-216-697-91	METAL CHIP 82K	0.50% 1/10W
Q127	8-729-216-22	TRANSISTOR 2SA1162-G		R144	1-216-697-91	METAL CHIP 82K	0.50% 1/10W
Q128	1-801-806-11	TRANSISTOR DTC144EKA-T146		R145	1-216-081-00	RES,CHIP 22K	5% 1/10W
Q301	8-729-230-49	TRANSISTOR 2SC2712-YG		R146	1-216-049-91	RES,CHIP 1K	5% 1/10W
Q302	8-729-216-22	TRANSISTOR 2SA1162-G		R147	1-216-643-11	METAL CHIP 470	0.50% 1/10W
Q351	8-729-230-49	TRANSISTOR 2SC2712-YG		R148	1-216-663-11	METAL CHIP 3.3K	0.50% 1/10W
Q352	8-729-216-22	TRANSISTOR 2SA1162-G		R149	1-216-091-00	RES,CHIP 56K	5% 1/10W
Q353	8-729-230-49	TRANSISTOR 2SC2712-YG		R150	1-216-049-91	RES,CHIP 1K	5% 1/10W
Q354	8-729-030-02	TRANSISTOR DTC144ESA		R151	1-216-697-91	METAL CHIP 82K	0.50% 1/10W
Q401	8-729-926-23	TRANSISTOR FMW5		R152	1-216-697-91	METAL CHIP 82K	0.50% 1/10W
Q402	8-729-026-57	TRANSISTOR FMS1A-T148		R153	1-216-025-91	RES,CHIP 100	5% 1/10W
Q403	8-729-216-22	TRANSISTOR 2SA1162-G		R154	1-216-655-11	METAL CHIP 1.5K	0.50% 1/10W
Q404	8-729-230-49	TRANSISTOR 2SC2712-YG		R155	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
Q451	8-729-230-49	TRANSISTOR 2SC2712-YG		R156	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
Q452	8-729-230-49	TRANSISTOR 2SC2712-YG		R157	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
Q811	1-801-806-11	TRANSISTOR DTC144EKA-T146		R158	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
		<RESISTOR>		R159	1-216-677-11	METAL CHIP 12K	0.50% 1/10W
R101	1-216-699-11	METAL CHIP 100K	0.50% 1/10W	R160	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
R102	1-216-073-00	RES,CHIP 10K	5% 1/10W	R161	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
R103	1-216-049-91	RES,CHIP 1K	5% 1/10W	R162	1-216-695-11	METAL CHIP 68K	0.50% 1/10W
R104	1-216-651-11	METAL CHIP 1K	0.50% 1/10W	R163	1-216-679-11	METAL CHIP 15K	0.50% 1/10W
R105	1-216-649-11	METAL CHIP 820	0.50% 1/10W	R164	1-216-073-00	RES,CHIP 10K	5% 1/10W
R106	1-216-065-91	RES,CHIP 4.7K	5% 1/10W	R165	1-216-665-11	METAL CHIP 3.9K	0.50% 1/10W
R107	1-216-651-11	METAL CHIP 1K	0.50% 1/10W	R166	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R108	1-216-687-11	METAL CHIP 33K	0.50% 1/10W	R167	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
R109	1-216-049-91	RES,CHIP 1K	5% 1/10W	R168	1-216-085-00	RES,CHIP 33K	5% 1/10W
R110	1-216-077-00	RES,CHIP 15K	5% 1/10W	R169	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
				R170	1-216-073-00	RES,CHIP 10K	5% 1/10W
				R171	1-216-069-00	RES,CHIP 6.8K	5% 1/10W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R172	1-216-071-00	RES,CHIP	8.2K 5% 1/10W	R301	1-218-758-11	METAL CHIP	180K 0.50% 1/10W
R173	1-216-049-91	RES,CHIP	1K 5% 1/10W	R302	1-216-685-11	METAL CHIP	27K 0.50% 1/10W
R174	1-216-049-91	RES,CHIP	1K 5% 1/10W	R303	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R175	1-216-049-91	RES,CHIP	1K 5% 1/10W	R304	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R176	1-216-105-91	RES,CHIP	220K 5% 1/10W	R305	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R177	1-216-043-91	RES,CHIP	560 5% 1/10W	R306	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R178	1-216-017-91	RES,CHIP	47 5% 1/10W	R307	1-216-025-91	RES,CHIP	100 5% 1/10W
R179	1-216-089-91	RES,CHIP	47K 5% 1/10W	R308	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R180	1-216-031-00	RES,CHIP	180 5% 1/10W	R309	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R181	1-216-683-11	METAL CHIP	22K 0.50% 1/10W	R310	1-216-025-91	RES,CHIP	100 5% 1/10W
R182	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R311	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R183	1-216-043-91	RES,CHIP	560 5% 1/10W	R312	1-216-657-11	METAL CHIP	1.8K 0.50% 1/10W
R184	1-216-683-11	METAL CHIP	22K 0.50% 1/10W	R313	1-216-025-91	RES,CHIP	100 5% 1/10W
R185	1-216-025-91	RES,CHIP	100 5% 1/10W	R315	1-216-025-91	RES,CHIP	100 5% 1/10W
R186	1-216-091-00	RES,CHIP	56K 5% 1/10W	R317	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R187	1-216-025-91	RES,CHIP	100 5% 1/10W	R318	1-216-635-11	METAL CHIP	220 0.50% 1/10W
R188	1-216-049-91	RES,CHIP	1K 5% 1/10W	R319	1-216-685-11	METAL CHIP	27K 0.50% 1/10W
R189	1-216-073-00	RES,CHIP	10K 5% 1/10W	R320	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R190	1-216-073-00	RES,CHIP	10K 5% 1/10W	R321	1-216-665-11	METAL CHIP	3.9K 0.50% 1/10W
R191	1-216-061-00	RES,CHIP	3.3K 5% 1/10W	R322	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W
R192	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R323	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R193	1-216-059-00	RES,CHIP	2.7K 5% 1/10W	R324	1-216-025-91	RES,CHIP	100 5% 1/10W
R194	1-216-049-91	RES,CHIP	1K 5% 1/10W	R325	1-216-699-11	METAL CHIP	100K 0.50% 1/10W
R195	1-216-049-91	RES,CHIP	1K 5% 1/10W	R326	1-216-025-91	RES,CHIP	100 5% 1/10W
R196	1-216-073-00	RES,CHIP	10K 5% 1/10W	R327	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R197	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R328	1-216-695-11	METAL CHIP	68K 0.50% 1/10W
R198	1-216-055-00	RES,CHIP	1.8K 5% 1/10W	R329	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R199	1-216-025-91	RES,CHIP	100 5% 1/10W	R330	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R200	1-216-049-91	RES,CHIP	1K 5% 1/10W	R331	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R201	1-216-073-00	RES,CHIP	10K 5% 1/10W	R332	1-216-025-91	RES,CHIP	100 5% 1/10W
R202	1-216-691-11	METAL CHIP	47K 0.50% 1/10W	R333	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R203	1-216-077-00	RES,CHIP	15K 5% 1/10W	R334	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R204	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R335	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R205	1-216-073-00	RES,CHIP	10K 5% 1/10W	R336	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R206	1-216-077-00	RES,CHIP	15K 5% 1/10W	R337	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R207	1-216-073-00	RES,CHIP	10K 5% 1/10W	R338	1-216-679-11	METAL CHIP	15K 0.50% 1/10W
R208	1-216-073-00	RES,CHIP	10K 5% 1/10W	R339	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R209	1-216-073-00	RES,CHIP	10K 5% 1/10W	R341	1-216-049-91	RES,CHIP	1K 5% 1/10W
R210	1-216-073-00	RES,CHIP	10K 5% 1/10W	R342	1-216-049-91	RES,CHIP	1K 5% 1/10W
R211	1-216-049-91	RES,CHIP	1K 5% 1/10W	R343	1-216-097-91	RES,CHIP	100K 5% 1/10W
R212	1-216-643-11	METAL CHIP	470 0.50% 1/10W	R344	1-216-073-00	RES,CHIP	10K 5% 1/10W
R213	1-216-049-91	RES,CHIP	1K 5% 1/10W	R345	1-216-101-00	RES,CHIP	150K 5% 1/10W
R214	1-216-061-00	RES,CHIP	3.3K 5% 1/10W	R351	1-216-635-11	METAL CHIP	220 0.50% 1/10W
R215	1-216-061-00	RES,CHIP	3.3K 5% 1/10W	R352	1-216-683-11	METAL CHIP	22K 0.50% 1/10W
R216	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R353	1-216-681-11	METAL CHIP	18K 0.50% 1/10W
R217	1-216-677-11	METAL CHIP	12K 0.50% 1/10W	R354	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R218	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R355	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R219	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W	R356	1-218-754-11	METAL CHIP	120K 0.50% 1/10W
R220	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R357	1-218-754-11	METAL CHIP	120K 0.50% 1/10W
R221	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R358	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R222	1-216-001-00	RES,CHIP	10 5% 1/10W	R359	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R223	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R360	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R224	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R361	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R225	1-216-641-11	METAL CHIP	390 0.50% 1/10W	R362	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R226	1-216-673-11	METAL CHIP	8.2K 0.50% 1/10W	R363	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R227	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R364	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R228	1-216-025-91	RES,CHIP	100 5% 1/10W	R365	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R229	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R366	1-216-657-11	METAL CHIP	1.8K 0.50% 1/10W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R367	1-216-685-11	METAL CHIP	27K 0.50% 1/10W	R455	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W
R368	1-216-073-00	RES,CHIP	10K 5% 1/10W	R456	1-216-049-91	RES,CHIP	1K 5% 1/10W
R369	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W	R457	1-216-683-11	METAL CHIP	22K 0.50% 1/10W
R370	1-216-073-00	RES,CHIP	10K 5% 1/10W	R458	1-216-692-11	METAL CHIP	51K 0.50% 1/10W
R371	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R459	1-216-025-91	RES,CHIP	100 5% 1/10W
R375	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R460	1-216-699-11	METAL CHIP	100K 0.50% 1/10W
R376	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R462	1-216-025-91	RES,CHIP	100 5% 1/10W
R377	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R463	1-216-025-91	RES,CHIP	100 5% 1/10W
R378	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R464	1-216-025-91	RES,CHIP	100 5% 1/10W
R379	1-216-025-91	RES,CHIP	100 5% 1/10W	R465	1-216-025-91	RES,CHIP	100 5% 1/10W
R380	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W	R466	1-216-025-91	RES,CHIP	100 5% 1/10W
R381	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	<VARIABLE RESISTOR>			
R382	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	RV101	1-238-787-11	RES, ADJ, CERMET 10K	
R383	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	RV102	1-238-789-11	RES, ADJ, CERMET 50K	
R401	1-216-025-91	RES,CHIP	100 5% 1/10W	RV103	1-238-790-11	RES, ADJ, CERMET 100K	
R402	1-216-025-91	RES,CHIP	100 5% 1/10W	RV104	1-238-787-11	RES, ADJ, CERMET 10K	
R403	1-216-025-91	RES,CHIP	100 5% 1/10W	RV105	1-238-785-21	RES, ADJ, CERMET 2K	
R404	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	RV301	1-238-784-11	RES, ADJ, CERMET 1K	
R405	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	RV302	1-238-787-11	RES, ADJ, CERMET 10K	
R406	1-216-025-91	RES,CHIP	100 5% 1/10W	RV303	1-238-783-11	RES, ADJ, CERMET 500	
R407	1-216-673-11	METAL CHIP	8.2K 0.50% 1/10W	RV402	1-238-787-11	RES, ADJ, CERMET 10K	
R408	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	RV403	1-238-787-11	RES, ADJ, CERMET 10K	
R409	1-216-025-91	RES,CHIP	100 5% 1/10W	<SWITCH>			
R410	1-216-025-91	RES,CHIP	100 5% 1/10W	S101	1-570-865-11	SWITCH, SLIDE	
R411	1-216-025-91	RES,CHIP	100 5% 1/10W	S102	1-570-865-11	SWITCH, SLIDE	
R412	1-216-025-91	RES,CHIP	100 5% 1/10W	<TEST PIN>			
R413	1-216-025-91	RES,CHIP	100 5% 1/10W	TP101	* 1-537-864-11	PIN, POST	
R414	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	TP102	* 1-537-864-11	PIN, POST	
R415	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	TP103	* 1-537-864-11	PIN, POST	
R417	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	TP104	* 1-537-864-11	PIN, POST	
R418	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	TP105	* 1-537-864-11	PIN, POST	
R419	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W	TP106	* 1-537-864-11	PIN, POST	
R420	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	TP107	* 1-537-864-11	PIN, POST	
R421	1-216-681-11	METAL CHIP	18K 0.50% 1/10W	TP301	* 1-537-864-11	PIN, POST	
R422	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	TP401	* 1-537-864-11	PIN, POST	
R423	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	TP402	* 1-537-864-11	PIN, POST	
R424	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	TP403	* 1-537-864-11	PIN, POST	
R425	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	*****			
R426	1-216-025-91	RES,CHIP	100 5% 1/10W	* A-1346-775-A DD COMPLETE PC BOARD			
R427	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	*****			
R428	1-216-643-11	METAL CHIP	470 0.50% 1/10W	<CAPACITOR>			
R429	1-216-687-11	METAL CHIP	33K 0.50% 1/10W	C101	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R430	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	C102	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R431	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	C103	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R432	1-216-025-91	RES,CHIP	100 5% 1/10W	C104	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R433	1-216-097-91	RES,CHIP	100K 5% 1/10W	C105	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R434	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	C106	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R435	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	C107	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R436	1-216-057-00	RES,CHIP	2.2K 5% 1/10W				
R437	1-216-065-91	RES,CHIP	4.7K 5% 1/10W				
R438	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W				
R439	1-216-025-91	RES,CHIP	100 5% 1/10W				
R440	1-216-681-11	METAL CHIP	18K 0.50% 1/10W				
R441	1-216-025-91	RES,CHIP	100 5% 1/10W				
R442	1-216-025-91	RES,CHIP	100 5% 1/10W				
R451	1-216-061-00	RES,CHIP	3.3K 5% 1/10W				
R452	1-216-049-91	RES,CHIP	1K 5% 1/10W				
R453	1-216-677-11	METAL CHIP	12K 0.50% 1/10W				
R454	1-216-061-00	RES,CHIP	3.3K 5% 1/10W				



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C108	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C324	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C109	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C325	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C110	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C328	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C111	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C329	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C112	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C332	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C113	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C333	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C114	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C336	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C115	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C337	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C116	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C340	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C117	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C341	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C118	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C342	1-126-934-11	ELECT 220μF 20% 16V	16V
C119	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C343	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C120	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C344	1-164-346-11	CERAMIC CHIP 1μF	16V
C121	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C345	1-164-346-11	CERAMIC CHIP 1μF	16V
C122	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C346	1-164-346-11	CERAMIC CHIP 1μF	16V
C123	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C347	1-164-346-11	CERAMIC CHIP 1μF	16V
C124	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C348	1-164-346-11	CERAMIC CHIP 1μF	16V
C125	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C349	1-164-346-11	CERAMIC CHIP 1μF	16V
C126	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C450	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C127	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C451	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C128	1-126-933-11	ELECT 100μF	20% 16V	C452	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C129	1-126-933-11	ELECT 100μF	20% 16V	C453	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C131	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C454	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C132	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	C455	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C133	1-126-964-11	ELECT 10μF	20% 50V	C456	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C134	1-126-964-11	ELECT 10μF	20% 50V	C457	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C135	1-126-965-11	ELECT 22μF	20% 50V	C458	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C136	1-126-933-11	ELECT 100μF	20% 16V	C459	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C137	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C460	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C138	1-126-933-11	ELECT 100μF	20% 16V	C461	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C139	1-126-964-11	ELECT 10μF	20% 50V	C462	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C140	1-126-960-11	ELECT 1μF	20% 50V	C463	1-109-889-11	ELECT 1μF 20% 50V	50V
C141	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C142	1-163-031-11	CERAMIC CHIP 0.01μF	50V			<CONNECTOR>	
C143	1-109-889-11	ELECT 1μF	20% 50V				
C301	1-163-031-11	CERAMIC CHIP 0.01μF	50V	CN210	* 1-778-891-11	CONNECTOR, BOARD TO BOARD	
C302	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C303	1-163-031-11	CERAMIC CHIP 0.01μF	50V			<DIODE>	
C304	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D101	8-719-053-18	DIODE 1SR154-400TE-25	
C305	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D102	8-719-053-18	DIODE 1SR154-400TE-25	
C306	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D103	8-719-056-76	DIODE UDZ-TE-17-3.6B	
C307	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D104	8-719-404-50	DIODE MA111-TX	
C308	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D105	8-719-404-50	DIODE MA111-TX	
C309	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D106	8-719-404-50	DIODE MA111-TX	
C310	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D301	8-719-404-50	DIODE MA111-TX	
C311	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D302	8-719-404-50	DIODE MA111-TX	
C312	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C313	1-163-031-11	CERAMIC CHIP 0.01μF	50V			<IC>	
C314	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC101	8-759-326-65	IC MP7670AS-TE2	
C315	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC102	8-759-326-65	IC MP7670AS-TE2	
C316	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC103	8-759-326-65	IC MP7670AS-TE2	
C317	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC104	8-759-326-65	IC MP7670AS-TE2	
C318	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC105	8-759-326-65	IC MP7670AS-TE2	
C319	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC106	8-759-326-65	IC MP7670AS-TE2	
C320	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC107	8-759-326-65	IC MP7670AS-TE2	
C321	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC108	8-759-326-65	IC MP7670AS-TE2	
C322	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC109	8-759-326-65	IC MP7670AS-TE2	
C323	1-163-031-11	CERAMIC CHIP 0.01μF	50V				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
IC110	8-759-326-65	IC MP7670AS-TE2		R112	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
IC111	8-759-326-65	IC MP7670AS-TE2		R113	1-216-025-91	RES,CHIP 100	5% 1/10W
IC112	8-759-326-65	IC MP7670AS-TE2		R114	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
IC113	8-759-237-59	IC TC74HC541AF(EL)		R115	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
IC114	8-759-460-74	IC BA05FP-E2		R116	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
IC115	8-759-539-89	IC LM2990SX-5.0		R117	1-216-025-91	RES,CHIP 100	5% 1/10W
IC116	8-759-443-72	IC RH5VL43AA-T1		R118	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
IC117	8-759-908-15	IC TL431CLP		R119	1-216-695-11	METAL CHIP 68K	0.50% 1/10W
IC118	8-759-549-40	IC AD826AR-REEL		R120	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
IC301	8-759-326-65	IC MP7670AS-TE2		R121	1-216-695-11	METAL CHIP 68K	0.50% 1/10W
IC302	8-759-326-65	IC MP7670AS-TE2		R122	1-216-025-91	RES,CHIP 100	5% 1/10W
IC303	8-759-326-65	IC MP7670AS-TE2		R123	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
IC304	8-759-326-65	IC MP7670AS-TE2		R124	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
IC305	8-759-326-65	IC MP7670AS-TE2		R125	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
IC306	8-759-326-65	IC MP7670AS-TE2		R126	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
IC307	8-759-326-65	IC MP7670AS-TE2		R127	1-216-695-11	METAL CHIP 68K	0.50% 1/10W
IC308	8-759-326-65	IC MP7670AS-TE2		R128	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
IC309	8-759-326-65	IC MP7670AS-TE2		R129	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
IC310	8-759-326-65	IC MP7670AS-TE2		R130	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
IC311	8-759-326-65	IC MP7670AS-TE2		R131	1-216-025-91	RES,CHIP 100	5% 1/10W
IC312	8-759-326-65	IC MP7670AS-TE2		R132	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
IC313	8-759-392-64	IC AD828AR		R133	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
IC314	8-759-392-64	IC AD828AR		R134	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
IC315	8-759-392-64	IC AD828AR		R135	1-216-025-91	RES,CHIP 100	5% 1/10W
IC316	8-759-392-64	IC AD828AR		R136	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
IC317	8-759-392-64	IC AD828AR		R137	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
IC322	8-759-443-72	IC RH5VL43AA-T1		R138	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
IC323	8-759-392-64	IC AD828AR		R139	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
IC450	8-759-326-65	IC MP7670AS-TE2		R140	1-216-025-91	RES,CHIP 100	5% 1/10W
IC451	8-759-326-65	IC MP7670AS-TE2		R141	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
IC452	8-759-326-65	IC MP7670AS-TE2		R142	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
IC453	8-759-326-65	IC MP7670AS-TE2		R143	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
IC454	8-759-326-65	IC MP7670AS-TE2		R144	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
IC455	8-759-326-65	IC MP7670AS-TE2		R145	1-216-025-91	RES,CHIP 100	5% 1/10W
	<COIL>			R146	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
L101	1-412-533-21	INDUCTOR 47μH		R147	1-216-665-11	METAL CHIP 3.9K	0.50% 1/10W
L102	1-412-533-21	INDUCTOR 47μH		R148	1-216-679-11	METAL CHIP 15K	0.50% 1/10W
	<TRANSISTOR>			R149	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
Q101	8-729-230-49	TRANSISTOR 2SC2712-YG		R150	1-216-025-91	RES,CHIP 100	5% 1/10W
Q102	1-801-806-11	TRANSISTOR DTC144EKA-T146		R151	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
	<RESISTOR>			R152	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R101	1-216-681-11	METAL CHIP 18K	0.50% 1/10W	R153	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
R102	1-216-697-91	METAL CHIP 82K	0.50% 1/10W	R154	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W
R103	1-216-681-11	METAL CHIP 18K	0.50% 1/10W	R155	1-216-025-91	RES,CHIP 100	5% 1/10W
R104	1-216-025-91	RES,CHIP 100	5% 1/10W	R156	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W
R105	1-216-683-11	METAL CHIP 22K	0.50% 1/10W	R157	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
R106	1-216-683-11	METAL CHIP 22K	0.50% 1/10W	R158	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W
R107	1-216-681-11	METAL CHIP 18K	0.50% 1/10W	R159	1-216-665-11	METAL CHIP 3.9K	0.50% 1/10W
R108	1-216-697-91	METAL CHIP 82K	0.50% 1/10W	R160	1-216-025-91	RES,CHIP 100	5% 1/10W
R109	1-216-025-91	RES,CHIP 100	5% 1/10W	R161	1-216-025-91	RES,CHIP 100	5% 1/10W
R110	1-216-697-91	METAL CHIP 82K	0.50% 1/10W	R162	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
R111	1-216-687-11	METAL CHIP 33K	0.50% 1/10W	R163	1-216-683-11	METAL CHIP 22K	0.50% 1/10W
				R164	1-216-683-11	METAL CHIP 22K	0.50% 1/10W
				R165	1-216-683-11	METAL CHIP 22K	0.50% 1/10W
				R166	1-216-025-91	RES,CHIP 100	5% 1/10W
				R167	1-216-681-11	METAL CHIP 18K	0.50% 1/10W
				R168	1-216-025-91	RES,CHIP 100	5% 1/10W
				R169	1-216-025-91	RES,CHIP 100	5% 1/10W
				R170	1-216-025-91	RES,CHIP 100	5% 1/10W



Ref.No.	Part No.	Description		Remark	Ref.No.	Part No.	Description		Remark
R171	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R230	1-216-699-11	METAL CHIP	100K	0.50% 1/10W
R172	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R231	1-216-033-00	RES,CHIP	220	5% 1/10W
R173	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R232	1-216-683-11	METAL CHIP	22K	0.50% 1/10W
R174	1-216-025-91	RES,CHIP	100	5% 1/10W	R233	1-216-683-11	METAL CHIP	22K	0.50% 1/10W
R175	1-216-683-11	METAL CHIP	22K	0.50% 1/10W	R234	1-216-683-11	METAL CHIP	22K	0.50% 1/10W
R176	1-216-683-11	METAL CHIP	22K	0.50% 1/10W	R235	1-216-681-11	METAL CHIP	18K	0.50% 1/10W
R177	1-216-683-11	METAL CHIP	22K	0.50% 1/10W	R236	1-216-025-91	RES,CHIP	100	5% 1/10W
R178	1-216-025-91	RES,CHIP	100	5% 1/10W	R237	1-216-025-91	RES,CHIP	100	5% 1/10W
R179	1-216-025-91	RES,CHIP	100	5% 1/10W	R238	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R180	1-216-683-11	METAL CHIP	22K	0.50% 1/10W	R239	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R181	1-216-683-11	METAL CHIP	22K	0.50% 1/10W	R240	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R182	1-216-683-11	METAL CHIP	22K	0.50% 1/10W	R241	1-216-677-11	METAL CHIP	12K	0.50% 1/10W
R183	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R242	1-216-677-11	METAL CHIP	12K	0.50% 1/10W
R184	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R243	1-216-677-11	METAL CHIP	12K	0.50% 1/10W
R185	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R244	1-216-681-11	METAL CHIP	18K	0.50% 1/10W
R186	1-216-025-91	RES,CHIP	100	5% 1/10W	R245	1-216-681-11	METAL CHIP	18K	0.50% 1/10W
R187	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W	R246	1-216-681-11	METAL CHIP	18K	0.50% 1/10W
R188	1-216-025-91	RES,CHIP	100	5% 1/10W	R247	1-218-756-11	METAL CHIP	150K	0.50% 1/10W
R189	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W	R248	1-218-756-11	METAL CHIP	150K	0.50% 1/10W
R190	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R249	1-218-756-11	METAL CHIP	150K	0.50% 1/10W
R191	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R250	1-216-695-11	METAL CHIP	68K	0.50% 1/10W
R192	1-216-025-91	RES,CHIP	100	5% 1/10W	R251	1-216-695-11	METAL CHIP	68K	0.50% 1/10W
R193	1-216-025-91	RES,CHIP	100	5% 1/10W	R252	1-216-695-11	METAL CHIP	68K	0.50% 1/10W
R194	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R253	1-216-681-11	METAL CHIP	18K	0.50% 1/10W
R195	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R254	1-216-681-11	METAL CHIP	18K	0.50% 1/10W
R196	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R255	1-216-681-11	METAL CHIP	18K	0.50% 1/10W
R197	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W	R256	1-247-807-31	CARBON	100	5% 1/4W
R198	1-216-025-91	RES,CHIP	100	5% 1/10W	R257	1-247-807-31	CARBON	100	5% 1/4W
R199	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R258	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
R200	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R259	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
R201	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R260	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R202	1-216-025-91	RES,CHIP	100	5% 1/10W	R261	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R203	1-216-025-91	RES,CHIP	100	5% 1/10W	R262	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R204	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R263	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R205	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R264	1-216-683-11	METAL CHIP	22K	0.50% 1/10W
R206	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R265	1-216-683-11	METAL CHIP	22K	0.50% 1/10W
R207	1-216-025-91	RES,CHIP	100	5% 1/10W	R266	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R208	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R267	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R209	1-216-679-11	METAL CHIP	15K	0.50% 1/10W	R268	1-216-025-91	RES,CHIP	100	5% 1/10W
R210	1-216-679-11	METAL CHIP	15K	0.50% 1/10W	R269	1-216-681-11	METAL CHIP	18K	0.50% 1/10W
R211	1-216-025-91	RES,CHIP	100	5% 1/10W	R270	1-216-681-11	METAL CHIP	18K	0.50% 1/10W
R212	1-216-025-91	RES,CHIP	100	5% 1/10W	R271	1-216-681-11	METAL CHIP	18K	0.50% 1/10W
R213	1-216-679-11	METAL CHIP	15K	0.50% 1/10W	R272	1-247-807-31	CARBON	100	5% 1/4W
R214	1-216-679-11	METAL CHIP	15K	0.50% 1/10W	R273	1-216-025-91	RES,CHIP	100	5% 1/10W
R215	1-216-679-11	METAL CHIP	15K	0.50% 1/10W	R274	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
R216	1-216-025-91	RES,CHIP	100	5% 1/10W	R276	1-216-669-11	METAL CHIP	5.6K	0.50% 1/10W
R217	1-216-679-11	METAL CHIP	15K	0.50% 1/10W	R277	1-216-651-11	METAL CHIP	1K	0.50% 1/10W
R218	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R278	1-216-653-11	METAL CHIP	1.2K	0.50% 1/10W
R219	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R279	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R220	1-216-025-91	RES,CHIP	100	5% 1/10W	R280	1-216-687-11	METAL CHIP	33K	0.50% 1/10W
R221	1-216-025-91	RES,CHIP	100	5% 1/10W	R281	1-216-661-11	METAL CHIP	2.7K	0.50% 1/10W
R222	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R301	1-216-683-11	METAL CHIP	22K	0.50% 1/10W
R223	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R302	1-216-683-11	METAL CHIP	22K	0.50% 1/10W
R224	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R303	1-216-683-11	METAL CHIP	22K	0.50% 1/10W
R225	1-216-025-91	RES,CHIP	100	5% 1/10W	R304	1-216-025-91	RES,CHIP	100	5% 1/10W
R226	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R305	1-216-683-11	METAL CHIP	22K	0.50% 1/10W
R227	1-216-669-11	METAL CHIP	5.6K	0.50% 1/10W	R306	1-216-683-11	METAL CHIP	22K	0.50% 1/10W
R228	1-216-065-91	RES,CHIP	4.7K	5% 1/10W	R307	1-216-683-11	METAL CHIP	22K	0.50% 1/10W
R229	1-216-065-91	RES,CHIP	4.7K	5% 1/10W					



Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description			Remark
R308	1-216-025-91	RES,CHIP	100	5%	1/10W	R366	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R309	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R367	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R310	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R368	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
						R369	1-216-025-91	RES,CHIP	100	5%	1/10W
R311	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R370	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R312	1-216-025-91	RES,CHIP	100	5%	1/10W						
R313	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R371	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R314	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R372	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R315	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R373	1-216-025-91	RES,CHIP	100	5%	1/10W
						R374	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R316	1-216-025-91	RES,CHIP	100	5%	1/10W	R375	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R317	1-216-687-11	METAL CHIP	33K	0.50%	1/10W						
R318	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R376	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R319	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R377	1-216-025-91	RES,CHIP	100	5%	1/10W
R320	1-216-025-91	RES,CHIP	100	5%	1/10W	R378	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
						R379	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R321	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R380	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R322	1-216-687-11	METAL CHIP	33K	0.50%	1/10W						
R323	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R381	1-216-025-91	RES,CHIP	100	5%	1/10W
R324	1-216-025-91	RES,CHIP	100	5%	1/10W	R382	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R325	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R383	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
						R384	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R326	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R385	1-216-025-91	RES,CHIP	100	5%	1/10W
R327	1-216-687-11	METAL CHIP	33K	0.50%	1/10W						
R328	1-216-025-91	RES,CHIP	100	5%	1/10W	R386	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R329	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R387	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R330	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R388	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
						R389	1-216-025-91	RES,CHIP	100	5%	1/10W
R331	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R390	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R332	1-216-687-11	METAL CHIP	33K	0.50%	1/10W						
R333	1-216-025-91	RES,CHIP	100	5%	1/10W	R391	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R334	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R392	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R335	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R393	1-216-025-91	RES,CHIP	100	5%	1/10W
						R394	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R336	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R395	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R337	1-216-687-11	METAL CHIP	33K	0.50%	1/10W						
R338	1-216-025-91	RES,CHIP	100	5%	1/10W	R396	1-216-681-11	METAL CHIP	18K	0.50%	1/10W
R339	1-216-025-91	RES,CHIP	100	5%	1/10W	R397	1-216-025-91	RES,CHIP	100	5%	1/10W
R340	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R398	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
						R399	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R341	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R400	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R342	1-216-687-11	METAL CHIP	33K	0.50%	1/10W						
R343	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R401	1-216-025-91	RES,CHIP	100	5%	1/10W
R344	1-216-025-91	RES,CHIP	100	5%	1/10W	R402	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R345	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R403	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
						R404	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R346	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R405	1-216-025-91	RES,CHIP	100	5%	1/10W
R347	1-216-687-11	METAL CHIP	33K	0.50%	1/10W						
R348	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R406	1-216-665-11	METAL CHIP	3.9K	0.50%	1/10W
R349	1-216-025-91	RES,CHIP	100	5%	1/10W	R407	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R350	1-216-025-91	RES,CHIP	100	5%	1/10W	R408	1-216-665-11	METAL CHIP	3.9K	0.50%	1/10W
						R409	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R351	1-216-025-91	RES,CHIP	100	5%	1/10W	R410	1-216-665-11	METAL CHIP	3.9K	0.50%	1/10W
R352	1-216-687-11	METAL CHIP	33K	0.50%	1/10W						
R353	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R411	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R354	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R412	1-216-665-11	METAL CHIP	3.9K	0.50%	1/10W
R355	1-216-687-11	METAL CHIP	33K	0.50%	1/10W	R413	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
						R414	1-216-665-11	METAL CHIP	3.9K	0.50%	1/10W
R356	1-216-025-91	RES,CHIP	100	5%	1/10W	R415	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R357	1-216-687-11	METAL CHIP	33K	0.50%	1/10W						
R358	1-216-683-11	METAL CHIP	22K	0.50%	1/10W	R416	1-216-665-11	METAL CHIP	3.9K	0.50%	1/10W
R359	1-216-683-11	METAL CHIP	22K	0.50%	1/10W	R417	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R360	1-216-683-11	METAL CHIP	22K	0.50%	1/10W	R418	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
						R419	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R361	1-216-025-91	RES,CHIP	100	5%	1/10W	R420	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
R362	1-216-683-11	METAL CHIP	22K	0.50%	1/10W						
R363	1-216-683-11	METAL CHIP	22K	0.50%	1/10W	R421	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R364	1-216-683-11	METAL CHIP	22K	0.50%	1/10W	R422	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
R365	1-216-025-91	RES,CHIP	100	5%	1/10W	R423	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
						R424	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C12	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C120	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C13	1-104-664-11	ELECT 47μF 20%	16V	C121	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C14	1-104-664-11	ELECT 47μF 20%	16V	C122	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C15	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C126	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C16	1-104-665-11	ELECT 100μF 20%	25V	C127	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C17	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V	C128	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C18	1-126-933-11	ELECT 100μF 20%	16V	C129	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C19	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V	C130	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C21	1-126-933-11	ELECT 100μF 20%	16V	C131	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C22	1-104-665-11	ELECT 100μF 20%	25V	C133	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C23	1-126-933-11	ELECT 100μF 20%	16V	C134	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C24	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C135	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C25	1-126-961-11	ELECT 2.2μF 20%	50V	C136	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C26	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C137	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C27	1-126-960-11	ELECT 1μF 20%	50V	C138	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C28	1-126-960-11	ELECT 1μF 20%	50V	C141	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C29	1-136-153-00	FILM 0.01μF 5%	50V	C142	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C30	1-104-664-11	ELECT 47μF 20%	16V	C143	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C31	1-126-964-11	ELECT 10μF 20%	50V	C144	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C32	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C145	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C33	1-126-960-11	ELECT 1μF 20%	50V	C146	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C34	1-136-153-00	FILM 0.01μF 5%	50V	C500	1-102-973-00	CERAMIC 100PF 5%	50V
C35	1-104-664-11	ELECT 47μF 20%	16V	<CONNECTOR>			
C36	1-163-031-11	CERAMIC CHIP 0.01μF	50V	CN220 * 1-778-891-11 CONNECTOR, BOARD TO BOARD			
C37	1-104-664-11	ELECT 47μF 20%	16V	<DIODE>			
C38	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D1	8-719-900-95	DIODE V09G	
C39	1-104-664-11	ELECT 47μF 20%	16V	D2	8-719-900-95	DIODE V09G	
C40	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D3	8-719-801-78	DIODE 1SS184	
C41	1-126-963-11	ELECT 4.7μF 20%	50V	D4	8-719-801-78	DIODE 1SS184	
C42	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D5	8-719-900-95	DIODE V09G	
C43	1-126-964-11	ELECT 10μF 20%	50V	D6	8-719-900-95	DIODE V09G	
C44	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D7	8-719-801-78	DIODE 1SS184	
C45	1-136-161-00	FILM 0.047μF 5%	50V	D8	8-719-801-78	DIODE 1SS184	
C46	1-126-964-11	ELECT 10μF 20%	50V	D9	8-719-801-78	DIODE 1SS184	
C47	1-126-959-11	ELECT 0.47μF 20%	50V	<IC>			
C48	1-126-960-11	ELECT 1μF 20%	50V	IC1	8-759-460-74	IC BA05FP-E2	
C49	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC2	8-759-539-89	IC LM2990SX-5.0	
C50	1-126-964-11	ELECT 10μF 20%	50V	IC4	8-752-068-37	IC CXA1726AM	
C51	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC5	8-759-549-40	IC AD826AR-REEL	
C52	1-136-155-00	FILM 0.015μF 5%	50V	IC6	8-759-234-20	IC TC7S08F	
C53	1-136-159-00	FILM 0.033μF 5%	50V	IC7	8-759-908-15	IC TL431CLP	
C54	1-136-165-00	FILM 0.1μF 5%	50V	IC8	8-759-549-40	IC AD826AR-REEL	
C100	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC9	8-759-460-81	IC BA12FP-E2	
C101	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC10	8-759-700-69	IC NJM79L12A	
C102	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC11	8-759-443-72	IC RH5VL43AA-T1	
C103	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC12	8-759-300-78	IC HD14538BFP	
C104	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC13	8-759-100-96	IC UPC4558G2	
C105	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC15	8-759-549-40	IC AD826AR-REEL	
C106	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC17	8-752-068-37	IC CXA1726AM	
C109	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC19	8-752-065-69	IC CXA1470AS	
C110	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC100	8-759-326-65	IC MP7670AS-TE2	
C111	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC101	8-759-326-65	IC MP7670AS-TE2	
C112	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC102	8-759-326-65	IC MP7670AS-TE2	
C113	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C114	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C117	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C118	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C119	1-163-031-11	CERAMIC CHIP 0.01μF	50V				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
IC104	8-759-237-59	IC TC74HC541AF(EL)		R14	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC105	8-759-392-64	IC AD828AR		R15	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC106	8-759-326-65	IC MP7670AS-TE2		R16	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC107	8-759-326-65	IC MP7670AS-TE2		R17	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC108	8-759-326-65	IC MP7670AS-TE2		R18	1-216-033-00	RES,CHIP 220	5% 1/10W
IC110	8-759-392-64	IC AD828AR		R19	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC111	8-759-326-65	IC MP7670AS-TE2		R20	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC112	8-759-326-65	IC MP7670AS-TE2		R21	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC113	8-759-326-65	IC MP7670AS-TE2		R22	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC115	8-759-392-64	IC AD828AR		R23	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC116	8-759-392-64	IC AD828AR		R24	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC117	8-759-326-65	IC MP7670AS-TE2		R25	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC118	8-759-326-65	IC MP7670AS-TE2		R26	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
IC119	8-759-326-65	IC MP7670AS-TE2		R27	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
IC121	8-759-392-64	IC AD828AR		R28	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
IC122	8-759-392-64	IC AD828AR		R29	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
IC123	8-759-326-65	IC MP7670AS-TE2		R30	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
IC124	8-759-326-65	IC MP7670AS-TE2		R34	1-216-627-11	METAL CHIP 100	0.50% 1/10W
IC125	8-759-326-65	IC MP7670AS-TE2		R35	1-216-679-11	METAL CHIP 15K	0.50% 1/10W
IC127	8-759-392-64	IC AD828AR		R36	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
IC128	8-759-392-64	IC AD828AR		R37	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
IC129	8-759-326-65	IC MP7670AS-TE2		R40	1-216-073-00	RES,CHIP 10K	5% 1/10W
IC130	8-759-326-65	IC MP7670AS-TE2		R41	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
IC131	8-759-326-65	IC MP7670AS-TE2		R42	1-216-049-91	RES,CHIP 1K	5% 1/10W
IC133	8-759-392-64	IC AD828AR		R45	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
				R50	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
				R51	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
	<COIL>			R52	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
L1	1-412-533-21	INDUCTOR 47μH		R53	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
L2	1-412-533-21	INDUCTOR 47μH		R54	1-216-627-11	METAL CHIP 100	0.50% 1/10W
				R55	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
				R56	1-216-679-11	METAL CHIP 15K	0.50% 1/10W
	<TRANSISTOR>			R57	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
Q1	8-729-900-53	TRANSISTOR DTC114EK		R58	1-216-661-11	METAL CHIP 2.7K	0.50% 1/10W
Q2	8-729-900-53	TRANSISTOR DTC114EK		R59	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
Q3	8-729-900-53	TRANSISTOR DTC114EK		R60	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q4	8-729-904-04	TRANSISTOR FMS2		R61	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q7	8-729-230-49	TRANSISTOR 2SC2712-YG		R66	1-216-627-11	METAL CHIP 100	0.50% 1/10W
Q10	8-729-216-22	TRANSISTOR 2SA1162-G		R67	1-216-661-11	METAL CHIP 2.7K	0.50% 1/10W
Q11	8-729-230-49	TRANSISTOR 2SC2712-YG		R68	1-216-657-11	METAL CHIP 1.8K	0.50% 1/10W
Q12	8-729-230-49	TRANSISTOR 2SC2712-YG		R69	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
Q13	8-729-230-49	TRANSISTOR 2SC2712-YG		R70	1-216-679-11	METAL CHIP 15K	0.50% 1/10W
Q134	8-729-230-49	TRANSISTOR 2SC2712-YG		R71	1-216-685-11	METAL CHIP 27K	0.50% 1/10W
				R72	1-216-677-11	METAL CHIP 12K	0.50% 1/10W
	<RESISTOR>			R73	1-216-679-11	METAL CHIP 15K	0.50% 1/10W
R1	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W	R75	1-216-627-11	METAL CHIP 100	0.50% 1/10W
R2	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R76	1-216-627-11	METAL CHIP 100	0.50% 1/10W
R3	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R80	1-216-663-11	METAL CHIP 3.3K	0.50% 1/10W
R4	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R81	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
R5	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R82	1-216-692-11	METAL CHIP 51K	0.50% 1/10W
R6	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R84	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R7	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W	R85	1-216-627-11	METAL CHIP 100	0.50% 1/10W
R8	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R86	1-216-073-00	RES,CHIP 10K	5% 1/10W
R9	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R87	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R10	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R88	1-216-649-11	METAL CHIP 820	0.50% 1/10W
R11	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R89	1-216-627-11	METAL CHIP 100	0.50% 1/10W
R12	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R90	1-216-663-11	METAL CHIP 3.3K	0.50% 1/10W
R13	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R91	1-216-651-11	METAL CHIP 1K	0.50% 1/10W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R92	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R160	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R93	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R161	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R94	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R163	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R95	1-216-647-11	METAL CHIP	680 0.50% 1/10W	R164	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
				R165	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R96	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R167	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R99	1-247-807-31	CARBON	100 5% 1/4W	R168	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R100	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R169	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R101	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R170	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R102	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R172	1-247-807-31	CARBON	100 5% 1/4W
R103	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R173	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R104	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R174	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R105	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R176	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R106	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R177	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R107	1-216-649-11	METAL CHIP	820 0.50% 1/10W	R179	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R108	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R181	1-247-807-31	CARBON	100 5% 1/4W
R109	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R182	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R110	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R183	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R111	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R184	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R112	1-216-679-11	METAL CHIP	15K 0.50% 1/10W	R185	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R113	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R187	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R114	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R188	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R115	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R189	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R116	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R191	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R117	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R194	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R118	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R196	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R119	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R200	1-247-807-31	CARBON	100 5% 1/4W
R120	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R201	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R121	1-216-025-91	RES,CHIP	100 5% 1/10W	R202	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R122	1-216-025-91	RES,CHIP	100 5% 1/10W	R203	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R123	1-216-025-91	RES,CHIP	100 5% 1/10W	R204	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W
R124	1-216-025-91	RES,CHIP	100 5% 1/10W	R205	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R125	1-216-025-91	RES,CHIP	100 5% 1/10W	R206	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R126	1-216-025-91	RES,CHIP	100 5% 1/10W	R207	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R127	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R208	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R128	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R211	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R129	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R212	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R130	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R213	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R131	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R215	1-247-807-31	CARBON	100 5% 1/4W
R132	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R216	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R133	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R217	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R134	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R218	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R136	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W	R219	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R137	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R221	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R138	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R222	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R140	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W	R223	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R141	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W	R225	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R142	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R226	1-247-807-31	CARBON	100 5% 1/4W
R143	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R227	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R144	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R229	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R145	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R230	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R148	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W	R231	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R149	1-247-807-31	CARBON	100 5% 1/4W	R232	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R150	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W	R234	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W
R152	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R235	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R153	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R236	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R154	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R238	1-247-807-31	CARBON	100 5% 1/4W
R155	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R239	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W
R158	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R240	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R159	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R241	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R320	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R243	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R322	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R244	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W	R323	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R245	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W	R324	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R246	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R325	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R247	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R327	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R248	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R328	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R249	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R329	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R252	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W	R331	1-247-807-31	CARBON	100 5% 1/4W
R253	1-247-807-31	CARBON	100 5% 1/4W	R332	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R254	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R333	1-216-665-11	METAL CHIP	3.9K 0.50% 1/10W
R255	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W	R335	1-247-807-31	CARBON	100 5% 1/4W
R256	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W	R336	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R257	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R337	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R258	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R338	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R259	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R340	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R260	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R341	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W
R263	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W	R342	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R264	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W	R343	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R265	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R345	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W
R266	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R346	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R268	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W	R347	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R269	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R349	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R270	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R350	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W
R272	1-247-807-31	CARBON	100 5% 1/4W	R351	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W
R273	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R352	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R274	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R353	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R275	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R354	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R276	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R355	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R278	1-216-665-11	METAL CHIP	3.9K 0.50% 1/10W	R358	1-247-807-31	CARBON	100 5% 1/4W
R279	1-247-807-31	CARBON	100 5% 1/4W	R359	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R280	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R360	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R283	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R361	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W
R284	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R362	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W
R285	1-216-627-11	METAL CHIP	100 0.50% 1/10W	R363	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R287	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W	R364	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R288	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W	R365	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R289	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R366	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R290	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R367	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W
R292	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W	R368	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R293	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R369	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R294	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R370	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R296	1-247-807-31	CARBON	100 5% 1/4W	R371	1-247-807-31	CARBON	100 5% 1/4W
R297	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W	R372	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R299	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R373	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W
R301	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R374	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R305	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R375	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W
R307	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W	R376	1-216-673-11	METAL CHIP	8.2K 0.50% 1/10W
R308	1-247-807-31	CARBON	100 5% 1/4W	R377	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R309	1-216-651-11	METAL CHIP	1K 0.50% 1/10W	R378	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R310	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W	R379	1-216-627-11	METAL CHIP	100 0.50% 1/10W
R311	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W	R380	1-216-673-11	METAL CHIP	8.2K 0.50% 1/10W
R312	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R381	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R313	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R382	1-216-673-11	METAL CHIP	8.2K 0.50% 1/10W
R314	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R383	1-247-807-31	CARBON	100 5% 1/4W
R315	1-216-661-11	METAL CHIP	2.7K 0.50% 1/10W	R384	1-216-651-11	METAL CHIP	1K 0.50% 1/10W
R318	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W	R386	1-216-671-11	METAL CHIP	6.8K 0.50% 1/10W
R319	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R387	1-216-627-11	METAL CHIP	100 0.50% 1/10W

Ref.No.	Part No.	Description	Remark			Ref.No.	Part No.	Description	Remark		
R388	1-216-627-11	METAL CHIP	100	0.50%	1/10W	C18	1-107-909-11	ELECT	47μF	20%	16V
R389	1-216-627-11	METAL CHIP	100	0.50%	1/10W	C19	1-164-004-11	CERAMIC CHIP	0.1μF	10%	25V
R391	1-216-665-11	METAL CHIP	3.9K	0.50%	1/10W	C20	1-128-526-11	ELECT	100μF	20%	16V
R392	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W	C22	1-137-366-11	FILM	0.0022μF	5%	50V
R393	1-216-661-11	METAL CHIP	2.7K	0.50%	1/10W	C26	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R394	1-216-661-11	METAL CHIP	2.7K	0.50%	1/10W	C27	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R395	1-216-681-11	METAL CHIP	18K	0.50%	1/10W	C28	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R397	1-247-807-31	CARBON	100	5%	1/4W	C29	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R398	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W	C30	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R399	1-216-661-11	METAL CHIP	2.7K	0.50%	1/10W	C31	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R400	1-216-661-11	METAL CHIP	2.7K	0.50%	1/10W	C32	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R401	1-216-681-11	METAL CHIP	18K	0.50%	1/10W	C33	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R402	1-216-651-11	METAL CHIP	1K	0.50%	1/10W	C34	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R403	1-216-655-11	METAL CHIP	1.5K	0.50%	1/10W	C35	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R405	1-216-661-11	METAL CHIP	2.7K	0.50%	1/10W	C36	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R407	1-216-661-11	METAL CHIP	2.7K	0.50%	1/10W	C37	1-163-031-11	CERAMIC CHIP	0.01μF		50V
R409	1-216-681-11	METAL CHIP	18K	0.50%	1/10W	C38	1-107-902-11	ELECT	1μF	20%	50V
R410	1-216-059-00	RES,CHIP	2.7K	5%	1/10W	C39	1-107-902-11	ELECT	1μF	20%	50V
R411	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C40	1-107-713-11	ELECT	4.7μF	20%	35V
R412	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	C41	1-128-526-11	ELECT	100μF	20%	16V
R413	1-216-049-91	RES,CHIP	1K	5%	1/10W	C100	1-107-905-11	ELECT	4.7μF	20%	50V
<TEST PIN>						C101	1-102-514-11	CERAMIC	22PF	5%	50V
TP1	* 1-537-864-11	PIN, POST				C102	1-104-653-11	ELECT	220μF	20%	16V
TP2	* 1-537-864-11	PIN, POST				C103	1-128-526-11	ELECT	100μF	20%	25V
TP3	* 1-537-864-11	PIN, POST				C104	1-164-004-11	CERAMIC CHIP	0.1μF	10%	25V
TP4	* 1-537-864-11	PIN, POST				C105	1-107-933-11	ELECT	100μF	20%	100V
*****						C106	1-107-933-11	ELECT	100μF	20%	100V
* A-1346-777-A DF COMPLETE PC BOARD						C107	1-164-004-11	CERAMIC CHIP	0.1μF	10%	25V
*****						C108	1-163-031-11	CERAMIC CHIP	0.01μF		50V
3-701-809-31 SCREW, TERMINAL (M3X8)						C109	1-163-031-11	CERAMIC CHIP	0.01μF		50V
* 4-056-076-01 PIN, GUIDE						C110	1-136-728-11	FILM	0.47μF	5%	100V
* 4-067-816-01 HOLDER (DF), TR						C111	1-104-653-11	ELECT	220μF	20%	16V
* 4-067-822-01 HOLDER (D), TR						C112	1-137-418-11	FILM	0.022μF	10%	100V
4-067-843-01 SHEET (DF), INSULATOR						C113	1-163-031-11	CERAMIC CHIP	0.01μF		50V
4-382-854-11 SCREW (M3X10), P, SW (+)						C114	1-107-905-11	ELECT	4.7μF	20%	50V
<CAPACITOR>						C115	1-102-514-11	CERAMIC	22PF	5%	50V
C1	1-107-909-11	ELECT	47μF	20%	16V	C116	1-104-653-11	ELECT	220μF	20%	16V
C2	1-107-907-11	ELECT	22μF	20%	16V	C117	1-164-004-11	CERAMIC CHIP	0.1μF	10%	25V
C3	1-107-909-11	ELECT	47μF	20%	16V	C118	1-107-933-11	ELECT	100μF	20%	100V
C4	1-136-159-00	FILM	0.033μF	5%	50V	C119	1-107-933-11	ELECT	100μF	20%	100V
C5	1-107-909-11	ELECT	47μF	20%	16V	C120	1-164-004-11	CERAMIC CHIP	0.1μF	10%	25V
C6	1-107-902-11	ELECT	1μF	20%	50V	C121	1-136-728-11	FILM	0.47μF	5%	100V
C7	1-107-909-11	ELECT	47μF	20%	16V	C122	1-104-653-11	ELECT	220μF	20%	16V
C8	1-136-159-00	FILM	0.033μF	5%	50V	C123	1-137-418-11	FILM	0.022μF	10%	100V
C9	1-136-155-00	FILM	0.015μF	5%	50V	C124	1-163-031-11	CERAMIC CHIP	0.01μF		50V
C10	1-136-165-00	FILM	0.1μF	5%	50V	C125	1-163-031-11	CERAMIC CHIP	0.01μF		50V
C11	1-107-907-11	ELECT	22μF	20%	16V	C126	1-107-905-11	ELECT	4.7μF	20%	50V
C12	1-163-251-11	CERAMIC CHIP	100PF	5%	50V	C127	1-102-514-11	CERAMIC	22PF	5%	50V
C14	1-128-526-11	ELECT	100μF	20%	16V	C128	1-128-526-11	ELECT	100μF	20%	16V
C15	1-164-004-11	CERAMIC CHIP	0.1μF	10%	25V	C129	1-104-653-11	ELECT	220μF	20%	16V
C16	1-107-909-11	ELECT	47μF	20%	16V	C130	1-164-004-11	CERAMIC CHIP	0.1μF	10%	25V
						C131	1-107-902-11	ELECT	1μF	20%	50V
						C132	1-107-933-11	ELECT	100μF	20%	100V
						C133	1-107-933-11	ELECT	100μF	20%	100V
						C134	1-164-004-11	CERAMIC CHIP	0.1μF	10%	25V
						C135	1-104-653-11	ELECT	220μF	20%	16V
						C136	1-163-031-11	CERAMIC CHIP	0.01μF		50V
						C137	1-136-728-11	FILM	0.47μF	5%	100V
						C138	1-137-418-11	FILM	0.022μF	10%	100V



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C139	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D109	8-719-911-19	DIODE 1SS119-25	
C140	1-107-889-11	ELECT 220μF 20%	25V	D110	8-719-900-95	DIODE V09G	
C141	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V	D111	8-719-900-95	DIODE V09G	
C142	1-104-653-11	ELECT 220μF 20%	16V	D112	8-719-900-95	DIODE V09G	
C143	1-104-653-11	ELECT 220μF 20%	16V	D113	8-719-900-95	DIODE V09G	
C144	1-164-004-11	CERAMIC CHIP 0.1μF 10%	25V	D201	8-719-800-76	DIODE 1SS226	
C145	1-107-889-11	ELECT 220μF 20%	25V	D202	8-719-800-76	DIODE 1SS226	
C147	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D203	8-719-800-76	DIODE 1SS226	
C148	1-137-462-11	FILM 0.018μF 5%	100V	D204	8-719-800-76	DIODE 1SS226	
C149	1-137-462-11	FILM 0.018μF 5%	100V	D205	8-719-800-76	DIODE 1SS226	
C150	1-137-462-11	FILM 0.018μF 5%	100V	D206	8-719-800-76	DIODE 1SS226	
C151	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D207	8-719-801-78	DIODE 1SS184	
C152	1-107-907-11	ELECT 22μF 20%	16V	D208	8-719-800-76	DIODE 1SS226	
C153	1-137-410-11	FILM 0.001μF 10%	100V	D209	8-719-800-76	DIODE 1SS226	
C154	1-137-410-11	FILM 0.001μF 10%	100V	D210	8-719-800-76	DIODE 1SS226	
C155	1-137-410-11	FILM 0.001μF 10%	100V	D211	8-719-800-76	DIODE 1SS226	
C201	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D212	8-719-800-76	DIODE 1SS226	
C202	1-136-165-00	FILM 0.1μF 5%	50V	D213	8-719-800-76	DIODE 1SS226	
C203	1-136-165-00	FILM 0.1μF 5%	50V				
C204	1-163-031-11	CERAMIC CHIP 0.01μF	50V			<IC>	
C205	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC1	8-759-381-53	IC UPC814G2-E2	
C206	1-136-165-00	FILM 0.1μF 5%	50V	IC2	8-759-100-96	IC UPC4558G2	
C207	1-136-165-00	FILM 0.1μF 5%	50V	IC3	8-752-065-69	IC CXA1470AS	
C208	1-107-909-11	ELECT 47μF 20%	16V	IC4	8-759-100-96	IC UPC4558G2	
C209	1-136-165-00	FILM 0.1μF 5%	50V	IC5	8-759-100-96	IC UPC4558G2	
C210	1-136-165-00	FILM 0.1μF 5%	50V	IC8	8-759-144-82	IC UPC2405HF	
C211	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC9	8-759-247-67	IC LM2990T-5.0	
C212	1-107-909-11	ELECT 47μF 20%	16V	IC10	8-759-300-78	IC HD14538BFP	
C213	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC11	8-759-286-47	IC PC74HC4053D-T	
C214	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC20	8-759-381-53	IC UPC814G2-E2	
C215	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC100	8-759-035-93	IC SC7S32F	
C216	1-136-165-00	FILM 0.1μF 5%	50V	IC101	8-759-497-41	IC LA7876NZA	
C217	1-136-165-00	FILM 0.1μF 5%	50V	IC102	8-759-326-65	IC MP7670AS-TE2	
C218	1-136-165-00	FILM 0.1μF 5%	50V	IC103	8-759-100-93	IC UPC393G2	
C219	1-136-165-00	FILM 0.1μF 5%	50V	IC104	8-759-497-41	IC LA7876NZA	
C220	1-136-165-00	FILM 0.1μF 5%	50V	IC105	8-759-326-65	IC MP7670AS-TE2	
C221	1-136-165-00	FILM 0.1μF 5%	50V	IC106	8-759-497-41	IC LA7876NZA	
C222	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC107	8-759-326-65	IC MP7670AS-TE2	
C223	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC108	8-759-231-58	IC TA7812S	
				IC109	8-759-701-88	IC NJM7912FA	
				IC110	8-759-285-52	IC PC74HC02D-T	
				IC201	8-759-326-65	IC MP7670AS-TE2	
				IC202	8-759-237-59	IC TC74HC541AF(EL)	
				IC203	8-759-100-96	IC UPC4558G2	
				IC204	8-759-100-96	IC UPC4558G2	
				IC205	8-759-908-15	IC TL431CLP	
				IC206	8-759-100-96	IC UPC4558G2	
				IC207	8-759-234-20	IC TC7S08F	
				IC208	8-759-443-72	IC RH5VL43AA-T1	
				IC209	8-759-326-65	IC MP7670AS-TE2	
				IC210	8-759-100-96	IC UPC4558G2	
				IC211	8-759-100-96	IC UPC4558G2	
				IC212	8-759-326-65	IC MP7670AS-TE2	
				IC213	8-759-100-96	IC UPC4558G2	
						<COIL>	
				L100	1-412-533-21	INDUCTOR 47μH	

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
L101	1-412-533-21	INDUCTOR 47 μ H		R16	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
L102	1-412-533-21	INDUCTOR 47 μ H		R17	1-218-756-11	METAL CHIP 150K	0.50% 1/10W
<TRANSISTOR>				R18	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
Q1	8-729-926-23	TRANSISTOR FMW5		R19	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
Q2	8-729-105-73	TRANSISTOR 2SK523-L2		R20	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
Q3	8-729-216-22	TRANSISTOR 2SA1162-G		R21	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
Q4	8-729-230-49	TRANSISTOR 2SC2712-YG		R23	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q5	8-729-902-96	TRANSISTOR FMS1		R24	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
Q6	1-801-806-11	TRANSISTOR DTC144EKA-T146		R26	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
Q100	8-729-230-49	TRANSISTOR 2SC2712-YG		R27	1-216-627-11	METAL CHIP 100	0.50% 1/10W
Q101	1-801-806-11	TRANSISTOR DTC144EKA-T146		R28	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
Q102	8-729-230-49	TRANSISTOR 2SC2712-YG		R29	1-216-627-11	METAL CHIP 100	0.50% 1/10W
Q103	8-729-230-49	TRANSISTOR 2SC2712-YG		R30	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q104	8-729-230-49	TRANSISTOR 2SC2712-YG		R31	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
Q105	8-729-230-49	TRANSISTOR 2SC2712-YG		R33	1-216-627-11	METAL CHIP 100	0.50% 1/10W
Q106	1-801-806-11	TRANSISTOR DTC144EKA-T146		R34	1-216-627-11	METAL CHIP 100	0.50% 1/10W
Q201	8-729-207-82	TRANSISTOR 2SC3421-Y		R35	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
Q202	8-729-207-82	TRANSISTOR 2SC3421-Y		R36	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
Q203	8-729-207-89	TRANSISTOR 2SA1358-Y		R38	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q204	8-729-207-89	TRANSISTOR 2SA1358-Y		R39	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
Q205	8-729-207-82	TRANSISTOR 2SC3421-Y		R41	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
Q206	8-729-207-82	TRANSISTOR 2SC3421-Y		R42	1-216-677-11	METAL CHIP 12K	0.50% 1/10W
Q207	8-729-207-89	TRANSISTOR 2SA1358-Y		R43	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
Q208	8-729-207-89	TRANSISTOR 2SA1358-Y		R44	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
Q209	8-729-207-82	TRANSISTOR 2SC3421-Y		R45	1-216-683-11	METAL CHIP 22K	0.50% 1/10W
Q210	8-729-207-82	TRANSISTOR 2SC3421-Y		R46	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q211	8-729-207-89	TRANSISTOR 2SA1358-Y		R47	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
Q212	8-729-207-89	TRANSISTOR 2SA1358-Y		R48	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
Q213	8-729-207-82	TRANSISTOR 2SC3421-Y		R49	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
Q214	8-729-207-82	TRANSISTOR 2SC3421-Y		R50	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q215	8-729-207-89	TRANSISTOR 2SA1358-Y		R55	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
Q216	8-729-207-89	TRANSISTOR 2SA1358-Y		R56	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
Q217	8-729-207-82	TRANSISTOR 2SC3421-Y		R57	1-216-665-11	METAL CHIP 3.9K	0.50% 1/10W
Q218	8-729-207-82	TRANSISTOR 2SC3421-Y		R58	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
Q219	8-729-207-89	TRANSISTOR 2SA1358-Y		R60	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
Q220	8-729-207-89	TRANSISTOR 2SA1358-Y		R62	1-216-627-11	METAL CHIP 100	0.50% 1/10W
Q221	8-729-207-82	TRANSISTOR 2SC3421-Y		R63	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
Q222	8-729-207-82	TRANSISTOR 2SC3421-Y		R64	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
Q223	8-729-207-89	TRANSISTOR 2SA1358-Y		R65	1-216-603-11	METAL CHIP 10	0.50% 1/10W
Q224	8-729-207-89	TRANSISTOR 2SA1358-Y		R66	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
<RESISTOR>				R67	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
R1	1-216-677-11	METAL CHIP 12K	0.50% 1/10W	R100	1-216-685-11	METAL CHIP 27K	0.50% 1/10W
R2	1-216-699-11	METAL CHIP 100K	0.50% 1/10W	R101	1-216-683-11	METAL CHIP 22K	0.50% 1/10W
R3	1-216-683-11	METAL CHIP 22K	0.50% 1/10W	R102	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R4	1-216-663-11	METAL CHIP 3.3K	0.50% 1/10W	R103	1-216-627-11	METAL CHIP 100	0.50% 1/10W
R6	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R104	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R7	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R105	1-216-668-11	METAL CHIP 5.1K	0.50% 1/10W
R8	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R106	1-218-756-11	METAL CHIP 150K	0.50% 1/10W
R9	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R107	1-216-369-00	METAL OXIDE 1	5% 1/10W F
R10	1-216-691-11	METAL CHIP 47K	0.50% 1/10W	R108	1-218-762-11	METAL CHIP 270K	0.50% 1/10W
R11	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R109	1-218-768-11	METAL CHIP 470K	0.50% 1/10W
R12	1-216-692-11	METAL CHIP 51K	0.50% 1/10W	R110	1-216-627-11	METAL CHIP 100	0.50% 1/10W
R13	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W	R111	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
R14	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R112	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
R15	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R113	1-216-699-11	METAL CHIP 100K	0.50% 1/10W
				R114	1-215-892-11	METAL OXIDE 1K	5% 1/10W F
				R115	1-216-691-11	METAL CHIP 47K	0.50% 1/10W
				R116	1-216-675-11	METAL CHIP 10K	0.50% 1/10W

Ref.No.	Part No.	Description		Remark	Ref.No.	Part No.	Description		Remark
R117	1-216-627-11	METAL CHIP	100	0.50% 1/10W	R175	1-218-768-11	METAL CHIP	470K	0.50% 1/10W
R118	1-249-420-11	CARBON	1.8K	5% 1/4W	R176	1-216-627-11	METAL CHIP	100	0.50% 1/10W
R119	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R177	1-216-691-11	METAL CHIP	47K	0.50% 1/10W
					R178	1-249-420-11	CARBON	1.8K	5% 1/4W
R120	1-249-413-11	CARBON	470	5% 1/4W	R179	1-216-627-11	METAL CHIP	100	0.50% 1/10W
R121	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W					
R122	1-214-800-11	METAL	2.2	1% 1/2W	R180	1-249-413-11	CARBON	470	5% 1/4W
R123	1-214-800-11	METAL	2.2	1% 1/2W	R181	1-214-800-11	METAL	2.2	1% 1/2W
R124	1-216-627-11	METAL CHIP	100	0.50% 1/10W	R182	1-214-800-11	METAL	2.2	1% 1/2W
					R183	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
R125	1-218-756-11	METAL CHIP	150K	0.50% 1/10W	R184	1-216-627-11	METAL CHIP	100	0.50% 1/10W
R126	1-216-627-11	METAL CHIP	100	0.50% 1/10W					
R127	1-218-773-11	METAL CHIP	750K	0.50% 1/10W	R185	1-216-627-11	METAL CHIP	100	0.50% 1/10W
R128	1-216-627-11	METAL CHIP	100	0.50% 1/10W	R186	1-218-756-11	METAL CHIP	150K	0.50% 1/10W
R129	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R187	1-216-627-11	METAL CHIP	100	0.50% 1/10W
					R188	1-218-773-11	METAL CHIP	750K	0.50% 1/10W
R130	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R189	1-216-627-11	METAL CHIP	100	0.50% 1/10W
R131	1-218-764-11	METAL CHIP	330K	0.50% 1/10W					
R132	1-218-764-11	METAL CHIP	330K	0.50% 1/10W	R190	1-218-764-11	METAL CHIP	330K	0.50% 1/10W
R133	1-216-685-11	METAL CHIP	27K	0.50% 1/10W	R191	1-218-764-11	METAL CHIP	330K	0.50% 1/10W
R134	1-218-756-11	METAL CHIP	150K	0.50% 1/10W	R192	1-216-699-11	METAL CHIP	100K	0.50% 1/10W
					R194	1-247-807-31	CARBON	100	5% 1/4W
R135	1-218-773-11	METAL CHIP	750K	0.50% 1/10W	R195	1-216-627-11	METAL CHIP	100	0.50% 1/10W
R136	1-216-627-11	METAL CHIP	100	0.50% 1/10W					
R137	1-216-683-11	METAL CHIP	22K	0.50% 1/10W	R201	1-216-025-91	RES,CHIP	100	5% 1/10W
R138	1-216-651-11	METAL CHIP	1K	0.50% 1/10W	R202	1-216-025-91	RES,CHIP	100	5% 1/10W
R139	1-216-369-00	METAL OXIDE	1	5% 2W F	R203	1-216-025-91	RES,CHIP	100	5% 1/10W
					R204	1-216-685-11	METAL CHIP	27K	0.50% 1/10W
R140	1-216-627-11	METAL CHIP	100	0.50% 1/10W	R205	1-216-685-11	METAL CHIP	27K	0.50% 1/10W
R141	1-216-627-11	METAL CHIP	100	0.50% 1/10W					
R142	1-215-892-11	METAL OXIDE	1K	5% 2W F	R206	1-216-001-00	RES,CHIP	10	5% 1/10W
R143	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R207	1-216-001-00	RES,CHIP	10	5% 1/10W
R144	1-216-668-11	METAL CHIP	5.1K	0.50% 1/10W	R208	1-216-627-11	METAL CHIP	100	0.50% 1/10W
					R209	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R145	1-218-768-11	METAL CHIP	470K	0.50% 1/10W	R210	1-249-417-11	CARBON	1K	5% 1/4W
R146	1-218-770-11	METAL CHIP	560K	0.50% 1/10W					
R147	1-218-762-11	METAL CHIP	270K	0.50% 1/10W	R211	1-249-417-11	CARBON	1K	5% 1/4W
R148	1-216-691-11	METAL CHIP	47K	0.50% 1/10W	R212	1-216-073-00	RES,CHIP	10K	5% 1/10W
R149	1-249-420-11	CARBON	1.8K	5% 1/4W	R213	1-216-073-00	RES,CHIP	10K	5% 1/10W
					R214	1-214-792-00	METAL	1	1% 1/2W
R150	1-249-413-11	CARBON	470	5% 1/4W	R215	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R151	1-216-627-11	METAL CHIP	100	0.50% 1/10W					
R152	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W	R216	1-214-792-00	METAL	1	1% 1/2W
R153	1-214-800-11	METAL	2.2	1% 1/2W	R217	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
R154	1-214-800-11	METAL	2.2	1% 1/2W	R218	1-216-675-11	METAL CHIP	10K	0.50% 1/10W
					R219	1-216-001-00	RES,CHIP	10	5% 1/10W
R155	1-216-627-11	METAL CHIP	100	0.50% 1/10W	R220	1-216-001-00	RES,CHIP	10	5% 1/10W
R156	1-216-627-11	METAL CHIP	100	0.50% 1/10W					
R157	1-218-756-11	METAL CHIP	150K	0.50% 1/10W	R221	1-216-627-11	METAL CHIP	100	0.50% 1/10W
R158	1-216-627-11	METAL CHIP	100	0.50% 1/10W	R222	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R159	1-218-773-11	METAL CHIP	750K	0.50% 1/10W	R223	1-249-417-11	CARBON	1K	5% 1/4W
					R224	1-216-073-00	RES,CHIP	10K	5% 1/10W
R160	1-216-627-11	METAL CHIP	100	0.50% 1/10W	R225	1-214-792-00	METAL	1	1% 1/2W
R161	1-216-685-11	METAL CHIP	27K	0.50% 1/10W					
R162	1-218-764-11	METAL CHIP	330K	0.50% 1/10W	R226	1-249-417-11	CARBON	1K	5% 1/4W
R163	1-218-764-11	METAL CHIP	330K	0.50% 1/10W	R227	1-216-073-00	RES,CHIP	10K	5% 1/10W
R164	1-216-683-11	METAL CHIP	22K	0.50% 1/10W	R228	1-216-025-91	RES,CHIP	100	5% 1/10W
					R229	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R165	1-216-651-11	METAL CHIP	1K	0.50% 1/10W	R230	1-214-792-00	METAL	1	1% 1/2W
R166	1-218-756-11	METAL CHIP	150K	0.50% 1/10W					
R167	1-218-773-11	METAL CHIP	750K	0.50% 1/10W	R231	1-216-685-11	METAL CHIP	27K	0.50% 1/10W
R168	1-216-668-11	METAL CHIP	5.1K	0.50% 1/10W	R232	1-216-685-11	METAL CHIP	27K	0.50% 1/10W
R169	1-218-756-11	METAL CHIP	150K	0.50% 1/10W	R233	1-216-001-00	RES,CHIP	10	5% 1/10W
					R234	1-216-001-00	RES,CHIP	10	5% 1/10W
R170	1-216-369-00	METAL OXIDE	1	5% 2W F	R235	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R171	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W					
R172	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	R236	1-249-417-11	CARBON	1K	5% 1/4W
R173	1-215-892-11	METAL OXIDE	1K	5% 2W F	R237	1-216-073-00	RES,CHIP	10K	5% 1/10W
R174	1-218-762-11	METAL CHIP	270K	0.50% 1/10W	R238	1-214-792-00	METAL	1	1% 1/2W
					R239	1-249-417-11	CARBON	1K	5% 1/4W

Ref.No.	Part No.	Description		Remark	Ref.No.	Part No.	Description	Remark
R240	1-216-097-91	RES,CHIP	100K	5% 1/10W	TP3	* 1-537-864-11	PIN, POST	
R241	1-216-073-00	RES,CHIP	10K	5% 1/10W	TP102	* 1-537-864-11	PIN, POST	
R242	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	TP201	* 1-537-864-11	PIN, POST	
R243	1-214-792-00	METAL	1	1% 1/2W	*****			
R244	1-216-065-91	RES,CHIP	4.7K	5% 1/10W				
R245	1-216-627-11	METAL CHIP	100	0.50% 1/10W				
					* A-1346-778-A DB COMPLETE PC BOARD			
R246	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	*****			
R247	1-216-675-11	METAL CHIP	10K	0.50% 1/10W				
R248	1-216-001-00	RES,CHIP	10	5% 1/10W	<CAPACITOR>			
R249	1-216-001-00	RES,CHIP	10	5% 1/10W	C101	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R250	1-216-627-11	METAL CHIP	100	0.50% 1/10W	C103	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R251	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	C105	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R252	1-249-417-11	CARBON	1K	5% 1/4W	C106	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R253	1-249-417-11	CARBON	1K	5% 1/4W	C107	1-126-964-11	ELECT 10μF	20% 50V
R254	1-216-073-00	RES,CHIP	10K	5% 1/10W				
R255	1-216-073-00	RES,CHIP	10K	5% 1/10W	C108	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R256	1-214-792-00	METAL	1	1% 1/2W	C109	1-126-964-11	ELECT 10μF	20% 50V
R257	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	C110	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R258	1-214-792-00	METAL	1	1% 1/2W	C201	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R259	1-216-685-11	METAL CHIP	27K	0.50% 1/10W	C202	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R260	1-216-685-11	METAL CHIP	27K	0.50% 1/10W				
R261	1-216-001-00	RES,CHIP	10	5% 1/10W	C203	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R262	1-216-001-00	RES,CHIP	10	5% 1/10W	C204	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R263	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	C205	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R264	1-249-417-11	CARBON	1K	5% 1/4W	C206	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R265	1-216-073-00	RES,CHIP	10K	5% 1/10W	C207	1-126-964-11	ELECT 10μF	20% 50V
R266	1-214-792-00	METAL	1	1% 1/2W	C208	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R267	1-249-417-11	CARBON	1K	5% 1/4W	C209	1-126-964-11	ELECT 10μF	20% 50V
R268	1-216-073-00	RES,CHIP	10K	5% 1/10W	C210	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R269	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	C211	1-126-960-11	ELECT 1μF	20% 50V
R270	1-214-792-00	METAL	1	1% 1/2W	C301	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R271	1-216-675-11	METAL CHIP	10K	0.50% 1/10W				
R272	1-216-675-11	METAL CHIP	10K	0.50% 1/10W	C302	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R273	1-216-001-00	RES,CHIP	10	5% 1/10W	C305	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R274	1-216-001-00	RES,CHIP	10	5% 1/10W	C306	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R275	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	C307	1-126-964-11	ELECT 10μF	20% 50V
R276	1-249-417-11	CARBON	1K	5% 1/4W	C308	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R277	1-216-073-00	RES,CHIP	10K	5% 1/10W				
R278	1-214-792-00	METAL	1	1% 1/2W	C309	1-126-964-11	ELECT 10μF	20% 50V
R279	1-249-417-11	CARBON	1K	5% 1/4W	C310	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R280	1-216-073-00	RES,CHIP	10K	5% 1/10W	C401	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R281	1-216-627-11	METAL CHIP	100	0.50% 1/10W	C402	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R282	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	C403	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R283	1-214-792-00	METAL	1	1% 1/2W				
R284	1-216-627-11	METAL CHIP	100	0.50% 1/10W	C404	1-163-031-11	CERAMIC CHIP 0.01μF	50V
R300	1-216-671-11	METAL CHIP	6.8K	0.50% 1/10W	C405	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
R301	1-247-807-31	CARBON	100	5% 1/4W	C406	1-163-031-11	CERAMIC CHIP 0.01μF	50V
<RELAY>					C407	1-126-964-11	ELECT 10μF	20% 50V
RY100	1-515-716-11	RELAY (TQ2-5V)			C408	1-163-031-11	CERAMIC CHIP 0.01μF	50V
RY101	1-515-716-11	RELAY (TQ2-5V)						
RY102	1-515-716-11	RELAY (TQ2-5V)			C409	1-126-964-11	ELECT 10μF	20% 50V
<TEST PIN>					C410	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
TP1	* 1-537-864-11	PIN, POST			C503	1-163-031-11	CERAMIC CHIP 0.01μF	50V
TP2	* 1-537-864-11	PIN, POST			C504	1-163-031-11	CERAMIC CHIP 0.01μF	50V
					C507	1-163-031-11	CERAMIC CHIP 0.01μF	50V
					C508	1-163-031-11	CERAMIC CHIP 0.01μF	50V
					C601	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V
					C602	1-126-964-11	ELECT 10μF	20% 50V
					C603	1-163-031-11	CERAMIC CHIP 0.01μF	50V
					C604	1-126-964-11	ELECT 10μF	20% 50V
					C605	1-163-031-11	CERAMIC CHIP 0.01μF	50V
					C606	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C607	1-163-031-11	CERAMIC CHIP 0.01μF	50V	C926	1-163-031-11	CERAMIC CHIP 0.01μF	50V
C608	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C609	1-163-031-11	CERAMIC CHIP 0.01μF	50V			<CONNECTOR>	
C610	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C611	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	CN180	* 1-778-891-11	CONNECTOR, BOARD TO BOARD	
C612	1-126-964-11	ELECT 10μF	20% 50V				
C613	1-163-031-11	CERAMIC CHIP 0.01μF	50V			<DIODE>	
C614	1-126-964-11	ELECT 10μF	20% 50V				
C615	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D601	8-719-053-18	DIODE 1SR154-400TE-25	
C616	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	D602	8-719-053-18	DIODE 1SR154-400TE-25	
C619	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D603	8-719-056-76	DIODE UDZ-TE-17-3.6B	
C620	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D604	8-719-404-50	DIODE MA1111-TX	
C621	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D605	8-719-976-99	DIODE DTZ5.1B	
C622	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D901	8-719-404-50	DIODE MA1111-TX	
C623	1-163-031-11	CERAMIC CHIP 0.01μF	50V	D902	8-719-404-50	DIODE MA1111-TX	
C624	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C625	1-163-031-11	CERAMIC CHIP 0.01μF	50V			<IC>	
C632	1-107-725-11	CERAMIC CHIP 0.1μF	10% 16V				
C633	1-126-964-11	ELECT 10μF	20% 50V	IC101	8-759-286-47	IC PC74HC4053D-T	
C635	1-126-933-11	ELECT 100μF	20% 16V	IC102	8-759-457-54	IC AD835AR-REEL7	
C636	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC201	8-759-286-47	IC PC74HC4053D-T	
C637	1-126-964-11	ELECT 10μF	20% 50V	IC202	8-759-457-54	IC AD835AR-REEL7	
C638	1-107-725-11	CERAMIC CHIP 0.1μF	10% 16V	IC203	8-759-392-64	IC AD828AR	
C639	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC301	8-759-286-47	IC PC74HC4053D-T	
C640	1-126-933-11	ELECT 100μF	20% 16V	IC302	8-759-457-54	IC AD835AR-REEL7	
C641	1-126-965-11	ELECT 22μF	20% 50V	IC401	8-759-286-47	IC PC74HC4053D-T	
C643	1-126-933-11	ELECT 100μF	20% 16V	IC402	8-759-457-54	IC AD835AR-REEL7	
C701	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	IC403	8-759-392-64	IC AD828AR	
C702	1-126-964-11	ELECT 10μF	20% 50V	IC501	8-759-549-40	IC AD826AR-REEL	
C703	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC503	8-759-392-64	IC AD828AR	
C704	1-126-964-11	ELECT 10μF	20% 50V	IC601	8-759-457-54	IC AD835AR-REEL7	
C705	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC602	8-759-392-64	IC AD828AR	
C706	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	IC603	8-759-392-64	IC AD828AR	
C709	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	IC604	8-759-457-54	IC AD835AR-REEL7	
C710	1-126-964-11	ELECT 10μF	20% 50V	IC606	8-759-381-53	IC UPC814G2-E2	
C711	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC607	8-759-286-47	IC PC74HC4053D-T	
C712	1-126-964-11	ELECT 10μF	20% 50V	IC608	8-759-381-53	IC UPC814G2-E2	
C713	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC609	8-759-392-64	IC AD828AR	
C714	1-164-004-11	CERAMIC CHIP 0.1μF	10% 25V	IC612	8-759-539-89	IC LM2990SX-5.0	
C715	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC613	8-759-460-74	IC BA05FP-E2	
C716	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC614	8-759-242-74	IC TC7W04F	
C717	1-126-965-11	ELECT 22μF	20% 50V	IC701	8-759-457-54	IC AD835AR-REEL7	
C718	1-126-965-11	ELECT 22μF	20% 50V	IC702	8-759-392-64	IC AD828AR	
C903	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC703	8-759-457-54	IC AD835AR-REEL7	
C904	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC902	8-759-286-47	IC PC74HC4053D-T	
C911	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC905	8-759-392-64	IC AD828AR	
C912	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC906	8-759-421-87	IC UPC319G2-E2	
C913	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC907	8-759-925-85	IC SN74HC32ANS	
C914	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC908	8-759-100-96	IC UPC4558G2	
C915	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC909	8-759-381-53	IC UPC814G2-E2	
C916	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC910	8-759-286-47	IC PC74HC4053D-T	
C917	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC911	8-759-908-15	IC TL431CLP	
C918	1-163-031-11	CERAMIC CHIP 0.01μF	50V	IC912	8-759-381-53	IC UPC814G2-E2	
C919	1-163-275-11	CERAMIC CHIP 0.001μF	5% 50V			<COIL>	
C920	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C921	1-163-031-11	CERAMIC CHIP 0.01μF	50V	L601	1-412-533-21	INDUCTOR 47μH	
C922	1-163-031-11	CERAMIC CHIP 0.01μF	50V	L602	1-412-533-21	INDUCTOR 47μH	
C923	1-163-031-11	CERAMIC CHIP 0.01μF	50V				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
		<TRANSISTOR>		Q708	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q101	8-729-216-22	TRANSISTOR 2SA1162-G		Q709	8-729-926-23	TRANSISTOR FMW5	
Q102	8-729-230-49	TRANSISTOR 2SC2712-YG		Q710	8-729-216-22	TRANSISTOR 2SA1162-G	
Q103	8-729-026-57	TRANSISTOR FMS1A-T148		Q711	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q104	8-729-926-23	TRANSISTOR FMW5		Q712	8-729-026-57	TRANSISTOR FMS1A-T148	
Q105	8-729-216-22	TRANSISTOR 2SA1162-G		Q901	8-729-926-23	TRANSISTOR FMW5	
Q106	8-729-230-49	TRANSISTOR 2SC2712-YG		Q902	8-729-026-57	TRANSISTOR FMS1A-T148	
Q107	8-729-926-23	TRANSISTOR FMW5		Q903	8-729-216-22	TRANSISTOR 2SA1162-G	
Q108	8-729-026-57	TRANSISTOR FMS1A-T148		Q904	8-729-230-49	TRANSISTOR 2SC2712-YG	
Q201	8-729-216-22	TRANSISTOR 2SA1162-G				<RESISTOR>	
Q202	8-729-230-49	TRANSISTOR 2SC2712-YG		R101	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q203	8-729-926-23	TRANSISTOR FMW5		R102	1-216-025-91	RES,CHIP 100	5% 1/10W
Q204	8-729-026-57	TRANSISTOR FMS1A-T148		R103	1-216-025-91	RES,CHIP 100	5% 1/10W
Q205	8-729-216-22	TRANSISTOR 2SA1162-G		R104	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q206	8-729-230-49	TRANSISTOR 2SC2712-YG		R105	1-216-025-91	RES,CHIP 100	5% 1/10W
Q207	8-729-926-23	TRANSISTOR FMW5		R106	1-216-025-91	RES,CHIP 100	5% 1/10W
Q208	8-729-026-57	TRANSISTOR FMS1A-T148		R107	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q301	8-729-216-22	TRANSISTOR 2SA1162-G		R108	1-216-025-91	RES,CHIP 100	5% 1/10W
Q302	8-729-230-49	TRANSISTOR 2SC2712-YG		R109	1-216-025-91	RES,CHIP 100	5% 1/10W
Q303	8-729-926-23	TRANSISTOR FMW5		R110	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q304	8-729-026-57	TRANSISTOR FMS1A-T148		R111	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q305	8-729-216-22	TRANSISTOR 2SA1162-G		R112	1-216-025-91	RES,CHIP 100	5% 1/10W
Q306	8-729-230-49	TRANSISTOR 2SC2712-YG		R113	1-216-025-91	RES,CHIP 100	5% 1/10W
Q307	8-729-926-23	TRANSISTOR FMW5		R114	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q308	8-729-026-57	TRANSISTOR FMS1A-T148		R115	1-216-025-91	RES,CHIP 100	5% 1/10W
Q401	8-729-216-22	TRANSISTOR 2SA1162-G		R116	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q402	8-729-230-49	TRANSISTOR 2SC2712-YG		R117	1-216-025-91	RES,CHIP 100	5% 1/10W
Q403	8-729-926-23	TRANSISTOR FMW5		R118	1-216-025-91	RES,CHIP 100	5% 1/10W
Q404	8-729-026-57	TRANSISTOR FMS1A-T148		R119	1-216-025-91	RES,CHIP 100	5% 1/10W
Q405	8-729-216-22	TRANSISTOR 2SA1162-G		R120	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q406	8-729-230-49	TRANSISTOR 2SC2712-YG		R121	1-216-679-11	METAL CHIP 15K	0.50% 1/10W
Q407	8-729-926-23	TRANSISTOR FMW5		R122	1-216-669-11	METAL CHIP 5.6K	0.50% 1/10W
Q408	8-729-026-57	TRANSISTOR FMS1A-T148		R123	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
Q501	8-729-216-22	TRANSISTOR 2SA1162-G		R124	1-216-663-11	METAL CHIP 3.3K	0.50% 1/10W
Q502	8-729-230-49	TRANSISTOR 2SC2712-YG		R125	1-216-663-11	METAL CHIP 3.3K	0.50% 1/10W
Q503	8-729-926-23	TRANSISTOR FMW5		R126	1-216-643-11	METAL CHIP 470	0.50% 1/10W
Q504	8-729-026-57	TRANSISTOR FMS1A-T148		R127	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q601	8-729-926-23	TRANSISTOR FMW5		R128	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
Q602	8-729-026-57	TRANSISTOR FMS1A-T148		R129	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q603	8-729-216-22	TRANSISTOR 2SA1162-G		R130	1-216-661-11	METAL CHIP 2.7K	0.50% 1/10W
Q604	8-729-230-49	TRANSISTOR 2SC2712-YG		R131	1-216-647-11	METAL CHIP 680	0.50% 1/10W
Q605	8-729-926-23	TRANSISTOR FMW5		R132	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q606	8-729-026-57	TRANSISTOR FMS1A-T148		R201	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q607	8-729-216-22	TRANSISTOR 2SA1162-G		R202	1-216-025-91	RES,CHIP 100	5% 1/10W
Q608	8-729-230-49	TRANSISTOR 2SC2712-YG		R203	1-216-025-91	RES,CHIP 100	5% 1/10W
Q609	8-729-230-49	TRANSISTOR 2SC2712-YG		R204	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q610	1-801-806-11	TRANSISTOR DTC144EKA-T146		R205	1-216-025-91	RES,CHIP 100	5% 1/10W
Q611	8-729-216-22	TRANSISTOR 2SA1162-G		R206	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q612	1-801-806-11	TRANSISTOR DTC144EKA-T146		R207	1-216-025-91	RES,CHIP 100	5% 1/10W
Q613	1-801-806-11	TRANSISTOR DTC144EKA-T146		R208	1-216-025-91	RES,CHIP 100	5% 1/10W
Q614	1-801-806-11	TRANSISTOR DTC144EKA-T146		R209	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q701	8-729-926-23	TRANSISTOR FMW5		R210	1-216-025-91	RES,CHIP 100	5% 1/10W
Q702	8-729-026-57	TRANSISTOR FMS1A-T148		R211	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q703	8-729-216-22	TRANSISTOR 2SA1162-G		R212	1-216-025-91	RES,CHIP 100	5% 1/10W
Q704	8-729-230-49	TRANSISTOR 2SC2712-YG		R213	1-216-025-91	RES,CHIP 100	5% 1/10W
Q705	8-729-926-23	TRANSISTOR FMW5		R214	1-216-659-11	METAL CHIP 2.2K	0.50% 1/10W
Q706	8-729-026-57	TRANSISTOR FMS1A-T148					
Q707	8-729-216-22	TRANSISTOR 2SA1162-G					



Ref.No.	Part No.	Description		Remark	Ref.No.	Part No.	Description		Remark
R215	1-216-025-91	RES,CHIP	100	5% 1/10W	R409	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R216	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R410	1-216-025-91	RES,CHIP	100	5% 1/10W
R217	1-216-025-91	RES,CHIP	100	5% 1/10W	R411	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R218	1-216-025-91	RES,CHIP	100	5% 1/10W	R412	1-216-025-91	RES,CHIP	100	5% 1/10W
					R413	1-216-025-91	RES,CHIP	100	5% 1/10W
R219	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W					
R220	1-216-025-91	RES,CHIP	100	5% 1/10W	R414	1-216-025-91	RES,CHIP	100	5% 1/10W
R221	1-216-679-11	METAL CHIP	15K	0.50% 1/10W	R415	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R222	1-216-669-11	METAL CHIP	5.6K	0.50% 1/10W	R416	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R223	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W	R417	1-216-025-91	RES,CHIP	100	5% 1/10W
					R418	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R224	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W					
R225	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W	R419	1-216-025-91	RES,CHIP	100	5% 1/10W
R226	1-216-687-11	METAL CHIP	33K	0.50% 1/10W	R420	1-216-025-91	RES,CHIP	100	5% 1/10W
R227	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R421	1-216-679-11	METAL CHIP	15K	0.50% 1/10W
R228	1-216-643-11	METAL CHIP	470	0.50% 1/10W	R422	1-216-669-11	METAL CHIP	5.6K	0.50% 1/10W
					R423	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
R229	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W					
R230	1-216-661-11	METAL CHIP	2.7K	0.50% 1/10W	R424	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
R231	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W	R425	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
R232	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R426	1-216-687-11	METAL CHIP	33K	0.50% 1/10W
R233	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R427	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
					R428	1-216-643-11	METAL CHIP	470	0.50% 1/10W
R301	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W					
R302	1-216-025-91	RES,CHIP	100	5% 1/10W	R429	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R303	1-216-025-91	RES,CHIP	100	5% 1/10W	R430	1-216-665-11	METAL CHIP	3.9K	0.50% 1/10W
R304	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R431	1-216-643-11	METAL CHIP	470	0.50% 1/10W
R305	1-216-025-91	RES,CHIP	100	5% 1/10W	R432	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
					R501	1-216-025-91	RES,CHIP	100	5% 1/10W
R306	1-216-025-91	RES,CHIP	100	5% 1/10W					
R307	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R502	1-216-025-91	RES,CHIP	100	5% 1/10W
R308	1-216-025-91	RES,CHIP	100	5% 1/10W	R503	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
R309	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R504	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
R310	1-216-025-91	RES,CHIP	100	5% 1/10W	R505	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
					R506	1-216-025-91	RES,CHIP	100	5% 1/10W
R311	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W					
R312	1-216-025-91	RES,CHIP	100	5% 1/10W	R507	1-216-025-91	RES,CHIP	100	5% 1/10W
R313	1-216-025-91	RES,CHIP	100	5% 1/10W	R508	1-216-025-91	RES,CHIP	100	5% 1/10W
R314	1-216-025-91	RES,CHIP	100	5% 1/10W	R509	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R315	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R510	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
					R511	1-216-025-91	RES,CHIP	100	5% 1/10W
R316	1-216-025-91	RES,CHIP	100	5% 1/10W					
R317	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R512	1-216-025-91	RES,CHIP	100	5% 1/10W
R318	1-216-025-91	RES,CHIP	100	5% 1/10W	R513	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R319	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R514	1-216-025-91	RES,CHIP	100	5% 1/10W
R320	1-216-025-91	RES,CHIP	100	5% 1/10W	R515	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
					R516	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
R321	1-216-677-11	METAL CHIP	12K	0.50% 1/10W					
R322	1-216-665-11	METAL CHIP	3.9K	0.50% 1/10W	R517	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
R323	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W	R518	1-216-687-11	METAL CHIP	33K	0.50% 1/10W
R324	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W	R519	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
R325	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W	R520	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
					R521	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
R326	1-216-687-11	METAL CHIP	33K	0.50% 1/10W					
R327	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R522	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
R328	1-216-643-11	METAL CHIP	470	0.50% 1/10W	R523	1-216-667-11	METAL CHIP	4.7K	0.50% 1/10W
R329	1-216-661-11	METAL CHIP	2.7K	0.50% 1/10W	R524	1-216-687-11	METAL CHIP	33K	0.50% 1/10W
R330	1-216-677-11	METAL CHIP	12K	0.50% 1/10W	R525	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
					R526	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
R331	1-216-649-11	METAL CHIP	820	0.50% 1/10W					
R332	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R601	1-216-665-11	METAL CHIP	3.9K	0.50% 1/10W
R401	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R602	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R402	1-216-025-91	RES,CHIP	100	5% 1/10W	R603	1-216-665-11	METAL CHIP	3.9K	0.50% 1/10W
R403	1-216-025-91	RES,CHIP	100	5% 1/10W	R604	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
					R605	1-216-643-11	METAL CHIP	470	0.50% 1/10W
R404	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W					
R405	1-216-025-91	RES,CHIP	100	5% 1/10W	R606	1-216-687-11	METAL CHIP	33K	0.50% 1/10W
R406	1-216-025-91	RES,CHIP	100	5% 1/10W	R607	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W
R407	1-216-659-11	METAL CHIP	2.2K	0.50% 1/10W	R608	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W
R408	1-216-025-91	RES,CHIP	100	5% 1/10W	R609	1-216-663-11	METAL CHIP	3.3K	0.50% 1/10W

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R610	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R677	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R611	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R678	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R612	1-216-677-11	METAL CHIP	12K 0.50% 1/10W	R679	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R613	1-216-025-91	RES,CHIP	100 5% 1/10W	R680	1-216-025-91	RES,CHIP	100 5% 1/10W
R614	1-216-025-91	RES,CHIP	100 5% 1/10W	R681	1-216-025-91	RES,CHIP	100 5% 1/10W
R615	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R682	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W
R616	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R683	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W
R617	1-216-025-91	RES,CHIP	100 5% 1/10W	R684	1-216-025-91	RES,CHIP	100 5% 1/10W
R618	1-216-025-91	RES,CHIP	100 5% 1/10W	R685	1-218-756-11	METAL CHIP	150K 0.50% 1/10W
R619	1-216-025-91	RES,CHIP	100 5% 1/10W	R701	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R620	1-216-025-91	RES,CHIP	100 5% 1/10W	R702	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R621	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R703	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R622	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R704	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R623	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R705	1-216-643-11	METAL CHIP	470 0.50% 1/10W
R624	1-216-681-11	METAL CHIP	18K 0.50% 1/10W	R706	1-216-687-11	METAL CHIP	33K 0.50% 1/10W
R625	1-218-760-11	METAL CHIP	220K 0.50% 1/10W	R707	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R626	1-216-675-11	METAL CHIP	10K 0.50% 1/10W	R708	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W
R627	1-216-645-11	METAL CHIP	560 0.50% 1/10W	R709	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W
R628	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R710	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R629	1-216-665-11	METAL CHIP	3.9K 0.50% 1/10W	R711	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R630	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R712	1-216-683-11	METAL CHIP	22K 0.50% 1/10W
R631	1-216-643-11	METAL CHIP	470 0.50% 1/10W	R713	1-216-025-91	RES,CHIP	100 5% 1/10W
R632	1-216-687-11	METAL CHIP	33K 0.50% 1/10W	R714	1-216-025-91	RES,CHIP	100 5% 1/10W
R633	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R715	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R634	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W	R716	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R635	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W	R717	1-216-025-91	RES,CHIP	100 5% 1/10W
R636	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W	R718	1-216-025-91	RES,CHIP	100 5% 1/10W
R637	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R719	1-216-025-91	RES,CHIP	100 5% 1/10W
R638	1-216-679-11	METAL CHIP	15K 0.50% 1/10W	R720	1-216-025-91	RES,CHIP	100 5% 1/10W
R639	1-216-025-91	RES,CHIP	100 5% 1/10W	R721	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R640	1-216-025-91	RES,CHIP	100 5% 1/10W	R722	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R641	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R723	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R642	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R724	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R643	1-216-025-91	RES,CHIP	100 5% 1/10W	R725	1-216-643-11	METAL CHIP	470 0.50% 1/10W
R644	1-216-025-91	RES,CHIP	100 5% 1/10W	R726	1-216-687-11	METAL CHIP	33K 0.50% 1/10W
R645	1-216-025-91	RES,CHIP	100 5% 1/10W	R727	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R646	1-216-025-91	RES,CHIP	100 5% 1/10W	R728	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W
R647	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R729	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W
R648	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	R730	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R649	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W	R731	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W
R650	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R732	1-216-683-11	METAL CHIP	22K 0.50% 1/10W
R651	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R733	1-216-025-91	RES,CHIP	100 5% 1/10W
R652	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W	R734	1-216-025-91	RES,CHIP	100 5% 1/10W
R653	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R735	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R654	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R736	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R655	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W	R737	1-216-025-91	RES,CHIP	100 5% 1/10W
R656	1-216-663-11	METAL CHIP	3.3K 0.50% 1/10W	R738	1-216-025-91	RES,CHIP	100 5% 1/10W
R657	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R739	1-216-025-91	RES,CHIP	100 5% 1/10W
R658	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R740	1-216-025-91	RES,CHIP	100 5% 1/10W
R659	1-216-025-91	RES,CHIP	100 5% 1/10W	R741	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R660	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R742	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R661	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R743	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R662	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R744	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R671	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R745	1-216-025-91	RES,CHIP	100 5% 1/10W
R672	1-216-679-11	METAL CHIP	15K 0.50% 1/10W	R746	1-216-657-11	METAL CHIP	1.8K 0.50% 1/10W
R673	1-216-669-11	METAL CHIP	5.6K 0.50% 1/10W	R747	1-216-025-91	RES,CHIP	100 5% 1/10W
R674	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R748	1-216-025-91	RES,CHIP	100 5% 1/10W
R675	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	R749	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W
R676	1-216-017-91	RES,CHIP	47 5% 1/10W				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R750	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W	RV601	1-238-798-11	RES, ADJ, CERMET 500	
R751	1-216-025-91	RES,CHIP	100 5% 1/10W	RV602	1-238-802-11	RES, ADJ, CERMET 10K	
R752	1-216-025-91	RES,CHIP	100 5% 1/10W	RV603	1-238-798-11	RES, ADJ, CERMET 500	
R753	1-216-025-91	RES,CHIP	100 5% 1/10W	RV604	1-238-802-11	RES, ADJ, CERMET 10K	
R754	1-216-657-11	METAL CHIP	1.8K 0.50% 1/10W	RV701	1-238-798-11	RES, ADJ, CERMET 500	
R933	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	RV702	1-238-802-11	RES, ADJ, CERMET 10K	
R934	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	RV703	1-238-798-11	RES, ADJ, CERMET 500	
R935	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W	RV704	1-238-802-11	RES, ADJ, CERMET 10K	
R936	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R938	1-216-025-91	RES,CHIP	100 5% 1/10W				
R939	1-216-025-91	RES,CHIP	100 5% 1/10W				
R940	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R941	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R942	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R943	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R944	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R946	1-216-025-91	RES,CHIP	100 5% 1/10W				
R947	1-216-025-91	RES,CHIP	100 5% 1/10W				
R948	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R949	1-216-025-91	RES,CHIP	100 5% 1/10W				
R951	1-216-033-00	RES,CHIP	220 5% 1/10W				
R952	1-216-025-91	RES,CHIP	100 5% 1/10W				
R953	1-216-025-91	RES,CHIP	100 5% 1/10W				
R954	1-216-025-91	RES,CHIP	100 5% 1/10W				
R955	1-216-025-91	RES,CHIP	100 5% 1/10W				
R956	1-216-025-91	RES,CHIP	100 5% 1/10W				
R957	1-216-025-91	RES,CHIP	100 5% 1/10W				
R958	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W				
R959	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W				
R960	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W				
R961	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W				
R962	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R963	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R964	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R965	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R966	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R967	1-216-675-11	METAL CHIP	10K 0.50% 1/10W				
R968	1-216-679-11	METAL CHIP	15K 0.50% 1/10W				
R969	1-216-675-11	METAL CHIP	10K 0.50% 1/10W				
R970	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R971	1-216-681-11	METAL CHIP	18K 0.50% 1/10W				
R972	1-216-659-11	METAL CHIP	2.2K 0.50% 1/10W				
R973	1-218-776-11	METAL CHIP	1M 0.50% 1/10W				
R974	1-216-655-11	METAL CHIP	1.5K 0.50% 1/10W				
R975	1-216-683-11	METAL CHIP	22K 0.50% 1/10W				
R985	1-216-667-11	METAL CHIP	4.7K 0.50% 1/10W				
R986	1-216-651-11	METAL CHIP	1K 0.50% 1/10W				
<VARIABLE RESISTOR>							
RV101	1-238-802-11	RES, ADJ, CERMET 10K					
RV102	1-238-798-11	RES, ADJ, CERMET 500					
RV202	1-238-798-11	RES, ADJ, CERMET 500					
RV301	1-238-802-11	RES, ADJ, CERMET 10K					
RV302	1-238-798-11	RES, ADJ, CERMET 500					
RV401	1-238-802-11	RES, ADJ, CERMET 10K					
RV402	1-238-798-11	RES, ADJ, CERMET 500					
RV501	1-238-798-11	RES, ADJ, CERMET 500					
RV502	1-238-798-11	RES, ADJ, CERMET 500					

* A-1346-779-A EBR COMPLETE PC BOARD
(Include EBA, EBC Mounted PC BOARD)

3-701-809-31 SCREW, TERMINAL (M3X8)
* 4-067-812-01 HOLDER (C), TR
4-382-854-11 SCREW (M3X10), P, SW (+)
4-382-854-11 SCREW (M3X10), P, SW (+)

<CAPACITOR>

C100	1-107-921-91	ELECT	100μF	20%	63V
C101	1-107-921-91	ELECT	100μF	20%	63V
C108	1-107-369-11	MYLAR	0.068μF	10%	100V
C109	1-107-369-11	MYLAR	0.068μF	10%	100V
C110	1-107-923-11	ELECT	330μF	20%	63V
C111	1-107-923-11	ELECT	330μF	20%	63V
C112	1-107-914-11	ELECT	1000μF	20%	25V
C113	1-107-914-11	ELECT	1000μF	20%	25V
C114	1-136-481-11	MYLAR	0.0022μF	10%	100V
C115	1-137-150-11	MYLAR	0.01μF	10%	100V
C118	1-163-001-11	CERAMIC CHIP	220PF	10%	50V
C121	1-107-906-11	ELECT	10μF	20%	50V
C122	1-107-504-11	CERAMIC	10PF	0.5PF	500V
C123	1-115-339-11	CERAMIC CHIP	0.1μF	10%	50V
C140	1-128-526-11	ELECT	100μF	20%	25V
C141	1-107-906-11	ELECT	10μF	20%	50V
C142	1-128-526-11	ELECT	100μF	20%	25V
C143	1-107-906-11	ELECT	10μF	20%	50V
C150	1-128-526-11	ELECT	100μF	20%	25V
C151	1-163-021-91	CERAMIC CHIP	0.01μF	10%	50V
C152	1-104-653-11	ELECT	220μF	20%	16V
C153	1-128-526-11	ELECT	100μF	20%	25V
C154	1-163-021-91	CERAMIC CHIP	0.01μF	10%	50V
C155	1-104-653-11	ELECT	220μF	20%	16V
C156	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C157	1-163-021-91	CERAMIC CHIP	0.01μF	10%	50V
C158	1-163-021-91	CERAMIC CHIP	0.01μF	10%	50V
C159	1-107-909-11	ELECT	47μF	20%	50V
C160	1-107-909-11	ELECT	47μF	20%	50V
C161	1-163-021-91	CERAMIC CHIP	0.01μF	10%	50V
C162	1-163-021-91	CERAMIC CHIP	0.01μF	10%	50V
C163	1-136-169-00	FILM	0.22μF	5%	50V
C400	1-124-242-00	ELECT	33μF	20%	25V
C420	1-163-031-11	CERAMIC CHIP	0.01μF		50V
C421	1-163-031-11	CERAMIC CHIP	0.01μF		50V
C422	1-163-031-11	CERAMIC CHIP	0.01μF		50V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C500	1-124-242-00	ELECT 33μF 20%	25V			<COIL>	
C501	1-124-242-00	ELECT 33μF 20%	25V	L100	1-406-663-21	INDUCTOR 47μH	
C502	1-163-031-11	CERAMIC CHIP 0.01μF	50V	L101	1-406-663-21	INDUCTOR 47μH	
C503	1-163-031-11	CERAMIC CHIP 0.01μF	50V	L102	1-412-533-21	INDUCTOR 47μH	
C504	1-163-031-11	CERAMIC CHIP 0.01μF	50V	L103	1-412-533-21	INDUCTOR 47μH	
C505	1-163-227-11	CERAMIC CHIP 10PF 0.5PF	50V	L150	1-410-645-31	INDUCTOR 100μH	
C506	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	L151	1-410-645-31	INDUCTOR 100μH	
C507	1-124-242-00	ELECT 33μF 20%	25V	L152	1-412-533-21	INDUCTOR 47μH	
C508	1-124-242-00	ELECT 33μF 20%	25V	L153	1-412-533-21	INDUCTOR 47μH	
C509	1-163-031-11	CERAMIC CHIP 0.01μF	50V	L500	1-410-645-31	INDUCTOR 100μH	
C510	1-163-031-11	CERAMIC CHIP 0.01μF	50V	L501	1-410-645-31	INDUCTOR 100μH	
C511	1-163-031-11	CERAMIC CHIP 0.01μF	50V			<TRANSISTOR>	
		<CONNECTOR>		Q102	8-729-142-68	TRANSISTOR 2SJ143	
CN140	* 1-564-709-11	PIN, CONNECTOR (SMALL TYPE) 7P		Q103	8-729-142-69	TRANSISTOR 2SK817	
CN141	* 1-564-713-11	PIN, CONNECTOR (SMALL TYPE) 11P		Q104	8-729-207-89	TRANSISTOR 2SA1358-Y	
CN142	* 1-564-713-11	PIN, CONNECTOR (SMALL TYPE) 11P		Q105	8-729-207-82	TRANSISTOR 2SC3421-Y	
CN143	* 1-785-518-11	CONNECTOR, BOARD TO BOARD 15P		Q106	8-729-021-76	TRANSISTOR 2SA1804-RO	
CN144	* 1-774-249-11	CONNECTOR, BOARD TO BOARD 10P		Q107	8-729-021-75	TRANSISTOR 2SC4689N-RO	
CN145	* 1-564-507-11	PLUG, CONNECTOR 4P		Q140	8-729-216-22	TRANSISTOR 2SA1162-G	
CN168	* 1-785-517-11	CONNECTOR, BOARD TO BOARD 13P		Q141	8-729-230-49	TRANSISTOR 2SC2712-YG	
CN500	* 1-774-246-11	CONNECTOR, BOARD TO BOARD 10P		Q400	1-801-806-11	TRANSISTOR DTC144EKA-T146	
		<DIODE>		Q420	8-729-230-49	TRANSISTOR 2SC2712-YG	
D100	8-719-106-89	DIODE RD15M-T1B2		Q421	8-729-230-49	TRANSISTOR 2SC2712-YG	
D101	8-719-106-89	DIODE RD15M-T1B2		Q422	8-729-230-49	TRANSISTOR 2SC2712-YG	
D102	8-719-025-10	DIODE D8LC20U		Q423	8-729-033-10	TRANSISTOR 2SC3776-CD-AA	
D103	8-719-025-11	DIODE D8LC20UR		Q424	8-729-230-49	TRANSISTOR 2SC2712-YG	
D104	8-719-106-71	DIODE RD12M-B2		Q425	8-729-216-22	TRANSISTOR 2SA1162-G	
D105	8-719-801-78	DIODE 1SS184		Q426	8-729-033-10	TRANSISTOR 2SC3776-CD-AA	
D140	8-719-801-78	DIODE 1SS184		Q427	8-729-230-49	TRANSISTOR 2SC2712-YG	
D141	8-719-801-78	DIODE 1SS184		Q428	8-729-216-22	TRANSISTOR 2SA1162-G	
D150	8-719-801-78	DIODE 1SS184		Q500	8-729-216-22	TRANSISTOR 2SA1162-G	
D151	8-719-801-78	DIODE 1SS184		Q501	8-729-216-22	TRANSISTOR 2SA1162-G	
D400	8-719-801-78	DIODE 1SS184		Q502	8-729-230-49	TRANSISTOR 2SC2712-YG	
D420	8-719-801-78	DIODE 1SS184		Q503	8-729-230-49	TRANSISTOR 2SC2712-YG	
D421	8-719-106-53	DIODE RD10M-B2				<RESISTOR>	
		<FERRITE BEAD>		R110	1-216-073-00	RES,CHIP 10K 5%	1/10W
FB100	1-410-396-41	FERRITE 0.45μH		R111	1-216-073-00	RES,CHIP 10K 5%	1/10W
FB101	1-410-396-41	FERRITE 0.45μH		R112	1-216-005-00	RES,CHIP 15 5%	1/10W
FB102	1-410-396-41	FERRITE 0.45μH		R113	1-216-005-00	RES,CHIP 15 5%	1/10W
FB103	1-410-396-41	FERRITE 0.45μH		R116	1-216-067-00	RES,CHIP 5.6K 5%	1/10W
FB104	1-410-396-41	FERRITE 0.45μH		R117	1-216-045-00	RES,CHIP 680 5%	1/10W
FB105	1-410-396-41	FERRITE 0.45μH		R118	1-216-025-91	RES,CHIP 100 5%	1/10W
		<IC>		R119	1-216-647-11	METAL CHIP 680 0.50%	1/10W F
IC150	8-759-231-58	IC TA7812S		R120	1-215-875-11	METAL OXIDE 10K 5%	1/10W F
IC151	8-759-701-88	IC NJM7912FA		R121	1-216-623-11	METAL CHIP 68 0.50%	1/10W
IC152	8-759-100-96	IC UPC4558G2		R122	1-216-627-11	METAL CHIP 100 0.50%	1/10W
IC153	8-759-336-63	IC LM675T		R123	1-249-393-11	CARBON 10 5%	1/4W
IC400	8-759-988-13	IC LM393PS		R124	1-249-393-11	CARBON 10 5%	1/4W
IC420	8-759-105-49	IC UPC319G2		R125	1-216-345-11	METAL OXIDE 0.47 5%	1/10W F
IC500	8-759-381-53	IC UPC814G2-E2		R126	1-216-345-11	METAL OXIDE 0.47 5%	1/10W F
IC501	8-759-984-88	IC LM6361M		R127	1-216-480-11	METAL OXIDE 820 5%	3/10W F
				R128	1-216-371-00	METAL OXIDE 1.5 5%	2/10W F
				R129	1-216-480-11	METAL OXIDE 820 5%	3/10W F
				R130	1-216-371-00	METAL OXIDE 1.5 5%	2/10W F
				R131	1-216-480-11	METAL OXIDE 820 5%	3/10W F

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R132	1-216-480-11	METAL OXIDE 820	5% 3W F	R450	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R140	1-216-041-00	RES,CHIP 470	5% 1/10W	R451	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R141	1-216-367-11	METAL OXIDE 0.68	5% 2W F	R500	1-216-669-11	METAL CHIP 5.6K	0.50% 1/10W
R142	1-216-073-00	RES,CHIP 10K	5% 1/10W	R501	1-216-677-11	METAL CHIP 12K	0.50% 1/10W
R143	1-216-081-00	RES,CHIP 22K	5% 1/10W	R502	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W
R144	1-216-041-00	RES,CHIP 470	5% 1/10W	R503	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R145	1-216-073-00	RES,CHIP 10K	5% 1/10W	R504	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
R146	1-216-367-11	METAL OXIDE 0.68	5% 2W F	R505	1-216-665-11	METAL CHIP 3.9K	0.50% 1/10W
R150	1-216-669-11	METAL CHIP 5.6K	0.50% 1/10W	R506	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R151	1-216-645-11	METAL CHIP 560	0.50% 1/10W	R507	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R152	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R508	1-216-643-11	METAL CHIP 470	0.50% 1/10W
R153	1-216-677-11	METAL CHIP 12K	0.50% 1/10W	R509	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R154	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R510	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
R156	1-249-389-11	CARBON 4.7	5% 1/4W F	R511	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
R157	1-249-389-11	CARBON 4.7	5% 1/4W F	R512	1-216-641-11	METAL CHIP 390	0.50% 1/10W
R158	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R513	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
R159	1-216-651-11	METAL CHIP 1K	0.50% 1/10W	R514	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R160	1-216-651-11	METAL CHIP 1K	0.50% 1/10W	R515	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R161	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R516	1-216-641-11	METAL CHIP 390	0.50% 1/10W
R162	1-249-389-11	CARBON 4.7	5% 1/4W	R517	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
R163	1-249-380-11	CARBON 0.82	5% 1/4W F	R518	1-216-693-11	METAL CHIP 56K	0.50% 1/10W
R164	1-215-915-11	METAL OXIDE 470	5% 3W F				
R165	1-216-379-11	METAL OXIDE 6.8	5% 2W F				
R400	1-216-073-00	RES,CHIP 10K	5% 1/10W				
R401	1-216-077-00	RES,CHIP 15K	5% 1/10W				
R402	1-216-077-00	RES,CHIP 15K	5% 1/10W				
R403	1-216-085-00	RES,CHIP 33K	5% 1/10W				
R404	1-216-073-00	RES,CHIP 10K	5% 1/10W				
R405	1-216-049-91	RES,CHIP 1K	5% 1/10W				
R406	1-216-025-91	RES,CHIP 100	5% 1/10W				
R420	1-216-691-11	METAL CHIP 47K	0.50% 1/10W				
R421	1-216-679-11	METAL CHIP 15K	0.50% 1/10W				
R422	1-216-691-11	METAL CHIP 47K	0.50% 1/10W				
R423	1-216-675-11	METAL CHIP 10K	0.50% 1/10W				
R424	1-216-699-11	METAL CHIP 100K	0.50% 1/10W				
R425	1-216-049-91	RES,CHIP 1K	5% 1/10W				
R426	1-216-065-91	RES,CHIP 4.7K	5% 1/10W				
R427	1-216-041-00	RES,CHIP 470	5% 1/10W				
R428	1-216-041-00	RES,CHIP 470	5% 1/10W				
R429	1-216-041-00	RES,CHIP 470	5% 1/10W				
R430	1-216-041-00	RES,CHIP 470	5% 1/10W				
R431	1-216-679-11	METAL CHIP 15K	0.50% 1/10W				
R432	1-216-691-11	METAL CHIP 47K	0.50% 1/10W				
R433	1-216-687-11	METAL CHIP 33K	0.50% 1/10W				
R435	1-216-691-11	METAL CHIP 47K	0.50% 1/10W				
R436	1-216-017-91	RES,CHIP 47	5% 1/10W				
R437	1-249-414-11	CARBON 560	5% 1/4W				
R438	1-216-017-91	RES,CHIP 47	5% 1/10W				
R439	1-216-047-91	RES,CHIP 820	5% 1/10W				
R440	1-216-017-91	RES,CHIP 47	5% 1/10W				
R441	1-216-001-00	RES,CHIP 10	5% 1/10W				
R442	1-216-001-00	RES,CHIP 10	5% 1/10W				
R443	1-249-414-11	CARBON 560	5% 1/4W				
R444	1-216-017-91	RES,CHIP 47	5% 1/10W				
R445	1-216-017-91	RES,CHIP 47	5% 1/10W				
R446	1-216-047-91	RES,CHIP 820	5% 1/10W				
R447	1-216-017-91	RES,CHIP 47	5% 1/10W				
R448	1-216-001-00	RES,CHIP 10	5% 1/10W				
R449	1-216-001-00	RES,CHIP 10	5% 1/10W				

				* A-1346-780-A EBG COMPLETE PC BOARD			
				(Include EBA, EBC Mounted PC BOARD)			

				3-701-809-31 SCREW, TERMINAL (M3X8)			
				* 4-067-812-01 HOLDER (C), TR			
				4-382-854-11 SCREW (M3X10), P, SW (+)			
				4-382-854-11 SCREW (M3X10), P, SW (+)			
				<CAPACITOR>			
				C200	1-107-921-91	ELECT 100μF	20% 63V
				C201	1-107-921-91	ELECT 100μF	20% 63V
				C208	1-107-369-11	MYLAR 0.068μF	10% 100V
				C209	1-107-369-11	MYLAR 0.068μF	10% 100V
				C210	1-107-923-11	ELECT 330μF	20% 63V
				C211	1-107-923-11	ELECT 330μF	20% 63V
				C212	1-107-914-11	ELECT 1000μF	20% 25V
				C213	1-107-914-11	ELECT 1000μF	20% 25V
				C214	1-136-481-11	MYLAR 0.0022μF	10% 100V
				C215	1-137-150-11	MYLAR 0.01μF	10% 100V
				C218	1-163-001-11	CERAMIC CHIP 220PF	10% 50V
				C221	1-107-906-11	ELECT 10μF	20% 50V
				C222	1-107-504-11	CERAMIC 10PF	0.5PF 500V
				C223	1-115-339-11	CERAMIC CHIP 0.1μF	10% 50V
				C240	1-128-526-11	ELECT 100μF	20% 25V
				C241	1-107-906-11	ELECT 10μF	20% 50V
				C242	1-128-526-11	ELECT 100μF	20% 25V
				C243	1-107-906-11	ELECT 10μF	20% 50V
				C250	1-128-526-11	ELECT 100μF	20% 25V
				C251	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
				C252	1-104-653-11	ELECT 220μF	20% 16V
				C253	1-128-526-11	ELECT 100μF	20% 25V
				C254	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
				C255	1-104-653-11	ELECT 220μF	20% 16V

Ref.No.	Part No.	Description	Remark			Ref.No.	Part No.	Description	Remark		
C256	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		FB205	1-410-396-41	FERRITE 0.45μH			
C257	1-163-021-91	CERAMIC CHIP 0.01μF	10%	50V							
C258	1-163-021-91	CERAMIC CHIP 0.01μF	10%	50V			<IC>				
C259	1-107-909-11	ELECT 47μF	20%	50V							
C260	1-107-909-11	ELECT 47μF	20%	50V		IC250	8-759-231-58	IC TA7812S			
C261	1-163-021-91	CERAMIC CHIP 0.01μF	10%	50V		IC251	8-759-701-88	IC NJM7912FA			
						IC252	8-759-100-96	IC UPC4558G2			
C262	1-163-021-91	CERAMIC CHIP 0.01μF	10%	50V		IC253	8-759-336-63	IC LM675T			
C263	1-136-169-00	FILM 0.22μF	5%	50V		IC400	8-759-988-13	IC LM393PS			
C400	1-124-242-00	ELECT 33μF	20%	25V							
C420	1-163-031-11	CERAMIC CHIP 0.01μF		50V		IC420	8-759-105-49	IC UPC319G2			
C421	1-163-031-11	CERAMIC CHIP 0.01μF		50V		IC500	8-759-381-53	IC UPC814G2-E2			
						IC501	8-759-984-88	IC LM6361M			
C422	1-163-031-11	CERAMIC CHIP 0.01μF		50V							
C500	1-124-242-00	ELECT 33μF	20%	25V			<COIL>				
C501	1-124-242-00	ELECT 33μF	20%	25V							
C502	1-163-031-11	CERAMIC CHIP 0.01μF		50V		L200	1-406-663-21	INDUCTOR 47μH			
C503	1-163-031-11	CERAMIC CHIP 0.01μF		50V		L201	1-406-663-21	INDUCTOR 47μH			
						L202	1-412-533-21	INDUCTOR 47μH			
C504	1-163-031-11	CERAMIC CHIP 0.01μF		50V		L203	1-412-533-21	INDUCTOR 47μH			
C505	1-163-227-11	CERAMIC CHIP 10PF	0.5PF	50V		L250	1-410-645-31	INDUCTOR 100μH			
C506	1-163-251-11	CERAMIC CHIP 100PF	5%	50V							
C507	1-124-242-00	ELECT 33μF	20%	25V		L251	1-410-645-31	INDUCTOR 100μH			
C508	1-124-242-00	ELECT 33μF	20%	25V		L252	1-412-533-21	INDUCTOR 47μH			
						L253	1-412-533-21	INDUCTOR 47μH			
C509	1-163-031-11	CERAMIC CHIP 0.01μF		50V		L500	1-410-645-31	INDUCTOR 100μH			
C510	1-163-031-11	CERAMIC CHIP 0.01μF		50V		L501	1-410-645-31	INDUCTOR 100μH			
C511	1-163-031-11	CERAMIC CHIP 0.01μF		50V							
							<TRANSISTOR>				
	<CONNECTOR>										
CN150	*1-564-709-11	PIN, CONNECTOR (SMALL TYPE) 7P				Q202	8-729-142-68	TRANSISTOR 2SJ143			
CN151	*1-564-713-11	PIN, CONNECTOR (SMALL TYPE)11P				Q203	8-729-142-69	TRANSISTOR 2SK817			
CN152	*1-564-713-11	PIN, CONNECTOR (SMALL TYPE)11P				Q204	8-729-207-89	TRANSISTOR 2SA1358-Y			
CN153	*1-785-518-11	CONNECTOR, BOARD TO BOARD 15P				Q205	8-729-207-82	TRANSISTOR 2SC3421-Y			
CN154	*1-774-249-11	CONNECTOR, BOARD TO BOARD 10P				Q206	8-729-021-76	TRANSISTOR 2SA1804-RO			
CN155	*1-564-507-11	PLUG, CONNECTOR 4P				Q207	8-729-021-75	TRANSISTOR 2SC4689N-RO			
CN168	*1-785-517-11	CONNECTOR, BOARD TO BOARD 13P				Q240	8-729-216-22	TRANSISTOR 2SA1162-G			
CN500	*1-774-246-11	CONNECTOR, BOARD TO BOARD 10P				Q241	8-729-230-49	TRANSISTOR 2SC2712-YG			
						Q400	1-801-806-11	TRANSISTOR DTC144EKA-T146			
						Q420	8-729-230-49	TRANSISTOR 2SC2712-YG			
	<DIODE>										
D200	8-719-106-89	DIODE RD15M-T1B2				Q421	8-729-230-49	TRANSISTOR 2SC2712-YG			
D201	8-719-106-89	DIODE RD15M-T1B2				Q422	8-729-230-49	TRANSISTOR 2SC2712-YG			
D202	8-719-025-10	DIODE D8LC20U				Q423	8-729-033-10	TRANSISTOR 2SC3776-CD-AA			
D203	8-719-025-11	DIODE D8LC20UR				Q424	8-729-230-49	TRANSISTOR 2SC2712-YG			
D204	8-719-106-71	DIODE RD12M-B2				Q425	8-729-216-22	TRANSISTOR 2SA1162-G			
D205	8-719-801-78	DIODE 1SS184				Q426	8-729-033-10	TRANSISTOR 2SC3776-CD-AA			
D240	8-719-801-78	DIODE 1SS184				Q427	8-729-230-49	TRANSISTOR 2SC2712-YG			
D241	8-719-801-78	DIODE 1SS184				Q428	8-729-216-22	TRANSISTOR 2SA1162-G			
D250	8-719-801-78	DIODE 1SS184				Q500	8-729-216-22	TRANSISTOR 2SA1162-G			
D251	8-719-801-78	DIODE 1SS184				Q501	8-729-216-22	TRANSISTOR 2SA1162-G			
D400	8-719-801-78	DIODE 1SS184				Q502	8-729-230-49	TRANSISTOR 2SC2712-YG			
D420	8-719-801-78	DIODE 1SS184				Q503	8-729-230-49	TRANSISTOR 2SC2712-YG			
D421	8-719-106-53	DIODE RD10M-B2									
							<RESISTOR>				
	<FERRITE BEAD>										
FB200	1-410-396-41	FERRITE 0.45μH				R210	1-216-073-00	RES,CHIP 10K 5%	1/10W		
FB201	1-410-396-41	FERRITE 0.45μH				R211	1-216-073-00	RES,CHIP 10K 5%	1/10W		
FB202	1-410-396-41	FERRITE 0.45μH				R212	1-216-005-00	RES,CHIP 15 5%	1/10W		
FB203	1-410-396-41	FERRITE 0.45μH				R213	1-216-005-00	RES,CHIP 15 5%	1/10W		
FB204	1-410-396-41	FERRITE 0.45μH				R216	1-216-067-00	RES,CHIP 5.6K 5%	1/10W		
						R217	1-216-045-00	RES,CHIP 680 5%	1/10W		

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R218	1-216-025-91	RES,CHIP 100	5% 1/10W	R436	1-216-017-91	RES,CHIP 47	5% 1/10W
R219	1-216-647-11	METAL CHIP 680	0.50% 1/10W	R437	1-249-414-11	CARBON 560	5% 1/4W
R220	1-215-875-11	METAL OXIDE 10K	5% 1W F	R438	1-216-017-91	RES,CHIP 47	5% 1/10W
R221	1-216-623-11	METAL CHIP 68	0.50% 1/10W	R439	1-216-047-91	RES,CHIP 820	5% 1/10W
R222	1-216-627-11	METAL CHIP 100	0.50% 1/10W	R440	1-216-017-91	RES,CHIP 47	5% 1/10W
R223	1-249-393-11	CARBON 10	5% 1/4W	R441	1-216-001-00	RES,CHIP 10	5% 1/10W
R224	1-249-393-11	CARBON 10	5% 1/4W	R442	1-216-001-00	RES,CHIP 10	5% 1/10W
R225	1-216-345-11	METAL OXIDE 0.47	5% 1W F	R443	1-249-414-11	CARBON 560	5% 1/4W
R226	1-216-345-11	METAL OXIDE 0.47	5% 1W F	R444	1-216-017-91	RES,CHIP 47	5% 1/10W
R227	1-216-480-11	METAL OXIDE 820	5% 3W F	R445	1-216-017-91	RES,CHIP 47	5% 1/10W
R228	1-216-371-00	METAL OXIDE 1.5	5% 2W F	R446	1-216-047-91	RES,CHIP 820	5% 1/10W
R229	1-216-480-11	METAL OXIDE 820	5% 3W F	R447	1-216-017-91	RES,CHIP 47	5% 1/10W
R230	1-216-371-00	METAL OXIDE 1.5	5% 2W F	R448	1-216-001-00	RES,CHIP 10	5% 1/10W
R231	1-216-480-11	METAL OXIDE 820	5% 3W F	R449	1-216-001-00	RES,CHIP 10	5% 1/10W
R232	1-216-480-11	METAL OXIDE 820	5% 3W F	R450	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R240	1-216-041-00	RES,CHIP 470	5% 1/10W	R451	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R241	1-216-367-11	METAL OXIDE 0.68	5% 2W F	R500	1-216-669-11	METAL CHIP 5.6K	0.50% 1/10W
R242	1-216-073-00	RES,CHIP 10K	5% 1/10W	R501	1-216-677-11	METAL CHIP 12K	0.50% 1/10W
R243	1-216-081-00	RES,CHIP 22K	5% 1/10W	R502	1-216-653-11	METAL CHIP 1.2K	0.50% 1/10W
R244	1-216-041-00	RES,CHIP 470	5% 1/10W	R503	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R245	1-216-073-00	RES,CHIP 10K	5% 1/10W	R504	1-216-671-11	METAL CHIP 6.8K	0.50% 1/10W
R246	1-216-367-11	METAL OXIDE 0.68	5% 2W F	R505	1-216-665-11	METAL CHIP 3.9K	0.50% 1/10W
R250	1-216-669-11	METAL CHIP 5.6K	0.50% 1/10W	R506	1-216-675-11	METAL CHIP 10K	0.50% 1/10W
R251	1-216-645-11	METAL CHIP 560	0.50% 1/10W	R507	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R252	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R508	1-216-643-11	METAL CHIP 470	0.50% 1/10W
R253	1-216-677-11	METAL CHIP 12K	0.50% 1/10W	R509	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R254	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R510	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
R256	1-249-389-11	CARBON 4.7	5% 1/4W F	R511	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
R257	1-249-389-11	CARBON 4.7	5% 1/4W F	R512	1-216-641-11	METAL CHIP 390	0.50% 1/10W
R258	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R513	1-216-687-11	METAL CHIP 33K	0.50% 1/10W
R259	1-216-651-11	METAL CHIP 1K	0.50% 1/10W	R514	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R260	1-216-651-11	METAL CHIP 1K	0.50% 1/10W	R515	1-216-651-11	METAL CHIP 1K	0.50% 1/10W
R261	1-216-675-11	METAL CHIP 10K	0.50% 1/10W	R516	1-216-641-11	METAL CHIP 390	0.50% 1/10W
R262	1-249-389-11	CARBON 4.7	5% 1/4W	R517	1-216-673-11	METAL CHIP 8.2K	0.50% 1/10W
R263	1-249-380-11	CARBON 0.82	5% 1/4W F	R518	1-216-693-11	METAL CHIP 56K	0.50% 1/10W
R264	1-215-915-11	METAL OXIDE 470	5% 3W F				
R265	1-216-379-11	METAL OXIDE 6.8	5% 2W F				
R400	1-216-073-00	RES,CHIP 10K	5% 1/10W				
R401	1-216-077-00	RES,CHIP 15K	5% 1/10W				
R402	1-216-077-00	RES,CHIP 15K	5% 1/10W				
R403	1-216-085-00	RES,CHIP 33K	5% 1/10W				
R404	1-216-073-00	RES,CHIP 10K	5% 1/10W				
R405	1-216-049-91	RES,CHIP 1K	5% 1/10W				
R406	1-216-025-91	RES,CHIP 100	5% 1/10W				
R420	1-216-691-11	METAL CHIP 47K	0.50% 1/10W				
R421	1-216-679-11	METAL CHIP 15K	0.50% 1/10W				
R422	1-216-691-11	METAL CHIP 47K	0.50% 1/10W				
R423	1-216-675-11	METAL CHIP 10K	0.50% 1/10W				
R424	1-216-699-11	METAL CHIP 100K	0.50% 1/10W				
R425	1-216-049-91	RES,CHIP 1K	5% 1/10W				
R426	1-216-065-91	RES,CHIP 4.7K	5% 1/10W				
R427	1-216-041-00	RES,CHIP 470	5% 1/10W				
R428	1-216-041-00	RES,CHIP 470	5% 1/10W				
R429	1-216-041-00	RES,CHIP 470	5% 1/10W				
R430	1-216-041-00	RES,CHIP 470	5% 1/10W				
R431	1-216-679-11	METAL CHIP 15K	0.50% 1/10W				
R432	1-216-691-11	METAL CHIP 47K	0.50% 1/10W				
R433	1-216-687-11	METAL CHIP 33K	0.50% 1/10W				
R435	1-216-691-11	METAL CHIP 47K	0.50% 1/10W				

* A-1346-781-A EBB COMPLETE PC BOARD
(Include EBA, EBC Mounted PC BOARD)

3-701-809-31 SCREW, TERMINAL (M3X8)
* 4-067-812-01 HOLDER (C), TR
4-382-854-11 SCREW (M3X10), P, SW (+)
4-382-854-11 SCREW (M3X10), P, SW (+)

<CAPACITOR>

C300	1-107-921-91	ELECT	100μF	20%	63V
C301	1-107-921-91	ELECT	100μF	20%	63V
C308	1-107-369-11	MYLAR	0.068μF	10%	100V
C309	1-107-369-11	MYLAR	0.068μF	10%	100V
C310	1-107-923-11	ELECT	330μF	20%	63V
C311	1-107-923-11	ELECT	330μF	20%	63V
C312	1-107-914-11	ELECT	1000μF	20%	25V
C313	1-107-914-11	ELECT	1000μF	20%	25V
C314	1-136-481-11	MYLAR	0.0022μF	10%	100V
C315	1-137-150-11	MYLAR	0.01μF	10%	100V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C318	1-163-001-11	CERAMIC CHIP 220PF	10% 50V	D341	8-719-801-78	DIODE 1SS184	
C321	1-107-906-11	ELECT 10μF	20% 50V	D350	8-719-801-78	DIODE 1SS184	
C322	1-107-504-11	CERAMIC 10PF	0.5PF 500V	D351	8-719-801-78	DIODE 1SS184	
C323	1-115-339-11	CERAMIC CHIP 0.1μF	10% 50V	D400	8-719-801-78	DIODE 1SS184	
C340	1-128-526-11	ELECT 100μF	20% 25V	D420	8-719-801-78	DIODE 1SS184	
C341	1-107-906-11	ELECT 10μF	20% 50V	D421	8-719-106-53	DIODE RD10M-B2	
C342	1-128-526-11	ELECT 100μF	20% 25V				
C343	1-107-906-11	ELECT 10μF	20% 50V				
C350	1-128-526-11	ELECT 100μF	20% 25V				
C351	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V				
C352	1-104-653-11	ELECT 220μF	20% 16V				
C353	1-128-526-11	ELECT 100μF	20% 25V				
C354	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V				
C355	1-104-653-11	ELECT 220μF	20% 16V				
C356	1-163-251-11	CERAMIC CHIP 100PF	5% 50V				
C357	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V				
C358	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V				
C359	1-107-909-11	ELECT 47μF	20% 50V				
C360	1-107-909-11	ELECT 47μF	20% 50V				
C361	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V				
C362	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V				
C363	1-136-169-00	FILM 0.22μF	5% 50V				
C400	1-124-242-00	ELECT 33μF	20% 25V				
C420	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C421	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C422	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C500	1-124-242-00	ELECT 33μF	20% 25V				
C501	1-124-242-00	ELECT 33μF	20% 25V				
C502	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C503	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C504	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C505	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V				
C506	1-163-251-11	CERAMIC CHIP 100PF	5% 50V				
C507	1-124-242-00	ELECT 33μF	20% 25V				
C508	1-124-242-00	ELECT 33μF	20% 25V				
C509	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C510	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
C511	1-163-031-11	CERAMIC CHIP 0.01μF	50V				
<CONNECTOR>							
CN160	* 1-564-709-11	PIN, CONNECTOR (SMALL TYPE) 7P					
CN161	* 1-564-713-11	PIN, CONNECTOR (SMALL TYPE) 11P					
CN162	* 1-564-713-11	PIN, CONNECTOR (SMALL TYPE) 11P					
CN163	* 1-785-518-11	CONNECTOR, BOARD TO BOARD 15P					
CN164	* 1-774-249-11	CONNECTOR, BOARD TO BOARD 10P					
CN165	* 1-564-507-11	PLUG, CONNECTOR 4P					
CN168	* 1-785-517-11	CONNECTOR, BOARD TO BOARD 13P					
CN500	* 1-774-246-11	CONNECTOR, BOARD TO BOARD 10P					
<DIODE>							
D300	8-719-106-89	DIODE RD15M-T1B2					
D301	8-719-106-89	DIODE RD15M-T1B2					
D302	8-719-025-10	DIODE D8LC20U					
D303	8-719-025-11	DIODE D8LC20UR					
D304	8-719-106-71	DIODE RD12M-B2					
D305	8-719-801-78	DIODE 1SS184					
D340	8-719-801-78	DIODE 1SS184					
D341	8-719-801-78	DIODE 1SS184					
D350	8-719-801-78	DIODE 1SS184					
D351	8-719-801-78	DIODE 1SS184					
D400	8-719-801-78	DIODE 1SS184					
D420	8-719-801-78	DIODE 1SS184					
D421	8-719-106-53	DIODE RD10M-B2					
<FERRITE BEAD>							
FB300	1-410-396-41	FERRITE 0.45μH					
FB301	1-410-396-41	FERRITE 0.45μH					
FB302	1-410-396-41	FERRITE 0.45μH					
FB303	1-410-396-41	FERRITE 0.45μH					
FB304	1-410-396-41	FERRITE 0.45μH					
FB305	1-410-396-41	FERRITE 0.45μH					
<IC>							
IC350	8-759-231-58	IC TA7812S					
IC351	8-759-701-88	IC NJM7912FA					
IC352	8-759-100-96	IC UPC4558G2					
IC353	8-759-336-63	IC LM675T					
IC400	8-759-988-13	IC LM393PS					
IC420	8-759-105-49	IC UPC319G2					
IC500	8-759-381-53	IC UPC814G2-E2					
IC501	8-759-984-88	IC LM6361M					
<COIL>							
L300	1-406-663-21	INDUCTOR 47μH					
L301	1-406-663-21	INDUCTOR 47μH					
L302	1-412-533-21	INDUCTOR 47μH					
L303	1-412-533-21	INDUCTOR 47μH					
L350	1-410-645-31	INDUCTOR 100μH					
L351	1-410-645-31	INDUCTOR 100μH					
L352	1-412-533-21	INDUCTOR 47μH					
L353	1-412-533-21	INDUCTOR 47μH					
L500	1-410-645-31	INDUCTOR 100μH					
L501	1-410-645-31	INDUCTOR 100μH					
<TRANSISTOR>							
Q302	8-729-142-68	TRANSISTOR 2SJ143					
Q303	8-729-142-69	TRANSISTOR 2SK817					
Q304	8-729-207-89	TRANSISTOR 2SA1358-Y					
Q305	8-729-207-82	TRANSISTOR 2SC3421-Y					
Q306	8-729-021-76	TRANSISTOR 2SA1804-RO					
Q307	8-729-021-75	TRANSISTOR 2SC4689N-RO					
Q340	8-729-216-22	TRANSISTOR 2SA1162-G					
Q341	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q400	1-801-806-11	TRANSISTOR DTC144EKA-T146					
Q420	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q421	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q422	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q423	8-729-033-10	TRANSISTOR 2SC3776-CD-AA					
Q424	8-729-230-49	TRANSISTOR 2SC2712-YG					
Q425	8-729-216-22	TRANSISTOR 2SA1162-G					
Q426	8-729-033-10	TRANSISTOR 2SC3776-CD-AA					
Q427	8-729-230-49	TRANSISTOR 2SC2712-YG					

Ref.No.	Part No.	Description	Remark			Ref.No.	Part No.	Description	Remark		
Q428	8-729-216-22	TRANSISTOR 2SA1162-G				R420	1-216-691-11	METAL CHIP 47K	0.50%	1/10W	
Q500	8-729-216-22	TRANSISTOR 2SA1162-G				R421	1-216-679-11	METAL CHIP 15K	0.50%	1/10W	
Q501	8-729-216-22	TRANSISTOR 2SA1162-G				R422	1-216-691-11	METAL CHIP 47K	0.50%	1/10W	
						R423	1-216-675-11	METAL CHIP 10K	0.50%	1/10W	
Q502	8-729-230-49	TRANSISTOR 2SC2712-YG				R424	1-216-699-11	METAL CHIP 100K	0.50%	1/10W	
Q503	8-729-230-49	TRANSISTOR 2SC2712-YG									
		<RESISTOR>				R425	1-216-049-91	RES,CHIP 1K	5%	1/10W	
						R426	1-216-065-91	RES,CHIP 4.7K	5%	1/10W	
						R427	1-216-041-00	RES,CHIP 470	5%	1/10W	
						R428	1-216-041-00	RES,CHIP 470	5%	1/10W	
						R429	1-216-041-00	RES,CHIP 470	5%	1/10W	
R310	1-216-073-00	RES,CHIP 10K	5%	1/10W							
R311	1-216-073-00	RES,CHIP 10K	5%	1/10W		R430	1-216-041-00	RES,CHIP 470	5%	1/10W	
R312	1-216-005-00	RES,CHIP 15	5%	1/10W		R431	1-216-679-11	METAL CHIP 15K	0.50%	1/10W	
R313	1-216-005-00	RES,CHIP 15	5%	1/10W		R432	1-216-691-11	METAL CHIP 47K	0.50%	1/10W	
R316	1-216-067-00	RES,CHIP 5.6K	5%	1/10W		R433	1-216-687-11	METAL CHIP 33K	0.50%	1/10W	
						R435	1-216-691-11	METAL CHIP 47K	0.50%	1/10W	
R317	1-216-045-00	RES,CHIP 680	5%	1/10W							
R318	1-216-025-91	RES,CHIP 100	5%	1/10W		R436	1-216-017-91	RES,CHIP 47	5%	1/10W	
R319	1-216-647-11	METAL CHIP 680	0.50%	1/10W		R437	1-249-414-11	CARBON 560	5%	1/4W	
R320	1-215-875-11	METAL OXIDE 10K	5%	1W F		R438	1-216-017-91	RES,CHIP 47	5%	1/10W	
R321	1-216-623-11	METAL CHIP 68	0.50%	1/10W		R439	1-216-047-91	RES,CHIP 820	5%	1/10W	
						R440	1-216-017-91	RES,CHIP 47	5%	1/10W	
R322	1-216-627-11	METAL CHIP 100	0.50%	1/10W							
R323	1-249-393-11	CARBON 10	5%	1/4W		R441	1-216-001-00	RES,CHIP 10	5%	1/10W	
R324	1-249-393-11	CARBON 10	5%	1/4W		R442	1-216-001-00	RES,CHIP 10	5%	1/10W	
R325	1-216-345-11	METAL OXIDE 0.47	5%	1W F		R443	1-249-414-11	CARBON 560	5%	1/4W	
R326	1-216-345-11	METAL OXIDE 0.47	5%	1W F		R444	1-216-017-91	RES,CHIP 47	5%	1/10W	
						R445	1-216-017-91	RES,CHIP 47	5%	1/10W	
R327	1-216-480-11	METAL OXIDE 820	5%	3W F							
R328	1-216-371-00	METAL OXIDE 1.5	5%	2W F		R446	1-216-047-91	RES,CHIP 820	5%	1/10W	
R329	1-216-480-11	METAL OXIDE 820	5%	3W F		R447	1-216-017-91	RES,CHIP 47	5%	1/10W	
R330	1-216-371-00	METAL OXIDE 1.5	5%	2W F		R448	1-216-001-00	RES,CHIP 10	5%	1/10W	
R331	1-216-480-11	METAL OXIDE 820	5%	3W F		R449	1-216-001-00	RES,CHIP 10	5%	1/10W	
						R450	1-216-065-91	RES,CHIP 4.7K	5%	1/10W	
R332	1-216-480-11	METAL OXIDE 820	5%	3W F							
R340	1-216-041-00	RES,CHIP 470	5%	1/10W		R451	1-216-065-91	RES,CHIP 4.7K	5%	1/10W	
R341	1-216-367-11	METAL OXIDE 0.68	5%	2W F		R500	1-216-669-11	METAL CHIP 5.6K	0.50%	1/10W	
R342	1-216-073-00	RES,CHIP 10K	5%	1/10W		R501	1-216-677-11	METAL CHIP 12K	0.50%	1/10W	
R343	1-216-081-00	RES,CHIP 22K	5%	1/10W		R502	1-216-653-11	METAL CHIP 1.2K	0.50%	1/10W	
						R503	1-216-651-11	METAL CHIP 1K	0.50%	1/10W	
R344	1-216-041-00	RES,CHIP 470	5%	1/10W							
R345	1-216-073-00	RES,CHIP 10K	5%	1/10W		R504	1-216-671-11	METAL CHIP 6.8K	0.50%	1/10W	
R346	1-216-367-11	METAL OXIDE 0.68	5%	2W F		R505	1-216-665-11	METAL CHIP 3.9K	0.50%	1/10W	
R350	1-216-669-11	METAL CHIP 5.6K	0.50%	1/10W		R506	1-216-675-11	METAL CHIP 10K	0.50%	1/10W	
R351	1-216-645-11	METAL CHIP 560	0.50%	1/10W		R507	1-216-651-11	METAL CHIP 1K	0.50%	1/10W	
						R508	1-216-643-11	METAL CHIP 470	0.50%	1/10W	
R352	1-216-675-11	METAL CHIP 10K	0.50%	1/10W							
R353	1-216-677-11	METAL CHIP 12K	0.50%	1/10W		R509	1-216-651-11	METAL CHIP 1K	0.50%	1/10W	
R354	1-216-675-11	METAL CHIP 10K	0.50%	1/10W		R510	1-216-667-11	METAL CHIP 4.7K	0.50%	1/10W	
R356	1-249-389-11	CARBON 4.7	5%	1/4W F		R511	1-216-673-11	METAL CHIP 8.2K	0.50%	1/10W	
R357	1-249-389-11	CARBON 4.7	5%	1/4W F		R512	1-216-641-11	METAL CHIP 390	0.50%	1/10W	
						R513	1-216-687-11	METAL CHIP 33K	0.50%	1/10W	
R358	1-216-675-11	METAL CHIP 10K	0.50%	1/10W							
R359	1-216-651-11	METAL CHIP 1K	0.50%	1/10W		R514	1-216-651-11	METAL CHIP 1K	0.50%	1/10W	
R360	1-216-651-11	METAL CHIP 1K	0.50%	1/10W		R515	1-216-651-11	METAL CHIP 1K	0.50%	1/10W	
R361	1-216-675-11	METAL CHIP 10K	0.50%	1/10W		R516	1-216-641-11	METAL CHIP 390	0.50%	1/10W	
R362	1-249-389-11	CARBON 4.7	5%	1/4W		R517	1-216-673-11	METAL CHIP 8.2K	0.50%	1/10W	
						R518	1-216-693-11	METAL CHIP 56K	0.50%	1/10W	
R363	1-249-380-11	CARBON 0.82	5%	1/4W F							
R364	1-215-915-11	METAL OXIDE 470	5%	3W F							
R365	1-216-379-11	METAL OXIDE 6.8	5%	2W F							
R400	1-216-073-00	RES,CHIP 10K	5%	1/10W							
R401	1-216-077-00	RES,CHIP 15K	5%	1/10W							
R402	1-216-077-00	RES,CHIP 15K	5%	1/10W							
R403	1-216-085-00	RES,CHIP 33K	5%	1/10W							
R404	1-216-073-00	RES,CHIP 10K	5%	1/10W							
R405	1-216-049-91	RES,CHIP 1K	5%	1/10W							
R406	1-216-025-91	RES,CHIP 100	5%	1/10W							

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
*****				R44	1-216-025-91	RES,CHIP 100 5%	1/10W
* A-1390-887-A L MOUNTED PC BOARD				R45	1-216-025-91	RES,CHIP 100 5%	1/10W
*****				R60	1-216-077-00	RES,CHIP 15K 5%	1/10W
<CAPACITOR>				*****			
C6	1-126-795-11	ELECT 10μF 20% 50V		* A-1390-888-A NA MOUNTED PC BOARD			
C10	1-104-664-11	ELECT 47μF 20% 16V		*****			
<CONNECTOR>				* 4-041-068-01 HOLDER, LED			
CN83	* 1-785-517-11	CONNECTOR, BOARD TO BOARD 13P		<CAPACITOR>			
<DIODE>				C300	1-124-589-11	ELECT 47μF 20% 16V	
D2	8-719-801-78	DIODE 1SS184		C301	1-163-243-11	CERAMIC CHIP 47PF 5% 50V	
<IC>				<CONNECTOR>			
IC1	8-759-100-93	IC UPC393G2		CN460	* 1-564-507-11	PLUG, CONNECTOR 4P	
IC2	8-759-100-93	IC UPC393G2		<DIODE>			
<COIL>				D300	8-719-920-66	DIODE SLR-54VC12	
L2	1-412-533-21	INDUCTOR 47μH		D301	8-719-955-04	DIODE PY5504S-1	
<TRANSISTOR>				<IC>			
Q1	1-801-806-11	TRANSISTOR DTC144EKA-T146		<TRANSISTOR>			
Q2	1-801-806-11	TRANSISTOR DTC144EKA-T146		Q300	8-729-230-49	TRANSISTOR 2SC2712-YG	
<RESISTOR>				<RESISTOR>			
R1	1-216-101-00	RES,CHIP 150K 5% 1/10W		R300	1-216-033-00	RES,CHIP 220 5% 1/10W	
R2	1-216-101-00	RES,CHIP 150K 5% 1/10W		R301	1-216-081-00	RES,CHIP 22K 5% 1/10W	
R3	1-216-099-00	RES,CHIP 120K 5% 1/10W		R302	1-216-025-91	RES,CHIP 100 5% 1/10W	
R4	1-216-073-00	RES,CHIP 10K 5% 1/10W		R303	1-216-025-91	RES,CHIP 100 5% 1/10W	
R5	1-216-073-00	RES,CHIP 10K 5% 1/10W		R304	1-216-073-00	RES,CHIP 10K 5% 1/10W	
R8	1-216-099-00	RES,CHIP 120K 5% 1/10W		*****			
R9	1-216-081-00	RES,CHIP 22K 5% 1/10W		* A-1390-889-A NB MOUNTED PC BOARD			
R10	1-216-083-00	RES,CHIP 27K 5% 1/10W		*****			
R11	1-216-099-00	RES,CHIP 120K 5% 1/10W		* 4-374-987-01 GUIDE, LIGHT			
R13	1-216-073-00	RES,CHIP 10K 5% 1/10W		* 4-381-686-01 BRACKET (B), BAR, OPTICAL			
R15	1-216-083-00	RES,CHIP 27K 5% 1/10W		<CAPACITOR>			
R18	1-216-077-00	RES,CHIP 15K 5% 1/10W		C400	1-163-243-11	CERAMIC CHIP 47PF 5% 50V	
R19	1-216-077-00	RES,CHIP 15K 5% 1/10W		C401	1-124-589-11	ELECT 47μF 20% 16V	
R21	1-216-049-91	RES,CHIP 1K 5% 1/10W		<CONNECTOR>			
R23	1-216-049-91	RES,CHIP 1K 5% 1/10W		CN470	* 1-564-518-11	PLUG, CONNECTOR 3P	
R30	1-216-025-91	RES,CHIP 100 5% 1/10W					
R31	1-216-025-91	RES,CHIP 100 5% 1/10W					
R32	1-216-101-00	RES,CHIP 150K 5% 1/10W					
R33	1-216-097-91	RES,CHIP 100K 5% 1/10W					
R35	1-216-101-00	RES,CHIP 150K 5% 1/10W					
R37	1-216-049-91	RES,CHIP 1K 5% 1/10W					
R38	1-216-097-91	RES,CHIP 100K 5% 1/10W					
R39	1-216-077-00	RES,CHIP 15K 5% 1/10W					
R42	1-216-101-00	RES,CHIP 150K 5% 1/10W					
R43	1-216-049-91	RES,CHIP 1K 5% 1/10W					

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
		<IC>		C194	1-128-393-11	ELECT CHIP 100μF	20% 10V
				C201	1-163-233-11	CERAMIC CHIP 18PF	5% 50V
IC400	8-742-061-10	HYB IC SBX1820-59		C202	1-163-233-11	CERAMIC CHIP 18PF	5% 50V
				C203	1-165-319-11	CERAMIC CHIP 0.1μF	50V
*****				C205	1-163-133-00	CERAMIC CHIP 470PF	5% 50V
		* A-1394-911-A YA COMPLETE PC BOARD		C206	1-165-319-11	CERAMIC CHIP 0.1μF	50V
		(Include YB Mounted PC BOARD)		C207	1-165-319-11	CERAMIC CHIP 0.1μF	50V
		*****		C208	1-165-319-11	CERAMIC CHIP 0.1μF	50V
		* 1-526-660-21 SOCKET, IC (DP) 32P		C209	1-165-319-11	CERAMIC CHIP 0.1μF	50V
		* 1-526-662-21 SOCKET, IC (DP) 40P		C210	1-165-319-11	CERAMIC CHIP 0.1μF	50V
		1-540-151-21 SOCKET, IC		C211	1-165-319-11	CERAMIC CHIP 0.1μF	50V
		* 1-540-212-11 SOCKET (ROTARY SWITCH)		C212	1-165-319-11	CERAMIC CHIP 0.1μF	50V
		* 7-322-065-72 RUBBER, RTV (SE-9168) (130G)		C213	1-165-319-11	CERAMIC CHIP 0.1μF	50V
				C214	1-165-319-11	CERAMIC CHIP 0.1μF	50V
		<CAPACITOR>		C215	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C11	1-163-251-11	CERAMIC CHIP 100PF	5% 50V	C216	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C12	1-163-251-11	CERAMIC CHIP 100PF	5% 50V	C231	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C13	1-163-251-11	CERAMIC CHIP 100PF	5% 50V	C233	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C14	1-163-251-11	CERAMIC CHIP 100PF	5% 50V	C234	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C15	1-163-251-11	CERAMIC CHIP 100PF	5% 50V	C235	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C16	1-163-251-11	CERAMIC CHIP 100PF	5% 50V	C236	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C17	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C237	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C18	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C238	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C19	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C239	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C20	1-163-251-11	CERAMIC CHIP 100PF	5% 50V	C240	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C151	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C241	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C152	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C242	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C153	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C251	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C154	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C252	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C155	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C253	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C156	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C254	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C157	1-163-251-11	CERAMIC CHIP 100PF	5% 50V	C255	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C160	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C256	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C171	1-128-004-11	ELECT CHIP 10μF	20% 16V	C257	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C172	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C258	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C173	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C259	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C174	1-128-393-11	ELECT CHIP 100μF	20% 10V	C260	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C175	1-128-004-11	ELECT CHIP 10μF	20% 16V	C261	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C176	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C262	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C177	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C302	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C178	1-128-393-11	ELECT CHIP 100μF	20% 10V	C303	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C179	1-128-004-11	ELECT CHIP 10μF	20% 16V	C304	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C180	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C305	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C181	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C311	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C182	1-128-393-11	ELECT CHIP 100μF	20% 10V	C313	1-163-231-11	CERAMIC CHIP 15PF	5% 50V
C183	1-128-004-11	ELECT CHIP 10μF	20% 16V	C314	1-163-231-11	CERAMIC CHIP 15PF	5% 50V
C184	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C315	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C185	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C321	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C186	1-128-393-11	ELECT CHIP 100μF	20% 10V	C322	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C187	1-128-004-11	ELECT CHIP 10μF	20% 16V	C323	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C188	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C332	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C189	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C333	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C190	1-128-393-11	ELECT CHIP 100μF	20% 10V	C334	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C191	1-128-004-11	ELECT CHIP 10μF	20% 16V	C421	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C192	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C422	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C193	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C431	1-165-319-11	CERAMIC CHIP 0.1μF	50V
				C432	1-165-319-11	CERAMIC CHIP 0.1μF	50V
				C433	1-165-319-11	CERAMIC CHIP 0.1μF	50V
				C434	1-165-319-11	CERAMIC CHIP 0.1μF	50V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C435	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C579	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C436	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C582	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C441	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C583	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C442	1-163-231-11	CERAMIC CHIP 15PF	5% 50V	C584	1-163-121-00	CERAMIC CHIP 150PF	5% 50V
C443	1-163-231-11	CERAMIC CHIP 15PF	5% 50V	C585	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C444	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C590	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C445	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C591	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C453	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C592	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C454	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C593	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C455	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C595	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C456	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C596	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C457	1-163-231-11	CERAMIC CHIP 15PF	5% 50V	C597	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C458	1-163-231-11	CERAMIC CHIP 15PF	5% 50V	C598	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C459	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C601	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C460	1-128-004-11	ELECT CHIP 10μF	20% 16V	C602	1-126-204-11	ELECT CHIP 47μF	20% 16V
C461	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C603	1-163-249-11	CERAMIC CHIP 82PF	5% 50V
C462	1-163-127-00	CERAMIC CHIP 270PF	5% 50V	C604	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C463	1-163-275-11	CERAMIC CHIP 0.001μF	5% 50V	C605	1-163-020-00	CERAMIC CHIP 0.0082μF	10% 50V
C464	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C606	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C468	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C607	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C501	1-126-204-11	ELECT CHIP 47μF	20% 16V	C608	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C502	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C609	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C503	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C610	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C505	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C611	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C506	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C612	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C507	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C613	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C508	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C614	1-128-013-11	ELECT CHIP 1μF	20% 50V
C509	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C615	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C510	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C701	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C511	1-126-204-11	ELECT CHIP 47μF	20% 16V	C702	1-163-021-91	CERAMIC CHIP 0.01μF	10% 50V
C512	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C703	1-164-005-11	CERAMIC CHIP 0.47μF	25V
C520	1-163-243-11	CERAMIC CHIP 47PF	5% 50V	C704	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C521	1-163-243-11	CERAMIC CHIP 47PF	5% 50V	C705	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C522	1-163-243-11	CERAMIC CHIP 47PF	5% 50V	C706	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C523	1-163-243-11	CERAMIC CHIP 47PF	5% 50V	C731	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C525	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C732	1-126-204-11	ELECT CHIP 47μF	20% 16V
C526	1-163-231-11	CERAMIC CHIP 15PF	5% 50V	C733	1-128-393-11	ELECT CHIP 100μF	20% 10V
C527	1-163-231-11	CERAMIC CHIP 15PF	5% 50V	C734	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C532	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C801	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C533	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C802	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C534	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C803	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C535	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C804	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C541	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C805	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C542	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C806	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C551	1-128-393-11	ELECT CHIP 100μF	20% 10V	C807	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C552	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C808	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C553	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C809	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C554	1-128-393-11	ELECT CHIP 100μF	20% 10V	C810	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C555	1-128-013-11	ELECT CHIP 1μF	20% 50V	C811	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C556	1-163-037-11	CERAMIC CHIP 0.022μF	10% 50V	C812	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C557	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C813	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C558	1-126-204-11	ELECT CHIP 47μF	20% 16V	C814	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C571	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C815	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C573	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C816	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C574	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C817	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C575	1-128-013-11	ELECT CHIP 1μF	20% 50V	C818	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C576	1-128-013-11	ELECT CHIP 1μF	20% 50V	C819	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C577	1-165-319-11	CERAMIC CHIP 0.1μF	50V	C820	1-165-319-11	CERAMIC CHIP 0.1μF	50V
C578	1-126-204-11	ELECT CHIP 47μF	20% 16V				



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C821	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D701	8-719-914-43	DIODE DAN202K	
C822	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D702	8-719-914-42	DIODE DA204K	
C823	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D703	8-719-914-42	DIODE DA204K	
				D704	8-719-914-42	DIODE DA204K	
C824	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D706	8-719-404-50	DIODE MA111-TX	
C825	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D707	8-719-914-43	DIODE DAN202K	
C826	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D708	8-719-914-42	DIODE DA204K	
C827	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D731	8-719-404-50	DIODE MA111-TX	
C828	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D732	8-719-404-50	DIODE MA111-TX	
C829	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D733	8-719-974-51	DIODE SB20-03P	
C830	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D734	8-719-914-43	DIODE DAN202K	
C841	1-128-004-11	ELECT CHIP 10μF	20% 16V	D801	8-719-914-43	DIODE DAN202K	
C842	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D802	8-719-914-43	DIODE DAN202K	
C844	1-128-013-11	ELECT CHIP 1μF	20% 50V	D803	8-719-914-43	DIODE DAN202K	
C846	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D804	8-719-914-43	DIODE DAN202K	
C861	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D805	8-719-914-43	DIODE DAN202K	
C862	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D806	8-719-914-43	DIODE DAN202K	
C863	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D807	8-719-914-43	DIODE DAN202K	
C864	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D808	8-719-914-43	DIODE DAN202K	
C901	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D809	8-719-914-43	DIODE DAN202K	
C903	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D810	8-719-914-43	DIODE DAN202K	
C904	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D811	8-719-914-43	DIODE DAN202K	
C905	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D812	8-719-914-43	DIODE DAN202K	
C921	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D813	8-719-914-43	DIODE DAN202K	
C923	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D814	8-719-914-43	DIODE DAN202K	
C924	1-163-231-11	CERAMIC CHIP 15PF	5% 50V	D815	8-719-914-43	DIODE DAN202K	
C925	1-163-231-11	CERAMIC CHIP 15PF	5% 50V	D842	8-719-404-50	DIODE MA111-TX	
C941	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D941	8-719-404-50	DIODE MA111-TX	
C942	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D942	8-719-404-50	DIODE MA111-TX	
C943	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D943	8-719-404-50	DIODE MA111-TX	
C944	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D944	8-719-404-50	DIODE MA111-TX	
C945	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D961	8-719-914-42	DIODE DA204K	
C946	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D962	8-719-914-42	DIODE DA204K	
C961	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D963	8-719-914-42	DIODE DA204K	
C962	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D964	8-719-914-42	DIODE DA204K	
C983	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D965	8-719-914-42	DIODE DA204K	
C986	1-165-319-11	CERAMIC CHIP 0.1μF	50V	D966	8-719-914-42	DIODE DA204K	
C990	1-126-935-11	ELECT 470μF	20% 6.3V	D967	8-719-914-42	DIODE DA204K	
C991	1-126-935-11	ELECT 470μF	20% 6.3V	D968	8-719-914-42	DIODE DA204K	
<CONNECTOR>				D969	8-719-914-42	DIODE DA204K	
CN410	*1-785-517-11	CONNECTOR, BOARD TO BOARD 13P		D970	8-719-914-42	DIODE DA204K	
CN420	*1-778-891-11	CONNECTOR, BOARD TO BOARD		D971	8-719-914-42	DIODE DA204K	
CN421	*1-778-891-11	CONNECTOR, BOARD TO BOARD		D972	8-719-914-42	DIODE DA204K	
CN902	*1-785-518-11	CONNECTOR, BOARD TO BOARD 15P		D991	8-719-109-89	DIODE RD5.6ESB2	
<DIODE>				D992	8-719-109-89	DIODE RD5.6ESB2	
D13	8-719-105-73	DIODE RD4.7M-B2		ND200	8-719-071-85	DIODE LA-621LMA	
D14	8-719-105-73	DIODE RD4.7M-B2		ND201	8-719-071-85	DIODE LA-621LMA	
D15	8-719-105-73	DIODE RD4.7M-B2		<IC>			
D16	8-719-914-42	DIODE DA204K		IC11	8-759-186-30	IC TC74VHC14F	
D17	8-719-914-42	DIODE DA204K		IC12	8-759-479-84	IC TC74HCT541AF(EL)	
D171	8-719-404-50	DIODE MA111-TX		IC13	8-759-479-84	IC TC74HCT541AF(EL)	
D172	8-719-404-50	DIODE MA111-TX		IC104	8-759-012-02	IC MC10H124M	
D173	8-719-404-50	DIODE MA111-TX		IC105	8-759-186-46	IC TC74VHC132F	
D174	8-719-404-50	DIODE MA111-TX		IC106	8-759-012-02	IC MC10H124M	
D175	8-719-404-50	DIODE MA111-TX		IC107	8-759-186-46	IC TC74VHC132F	
D176	8-719-404-50	DIODE MA111-TX		IC108	8-759-186-30	IC TC74VHC14F	
				IC171	8-759-144-82	IC UPC2405HF	



Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description			Remark
R27	1-216-025-91	RES,CHIP	100	5%	1/10W	R86	1-216-025-91	RES,CHIP	100	5%	1/10W
R28	1-216-073-00	RES,CHIP	10K	5%	1/10W	R87	1-216-049-91	RES,CHIP	1K	5%	1/10W
R29	1-216-073-00	RES,CHIP	10K	5%	1/10W	R88	1-216-025-91	RES,CHIP	100	5%	1/10W
R30	1-216-049-91	RES,CHIP	1K	5%	1/10W	R89	1-216-025-91	RES,CHIP	100	5%	1/10W
						R90	1-216-025-91	RES,CHIP	100	5%	1/10W
R31	1-216-049-91	RES,CHIP	1K	5%	1/10W						
R32	1-216-049-91	RES,CHIP	1K	5%	1/10W	R91	1-216-025-91	RES,CHIP	100	5%	1/10W
R33	1-216-049-91	RES,CHIP	1K	5%	1/10W	R92	1-216-025-91	RES,CHIP	100	5%	1/10W
R34	1-216-049-91	RES,CHIP	1K	5%	1/10W	R93	1-216-025-91	RES,CHIP	100	5%	1/10W
R35	1-216-049-91	RES,CHIP	1K	5%	1/10W	R94	1-216-049-91	RES,CHIP	1K	5%	1/10W
						R95	1-216-049-91	RES,CHIP	1K	5%	1/10W
R36	1-216-049-91	RES,CHIP	1K	5%	1/10W						
R37	1-216-049-91	RES,CHIP	1K	5%	1/10W	R96	1-216-049-91	RES,CHIP	1K	5%	1/10W
R38	1-216-049-91	RES,CHIP	1K	5%	1/10W	R97	1-216-025-91	RES,CHIP	100	5%	1/10W
R39	1-216-049-91	RES,CHIP	1K	5%	1/10W	R98	1-216-025-91	RES,CHIP	100	5%	1/10W
R40	1-216-049-91	RES,CHIP	1K	5%	1/10W	R99	1-216-025-91	RES,CHIP	100	5%	1/10W
						R100	1-216-045-00	RES,CHIP	680	5%	1/10W
R41	1-216-049-91	RES,CHIP	1K	5%	1/10W						
R42	1-216-049-91	RES,CHIP	1K	5%	1/10W	R101	1-216-045-00	RES,CHIP	680	5%	1/10W
R43	1-216-049-91	RES,CHIP	1K	5%	1/10W	R102	1-216-045-00	RES,CHIP	680	5%	1/10W
R44	1-216-049-91	RES,CHIP	1K	5%	1/10W	R103	1-216-045-00	RES,CHIP	680	5%	1/10W
R45	1-216-049-91	RES,CHIP	1K	5%	1/10W	R104	1-216-045-00	RES,CHIP	680	5%	1/10W
						R105	1-216-045-00	RES,CHIP	680	5%	1/10W
R46	1-216-049-91	RES,CHIP	1K	5%	1/10W						
R47	1-216-049-91	RES,CHIP	1K	5%	1/10W	R106	1-216-045-00	RES,CHIP	680	5%	1/10W
R48	1-216-049-91	RES,CHIP	1K	5%	1/10W	R107	1-216-045-00	RES,CHIP	680	5%	1/10W
R49	1-216-049-91	RES,CHIP	1K	5%	1/10W	R108	1-216-047-91	RES,CHIP	820	5%	1/10W
R50	1-216-049-91	RES,CHIP	1K	5%	1/10W	R109	1-216-047-91	RES,CHIP	820	5%	1/10W
						R110	1-216-047-91	RES,CHIP	820	5%	1/10W
R51	1-216-049-91	RES,CHIP	1K	5%	1/10W						
R52	1-216-049-91	RES,CHIP	1K	5%	1/10W	R111	1-216-047-91	RES,CHIP	820	5%	1/10W
R53	1-216-049-91	RES,CHIP	1K	5%	1/10W	R112	1-216-047-91	RES,CHIP	820	5%	1/10W
R54	1-216-049-91	RES,CHIP	1K	5%	1/10W	R113	1-216-047-91	RES,CHIP	820	5%	1/10W
R55	1-216-049-91	RES,CHIP	1K	5%	1/10W	R114	1-216-047-91	RES,CHIP	820	5%	1/10W
						R115	1-216-047-91	RES,CHIP	820	5%	1/10W
R56	1-216-049-91	RES,CHIP	1K	5%	1/10W						
R57	1-216-049-91	RES,CHIP	1K	5%	1/10W	R116	1-216-047-91	RES,CHIP	820	5%	1/10W
R58	1-216-025-91	RES,CHIP	100	5%	1/10W	R117	1-216-047-91	RES,CHIP	820	5%	1/10W
R59	1-216-025-91	RES,CHIP	100	5%	1/10W	R118	1-216-047-91	RES,CHIP	820	5%	1/10W
R60	1-216-001-00	RES,CHIP	10	5%	1/10W	R119	1-216-047-91	RES,CHIP	820	5%	1/10W
						R120	1-216-047-91	RES,CHIP	820	5%	1/10W
R61	1-216-001-00	RES,CHIP	10	5%	1/10W						
R62	1-216-001-00	RES,CHIP	10	5%	1/10W	R121	1-216-049-91	RES,CHIP	1K	5%	1/10W
R63	1-216-001-00	RES,CHIP	10	5%	1/10W	R122	1-216-049-91	RES,CHIP	1K	5%	1/10W
R64	1-216-001-00	RES,CHIP	10	5%	1/10W	R151	1-216-001-00	RES,CHIP	10	5%	1/10W
R65	1-216-001-00	RES,CHIP	10	5%	1/10W	R152	1-216-025-91	RES,CHIP	100	5%	1/10W
						R153	1-216-025-91	RES,CHIP	100	5%	1/10W
R66	1-216-001-00	RES,CHIP	10	5%	1/10W						
R67	1-216-001-00	RES,CHIP	10	5%	1/10W	R154	1-216-001-00	RES,CHIP	10	5%	1/10W
R68	1-216-025-91	RES,CHIP	100	5%	1/10W	R155	1-216-001-00	RES,CHIP	10	5%	1/10W
R69	1-216-025-91	RES,CHIP	100	5%	1/10W	R156	1-216-025-91	RES,CHIP	100	5%	1/10W
R70	1-216-025-91	RES,CHIP	100	5%	1/10W	R157	1-216-025-91	RES,CHIP	100	5%	1/10W
						R158	1-216-001-00	RES,CHIP	10	5%	1/10W
R71	1-216-025-91	RES,CHIP	100	5%	1/10W						
R72	1-216-025-91	RES,CHIP	100	5%	1/10W	R159	1-216-001-00	RES,CHIP	10	5%	1/10W
R73	1-216-025-91	RES,CHIP	100	5%	1/10W	R160	1-216-001-00	RES,CHIP	10	5%	1/10W
R74	1-216-025-91	RES,CHIP	100	5%	1/10W	R161	1-216-001-00	RES,CHIP	10	5%	1/10W
R75	1-216-025-91	RES,CHIP	100	5%	1/10W	R162	1-216-001-00	RES,CHIP	10	5%	1/10W
						R163	1-216-001-00	RES,CHIP	10	5%	1/10W
R76	1-216-025-91	RES,CHIP	100	5%	1/10W						
R77	1-216-025-91	RES,CHIP	100	5%	1/10W	R171	1-216-295-91	SHORT 0			
R78	1-216-025-91	RES,CHIP	100	5%	1/10W	R172	1-216-295-91	SHORT 0			
R79	1-216-025-91	RES,CHIP	100	5%	1/10W	R173	1-216-295-91	SHORT 0			
R80	1-216-025-91	RES,CHIP	100	5%	1/10W	R174	1-216-295-91	SHORT 0			
						R175	1-216-295-91	SHORT 0			
R81	1-216-025-91	RES,CHIP	100	5%	1/10W						
R82	1-216-025-91	RES,CHIP	100	5%	1/10W	R176	1-216-295-91	SHORT 0			
R83	1-216-025-91	RES,CHIP	100	5%	1/10W	R177	1-216-041-00	RES,CHIP			
R84	1-216-025-91	RES,CHIP	100	5%	1/10W	R200	1-216-049-91	RES,CHIP	470	5%	1/10W
R85	1-216-025-91	RES,CHIP	100	5%	1/10W	R201	1-216-031-00	RES,CHIP	1K	5%	1/10W
									180	5%	1/10W


Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description			Remark
R201	1-216-049-91	RES,CHIP	1K	5%	1/10W	R406	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R202	1-216-025-91	RES,CHIP	100	5%	1/10W	R407	1-216-073-00	RES,CHIP	10K	5%	1/10W
R202	1-216-049-91	RES,CHIP	1K	5%	1/10W	R408	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R203	1-216-001-00	RES,CHIP	10	5%	1/10W	R409	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R203	1-216-049-91	RES,CHIP	1K	5%	1/10W	R410	1-216-073-00	RES,CHIP	10K	5%	1/10W
R204	1-216-025-91	RES,CHIP	100	5%	1/10W	R411	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R204	1-216-059-00	RES,CHIP	2.7K	5%	1/10W	R412	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R205	1-216-025-91	RES,CHIP	100	5%	1/10W	R413	1-216-073-00	RES,CHIP	10K	5%	1/10W
R205	1-216-031-00	RES,CHIP	180	5%	1/10W	R414	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R206	1-216-025-91	RES,CHIP	100	5%	1/10W	R415	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R206	1-216-073-00	RES,CHIP	10K	5%	1/10W	R416	1-216-073-00	RES,CHIP	10K	5%	1/10W
R207	1-216-025-91	RES,CHIP	100	5%	1/10W	R417	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R207	1-216-073-00	RES,CHIP	10K	5%	1/10W	R418	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R208	1-216-025-91	RES,CHIP	100	5%	1/10W	R419	1-216-073-00	RES,CHIP	10K	5%	1/10W
R208	1-216-073-00	RES,CHIP	10K	5%	1/10W	R420	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R209	1-216-025-91	RES,CHIP	100	5%	1/10W	R424	1-216-295-91	SHORT 0			
R209	1-216-073-00	RES,CHIP	10K	5%	1/10W	R431	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R210	1-216-025-91	RES,CHIP	100	5%	1/10W	R432	1-216-055-00	RES,CHIP	1.8K	5%	1/10W
R210	1-216-073-00	RES,CHIP	10K	5%	1/10W	R433	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R211	1-216-025-91	RES,CHIP	100	5%	1/10W	R434	1-216-031-00	RES,CHIP	180	5%	1/10W
R211	1-216-073-00	RES,CHIP	10K	5%	1/10W	R435	1-216-031-00	RES,CHIP	180	5%	1/10W
R212	1-216-073-00	RES,CHIP	10K	5%	1/10W	R436	1-216-031-00	RES,CHIP	180	5%	1/10W
R213	1-216-073-00	RES,CHIP	10K	5%	1/10W	R442	1-216-121-91	RES,CHIP	1M	5%	1/10W
R214	1-216-073-00	RES,CHIP	10K	5%	1/10W	R443	1-216-025-91	RES,CHIP	100	5%	1/10W
R215	1-216-073-00	RES,CHIP	10K	5%	1/10W	R452	1-216-025-91	RES,CHIP	100	5%	1/10W
R216	1-216-073-00	RES,CHIP	10K	5%	1/10W	R453	1-216-017-91	RES,CHIP	47	5%	1/10W
R217	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R454	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
R218	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R455	1-216-121-91	RES,CHIP	1M	5%	1/10W
R219	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R456	1-216-025-91	RES,CHIP	100	5%	1/10W
R220	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R457	1-216-073-00	RES,CHIP	10K	5%	1/10W
R221	1-216-073-00	RES,CHIP	10K	5%	1/10W	R458	1-216-295-91	SHORT 0			
R222	1-216-073-00	RES,CHIP	10K	5%	1/10W	R459	1-216-295-91	SHORT 0			
R223	1-216-073-00	RES,CHIP	10K	5%	1/10W	R460	1-216-073-00	RES,CHIP	10K	5%	1/10W
R224	1-216-073-00	RES,CHIP	10K	5%	1/10W	R461	1-216-295-91	SHORT 0			
R225	1-216-073-00	RES,CHIP	10K	5%	1/10W	R462	1-216-295-91	SHORT 0			
R226	1-216-073-00	RES,CHIP	10K	5%	1/10W	R463	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
R227	1-216-073-00	RES,CHIP	10K	5%	1/10W	R464	1-216-073-00	RES,CHIP	10K	5%	1/10W
R228	1-216-073-00	RES,CHIP	10K	5%	1/10W	R466	1-216-295-91	SHORT 0			
R231	1-216-025-91	RES,CHIP	100	5%	1/10W	R502	1-216-295-91	SHORT 0			
R236	1-216-073-00	RES,CHIP	10K	5%	1/10W	R503	1-216-295-91	SHORT 0			
R237	1-216-073-00	RES,CHIP	10K	5%	1/10W	R504	1-216-295-91	SHORT 0			
R241	1-216-073-00	RES,CHIP	10K	5%	1/10W	R505	1-216-025-91	RES,CHIP	100	5%	1/10W
R242	1-216-073-00	RES,CHIP	10K	5%	1/10W	R506	1-216-001-00	RES,CHIP	10	5%	1/10W
R243	1-216-073-00	RES,CHIP	10K	5%	1/10W	R507	1-216-001-00	RES,CHIP	10	5%	1/10W
R244	1-216-073-00	RES,CHIP	10K	5%	1/10W	R508	1-216-001-00	RES,CHIP	10	5%	1/10W
R245	1-216-073-00	RES,CHIP	10K	5%	1/10W	R509	1-216-001-00	RES,CHIP	10	5%	1/10W
R246	1-216-073-00	RES,CHIP	10K	5%	1/10W	R510	1-216-025-91	RES,CHIP	100	5%	1/10W
R247	1-216-073-00	RES,CHIP	10K	5%	1/10W	R511	1-216-025-91	RES,CHIP	100	5%	1/10W
R248	1-216-073-00	RES,CHIP	10K	5%	1/10W	R512	1-216-295-91	SHORT 0			
R301	1-216-025-91	RES,CHIP	100	5%	1/10W	R513	1-216-033-00	RES,CHIP	220	5%	1/10W
R303	1-216-073-00	RES,CHIP	10K	5%	1/10W	R514	1-216-073-00	RES,CHIP	10K	5%	1/10W
R305	1-216-073-00	RES,CHIP	10K	5%	1/10W	R515	1-216-073-00	RES,CHIP	10K	5%	1/10W
R315	1-216-025-91	RES,CHIP	100	5%	1/10W	R516	1-216-073-00	RES,CHIP	10K	5%	1/10W
R321	1-216-073-00	RES,CHIP	10K	5%	1/10W	R517	1-216-073-00	RES,CHIP	10K	5%	1/10W
R322	1-216-097-91	RES,CHIP	100K	5%	1/10W	R518	1-216-073-00	RES,CHIP	10K	5%	1/10W
R403	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R519	1-216-073-00	RES,CHIP	10K	5%	1/10W
R404	1-216-073-00	RES,CHIP	10K	5%	1/10W	R520	1-216-073-00	RES,CHIP	10K	5%	1/10W
R405	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	R521	1-216-073-00	RES,CHIP	10K	5%	1/10W





Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R522	1-216-295-91	SHORT 0		R731	1-216-667-11	METAL CHIP 4.7K	0.50% 1/10W
R525	1-216-097-91	RES,CHIP 100K	5% 1/10W	R732	1-216-655-11	METAL CHIP 1.5K	0.50% 1/10W
R526	1-216-001-00	RES,CHIP 10	5% 1/10W	R733	1-216-426-11	METAL OXIDE 82	5% 1W F
R527	1-216-001-00	RES,CHIP 10	5% 1/10W	R734	1-216-049-91	RES,CHIP 1K	5% 1/10W
R531	1-216-025-91	RES,CHIP 100	5% 1/10W	R735	1-216-073-00	RES,CHIP 10K	5% 1/10W
R532	1-216-073-00	RES,CHIP 10K	5% 1/10W	R736	1-216-073-00	RES,CHIP 10K	5% 1/10W
R533	1-216-049-91	RES,CHIP 1K	5% 1/10W	R737	1-216-079-00	RES,CHIP 18K	5% 1/10W
R541	1-216-073-00	RES,CHIP 10K	5% 1/10W	R738	1-216-085-00	RES,CHIP 33K	5% 1/10W
R542	1-216-073-00	RES,CHIP 10K	5% 1/10W	R739	1-216-081-00	RES,CHIP 22K	5% 1/10W
R543	1-216-073-00	RES,CHIP 10K	5% 1/10W	R740	1-216-073-00	RES,CHIP 10K	5% 1/10W
R551	1-216-073-00	RES,CHIP 10K	5% 1/10W	R741	1-216-089-91	RES,CHIP 47K	5% 1/10W
R552	1-216-073-00	RES,CHIP 10K	5% 1/10W	R841	1-216-073-00	RES,CHIP 10K	5% 1/10W
R553	1-216-025-91	RES,CHIP 100	5% 1/10W	R842	1-216-089-91	RES,CHIP 47K	5% 1/10W
R554	1-216-025-91	RES,CHIP 100	5% 1/10W	R843	1-216-073-00	RES,CHIP 10K	5% 1/10W
R555	1-216-025-91	RES,CHIP 100	5% 1/10W	R844	1-216-295-91	SHORT 0	
R556	1-216-073-00	RES,CHIP 10K	5% 1/10W	R845	1-216-295-91	SHORT 0	
R557	1-216-045-00	RES,CHIP 680	5% 1/10W	R846	1-216-097-91	RES,CHIP 100K	5% 1/10W
R558	1-216-073-00	RES,CHIP 10K	5% 1/10W	R847	1-216-073-00	RES,CHIP 10K	5% 1/10W
R561	1-216-057-00	RES,CHIP 2.2K	5% 1/10W	R848	1-216-073-00	RES,CHIP 10K	5% 1/10W
R562	1-216-295-91	SHORT 0		R849	1-216-049-91	RES,CHIP 1K	5% 1/10W
R571	1-216-001-00	RES,CHIP 10	5% 1/10W	R850	1-216-049-91	RES,CHIP 1K	5% 1/10W
R576	1-216-073-00	RES,CHIP 10K	5% 1/10W	R851	1-216-089-91	RES,CHIP 47K	5% 1/10W
R583	1-216-025-91	RES,CHIP 100	5% 1/10W	R852	1-216-097-91	RES,CHIP 100K	5% 1/10W
R585	1-216-049-91	RES,CHIP 1K	5% 1/10W	R853	1-216-073-00	RES,CHIP 10K	5% 1/10W
R586	1-216-025-91	RES,CHIP 100	5% 1/10W	R854	1-216-073-00	RES,CHIP 10K	5% 1/10W
R587	1-216-025-91	RES,CHIP 100	5% 1/10W	R855	1-216-073-00	RES,CHIP 10K	5% 1/10W
R588	1-216-049-91	RES,CHIP 1K	5% 1/10W	R856	1-216-073-00	RES,CHIP 10K	5% 1/10W
R589	1-216-073-00	RES,CHIP 10K	5% 1/10W	R857	1-216-073-00	RES,CHIP 10K	5% 1/10W
R601	1-216-001-00	RES,CHIP 10	5% 1/10W	R858	1-216-085-00	RES,CHIP 33K	5% 1/10W
R602	1-216-049-91	RES,CHIP 1K	5% 1/10W	R859	1-216-073-00	RES,CHIP 10K	5% 1/10W
R603	1-216-001-00	RES,CHIP 10	5% 1/10W	R860	1-216-073-00	RES,CHIP 10K	5% 1/10W
R604	1-216-695-11	METAL CHIP 68K	0.50% 1/10W	R861	1-216-025-91	RES,CHIP 100	5% 1/10W
R606	1-216-644-11	METAL CHIP 510	0.50% 1/10W	R862	1-216-065-91	RES,CHIP 4.7K	5% 1/10W
R607	1-216-001-00	RES,CHIP 10	5% 1/10W	R863	1-216-073-00	RES,CHIP 10K	5% 1/10W
R608	1-216-001-00	RES,CHIP 10	5% 1/10W	R864	1-216-073-00	RES,CHIP 10K	5% 1/10W
R609	1-216-023-00	RES,CHIP 82	5% 1/10W	R921	1-216-073-00	RES,CHIP 10K	5% 1/10W
R610	1-216-057-00	RES,CHIP 2.2K	5% 1/10W	R922	1-216-073-00	RES,CHIP 10K	5% 1/10W
R611	1-216-023-00	RES,CHIP 82	5% 1/10W	R923	1-216-073-00	RES,CHIP 10K	5% 1/10W
R612	1-216-057-00	RES,CHIP 2.2K	5% 1/10W	R924	1-216-073-00	RES,CHIP 10K	5% 1/10W
R613	1-216-298-00	RES,CHIP 2.2	5% 1/10W	R925	1-216-073-00	RES,CHIP 10K	5% 1/10W
R614	1-216-001-00	RES,CHIP 10	5% 1/10W	R926	1-216-073-00	RES,CHIP 10K	5% 1/10W
R615	1-216-295-91	SHORT 0		R927	1-216-073-00	RES,CHIP 10K	5% 1/10W
R701	1-216-073-00	RES,CHIP 10K	5% 1/10W	R929	1-216-121-91	RES,CHIP 1M	5% 1/10W
R702	1-216-025-91	RES,CHIP 100	5% 1/10W	R930	1-216-025-91	RES,CHIP 100	5% 1/10W
R703	1-216-073-00	RES,CHIP 10K	5% 1/10W	R961	1-216-295-91	SHORT 0	
R704	1-216-025-91	RES,CHIP 100	5% 1/10W	R962	1-216-295-91	SHORT 0	
R705	1-216-073-00	RES,CHIP 10K	5% 1/10W	R963	1-216-295-91	SHORT 0	
R706	1-216-073-00	RES,CHIP 10K	5% 1/10W	R964	1-216-295-91	SHORT 0	
R707	1-216-025-91	RES,CHIP 100	5% 1/10W	R965	1-216-049-91	RES,CHIP 1K	5% 1/10W
R708	1-216-073-00	RES,CHIP 10K	5% 1/10W	R966	1-216-295-91	SHORT 0	
R709	1-216-107-00	RES,CHIP 270K	5% 1/10W	R967	1-216-295-91	SHORT 0	
R710	1-216-097-91	RES,CHIP 100K	5% 1/10W	R968	1-216-295-91	SHORT 0	
R714	1-216-057-00	RES,CHIP 2.2K	5% 1/10W	R969	1-216-295-91	SHORT 0	
R715	1-216-057-00	RES,CHIP 2.2K	5% 1/10W	R970	1-216-295-91	SHORT 0	
R716	1-216-057-00	RES,CHIP 2.2K	5% 1/10W	R971	1-216-295-91	SHORT 0	
R717	1-216-037-00	RES,CHIP 330	5% 1/10W	R972	1-216-025-91	RES,CHIP 100	5% 1/10W
R718	1-216-073-00	RES,CHIP 10K	5% 1/10W	R973	1-216-025-91	RES,CHIP 100	5% 1/10W
R719	1-216-049-91	RES,CHIP 1K	5% 1/10W	R974	1-216-295-91	SHORT 0	
R720	1-216-073-00	RES,CHIP 10K	5% 1/10W				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R975	1-216-295-91	SHORT 0		S962	1-572-853-11	SWITCH, ROTARY	
R991	1-247-839-31	CARBON	2.2K 5% 1/4W	S963	1-572-853-11	SWITCH, ROTARY	
R992	1-247-839-31	CARBON	2.2K 5% 1/4W				
	<RESISTOR BLOCK>				<TERMINAL BOARD>		
RB11	1-233-576-11	RES, CHIP	NETWORK 100	TB701	1-694-480-11	TERMINAL BOARD ASSY, I/O	
RB13	1-233-576-11	RES, CHIP	NETWORK 100	TB961	1-694-479-11	TERMINAL BOARD ASSY, I/O	
RB14	1-233-576-11	RES, CHIP	NETWORK 100				
RB15	1-233-576-11	RES, CHIP	NETWORK 100		<TEST PIN>		
RB16	1-233-576-11	RES, CHIP	NETWORK 100	TP11	1-535-757-11	CHIP, CHECKER	
RB201	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP40	1-535-757-11	CHIP, CHECKER	
RB202	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP43	1-535-757-11	CHIP, CHECKER	
RB203	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP44	1-535-757-11	CHIP, CHECKER	
RB204	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP45	1-535-757-11	CHIP, CHECKER	
RB205	1-236-908-11	RES, CHIP	NETWORK 10K (3216)				
RB206	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP151	1-535-757-11	CHIP, CHECKER	
RB207	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP152	1-535-757-11	CHIP, CHECKER	
RB301	1-233-576-11	RES, CHIP	NETWORK 100	TP153	1-535-757-11	CHIP, CHECKER	
RB302	1-233-576-11	RES, CHIP	NETWORK 100	TP154	1-535-757-11	CHIP, CHECKER	
RB303	1-233-576-11	RES, CHIP	NETWORK 100	TP201	1-535-757-11	CHIP, CHECKER	
RB451	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP202	1-535-757-11	CHIP, CHECKER	
RB452	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP203	1-535-757-11	CHIP, CHECKER	
RB453	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP204	1-535-757-11	CHIP, CHECKER	
RB501	1-233-412-11	RES, CHIP	NETWORK 1.0K (3216)	TP205	1-535-757-11	CHIP, CHECKER	
RB531	1-233-576-11	RES, CHIP	NETWORK 100	TP231	1-535-757-11	CHIP, CHECKER	
RB532	1-233-576-11	RES, CHIP	NETWORK 100	TP251	1-535-757-11	CHIP, CHECKER	
RB551	1-233-574-11	RES, CHIP	NETWORK 10	TP252	1-535-757-11	CHIP, CHECKER	
RB552	1-233-574-11	RES, CHIP	NETWORK 10	TP301	1-535-757-11	CHIP, CHECKER	
RB571	1-233-574-11	RES, CHIP	NETWORK 10	TP311	1-535-757-11	CHIP, CHECKER	
RB701	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP312	1-535-757-11	CHIP, CHECKER	
RB861	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP321	1-535-757-11	CHIP, CHECKER	
RB862	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP401	1-535-757-11	CHIP, CHECKER	
RB863	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP402	1-535-757-11	CHIP, CHECKER	
RB864	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP424	1-535-757-11	CHIP, CHECKER	
RB865	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP425	1-535-757-11	CHIP, CHECKER	
RB866	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP428	1-535-757-11	CHIP, CHECKER	
RB867	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP429	1-535-757-11	CHIP, CHECKER	
RB868	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP431	1-535-757-11	CHIP, CHECKER	
RB961	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP432	1-535-757-11	CHIP, CHECKER	
RB962	1-236-908-11	RES, CHIP	NETWORK 10K (3216)	TP441	1-535-757-11	CHIP, CHECKER	
RB963	1-233-576-11	RES, CHIP	NETWORK 100	TP442	1-535-757-11	CHIP, CHECKER	
RB964	1-233-576-11	RES, CHIP	NETWORK 100	TP443	1-535-757-11	CHIP, CHECKER	
	<RELAY>			TP451	1-535-757-11	CHIP, CHECKER	
RY941	1-515-716-11	RELAY (TQ2-5V)		TP452	1-535-757-11	CHIP, CHECKER	
RY942	1-515-716-11	RELAY (TQ2-5V)		TP453	1-535-757-11	CHIP, CHECKER	
RY943	1-515-716-11	RELAY (TQ2-5V)		TP454	1-535-757-11	CHIP, CHECKER	
RY944	1-515-716-11	RELAY (TQ2-5V)		TP455	1-535-757-11	CHIP, CHECKER	
	<SWITCH>			TP456	1-535-757-11	CHIP, CHECKER	
S201	1-570-598-11	SWITCH, DIP		TP457	1-535-757-11	CHIP, CHECKER	
S202	1-570-204-21	SWITCH, KEY BOARD		TP458	1-535-757-11	CHIP, CHECKER	
S203	1-570-204-21	SWITCH, KEY BOARD		TP459	1-535-757-11	CHIP, CHECKER	
S204	1-692-271-21	SWITCH, SLIDE		TP460	1-535-757-11	CHIP, CHECKER	
S205	1-692-271-21	SWITCH, SLIDE		TP461	1-535-757-11	CHIP, CHECKER	
S961	1-571-658-11	SWITCH, SLIDE		TP501	1-535-757-11	CHIP, CHECKER	
				TP531	1-535-757-11	CHIP, CHECKER	
				TP551	1-535-757-11	CHIP, CHECKER	
				TP552	1-535-757-11	CHIP, CHECKER	
				TP553	1-535-757-11	CHIP, CHECKER	
				TP554	1-535-757-11	CHIP, CHECKER	


SECTION 9
BLOCK DIAGRAMS
























YA (3/4), YB **YA (3/4), YB**



























DF **DF**










EBH, EBQ





EBB, EBG, EBR EBB, EBG, EBR











SECTION 10
DIAGRAMS

10-1. FRAME SCHEMATIC DIAGRAMS

FRAME (1/11) WIRING


1

2


3

4

5



FRAME (2/11) WIRING



FRAME (3/11) WIRING


1

2

3

4

5



1



1

2


3

4

5



FRAME (6/11) WIRING



5

M (1/2)

FRAME (9/11) WIRING

1

2

3

4

5

TO M BOARD CN500	
CN500 96P	
GND	C33
GND	B33
GND	A33
SIRCS-RC	C31
RCON	B31
GND	A31
GND	C30
SIRCS NB	B30
GND	A30
GND	C29
GND	B29
SIRCS NA	A29
GND	C28
GND	B28
GND	A28
HV PROT (OUT)	C27
LOT PROT	B27
IK	A27
GND	C26
CLAMP P	B26
GND	A26
SUB PROT	C25
CRT PROT R	B25
CRT PROT G	A25
CRT PROT B	C24
DA PROT	B24
DB PROT	A24
DD PROT	C23
DE PROT	B23
H STOP	A23
V STOP	C22
EBR PROT	B22
EBB PROT	A22
P1 PROT	C21
P2 PROT	B21
P3 PROT	A21
P4 PROT	C20
FAN PROT	B20
POLA PROT	A20
EBG PROT	C19
EBH PROT	B19
FAN2 PROT	A19
GND	C18
P CONT	B18
P CONT	A18
GND	C17
GND	B17
GND	A17
HD	C16
GND	B16
VD	A16
HS	C15
GND	B15
VS	A15
GND	C14
GND	B14
GND	A14
GND	C13
ABL	B13
F-V	A13
GND	C12
GND	B12
SUB+6V	A12
SUB+6V	C11
SUB+6V	B11
SUB+6V	A11
SUB+6V	C10
SUB+6V	B10
SUB+6V	A10
+6V	C9
+6V	B9
+6V	A9
+6V	C8
+6V	B8
+6V	A8
GND	C7
GND	B7
GND	A7
GND	C6
GND	B6
GND	A6
-6V	C5
-6V	B5
-6V	A5
GND	C4
GND	B4
-15V	A4
-15V	C3
-15V	B3
-15V	A3
-15V	C2
-15V	B2
-15V	A2
GND	C1
GND	B1
GND	A1

TO M BOARD CN501	
CN501 96P	
+15V	C32
+15V	B32
+15V	A32
+15V	C31
+15V	B31
+15V	A31
GND	C30
GND	B30
GND	A30
GND	C29
GND	B29
GND	A29
GND	C28
GND	B28
GND	A28
GND	C27
GND	B27
GND	A27
CLAMP P	C26
GND	B26
BLKG P	A26
GND	C25
GND	B25
GND	A25
ABL IK-R	C24
ABL IK-G	B24
ABL IK-B	A24
ABG-R	C23
ABG-G	B23
ABG-B	A23
LIMIT-R	C22
LIMIT-G	B22
LIMIT-B	A22
DRV-R	C21
DRV-G	B21
DRV-B	A21
BKG-R	C20
BKG-G	B20
BKG-B	A20
ON/OFF-R	C19
ON/OFF-G	B19
ON/OFF-B	A19
ABG ON/OFF	C18
GND	B18
GND	A18
GND	C17
GND	B17
GND	A17
B MOD	C16
G MOD	B16
R MOD	A16
GND	C15
GND	B15
VS	A15
GND	C14
GND	B14
GND	A14
GND	C13
M1	B13
D-RESET	A13
D-SCL	C12
H-SYNC	B12
D-LD0	A12
D-SDA0	C11
M3	B11
D-LD1	A11
D-SDA1	C10
M4	B10
D-LD2	A10
D-SDA2	C9
M5	B9
D-LD3	A9
ABG-G	C8
ABG-B	B8
ABG-R	A8
ON/OFF-R	C7
ON/OFF-G	B7
ON/OFF-B	A7
RGB/VIDEO	C6
BOARD1 B	B6
BOARD1 C	A6
RT CONT	C5
AFC CONT	B5
D-VIDEO/RGB	A5
GND	C4
GND	B4
GND	A4
GND	C3
GND	B3
GND	A3
G2 CONT-R	C2
G2 CONT-G	B2
G2 CONT-B	A2
GND	C1
GND	B1
GND	A1

TO YA BOARD CN420	
CN420 96P	
GND	A1
GND	B1
GND	C1
SIRCS RC	A2
RCON	B2
GND	C2
SIRCS NB	B3
GND	A3
SIRCS CCO	A4
SIRCS NA	C4
GND	B5
GND	C5
GND	A6
LINK	A7
GND	B7
GND	C7
GND	A8
GND	B8
GND	C8
HV PROT	A9
LOT PROT	B9
SIGMA IK	C9
LENS PROT	A10
SUB PROT	B10
CRT PROT R	A11
CRT PROT G	B11
CRT PROT B	C11
DA PROT	A12
DB PROT	B12
DD PROT	C12
DE PROT	A13
H STOP	B13
V STOP	C13
EBR PROT	A14
EBB PROT	B14
P1 PROT	C14
P2 PROT	A15
P3 PROT	B15
P4 PROT	C15
FAN PROT	A16
POLA PROT	B16
EBG PROT	C16
EBH PROT	A17
FAN2 PROT	B17
GND	C17
IFB-B PROT	A18
IFB-C PROT	B18
EBH PROT	C18
EBG PROT	A19
P CONT	B19
GND	C19
GND	B20
GND	A20
H SYNC (RI) 2	C20
H-SYNC	B21
V-SYNC	A21
S ON G	C22
H-SYNC (RI)	B23
V-SYNC (RI)	A23
S ON G (RI)	C24
HD	B25
VD	A25
VS	C26
GND	B27
GND	A27
BLKG P	C28
SCP	B28
CLAMP P	A28
GND	C29
GND	B29
GND	A29
LIN SW	C30
SUB+6V	B30
SUB+6V	A30
-6V	C31
-6V	B31
-6V	A31
G2 CONT-R	C32
G2 CONT-G	B32
G2 CONT-B	A32
GND	C33
GND	B33
GND	A33

TO YA BOARD CN421	
CN421 96P	
GND	A1
GND	B1
GND	C1
+15V	A2
TEST IRE	C2
OSD-R	B3
OSD-R	C3
OSD-G	A4
OSD-G	C4
OSD-B	B5
OSD-B	C5
OSD-V	A6
OSD-V	C6
OSD-BRT	B7
OSD-BRT	C7
GND	A8
GND	B8
GND	C8
12C-SDA1	B9
12C-SCL1	C9
12C-SDA2	A10
12C-SCL2	C10
GND	B11
GND	C11
GND	A12
D-RESET	B12
D-SCL	C12
M2	A13
D-LD0	B13
D-SDA0	C13
M3	A14
D-LD1	B14
D-SDA1	C14
M4	A15
D-LD2	B15
D-SDA2	C15
M5	A16
D-LD3	B16
GND	C16
GND	A17
GND	B17
GND	C17
12C-SDA1	A18
12C-SCL1	B17
12C-SDA2	A18
12C-SCL2	B18
GND	C18
GND	A19
GND	B19
GND	C19
ABL IK-R	A20
ABL IK-G	B20
ABL IK-B	C20
GND	A21
GND	B21
GND	C21
LIN SW	A22
GND	B22
GND	C22
G2CONT-R	A23
G2CONT-G	B23
G2CONT-B	C23
ABG-R	A24
ABG-G	B24
ABG-B	C24
ON/OFF-R	A25
ON/OFF-G	B25
ON/OFF-B	C25
F-V	A26
ABL	B26
C PROT CONT	C26
GND	A27
GND	B27
GND	C27
CLAMP P	A28
SCP	B28
BLKG P	C28
1K PROT	A29
IN/OUT	B29
SEL B	C29
SUB+6V	A30
SUB+6V	B30
SUB+6V	C30
-6V	A31
-6V	B31
-6V	C31
IFB-SDA	B31
IFB-SCL	C31
GND	A32
GND	B32
GND	C32
GND	A33
GND	B33
GND	C33

TO BA BOARD CN340	
CN340 96P	
GND	A1
GND	B1
GND	C1
GND	A2
GND	B2
GND	C2
+15V	A3
+15V	B3
+15V	C3
R MOD	A4
G MOD	B4
B MOD	C4
GND	A5
GND	B5
GND	C5
TEST IRE	A6
HS-IFB	B6
VD	C6
OSD-R	A7
OSD-R	B7
OSD-G	C7
OSD-G	A8
OSD-B	B8
OSD-B	C8
OSD-B	A9
OSD-B	B9
OSD-V	A10
OSD-V	B10
OSD-BRT	C10
OSD-BRT	A11
GND	B11
GND	C11
GND	A12
GND	B12
GND	C12
D-SCL	A13
D-RESET	B13
GND	C13
D-SDA0	A14
D-LD0	B14
H-SYNC (RI)	C14
H-SYNC (RI)	A15
S ON G (RI)	B15
GND	C15
GND	A16
GND	B16
GND	C16
12C-SDA1	A17
12C-SCL1	B17
12C-SDA2	A18
12C-SCL2	B18
GND	C18
GND	A19
GND	B19
GND	C19
ABL IK-R	A20
ABL IK-G	B20
ABL IK-B	C20
GND	A21
GND	B21
GND	C21
LIMIT-R	A22
LIMIT-G	B22
LIMIT-B	C22
DRV-R	A23
DRV-G	B23
DRV-B	C23
BKG-R	A24
BKG-G	B24
BKG-B	C24
ON/OFF-R	A25
ON/OFF-G	B25
ON/OFF-B	C25
F-V	A26
C PROT CONT	B26
GND	C26
GND	A27
GND	B27
GND	C27
CLAMP P	A28
SCP	B28
BLKG P	C28
1K PROT	A29
IN/OUT	B29
SEL C	C29
SUB+6V	A30
SUB+6V	B30
SUB+6V	C30
-6V	A31
-6V	B31
-6V	C31
IFB-SDA	B31
IFB-SCL	C31
GND	A32
GND	B32
GND	C32
GND	A33
GND	B33
GND	C33

TO BA BOARD CN341	
CN341 96P	
-15V	A1
-15V	B1
-15V	C1
GND	A2
GND	B2
GND	C2
+15V	A3
+15V	B3
+15V	C3
R MOD	A4
G MOD	B4
B MOD	C4
GND	A5
GND	B5
GND	C5
TEST IRE	A6
HS-IFB	B6
VD	C6
OSD-R	A7
OSD-R	B7
OSD-G	C7
OSD-G	A8
OSD-B	B8
OSD-B	C8
OSD-B	A9
OSD-B	B9
OSD-V	A10
OSD-V	B10
OSD-BRT	C10
OSD-BRT	A11
GND	B11
GND	C11
GND	A12
GND	B12
GND	C12
D-SCL	A13
D-RESET	B13
GND	C13
D-SDA0	A14
D-LD0	B14
H-SYNC (RI)	C14
H-SYNC (RI)	A15
S ON G (RI)	B15
GND	C15
GND	A16
GND	B16
GND	C16
12C-SDA1	A17
12C-SCL1	B17
12C-SDA2	A18
12C-SCL2	B18
GND	C18
GND	A19
GND	B19
GND	C19
ABL IK-R	A20
ABL IK-G	B20
ABL IK-B	C20
GND	A21
GND	B21
GND	C21
LIMIT-R	A22
LIMIT-G	B22
LIMIT-B	C22
DRV-R	A23
DRV-G	B23
DRV-B	C23
BKG-R	A24
BKG-G	B24
BKG-B	C24
ON/OFF-R	A25
ON/OFF-G	B25
ON/OFF-B	C25
F-V	A26
C PROT CONT	B26
GND	C26
GND	A27
GND	B27
GND	C27
CLAMP P	A28
SCP	B28
BLKG P	C28
1K PROT	A29
IN/OUT	B29
SEL C	C29
SUB+6V	A30
SUB+6V	B30
SUB+6V	C30
-6V	A31
-6V	B31
-6V	C31
IFB-SDA	B31
IFB-SCL	C31
GND	A32
GND	B32
GND	C32
GND	A33
GND	B33
GND	C33

TO BC BOARD CN380		
CN380 96P		
+6V	A	
RED	B	
RED	C	
+6V	A	
GND	B	
GND	C	
+5V	A	
GREEN	B	
GREEN	C	
+5V	A	
GND	B	
GND	C	
GND	A	
BLUE	B	
BLUE	C	
IN/OUT	A	
HS-IFB	B	
HS-IFB	C	
SEL-B	A	
VS-IFB	B	
VS-IFB	C	
RED OUT-B	A	
RED OUT-B	B	
RED OUT-B	C	
GND	A	
GND	B	
GND	C	
GREEN OUT-B	A	
GREEN OUT-B	B	
GREEN OUT-B	C	
GND	A	
GND	B	
GND	C	
BLUE OUT-B	A	
BLUE OUT-B	B	
BLUE OUT-B	C	
GND	A	
GND	B	
GND	C	
CODE2-C	A	
CODE2-B	A	
GND	B	
HS OUT-B	B	
HD/CSYNC-B	B	
HD/CSYNC-B	B	
VD-B	A	
VD-B	B	
VD-B	C	
GND	A	
GND	B	
GND	C	
R/R-Y-B	A	
R/R-Y-B	B	
R/R-Y-B	C	
GND	A	
GND	B	
GND	C	
G/Y-B	A	
G/Y-B	B	
G/Y-B	C	
GND	A	
GND	B	
GND	C	
B/B-Y-B	A	
B/B-Y-B	B	
B/B-Y-B	C	
GND	A	
GND	B	
GND	C	
HD/CSYNC-C	A	
HD/CSYNC-C	B	
HD/CSYNC-C	C	
VD-C	A	
VD-C	B	
VD-C	C	
GND	A	
GND	B	
GND	C	
R/R-Y-C	A	
R/R-Y-C	B	
R/R-Y-C	C	
GND	A	
GND	B	
GND	C	
G/Y-C	A	
G/Y-C	B	
G/Y-C	C	
GND	A	
GND	B	
GND	C	
B/B-Y-C	A	
B/B-Y-C	B	
B/B-Y-C	C	
B/B-Y-C	A	

10-11



5

FRAME (11/11) WIRING






1

2

3

4

5



10-2. SCHEMATIC DIAGRAMS/PRINTED WIRING BOARDS

Note:

- All capacitors are in μF unless otherwise noted.
PF: 50 WV or less are not indicated except for electrolytics.
- All electrolytics are in 50 V unless otherwise specified.
- All resistors are in ohms, 1/4 W in resistance, 1/10 W in chip resistance.
 $\text{k}\Omega = 100$, $\text{M}\Omega = 1000 \text{ k}\Omega$
-  : nonflammable resistor.
-  : internal component.
-  : panel designation, or adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- METAL FILM (: RN) resister in 0.5 %, 1/4 W unless otherwise specified.
- The components identified by  in this basic schematic diagram have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation.
Should replacement be requited, replace only with the value originally used.
- When replacing components identified by , make the necessary adjustments indicated. If results do not meet the specified value, change the component identified by  and repeat the adjustment until the specified value is achieved.
(Refer to  RV100,  RV250 on page 4-1,  RV965 on page 4-2.)

The components identified by mark  are critical for safety.
Replace only with part number specified.

Les composants identifies par une marque  sont critiques pour la securite. Ne les remplacer que par une piece portant le numero specifie.


- When the power supply block has been replaced, check that the +B MAX voltage is within $200 \pm 2\text{V}$.
- All voltages are in V.
- Voltage variations may be noted due to normal production tolerances.
- Readings are taken with Composite Video and Component (R.G.B. HD, VD) color-bar signal input from color-bar pattern generator.
- Voltage are dc with respect to ground unless otherwise noted.
- no mark : Composite Video signal and common voltage.
-  : Component (R.G.B. HD, VD) signal received.
-  : B+ bus.
-  : B- bus.
-  : signal path.
- Circled numbers are waveform reference.

Reference information


- RESISTOR : RN METAL FILM
: RC SOLID
: FPRD NONFLAMMABLE CARBON
: FUSE NONFLAMMABLE FUSIBLE
: RS NONFLAMMABLE METAL OXIDE
: RB NONFLAMMABLE CEMENT
: RW NONFLAMMABLE WIREWOUND
: LF-8L MICRO INDUCTOR
- COIL : TA TANTALUM
CAPACITOR : PS STYROL
: PP POLYPROPYLENE
: PT MYLAR
: MPS METALIZED POLYESTER
: MPP METALIZED POLYPROPYLENE
: ALB BIPOLAR
: ALT HIGH TEMPERATURE
: ALR HIGH RIPPLE

Board	Part replaced ()	Adjustment ()
PA	C155, C157 R109, R111, R112, R114, R117, R118, R104, R105, R106, R107, R108, R120, R121, R157, R158 RV101, RV150 IC101, IC102, IC100, IC152, IC153 PH500	RV100 (HV. REGULATOR)
	C250 R250, R251, R252, R253, R256, R257, R258, R259, R260 D252, D253 IC250, IC251	RV250 (HV. PROTECTOR)
	C607, C608, C610, C611 L601, L602, L603, L604	RV100 (HV. REGULATOR) RV250 (HV. PROTECTOR)
PB	FBT10, FBT11	
CDR CDG CDB	R971, R972, R973, R974, R975 D960, D965 IC961, IC971	RV965 (CRT PROTECTOR)
	R960, R967, R1007 IC990	OPERATION CHECK (IK PROTECTOR)
BA	R839, R841, R847, R855, R848, R870, R873, R872, R877, R876 D806 IC804	


BD BOARD (EXCEPT VPH-G90E)



BD -A SIDE-
SUFFIX: -11




BD -B SIDE-
SUFFIX: -11



BA BA

BA BOARD




BA -A SIDE-
SUFFIX: -11

BA BOARD (A SIDE)

D4	H-9	IC1408	C-5	Q1609	H-6	TP1810	C-2
D5	G-10	IC1409	C-4	Q1610	H-6	TP1811	B-2
D7	H-9	IC1410	C-5	Q1611	H-6	TP1812	B-1
D11	H-9	IC1411	C-4	Q1709	F-5	TP1813	A-1
D501	B-11	IC1413	C-5	Q1710	E-5	TP1814	A-1
D502	B-12	IC1414	D-6	Q1711	E-4	TP1815	A-2
D503	B-13	IC1600	H-5	Q1801	A-2	TP2101	G-8
D600	A-10	IC1603	G-7	Q1802	A-2	TP2102	F-8
D806	G-8	IC1712	E-6	Q1803	A-2	TP2103	A-6
D807	H-8	IC1801	A-2	Q1804	A-2	TP2104	B-5
D810	C-11	IC1802	B-1	Q1807	D-4	TP2105	B-6
D811	D-10	IC1803	B-1	Q1808	E-3	TP2106	A-7
D812	D-10	IC1804	C-2	Q1809	E-4	TP2107	A-13
D813	D-9	IC1805	A-1	Q1811	E-4	TP2111	G-7
D1001	G-3	IC1806	A-1	Q1812	D-4	TP2112	E-7
D1600	H-2	IC1807	A-3	Q1813	E-4		
D1601	G-6	IC1811	B-2	Q1814	A-1		
D2101	D-7	IC1813	C-3	Q1815	A-1		
D2204	H-3	IC1814	A-2	Q2100	B-9		
D2205	H-3	IC2000	B-4				
		IC2002	A-4	RV200	E-10		
IC1	H-11	IC2004	B-5	RV501	B-13		
IC2	H-12	IC2005	B-6	RV502	B-10		
IC3	H-13	IC2008	B-3	RV503	B-10		
IC5	H-10	IC2101	F-8	RV504	B-11		
IC8	H-11	IC2102	G-8	RV800	E-10		
IC10	G-13	IC2103	D-8				
IC11	F-10	IC2104	F-8	TP1	H-9		
IC13	F-10	IC2105	F-7	TP3	H-11		
IC20	G-11	IC2106	C-7	TP4	H-12		
IC201	F-11	IC2107	F-8	TP5	H-13		
IC202	G-11	IC2108	C-7	TP451	A-11		
IC203	G-11	IC2109	A-7	TP501	A-12		
IC204	F-11	IC2110	B-8	TP551	A-12		
IC205	F-10	IC2002	H-3	TP800	D-9		
IC206	G-12			TP801	D-11		
IC207	G-11	Q1	G-10	TP802	G-8		
IC208	G-11	Q2	G-9	TP803	D-10		
IC209	F-12	Q5	H-9	TP804	C-11		
IC210	F-12	Q8	F-9	TP1000	G-3		
IC211	F-11	Q12	F-10	TP1001	G-2		
IC212	G-13	Q13	F-9	TP1002	E-2		
IC213	G-12	Q18	G-9	TP1005	G-2		
IC214	G-12	Q21	H-9	TP1007	F-3		
IC215	F-13	Q200	G-9	TP1010	G-2		
IC216	F-12	Q201	G-11	TP1011	G-1		
IC217	F-13	Q202	F-10	TP1012	H-2		
IC218	E-11	Q203	G-12	TP1013	H-1		
IC219	E-11	Q204	F-11	TP1014	H-3		
IC220	E-11	Q205	G-13	TP1015	E-2		
IC221	F-11	Q208	F-12	TP1030	F-1		
IC401	E-13	Q451	E-11	TP1200	C-4		
IC402	E-13	Q458	B-11	TP1201	D-4		
IC404	C-11	Q501	D-12	TP1202	E-3		
IC452	B-11	Q508	B-12	TP1204	C-2		
IC502	B-12	Q551	E-12	TP1400	E-4		
IC503	C-13	Q558	B-13	TP1401	E-5		
IC504	C-12	Q801	C-10	TP1402	C-5		
IC552	B-13	Q809	H-7	TP1403	D-5		
IC600	B-9	Q810	G-7	TP1404	B-6		
IC601	C-9	Q811	H-8	TP1405	E-4		
IC602	C-9	Q812	G-8	TP1406	E-4		
IC603	B-9	Q814	E-9	TP1407	E-5		
IC604	B-9	Q1007	G-2	TP1601	F-6		
IC605	C-9	Q1010	G-3	TP1602	F-6		
IC606	B-10	Q1011	G-1	TP1603	F-6		
IC607	C-10	Q1014	G-2	TP1604	F-6		
IC608	C-10	Q1017	H-3	TP1605	E-6		
IC612	C-9	Q1018	G-2	TP1606	F-6		
IC613	A-10	Q1021	G-2	TP1610	H-7		
IC614	C-10	Q1024	F-4	TP1611	H-7		
IC801	E-9	Q1025	F-4	TP1612	H-7		
IC802	D-9	Q1026	F-4	TP1613	G-6		
IC803	F-9	Q1028	G-3	TP1614	F-1		
IC804	H-8	Q1029	F-3	TP1615	G-1		
IC805	E-9	Q1201	B-3	TP1616	G-1		
IC807	D-9	Q1202	B-3	TP1617	G-5		
IC808	D-9	Q1204	C-3	TP1618	E-1		
IC809	D-9	Q1205	C-3	TP1619	E-1		
IC810	C-9	Q1208	C-3	TP1620	H-1		
IC811	C-9	Q1413	D-4	TP1621	H-1		
IC812	C-9	Q1416	D-7	TP1622	G-4		
IC1001	E-2	Q1417	D-6	TP1623	G-5		
IC1002	F-3	Q1419	D-5	TP1624	H-6		
IC1003	H-4	Q1421	D-4	TP1625	H-5		
IC1202	C-1	Q1422	D-4	TP1800	B-1		
IC1203	D-1	Q1425	C-4	TP1801	B-3		
IC1205	D-1	Q1426	D-6	TP1802	C-1		
IC1207	C-2	Q1427	D-7	TP1803	B-2		
IC1208	C-2	Q1429	D-4	TP1804	B-2		
IC1402	C-5	Q1601	H-3	TP1805	B-3		
IC1403	E-5	Q1602	F-5	TP1806	C-2		
IC1404	D-5	Q1603	F-5	TP1807	C-2		
IC1407	D-5	Q1604	F-4	TP1809	B-2		

BA BOARD




BA -B SIDE-
SUFFIX: -11


BA BOARD (B SIDE)

D1	B-10	Q1008	C-3
D2	B-11	Q1009	D-3
D3	B-13	Q1012	C-2
D6	C-10	Q1013	B-1
D8	A-10	Q1015	B-1
D9	E-10	Q1016	C-2
D10	C-9	Q1019	B-2
D601	H-10	Q1020	B-2
D800	G-9	Q1022	B-2
D801	E-9	Q1023	B-2
D802	F-10	Q1030	D-2
D803	F-9	Q1031	D-3
D804	E-10	Q1033	B-3
D805	E-10	Q1203	F-2
D808	F-9	Q1206	F-4
D809	E-9	Q1207	F-3
D1201	E-2	Q1217	F-4
D1401	G-4	Q1218	E-1
D1600	B-2	Q1218	E-4
D2200	A-2	Q1219	F-4
D2201	A-2	Q1220	E-4
D2202	A-3	Q1221	E-4
D2203	A-3	Q1222	F-3
		Q1223	E-4
IC12	B-9	Q1224	E-3
IC14	B-9	Q1225	E-3
IC402	E-13	Q1226	E-3
IC403	G-13	Q1227	D-3
IC404	G-11	Q1228	E-4
IC609	G-10	Q1229	D-3
IC610	H-10	Q1230	E-3
IC611	G-10	Q1403	G-5
IC612	G-9	Q1404	G-4
IC1004	C-4	Q1405	H-5
IC1005	D-2	Q1408	G-6
IC1006	D-3	Q1414	E-5
IC1206	E-2	Q1415	E-5
IC1402	G-5	Q1420	G-4
IC1602	B-6	Q1423	F-5
IC1801	H-2	Q1424	F-5
IC2001	H-7	Q1428	E-6
IC2003	H-5	Q1600	B-3
IC2103	E-8	Q1601	A-3
		Q1800	G-2
		Q1808	E-4
Q3	B-8		
Q4	B-9		
Q8	B-8	RV200	D-11
Q9	C-10	RV501	H-13
Q10	B-11	RV502	H-11
Q11	E-9	RV503	G-10
Q14	E-10	RV504	G-11
Q18	D-10	RV800	E-11
Q19	C-10		
Q20	D-9		
Q22	B-9		
Q23	A-9		
Q24	D-9		
Q25	D-9		
Q207	E-10		
Q208	C-10		
Q209	D-10		
Q210	C-12		
Q211	D-11		
Q212	C-13		
Q213	C-13		
Q455	H-11		
Q456	H-11		
Q457	H-11		
Q505	H-12		
Q506	H-12		
Q507	H-12		
Q555	H-12		
Q556	H-13		
Q557	H-13		
Q600	H-8		
Q601	H-8		
Q602	G-8		
Q800	F-10		
Q802	F-10		
Q803	F-9		
Q805	F-10		
Q807	F-10		
Q808	E-9		
Q809	F-10		
Q813	E-10		
Q815	E-10		
Q816	F-10		
Q817	F-10		
Q1000	D-1		
Q1001	D-2		
Q1002	C-2		
Q1004	D-1		
Q1005	B-1		
Q1006	B-1		


BA BOARD WAVEFORMS




BA (1/12) BOARD



BA (2/12) BOARD




BA (3/12) BOARD




BA (3/12)
(PRE AMX&OSDMIX)
GANNMA

B-NSX1640<AEP>-BA-3

BA (4/12) BOARD



BA (5/12) BOARD



1

2

3

4

5


BA MOUNT (6/12) VOLTAGES

Pin No.	IC1003	IC1002	IC1001	IC1005	IC1006
1	GND	4.4	4.2 (4.3)	4.4	4.4 (4.5)
2	GND	N.C	4.1 (0)	0 (3.6)	0 (3.6)
3	GND	4.4	4.2 (4.9)	4.5 (4.3)	4.5 (4.4)
4	GND	N.C	0	N.C	0
5	GND	4.4	4.5 (5.3)	N.C	N.C
6	GND	8 (7.9)	9	9	9
7	GND	4.4	3.5 (2.7)	3.7	3.8 (3.7)
8	GND	4.4	GND	GND	GND
9	GND	4.4			
10	GND	4.4			
11	2.3	4.4			
12	GND	0 (7.9)			
13	5	4.6			
14	2.4 (2.1)	4.6			
15	2.4 (2.1)	0			
16	2.4 (2.1)	N.C			
17	5	N.C			
18	5	N.C			
19	GND	N.C			
20	GND	N.C			
21	GND	N.C			
22	0.5	N.C			
23	GND	4.3 (0)			
24	GND	N.C			
25	1.2 (0.6)	N.C			
26	5	N.C			
27	2.5	N.C			
28	5	N.C			
29	5	3.8 (3.7)			
30	GND	GND			
31	0.5 (0)	3.7			
32	3.3	N.C			
33	1.9	N.C			
34	2	4.3 (4.4)			
35	GND	N.C			
36	1	4.4			
37	5	3.6			
38	GND	9			
39	0.7	3.7			
40	3.3	4.4			

Note: No Mark is VIDEO signal and common. () Mark is Component signal.

Pin No.	IC1003	IC1002
41	1.9	4.4
42	2	4.4
43	GND	4.4
44	N.C	N.C
45	N.C	4.4
46	N.C	N.C
47	N.C	4.4
48	N.C	7.9
49	N.C	
50	N.C	
51	N.C	
52	GND	
53	5	
54	N.C	
55	N.C	
56	5	
57	N.C	
58	N.C	
59	N.C	
60	N.C	
61	N.C	
62	N.C	
63	N.C	
64	N.C	
65	N.C	
66	N.C	
67	5	
68	4.9	
69	0 (4.9)	
70	0 (4.9)	
71	GND	
72	GND	
73	5	
74	GND	
75	GND	
76	GND	
77	GND	
78	0	
79	0	
80	0	

BA (6/12) BOARD



1

2

3

4

5


BA MOUNT (7/12) VOLTAGES

Pin No.	IC1203	IC1202	IC205	IC206
1	GND	5	1.6	3.2
2	1.4	2 (0)	1.6	0
3	1.4	2.3 (0)	0	5
4	1.4	1.3 (2.7)	3.2	2.6 (2.5)
5	1.4	2.3 (2.7)	3.2	GND
6	1.5 (1.4)	5	0	0
7	1.5 (1.4)	2.1 (2.7)	GND	2.5
8	1.4	2.2 (2.7)	N.C	0
9	1.3	0.8 (0)	3.3	2.2
10	0.9 (1)	1 (0)	N.C	5
11	2.8 (3)	N.C	3.3	GND
12	2.2	N.C	N.C	0
13	1.3 (0)	2.8 (2.9)	3.3	1.3 (1.5)
14	1.3 (0)	0.4	3.3	1.8 (0.5)
15	2.4 (3.8)	N.C		1.2 (2.7)
16	2.4 (3.8)	1.3		2.4 (4.4)
17	3.1 (3.8)	0 (1.4)		1.6 (4.4)
18	1.6 (1.9)	1.5 (1.4)		5
19	2.5 (2.6)	1.4 (1.3)		GND
20	2.1 (2.3)	5		1.6 (4.4)
21	1 (0)	GND		1.2 (0)
22	0.9 (0)	1.5		1.1 (0)
23	2.3 (0)	1.4		N.C
24	2.1 (0)	1.5 (1.4)		1.6
25	2.3 (0)	1.4		
26	1.4 (2.7)	0 (1.4)		
27	2.3 (0)	0 (2.2)		
28	1.8 (0)	0.8 (0.9)		
29	GND	0.8 (0.9)		
30	1.4	N.C		
31	1.5	1.4 (0)		
32	3.3	1.4 (0)		
33	N.C	2.5 (3.8)		
34	N.C	0 (3.8)		
35	N.C	GND		
36	N.C	3.1 (3.8)		
37	N.C	1.8 (2.2)		
38	N.C	2.5 (2.3)		
39	N.C	2.2 (1.7)		
40	GND	GND		
41	0			
42	0			
43	0			
44	0			
45	3.3			
46	3.2			
47	1.5			
48	GND			
49	GND			
50	1.5			

Note: No Mark is VIDEO signal and common. () Mark is Component signal.

Pin No.	IC1203
51	0 (0.8)
52	0 (0.8)
53	3.3
54	GND
55	GND
56	N.C
57	3.2
58	GND
59	4.6 (4.6)
60	4.6
61	0
62	N.C
63	N.C
64	3.3
65	0
66	0
67	1.4 (0.8)
68	1.8 (0.8)
69	1.4 (2.4)
70	2.5 (4.4)
71	1.7 (4.4)
72	1.7 (4.4)
73	1.4 (0)
74	1.1 (0)
75	1.6
76	4.2 (4.9)
77	GND
78	GND
79	GND
80	GND
81	3.3
82	9.9
83	1.5
84	1.4 (1.2)
85	0.9
86	GND
87	GND
88	0
89	0
90	0
91	0
92	3.3
93	3.3
94	0
95	
96	N.C
97	GND
98	0.4
99	1.5
100	3.3

BA (7/12) BOARD



BA (7/12)
(COMB (NT3.58))

BA MOUNT (8/12) VOLTAGES

PIN NO.	IC1402	IC1403	IC1404	IC1407	IC1408	IC1409
1	2.1	5	3.5	3.6 (3.5)	GND	N.C
2	2	N.C	0	0	4.6 (4.8)	0 (1.5)
3	2.4 (0)	GND	3.6 (3.5)	3.6 (3.5)	5	4.8 (0)
4	2.5 (0)	GND	N.C	N.C	4.8 (0)	GND
5	4.5	0.6	N.C	N.C	5	N.C
6	4.6 (4.5)	N.C	9	9	0.1 (0)	1.2
7	4.9	N.C	3.8	3.8	N.C	4.3 (4.9)
8	8	GND	GND	GND	GND	5
9	GND	5			N.C	
10	0.5 (0.6)	N.C			2.9 (0)	
11	0	2.9			0.3 (0)	
12	2.9 (0)	2.9			2.9 (0)	
13	2.5 (2.4)	N.C			5	
14	2.4 (2.5)	1.5			4.9 (2.8)	
15	0	N.C			GND	
16	N.C	1.8			5	
17	0.2 (0)					
18	N.C					
19	N.C					
20	N.C					
21	N.C					
22	7.3					
23	4.1 (0)					
24	3.9 (3.5)					
25	0					
26	3.6 (3.2)					
27	GND					
28	3.4					
29	4.5 (4.2)					
30	1.4 (1.9)					
31	2.2 (1.7)					
32	3.9 (3.7)					

Note: No Mark is VIDEO signal and common. () Mark is Component signal.

1


2

3

4

5

BA (8/12) BOARD



BA MOUNT (9/12) VOLTAGES

Pin No. IC1600			IC1712	Pin No. IC1600	
1	6.9 (2.4)	4	(3.9)	41	GND
2	7.1 (2.4)	3.9		42	0
3	2.8 (2.9)	3.9		43	8.7 (0)
4	2.8 (2.9)	4.9		44	3.2
5	2.9	3.9 (4.1)		45	GND
6	9	3.9 (4.1)		46	4.8
7	2.4 (7.3)	3.9 (0)		47	4.8
8	2.4 (7)	0.5 (0)		48	4.8
9	2.9	3.4 (0)		49	GND
10	2.9	3.4		50	4.1
11	2.9	3.4		51	4.1
12	GND	3.5		52	4.1
13	2.4 (7.3)	3.5		53	GND
14	2.4 (7)	3.5		54	3.7 (4.1)
15	2.8 (2.9)	N.C		55	4.5 (4.6)
16	2.8 (2.9)	4 (3.7)		56	4.6
17	2.8 (2.9)	3.7		57	0 (0.2)
18	3 (2.9)	3.6 (3.7)		58	3.3 (3.6)
19	2.4	GND		59	N.C
20	2.4 (2.5)	0		60	N.C
21	2.8	GND		61	GND
22	2.9 (2.8)	4.3 (0)		62	4.7
23	2.9 (2.8)	0		63	4.7 (4.2)
24	3 (2.9)	2.1 (0)		64	4.7 (4.8)
25	5.1 (5)	GND		65	0 (4.9)
26	2.5 (2.9)	2.1		66	4.5 (4.9)
27	4.5	GND		67	4.8
28	0.4 (0.3)	2.1		68	4.8
29	0.6 (0.3)			69	4.9 (4.8)
30	9			70	GND
31	0 (0.2)			71	2.5
32	GND			72	9
33	GND			73	2.4 (2.3)
34	GND			74	2.3
35	0 (2.1)			75	2.3
36	2.8 (0)			76	4.4
37	0 (2.1)			77	4.4
38	0			78	4.4
39	0.8 (2.1)			79	N.C
40	0				

Note: No Mark is VIDEO signal and common. () Mark is Component signal.

1

2

3

4

5

BA (9/12) BOARD



1

2

3

4


5

BA MOUNT (10/12) VOLTAGES

Pin No.	IC1801	IC1802	IC1804	IC1811	IC181
1	2.7 (7)	0 (3.5)	0	0	0
2	2.9 (0)	0	GND	4.5 (4.9)	0
3	1.8 (3.5)	0 (3.5)	0 (4.5)	5	0
4	2.7	0 (4.5)	0	4.5 (4.9)	GND
5	2.8	0 (4.9)	GND	GND	0
6	0.1 (0)	0 (4.1)	0 (4.9)	GND	0
7	1.1 (1.5)	0 (4.9)	0	N.C	0
8	5	GND	GND	GND	5
9	1.2	0 (4.9)	0	4.9	
10	1.2	0	GND	0 (4.9)	
11	GND	GND	0 (0.4)	4.9	
12	3.1	0 (4.5)	0	4.5	
13	0.3	0 (3.5)	GND	0 (4.5)	
14	4.9	GND	0	4.5 (4.9)	
15	0.1 (0)	GND	0	0	
16	N.C	5	5	5	
17	N.C				
18	0.2				
19	1				
20	1				
21	0.3				
22	5				

Note: No Mark is VIDEO signal and common. () Mark is Component signal.

BA (10/12) BOARD



BA (11/12) BOARD


1

2


3

4

5




BA (12/12) BOARD




BA (12/12)
(CONNECTOR&REG&LED DRIVE)


BA BOARD (1/12) IC1, 2, 3
MAX4121CSA




BA BOARD (3/12) IC403
MC10HC125MEL




BA BOARD (3/12) IC404
LM1283N




BA BOARD (2/12) IC202, 203, 207, 208, 213, 214
MAX4121CSA




BA BOARD (4/12) IC600, 601, 602
NJM4200M-T1




BA BOARD (2/12) IC204, 210, 217
AD835AF




BA BOARD (3/12) IC402
CXA3069S




BA BOARD (2/12) IC218
TC4W53FU




BA BOARD (6/12) IC1003
CXD2024AQ




**BA BOARD (4/12) IC609, 611
MP7670AS**




**BA BOARD (6/12) IC1002
CXA1855Q**




**BA BOARD (6/12) IC1001, 1006
NJM2235M**




**BA BOARD (6/12) IC1004
NJM2240M**




**BA BOARD (8/12) IC1404, 1407
MM1112XFF**




**BA BOARD (6/10) IC1005
NJM2533M**




**BA BOARD (8/12) IC1402
TDA9141-N2C**




**BA BOARD (10/12) IC1801
CXA2016S**




**BA BOARD (11/12) IC2000, 2002, 2004
PCF8574T**




**BA BOARD (9/12) IC1712
CXA2119M**




**BA BOARD (11/12) IC2001, 2003, 2005
CXA1875AM**




**BA BOARD (10/12) IC1802, 1804, 1811
SN74HC157ANS**




**BA BOARD (12/12) IC2110
MAX8213BCSE**



BB BOARD**BB BOARD (A SIDE)**

IC2	E-1	TP1	C-3
IC3	E-1	TP2	C-2
IC106	E-2	TP100	F-4
IC107	E-2	TP101	F-4
IC300	D-6	TP102	F-4
IC301	C-6	TP103	E-6
IC302	B-6	TP104	F-4
IC303	B-6	TP105	F-4
IC304	C-5	TP106	E-5
IC305	C-4	TP107	E-5
IC500	A-4	TP108	E-3
IC501	B-5	TP109	E-3
IC502	A-5	TP110	E-3
IC700	C-3	TP111	E-2
IC900	D-2	TP112	E-3
IC901	D-3	TP113	E-4
IC902	A-2	TP901	A-1
IC903	D-4		
Q901	C-1		
Q902	C-1		
Q904	C-2		
RV900	D-2		
RV901	D-3		
RV902	D-4		

BB -A SIDE-
SUFFIX: -11

**BB BOARD (B SIDE)**

D300	A-2	RV900	D-5
D301	D-2	RV901	D-4
D302	D-2	RV902	D-3
IC1	C-4		
IC4	C-5		
IC701	A-3		
IC702	A-3		
Q103	F-1		
Q104	F-1		
Q105	F-2		
Q106	F-2		
Q107	F-2		
Q108	F-2		
Q111	E-4		
Q112	E-4		
Q113	E-5		
Q300	E-1		
Q301	F-2		
Q302	F-2		
Q303	A-1		
Q304	C-1		
Q305	C-2		
Q306	D-3		
Q900	C-5		
Q903	C-6		
Q905	C-6		

BB -B SIDE-
SUFFIX: -11

BB (1/5) BOARD


1

2


3

4


5




B-%SX1640<AEP>-BB-1

BB (2/5) BOARD

BB (2/5)
(TBC, A/D)


BB (3/5) BOARD

BB (4/5) BOARD



BB (5/5) BOARD

1
2
3
4
5



BB (5/5)
(POST DRC/AMP)

B-41640<AEP>-BB-5

A

B

C

10-44

D

10-44


E

F


G

H


BB BOARD (1/5) IC1, 4
CXA1875AM



BB BOARD (2/5) IC303
TC74HC123AF



BB BOARD (2/5) IC302, 304
TLC2932IPW



BC BOARD


1

2

3

4

5



BC -A SIDE-
SUFFIX: -11


10-46

A

B

C

D



BC -B SIDE-
SUFFIX: -11

10-46


E

F


G

H


BC BOARD



BC BOARD IC500
TC4W53F



YA BOARD




YA -A SIDE-
SUFFIX: -11

YA BOARD (A SIDE)

D13	B-12	TP11	A-4
D14	B-12	TP40	B-7
D701	B-4	TP43	A-10
D702	H-5	TP44	A-8
D703	H-5	TP45	A-8
D704	H-4	TP151	B-10
D706	B-4	TP152	B-10
D731	C-6	TP153	B-12
D732	D-6	TP154	B-12
D733	D-6	TP201	C-1
D801	B-6	TP202	D-1
D802	B-6	TP203	A-2
D961	H-6	TP204	A-2
D962	H-6	TP205	A-2
D963	H-5	TP231	D-1
D964	H-5	TP251	D-4
D965	H-6	TP252	D-4
D966	H-6	TP301	G-6
D967	H-6	TP311	G-2
D968	H-6	TP312	G-1
D981	H-13	TP321	F-4
D982	H-13	TP401	A-11
D983	H-13	TP402	B-11
D984	H-13	TP424	D-11
		TP425	B-12
IC171	B-3	TP426	B-12
IC172	A-8	TP427	B-12
IC173	A-9	TP428	B-12
IC174	F-13	TP429	B-13
IC175	B-3	TP431	B-12
IC176	A-9	TP432	C-11
IC201	B-1	TP441	E-7
IC232	E-2	TP442	E-7
IC233	E-2	TP443	E-7
IC234	C-2	TP451	D-5
IC235	C-2	TP452	D-6
IC238	C-3	TP453	D-5
IC251	C-4	TP454	C-7
IC252	D-4	TP455	D-7
IC253	D-4	TP456	D-7
IC301	F-5	TP457	C-6
IC311	G-1	TP458	C-6
IC321	G-3	TP459	C-6
IC322	G-4	TP461	D-5
IC332	G-4	TP480	C-5
IC333	D-13	TP501	E-10
IC334	C-13	TP531	H-9
IC335	H-5	TP551	G-12
IC421	C-11	TP552	E-13
IC431	C-12	TP553	E-12
IC441	D-8	TP554	E-12
IC442	D-6	TP601	F-13
IC452	D-5	TP602	F-13
IC456	C-7	TP861	C-5
IC501	D-9	TP941	H-11
IC502	C-9	TP942	H-11
IC503	C-10	TP961	H-12
IC531	H-10	TP964	H-12
IC541	F-10	TP967	H-12
IC543	G-7	TP968	H-12
IC551	F-11	TP983	H-11
IC571	G-12		
IC593	G-8		
IC595	F-7		
IC596	F-7		
IC597	F-8		
IC598	G-7		
IC601	G-13		
IC602	G-13		
IC701	A-4		
IC703	A-3		
IC704	A-4		
IC731	D-6		
IC732	D-5		
IC841	B-4		
IC861	B-6		
IC901	H-1		
IC921	H-11		
IC941	H-10		
IC942	H-10		
IC961	H-12		
IC962	H-12		
IC981	H-12		
IC982	H-13		
Q401	B-11		
Q402	B-11		
Q403	B-11		
Q404	B-11		
Q701	A-4		
Q841	C-5		
Q842	C-4		
Q843	C-5		

YA BOARD




YA -B SIDE-
SUFFIX: -11

YA BOARD (B SIDE)


D15	B-2
D16	B-2
D17	B-2
D171	B-11
D172	A-5
D173	A-5
D174	F-1
D175	B-11
D176	B-5
D705	A-11
D707	A-11
D708	D-8
D734	D-8
D803	B-7
D804	B-7
D805	B-9
D806	B-7
D807	A-9
D809	B-7
D809	B-10
D810	B-7
D811	B-7
D812	B-9
D813	B-9
D814	B-9
D815	B-9
D841	B-10
D842	B-10
D941	H-3
D942	H-5
D943	H-6
D944	H-4
D969	H-2
D970	H-2
D971	H-2
D972	H-2
IC174	F-1
IC231	E-12
IC233	F-12
IC332	G-9
IC572	F-3
IC573	G-2
IC574	G-2
IC590	G-8
IC591	G-7
IC592	G-6
Q11	B-7
Q12	B-8
Q405	B-1
Q406	B-1
Q531	F-5
Q702	A-11
Q703	A-11
Q704	B-10
Q705	A-11
Q941	H-3
Q942	H-5
Q943	H-6
Q944	H-4
Q981	H-1
Q982	H-2
Q983	H-1
Q984	H-1

YA (1/10) BOARD




CONNECTOR
POWER SUPPLY
OUTPUT BUFFER
YA (1/10)


YA (2/10) BOARD




YA (3/10) BOARD



YA (4/10) BOARD





YA (5/10) BOARD




FH/FV COUNTER
SYNC CONTROLLER
YA (5/10)

B-%SX1640<AEP>-YA

YA (6/10) BOARD

YA (7/10) BOARD

YA (8/10) BOARD



YA (9/10) BOARD


1

2

3


4

5




SIRCS MIX
POWER SUPPLY
SET PROTECTOR
YA (9/10)


YA (10/10) BOARD




YA BOARD (1/10) IC104, 106
MC10H124MEL




YA BOARD (4/10) IC431
CXD2309Q




YA BOARD (7/10) IC590-593, 595-597
TC74VHC245F




YA BOARD (4/10) IC432
TC74HC4053A




YA BOARD (5/10) IC454
YA BOARD (8/10) IC574
TC74VHC123AF




YA BOARD (8/10) IC572
MB86022PF



YA B0ARD (5/10) IC456
TC7W241FU




YA BOARD (8/10) IC573
TC74VHC132F




YB YB


**YA BOARD (8/10) IC602
MC10H640FN**





**YA BOARD (9/10) IC703
TC4W66FU**




**YA BOARD (9/10) IC704
TC7W241FU**




**YA BOARD (10/10) IC961, 962
MAX3085CSA**

**YB BOARD**

YA -B SIDE-
SUFFIX: -11



YB -B SIDE-
SUFFIX: -11



DA BOARD

DA BOARD (A SIDE)

- D101 C-5

D103 C-5

D105 E-1

D351 E-5

D352 E-5
- IC101 B-3

IC102 C-5

IC103 E-2

IC104 C-3

IC105 C-4

IC106 B-1

IC107 B-3

IC108 E-3

IC108 F-2

IC110 D-3

IC112 B-2

IC113 C-2

IC114 B-3

IC115 A-4

IC116 A-5

IC117 B-5

IC301 B-7

IC302 B-8

IC303 B-7

IC305 C-7

IC307 D-7

IC308 C-7

IC308 D-8

IC309 C-7

IC310 D-6

IC311 C-6

IC312 D-6

IC313 C-6

IC314 C-7

IC351 E-8

IC352 E-7

IC353 D-5

IC354 E-8

IC355 E-4

IC401 E-5

IC402 E-6

IC403 B-6

IC405 E-7

IC406 B-5

IC407 E-5

IC451 F-8

IC452 G-7
- Q101 C-3

Q102 F-2

Q105 C-3

Q109 C-3

Q110 D-3

Q116 C-1

Q118 D-1

Q301 D-6

Q354 G-6

Q401 E-6

Q402 D-6

Q451 F-7

Q811 B-2
- RV101 A-3

RV102 A-2

RV103 A-4

RV104 A-3

RV105 A-3

RV301 A-7

RV302 A-7

RV303 A-7

RV402 A-5

RV403 A-6
- TP101 F-3

TP102 F-2

TP103 F-3

TP104 C-2

TP105 B-5

TP106 C-4


TP107 E-4

TP301 D-5

TP401 F-5

TP402 F-5


TP403 C-5



DA -A SIDE-
SUFFIX: -11

DA BOARD


DA BOARD (B SIDE)



DA -B SIDE-
SUFFIX: -11

D102	F-7
D104	C-6
D106	B-6
D107	D-6
D108	C-7
D109	C-5
D110	C-5
D111	B-5
D112	A-4
D113	A-4
D353	F-3
D354	F-3
D355	G-2
D356	G-3
IC106	B-8
IC110	E-6
IC351	F-1
IC451	F-1
Q101	C-6
Q102	F-7
Q103	F-5
Q104	E-7
Q105	C-6
Q106	E-7
Q107	E-7
Q108	B-6
Q111	E-6
Q112	E-7
Q113	D-7
Q114	D-7
Q115	D-7
Q116	C-8
Q117	E-7
Q118	D-8
Q119	B-4
Q120	B-5
Q121	C-5
Q122	B-5
Q123	D-5
Q124	C-5
Q125	C-5
Q126	B-4
Q127	B-4
Q128	B-4
Q302	D-3
Q351	F-3
Q352	F-2
Q353	F-3
Q354	G-3
Q403	E-3
Q404	D-3
Q452	F-2
RV101	A-6
RV102	A-7
RV103	A-5
RV104	A-6
RV105	A-6
RV301	A-2
RV302	A-2
RV303	A-2
RV402	A-4
RV403	A-3
TP101	F-6
TP102	F-7
TP103	F-6
TP104	C-7
TP105	B-4
TP106	D-5
TP107	E-5
TP301	D-3
TP401	F-3
TP402	F-4
TP403	C-3

DA BOARD WAVEFORMS




DA BORAD FUNCTIONS


REF	TYPE NAME	FUNCTION
IC101	HD14538BFP	PULSE GENERATOR
IC102	BA12FP-E2	+12VREG-1
IC103	HD14538BFP	VD GENERATOR
IC104	UPC814G2	HF AFC AMP
IC105	NJM79M12DLA	-12VREG-1
IC106	MC-8639A	H SHIFT
IC107	UPC814G2	H1 AFC BUFFER
IC108	UPC393G2	VAFC-2
IC109	UPC814G2	VAFC-1
IC110	UPC1377C	AFC
IC112	UPC814G2	F-V BUFFER
IC113	UPC814G2	VIDEO AFC BUFFER
IC114	HD14538BFP	AD HD GEN-1
IC115	UPC4558G2	AD COMPARATOR
IC116	HD14538BFP	AD HD GEN-2
IC117	TC74HC4538	HD WIDTH GEN
IC301	CXA1726AM	H PARA GEN-2
IC302	PC74HC4053D-T	H SAW SW-2
IC303	AD835AR	H PARA GEN-1
IC305	LM6361M	H SAW GEN-1
IC306	UPC814G2	H SAW GEN-2
IC307	LM6361M	H SAW BUFFER
IC308	SN74HC109	H SAW SW-1
IC309	UPC319G2	H SAW COMPARATOR
IC310	TC7504F	1/2H BUFFER
IC311	PC74HC4053D-T	H RT CONT SW
IC312	UPC814G2	H RT BUFFER
IC313	UPC814G2	H SIN GEN-2
IC314	TC7508F	H RT BUFFER
IC351	TL431CLP	VOLTAGE REF
IC352	UPC814G2	H SIZE BUFFER-1
IC353	BA05FP-E2	5V REG
IC354	UPC814G2	H SIZE BUFFER-2
IC355	LM2990SX	-5 REG
IC401	LM6361M	H SAW BUFFER
IC402	AD828AR	H PARA BUFFER
IC403	PC74HC4053D-T	H SIN SW
IC405	AD828AR	H SIG1GEN-1
IC406	AD835AR	H SIN GEN
IC407	UPC814G2	H SIG1GEN-2
IC451	CXA1470AS	V SIG GEN
IC452	UPC814G2	V SAW/PARA BUFFER
Q101	DTC144ESA	SW-2
Q102	2SK523	V SYNC INVERTER
Q103	2SC2712	H SYNC BUFFER
Q104	2SC2712	V SYNC BUFFER
Q105	DTC144ESA	SW-1
Q106	2SC2712	V AFC SW
Q107	2SC2712	V AFC AMP
Q108	2SC2712	V-I CONVERTER-3
Q109	FMW5	V-I CONVERTER-4
Q110	FMS2	CURRENT MIRROR
Q111	2SC2712	V AMP-2
Q112	2SC2712	V AMP-2
Q113	2SC2712	H OSC BUFFER-1
Q114	2SA1162	H OSC BUFFER-2

REF	TYPE NAME	FUNCTION
Q115	2SA1162	VIDEO AFC
Q116	DTC144ESA	SW-3
Q117	2SC2712	VD BUFFER
Q118	DTC144ESA	1/2H BUFFER
Q119	2SC2712	AD HD BUFFER
Q120	2SC2712	HD BUFFER-1
Q121	2SA1162	HD BUFFER-2
Q122	2SA1162	V-I CONVERTER-1
Q123	2SC2712	HD BUFFER-3
Q124	2SA1162	HD BUFFER-4
Q125	2SC2712	1/2H BUFFER
Q126	2SC2712	H RT BUFFER
Q127	2SA1162	HD WIDTH SW-1
Q128	DTC144EKA	HD WIDTH SW-2
Q301	2SC2712	1/2H BUFFER-1
Q302	2SA1162	1/2H BUFFER-2
Q351	2SC2712	-12VPROT
Q352	2SA1162	+12VPROT
Q353	2SC2712	-5VPROT
Q354	DTC144ESA	+5VPROT
Q401	FMW5	H SIG1 SW-1
Q402	FMS1A	H SIG1 SW-2
Q403	2SA1162	H SIG1 BUFFER-1
Q404	2SC2712	H SIG1 BUFFER-2
Q451	2SC2712	1/2V BUFFER
Q452	2SC2712	V TR BUFFER
Q811	DTC144EKA	FH SW BUFFER
D101	1SR154-400TE-25	REG PROTECTOR-1
D102	1S2837	V SYNC CLAMP
D103	1SR154-400TE-25	REG PROTECTOR-2
D104	1S2837	SPEED UP-2
D105	1SR154-400TE-25	H OUT PROTECTOR
D106	1S2837	LIMITER-1
D107	1S2837	SPEED UP-3
D108	1SS123	LEVEL SHIFT-1
D109	1S2837	SPEED UP-1
D110	UDZ12B	LIMITER-3
D111	1S2837	AD HD SW
D112	1S2837	LIMITER-2
D113	1S2837	SPEED UP-4
D351	1SR154-400TE-25	REG PROTECTOR-3
D352	1SR154-400TE-25	REG PROTECTOR-4
D353	UDZ10B	LIMITER-4
D354	UDZ3.6B	LIMITER-5
D355	UDZ5.6B	LIMITER-6
D356	1S2837	LEVEL SHIFT-2


DA (1/2) BOARD




DA BOARD (1/2) IC110
UPC1377C




DA BOARD (1/2) IC106
MC-8369A




DA BOARD (2/3) IC301
CXA1726AM




DA BOARD (2/3) IC451
CXA1470AS



DA BOARD (2/3) IC303, 406
AD835AR




DA (2/2) BOARD



DB BOARD

DB BOARD (A SIDE)

D601	H-5	RV702	E-4
D602	H-6	RV703	E-6
D605	D-3	RV704	F-4
D901	A-2		
D902	A-2	TP101	G-4
		TP201	G-4
IC101	G-3	TP301	F-4
IC102	F-5	TP401	F-4
IC201	H-4	TP501	C-5
IC202	G-5	TP502	C-5
IC203	G-4	TP601	D-4
IC301	F-3	TP602	D-4
IC302	E-5	TP603	H-5
IC401	F-3	TP701	E-4
IC402	F-5	TP702	E-4
IC403	F-4		
IC501	C-5		
IC503	C-5		
IC601	D-5		
IC602	D-4		
IC603	C-4		
IC604	C-5		
IC606	C-3		
IC607	D-3		
IC608	C-2		
IC609	C-4		
IC610	C-3		
IC612	H-5		
IC613	H-6		
IC614	D-2		
IC701	D-5		
IC702	E-4		
IC703	E-5		
IC901	B-6		
IC902	B-5		
IC903	B-6		
IC904	A-6		
IC905	A-4		
IC906	A-5		
IC907	B-5		
IC908	A-3		
IC909	A-2		
IC910	B-2		
IC911	A-4		
IC912	B-4		
IC913	A-6		
Q103	G-2		
Q104	G-2		
Q107	G-3		
Q108	G-3		
Q203	H-2		
Q204	G-2		
Q207	H-3		
Q208	G-3		
Q303	F-2		
Q304	F-2		
Q307	F-3		
Q308	F-3		
Q403	F-2		
Q404	F-2		
Q407	F-3		
Q408	F-3		
Q503	D-3		
Q504	D-3		
Q601	D-4		
Q602	D-4		
Q605	D-4		
Q606	C-4		
Q611	D-3		
Q701	E-3		
Q702	E-2		
Q705	E-3		
Q706	F-3		
Q709	B-2		
Q712	C-2		
Q901	A-3		
Q902	B-3		
RV101	G-5		
RV102	G-6		
RV201	G-5		
RV202	G-6		
RV301	F-5		
RV302	E-6		
RV401	F-5		
RV402	F-6		
RV501	B-6		
RV502	B-6		
RV601	D-6		
RV602	D-5		
RV603	C-6		
RV604	C-5		
RV701	D-6		




DB -A SIDE-
SUFFIX: -11

DB BOARD


DB BOARD (B SIDE)

- D604 A-1
- D603 A-1
- IC911 A-4
- Q101 G-2
- Q102 G-2
- Q105 G-3
- Q106 G-3
- Q201 H-2
- Q202 G-2
- Q205 H-3
- Q206 G-3
- Q301 F-2
- Q302 F-2
- Q305 F-3
- Q306 F-3
- Q401 G-2
- Q402 F-2
- Q405 G-3
- Q406 F-3
- Q501 E-3
- Q502 D-2
- Q603 D-4
- Q604 D-4
- Q607 D-4
- Q608 C-4
- Q609 A-1
- Q610 A-1
- Q612 A-2
- Q613 C-2
- Q614 D-2
- Q703 E-2
- Q704 E-2
- Q707 E-3
- Q708 E-2
- Q710 C-2
- Q711 B-2
- Q903 A-4
- Q904 B-3
- RV101 G-5
- RV102 G-7
- RV201 G-5
- RV202 G-7
- RV301 F-5
- RV302 E-7
- RV401 F-5
- RV402 F-7
- RV501 B-7
- RV502 B-7
- RV601 D-7
- RV602 D-5
- RV603 C-7
- RV604 D-5
- RV701 D-7
- RV702 E-4
- RV703 E-7
- RV704 E-4



DB -B SIDE-
SUFFIX: -11

DB BOARD WAVEFORMS




DB BORAD FUNCTIONS


REF	TYPE NAME	FANCTION
IC101	PC74HC4053D-T	REG SW-1
IC102	AD835AR	REG MULTIPLEX-1
IC201	PC74HC4053D-T	REG SW-2
IC202	AD835AR	REG MULTIPLEX-2
IC203	AD828AR	REG BUFFER-1
IC301	PC74HC4053D-T	REG SW-3
IC302	AD835AR	REG MULTIPLEX-3
IC401	PC74HC4053D-T	REG SW-4
IC402	AD835AR	REG MULTIPLEX-4
IC403	AD828AR	REG BUFFER-2
IC501	AD826AR	KEY BUFFER
IC503	AD828AR	KEY ADDER
IC601	AD835AR	REG MULTIPLEX-5
IC602	AD828AR	REG BUFFER-3
IC603	AD828AR	REG BUFFER-4
IC604	AD835AR	REG MULTIPLEX-6
IC606	UPC814G2	INVERTER-1
IC607	PC74HC4053D-T	REG INVERT SW
IC608	UPC814G2	INVERTER-2
IC609	AD828AR	INVERTER-3
IC612	LM2990SX	-5V REG
IC613	BA05FP	+5V REG
IC614	TC7W04F	INVERT SW BUFFER
IC701	AD835AR	REG MULTIPLEX-7
IC702	AD828AR	REG BUFFER-5
IC703	AD835AR	REG MULTIPLEX-8
IC901	AD828AR	INVERTER-4
IC902	PC74HC4053D-T	REG SW-5
IC903	AD828AR	REG BUFFER-6
IC904	AD835AR	REG MULTIPLEX-9
IC905	AD828AR	C. BLK ADDER
IC906	UPC319G2	C. BLK COMPARATOR
IC907	SN74HC32ANS	C. BLK OR
IC908	UPC4558G2	C. BLK GEN-1
IC909	UPC814G2	C. BLK GEN-2
IC910	PC74HC4053D-T	SAMPLE HOLD SW
IC911	TL431CLP-Z	VOLTAGE REF
IC912	UPC814G2	SAMPLE HOLD BUFFER
IC913	UPC814G2	REG GEN
Q101	2SA1162	ZONE 20 BUFFER
Q102	2SC2712	ZONE 21 BUFFER
Q103	FMS1A	ZONE 21 SW
Q104	FMW5	ZONE 20 SW
Q105	2SA1162	ZONE 19 BUFFER
Q106	2SC2712	ZONE 18 BUFFER
Q107	FMW5	ZONE 19 SW
Q108	FMS1A	ZONE 18 SW
Q201	2SA1162	ZONE 14 BUFFER
Q202	2SC2712	ZONE 12 BUFFER
Q203	FMW5	ZONE 14 SW
Q204	FMS1A	ZONE 12 SW
Q205	2SA1162	ZONE 15 BUFFER
Q206	2SC2712	ZONE 13 BUFFER
Q207	FMW5	ZONE 15 SW
Q208	FMS1A	ZONE 13 SW
Q301	2SA1162	ZONE 17 BUFFER
Q302	2SC2712	ZONE 16 BUFFER
Q303	FMW5	ZONE 17 SW
Q304	FMS1A	ZONE 16 SW
Q305	2SA1162	ZONE 11 BUFFER
Q306	2SC2712	ZONE 10 BUFFER
Q307	FMW5	ZONE 11 SW
Q308	FMS1A	ZONE 10 SW
Q401	2SA1162	ZONE 8 BUFFER
Q402	2SC2712	ZONE 9 BUFFER
Q403	FMW5	ZONE 8 SW
Q404	FMS1A	ZONE 9 SW
Q405	2SA1162	ZONE 7 BUFFER
Q406	2SC2712	ZONE 6 BUFFER


REF	TYPE NAME	FANCTION
Q407	FMW5	ZONE 7 SW
Q408	FMS1A	ZONE 6 SW
Q501	2SA1162	SIT T BUFFER
Q502	2SC2712	SIN B BUFFER
Q503	FMW5	SIN T SW
Q504	FMS1A	SIN B SW
Q601	FMW5	PIN R SW
Q602	FMS1A	PIN L SW
Q603	2SA1162	PIN R BUFFER
Q604	2SC2712	PIN L BUFFER
Q605	FMW5	PIN B SW
Q606	FMS1A	PIN T SW
Q607	2SA1162	PIN B BUFFER
Q608	2SC2712	PIN T BUFFER
Q609	2SC2712	-5V PROT-1
Q610	DTIC144EKA	-5V PROT-2
Q611	2SA1162	5V PROT-1
Q612	DTIC144EKA	5V PROT-2
Q613	DTIC144EKA	INV SW BUFFER-1
Q614	DTIC144EKA	INV SW BUFFER-2
Q701	FMW5	ZONE 24 SW
Q702	FMS1A	ZONE 25 SW
Q703	2SA1162	ZONE 24 BUFFER
Q704	2SC2712	ZONE 25 BUFFER
Q705	FMW5	ZONE 22 SW
Q706	FMS1A	ZONE 23 SW
Q707	2SA1162	ZONE 22 BUFFER
Q708	2SC2712	ZONE 23 BUFFER
Q709	FMW5	SIN L SW
Q710	2SA1162	SIN L BUFFER
Q711	2SC2712	SIN R BUFFER
Q712	FMS1A	SIN R SW
Q901	FMW5	V SAW 1 SW
Q902	FMS1A	V SAW 2 SW
Q903	2SA1162	V SAW 1 BUFFER
Q904	2SC2712	V SAW 2 BUFFER
D601	1SR154-400TE-25	REG PROTECTOR-1
D602	1SR154-400TE-25	REG PROTECTOR-2
D603	UDZ3 6B	LIMITER-1
D604	MA111	LIMITER-2
D605	UDZ5.1B	LIMITER-3
D901	MA111	V SAW RECT-1
D902	MA111	V SAW RECT-2

DB BOARD (1/2) IC601, 604, 701, 703
DB BOARD (2/2) IC102, 202, 302, 402
AD835AR



DB (1/2) BOARD



DB (2/2) BOARD

DC DC


DC BOARD

1

2

3

4



DC -A SIDE-
SUFFIX: -11

5

10-76

10-76

VPH-G90, G90E/G90U/G90M

A

B

C


D

E**F**

G

H


DC BOARD



DC -B SIDE-
SUFFIX: -11


NA BOARD

1



2


NA -A SIDE-
SUFFIX: -11



3


NA -B SIDE-
SUFFIX: -11

4




5

DC BOARD WAVEFORMS



DC DC

DC BOARD




DD BOARD

DD BOARD (A SIDE)

D101 G-6
D102 G-4
D105 A-4
D106 A-4
D301 A-5
D302 A-5

IC101 E-2
IC102 E-2
IC103 D-2
IC104 C-2
IC105 C-2
IC106 B-2
IC107 E-3
IC108 E-3
IC109 D-3
IC110 C-3
IC111 B-3
IC112 B-3
IC113 A-2
IC114 H-6
IC115 H-5
IC116 A-4
IC117 A-3
IC118 D-2
IC301 B-6
IC302 B-6
IC303 C-6
IC304 D-6
IC305 E-6
IC306 E-6
IC307 B-5
IC308 B-5
IC309 C-5
IC310 D-5
IC311 E-5
IC312 E-5
IC313 H-2
IC314 H-2
IC315 H-3
IC316 H-3
IC317 H-4
IC322 A-5
IC323 A-3
IC450 B-4
IC451 B-4
IC452 C-4
IC453 D-4
IC454 E-4
IC455 E-4

RV301 G-6
RV302 G-6
RV303 G-6
RV304 G-5
RV305 G-5
RV306 G-4




DD -A SIDE-
SUFFIX: -11

DD BOARD

DD BOARD (B SIDE)

- D103 A-1
- D104 A-2
- IC117 A-3
- Q101 A-1
- Q102 A-2
- RV301 G-6
- RV302 G-6
- RV303 G-6
- RV304 G-5
- RV305 G-5
- RV306 G-4



DD -B SIDE-
SUFFIX: -11

DD BORAD FUNCTIONS

REF	TYPE NAME	FUNCTION
IC101	MP7670AS	SIZE VSKEW ADJ
IC102	MP7670AS	V BOW PIN ADJ
IC103	MP7670AS	H LIN ADJ
IC104	MP7670AS	H BOW SKEW ADJ
IC105	MP7670AS	H KEY SKEW ADJ
IC106	MP7670AS	H CENT ADJ
IC107	MP7670AS	ZONE 4 ADJ
IC108	MP7670AS	ZONE 2. 3 ADJ
IC109	MP7670AS	L/R PIN ADJ
IC110	MP7670AS	T/B PIN ADJ
IC111	MP7670AS	L/R KEY ADJ
IC112	MP7670AS	T/B KEY ADJ
IC113	TC74HC541AF	DATA BUFFER
IC114	BA05FP	+5V REG
IC115	LM2990SX	-5V REG
IC116	RH5VL43AA	P-ON RESET-1
IC117	TL431CLP-Z	VOLTAGE REF
IC118	AD826AR	H PARA BUFFER
IC301	MP7670AS	ZONE 17 ADJ
IC302	MP7670AS	ZONE 18 ADJ
IC303	MP7670AS	ZONE 19 ADJ
IC304	MP7670AS	ZONE 20 ADJ
IC305	MP7670AS	ZONE 21. 22 ADJ
IC306	MP7670AS	ZONE 23. 24. 25 ADJ
IC307	MP7670AS	ZONE 11 ADJ
IC308	MP7670AS	ZONE 12 ADJ
IC309	MP7670AS	ZONE 13 ADJ
IC310	MP7670AS	ZONE 14 ADJ
IC311	MP7670AS	ZONE 15 ADJ
IC312	MP7670AS	ZONE 16 ADJ
IC313	AD828AR	SUB BUFFER AMP-1
IC314	AD828AR	SUB BUFFER AMP-2
IC315	AD828AR	SUB BUFFER AMP-3
IC316	AD828AR	MOD BUFFER AMP-1
IC317	AD828AR	MOD BUFFER AMP-2
IC322	RH5VL43AA	P-ON RESET-2
IC323	AD828AR	C. BLK BUFFER AMP
IC450	MP7670AS	ZONE 5 ADJ
IC451	MP7670AS	ZONE 6 ADJ
IC452	MP7670AS	ZONE 7 ADJ
IC453	MP7670AS	ZONE 8 ADJ
IC454	MP7670AS	ZONE 9 ADJ
IC455	MP7670AS	ZONE 10 ADJ
Q101	2SC2712	-5V PROT
Q102	DTC144EKA	5V PROT
D101	1SR154-400TE-25	REG. PROTECTOR-1
D102	1SR154-400TE-25	REG. PROTECTOR-2
D103	UDZ3.6B	LIMITER-1
D104	MA111	LIMITER-2
D105	MA111	RESET-1
D106	MA111	DISCHARGE-1
D301	MA111	DISCHARGE-2
D302	MA111	RESET-2


DD MOUNT (1/2) VOLTAGES

Pin No.	IC101	IC102	IC103	IC104	IC105	IC106	IC107	IC108	IC109	IC110
1	0.1 (0)	0.1 (0)	0	0.1 (0)	0.7 (0)	0.7 (0)	0	0.1 (0)	0.1 (0)	0.1 (0)
2	0.1 (0)	0.2 (0)	0.4 (0)	0.1 (0)	0.3 (0)	0.3 (0)	0	0.1 (0)	0.1 (0)	0.1 (0)
3	0.1 (0)	0	0	0	0.1 (0)	1 (0)	0	0.1 (0)	0.1 (0)	0
4	0	0.6 (0.5)	0.6 (0.5)	0	2.2	2.2	0.5 (0)	0.3 (0)	0	0
5	0	0.6 (0.5)	0	0	2.2	2.2	0.5 (0)	0.3 (0)	0	0
6	GND	GND	GND	GND	GND	GND	GND	GND	GND	GND
7	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9
8	0	0.6 (0.5)	0.6 (0.5)	0.5 (0.3)	0	2.2	0.5 (0)	-0.3 (-0.2)	0	0
9	0	0.6 (0.5)	0.6 (0.5)	0.5 (0.3)	0	2.2	0.5 (0)	-0.3 (-0.2)	0	0
10	0	0	0	0.1 (0)	0	0.4 (0)	0.1 (0)	0.1 (0)	0	0.1 (0)
11	0.1 (0)	0.1 (0)	0	0.1 (0)	0.1 (0)	0.2 (0)	0.1 (0)	0.1 (0)	0	0.1 (0)
12	0.1 (0)	0	0.1 (0)	0.1 (0)	0	0.4 (0)	0.1 (0)	0.1 (0)	0	2.5 (0)
13	0.1 (0)	0	0.1 (0)	0.1 (0)	0.1 (0)	0	0	-0.6 (-0.5)	0	2.5
14	0	0	0.6 (0.5)	0.5 (0.3)	0	2.2	0.5 (0)	-0.3 (-0.2)	0	0 (2.4)
15	0	0	0	0.5 (0.3)	0	2.2	0	0.6 (0.5)	0	0 (2.4)
16	0	0	0	0	0	0	0	0	0	0 0
17	0	0	0	0	0	0	0	0	0	0 0
18	N.C	4.9 (0)	4.9 (0)	4.9 (0)	4.9 (0)	4.9 (0)	N.C	4.9	4.9	4.9
19	-5	-5	-5	-5	-5	-5	-5	-5	-5	-5
20	4.9 (0)	4.9 (0)	4.9 (0)	4.9 (0)	4.9 (0)	0	4.9	4.9	4.9	4.9
21	5	5	5	5	5	5	5	5	5	5
22	0	0.6 (0.5)	0.6 (0.5)	0.5 (0.3)	0.5 (0.3)	2.2	0.5 (0)	0	0	0
23	0	0.6 (0.5)	0.6 (0.5)	0.5 (0.3)	0	2.2	0.5 (0)	0.3 (0)	0	0
24	0.1 (0)	0.1 (0)	0	0	0	0	0.5 (0)	0	0	0

Pin No.	IC111	IC112
1	0.1 (0)	0.1 (0)
2	0.1 (0)	0.1 (0)
3	0.1 (0)	0
4	0	0
5	0	0
6	GND	GND
7	4.9	4.9
8	0	0
9	0	0
10	0.1 (0)	0.1 (0)
11	0.1 (0)	0
12	0.1 (0)	0
13	0.1 (0)	0
14	0	0.6
15	0	0.6
16	0	0.6
17	0	0
18	4.9	4.9
19	-5	-5
20	4.9	4.9 (0)
21	5	5
22	0	0
23	0	0
24	0	0


Note: No Mark is VIDEO signal and common. () Mark is Component signal.

DD (1/2) BOARD



DD (1/2)
(SUB WAVE CONT.)

DD BOARD (1/2) IC101-112
DD BOARD (2/2) IC301-312, 450-455
MP7670AS




DD MOUNT (2/2) VOLTAGES

Pin No.	IC301	IC302	IC303	IC304	IC305	IC306	IC307	IC308	IC309	IC310
1	0.1 (0)	0.1 (0)	0	0.1 (0)	0	0	0	0	0	0
2	0.1 (0)	0.1 (0)	0	0	0.1 (0)	0	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
3	0.1 (0)	0.1 (0)	0	0	0.1 (0)	0	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
4	0.1 (0)	-0.2 (0)	0.2 (0)	0.2 (0)	-0.2	-0.2	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
5	0.1 (0)	-0.2 (0)	0.2 (0)	0.2 (0)	-0.2	-0.2	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
6	GND	GND	GND	GND	GND	GND	GND	GND	GND	GND
7	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9
8	0.1 (0)	-0.2 (0)	0.2 (0)	0.2 (0)	-0.2 (0)	0.2	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
9	0.1 (0)	-0.2 (0)	0.2 (0)	0.2 (0)	-0.2 (0)	-0.3	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
10	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
11	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
12	0.1 (0)	0	0	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
13	N.C	N.C	N.C	0.1 (0)	0.1 (0)	0.1 (0)	N.C	N.C	N.C	N.C
14	0.1 (0)	-0.2 (0)	0.2 (0)	-0.2	0.2 (0)	-0.3	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
15	0	0	GND	-0.2	-0.2	-0.3	GND	GND	GND	GND
16	0	0	0	0	0	0	0	0	0	0
17	0	0	0	0	0	0	0	0	0	0
18	4.9	4.9	4.9	4.9	4.9	4.9	4.9 (0)	4.9 (0)	4.9 (0)	4.9 (0)
19	-5	-5	-5	-5	-5	-5	-5	-5	-5	-5
20	0	4.9	4.9	4.9	4.9	4.9	0	4.9 (0)	4.9 (0)	4.9 (0)
21	5	5	5	5	5	5	5	5	5	5
22	GND	GND	GND	0.2 (0)	-0.2	0.2	GND	GND	GND	GND
23	0.1 (0)	-0.2 (0)	0.2 (0)	0.2 (0)	-0.2	0.2	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
24	N.C	N.C	N.C	0	0.1 (0)	0	N.C	N.C	N.C	N.C

Pin No.	IC311	IC312	IC450	IC451	IC452	IC453	IC454	IC455
1	0	0	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
2	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
3	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
4	0.1 (0)	0.1 (0)	-0.5 (-0.4)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
5	0.1 (0)	0.1 (0)	-0.5 (-0.4)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
6	GND	GND	GND	GND	GND	GND	GND	GND
7	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9
8	0.1 (0)	0.1 (0)	-0.5 (-0.4)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
9	0.1 (0)	0.1 (0)	-0.5 (-0.4)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
10	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
11	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
12	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
13	N.C	N.C	N.C	N.C	N.C	N.C	N.C	N.C
14	0.1 (0)	0.1 (0)	-0.5 (-0.4)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
15	GND	GND	GND	GND	0	GND	GND	GND
16	0	0	0	0	0	0	0	0
17	0	0	0	0	0	0	0	0
18	4.9 (0)	N.C	4.9 (0)	4.9 (0)	4.9 (0)	4.9 (0)	4.9 (0)	N.C
19	-5	-5	-5	-5	-5	-5	-5	-5
20	4.9 (0)	4.9 (0)	0	4.9 (0)	4.9 (0)	4.9 (0)	4.9 (0)	4.9 (0)
21	5	5	5	5	5	5	5	5
22	GND	GND	GND	2.2	GND	GND	GND	GND
23	0.1 (0)	0.1 (0)	-0.5 (-0.4)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)	0.1 (0)
24	N.C	N.C	N.C	0.1 (0)	N.C	N.C	N.C	N.C

Note: No Mark is VIDEO signal and common. () Mark is Component signal.

DD (2/2) BOARD



DE BOARD


DE BOARD (A SIDE)

D1 E-1
D2 E-1
D3 B-7
D4 A-1
D5 B-1
D6 D-1
D7 A-6
D8 B-5
D9 B-6

IC1 D-1
IC2 F-1
IC4 A-2
IC5 B-2
IC6 A-1
IC7 B-8
IC8 B-2
IC9 A-1
IC10 C-2
IC11 A-1
IC12 A-6
IC13 A-8
IC15 B-3
IC17 A-3
IC19 A-4
IC100 C-7
IC101 D-8
IC102 E-7
IC104 F-2
IC105 F-3
IC106 C-6
IC107 D-6
IC108 E-6
IC110 E-3
IC111 C-5
IC112 D-5
IC113 E-5
IC115 F-4
IC116 F-4
IC117 C-4
IC118 D-4
IC119 E-4
IC121 F-5
IC122 F-5
IC123 C-3
IC124 D-3
IC125 E-3
IC127 F-6
IC128 F-6
IC129 C-2
IC130 D-2
IC131 E-2
IC133 F-7

Q1 B-7
Q2 B-6
Q3 B-6
Q4 A-7
Q5 B-4
Q6 B-4
Q7 A-7
Q8 B-4
Q9 A-4
Q10 B-7
Q11 B-6
Q12 A-5
Q13 A-6
Q14 A-4
Q15 A-4
Q16 A-4
Q17 A-4
Q134 B-6

TP1 A-2
TP2 A-6
TP3 F-8
TP4 A-4



DE -A SIDE-
SUFFIX: -11

DE DE


DE BOARD

DE BOARD (B SIDE)

D1	E-7
D2	E-8
D5	C-8
D6	D-8


IC7	B-1
IC10	C-7
IC19	A-4

TP1	A-7
TP2	A-2
TP3	F-1
TP4	A-5




DE -B SIDE-
SUFFIX: -11

DE BOARD WAVEFORMS

1	①  10.6 V p-p (H)	②  4.3 V p-p (H)	③  2.3 V p-p (V)	④  2.6 V p-p (V)	⑤  3.1 V p-p (H)
	⑥  2.5 V p-p (H)	⑦  1.7 V p-p (V)	⑧  0.9 V p-p (V)	⑨  1.3 V p-p (V)	⑩  2.0 V p-p (H)
2	⑪  2.1 V p-p (V)	⑫  0.5 V p-p (V)			


DE (1/2) BOARD



DE (1/2)
(MG WAVE GEN.)

B-XS1640-AEP>>DE-1

DE BOARD (1/2) IC19
CXA1470AS




DE MOUNT (2/2) VOLTAGES

Pin No.	IC100	IC101	IC102	IC106	IC107	IC108	IC111	IC112	IC113	IC117
1	-0.6 (-0.4)	0.1 (0)	0	0	0	0	0	0	0	0
2	0	0 (0.1)	0	0	0	0	0	0	0	0
3	0	0.1 (0.2)	0	0	0	0	0	0	0	0
4	0	0.3 (0.4)	0	2.3	0.3 (0.4)	0	0	0.3 (0.5)	0	0
5	0	0.3 (0.4)	0	2.3	0.3 (0.4)	0	0	0.3 (0.5)	0	0
6	GND	GND	GND	GND	GND	GND	GND	GND	GND	GND
7	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9
8	2.3 (0)	0.3 (0.4)	0	2.3	0.3 (0.4)	0	0	0.3 (0.5)	0	0
9	2.3 (2.4)	0.3 (0.4)	0	2.3	0.3 (0.4)	0	0	0.3 (0.5)	0	0
10	0.7 (0)	0	0	0	0	0	0	0	0	0
11	-0.4 (-0.1)	0	0	0	0	0	0	0	0	0
12	-0.4 (0)	0	0	0	0	0	0	0	0	0
13	0	0	0	0 (0.1)	N.C	N.C	0	0	0	N.C
14	0	0.3 (0.4)	0	2.3	0.3 (0.4)	0	0	0.3 (0.5)	0	0
15	0	0.3 (0.4)	0	2.3	GND	GND	0	0.3 (0.5)	0	GND
16	0	0	0	0	0	0	0	0	0	0
17	0	0	0	0	0	0	0	0	0	0
18	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9
19	-5	-5	-5	-5	-5	-5	-5	-5	-5	-5
20	0	0	0	4.9	4.9	4.9	4.9	4.9	4.9	4.9
21	5	5	5	5	5	5	5	5	5	5
22	-0.9 (-1.1)	0.3 (0.4)	0	2.3	0.3 (0.4)	0	0	0.3 (0.5)	0	0
23	-0.9 (-0.5)	0.3 (0.4)	0	2.3	0.3 (0.4)	0	0	0.3 (0.5)	0	0
24	-0.9 (-1.1)	0	0	0	0	0	0	0	0	0

Pin No.	IC118	IC119	IC123	IIC124	IC125	IC129	IC130	IC131
1	0	0	0	0	0	0	0	0
2	0	0	0	0	0	0	0	0
3	0	0	0	0	0	0	0	0
4	0.3 (0.5)	0	0	0	0	0	0	0
5	0.3 (0.5)	0	0	0	0	0	0	0
6	GND	GND	GND	GND	GND	GND	GND	GND
7	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9
8	0.3 (0.5)	0	0	0	0	0	0	0
9	0.3 (0.5)	0	0	0	0	0	0	0
10	0	0	0	0	0	0	0	0
11	0	0	0	0	0	0	0	0
12	0	0	0	0	0	0	0	0
13	N.C	N.C	0	0	0	0	0	0
14	0.3 (0.5)	0	0	0	0	0	0	0
15	GND	GND	0	0	0	GND	GND	GND
16	0	0	0	0	0	0	0	0
17	0	0	0	0	0	0	0	0
18	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9
19	-5	-5	-5	-5	-5	-5	-5	-5
20	4.9	4.9	4.9	4.9	4.9	4.9	4.9	4.9
21	5	5	5	5	5	5	5	5
22	0.3 (0.5)	0	0	0	0	0	0	0
23	0.3 (0.5)	0	0	0	0	0	0	0
24	0	0	0	0	0	0	0	0

Note: No Mark is VIDEO signal and common. () Mark is Component signal.

DE (2/2) BOARD



DF BOARD


DF BOARD (A SIDE)

D1 F-3
D2 F-2
D100 A-5
D101 C-4
D102 C-4
D104 A-7
D105 A-5
D106 C-6
D107 C-6
D108 A-6
D109 B-8
D110 C-8
D111 C-8
D112 C-2
D113 C-3

IC2 B-3
IC3 A-4
IC4 A-1
IC8 G-3
IC9 G-2
IC10 A-3
IC11 A-2
IC100 B-7
IC101 C-4
IC102 E-1
IC103 A-8
IC104 C-5
IC105 D-2
IC106 C-7
IC107 E-3
IC108 C-1
IC109 C-2
IC110 A-7
IC201 F-1
IC202 F-1
IC205 F-2
IC208 F-3
IC209 F-2
IC212 E-3

Q1 B-3
Q2 A-2
Q3 B-3
Q4 B-3
Q5 B-4
Q6 A-3
Q101 B-7
Q102 B-7
Q201 E-4
Q202 E-4
Q203 F-4
Q204 F-4
Q205 E-4
Q206 E-5
Q207 F-4
Q208 F-5
Q209 E-5
Q210 E-5
Q211 F-5
Q212 F-5
Q213 E-6
Q214 E-6
Q215 F-6
Q216 F-6
Q217 E-7
Q218 E-7
Q219 F-7
Q220 F-7
Q221 E-7
Q222 E-8
Q223 F-7
Q224 F-8


TP1 A-1
TP2 A-3
TP3 A-3
TP102 D-1
TP201 F-8



DF -A SIDE-
SUFFIX: -11

DF BOARD


DF BOARD (B SIDE)




DF -B SIDE-
SUFFIX: -11

- | | |
|-------|-----|
| D1 | F-6 |
| D2 | F-6 |
| D100 | A-4 |
| D101 | C-5 |
| D102 | C-5 |
| D104 | A-1 |
| D105 | A-3 |
| D106 | C-3 |
| D107 | C-3 |
| D108 | A-2 |
| D109 | B-1 |
| D110 | C-1 |
| D111 | C-1 |
| D112 | C-7 |
| D113 | C-6 |
| D201 | E-5 |
| D202 | E-5 |
| D203 | E-4 |
| D204 | E-4 |
| D205 | E-4 |
| D206 | E-3 |
| D207 | F-6 |
| D208 | E-3 |
| D209 | E-3 |
| D210 | E-2 |
| D211 | E-2 |
| D212 | E-2 |
| D213 | E-1 |
| IC1 | A-7 |
| IC3 | A-5 |
| IC5 | B-4 |
| IC8 | G-6 |
| IC9 | G-7 |
| IC20 | A-7 |
| IC101 | C-5 |
| IC106 | C-2 |
| IC106 | C-3 |
| IC108 | C-7 |
| IC109 | C-7 |
| IC203 | D-5 |
| IC204 | D-4 |
| IC205 | F-7 |
| IC206 | D-3 |
| IC207 | F-6 |
| IC210 | D-3 |
| IC211 | D-2 |
| IC213 | D-1 |
| Q2 | A-7 |
| Q100 | B-4 |
| Q103 | B-3 |
| Q104 | B-2 |
| Q105 | B-1 |
| Q106 | A-2 |
| Q201 | E-5 |
| Q202 | E-5 |
| Q203 | F-5 |
| Q204 | F-5 |
| Q205 | E-4 |
| Q206 | E-4 |
| Q207 | F-4 |
| Q208 | F-4 |
| Q209 | E-4 |
| Q210 | E-3 |
| Q211 | F-4 |
| Q212 | F-3 |
| Q213 | E-3 |
| Q214 | E-3 |
| Q215 | F-3 |
| Q216 | F-3 |
| Q217 | E-2 |
| Q218 | E-2 |
| Q219 | F-2 |
| Q220 | F-2 |
| Q221 | E-2 |
| Q222 | E-1 |
| Q223 | F-2 |
| Q224 | F-1 |
| TP1 | A-8 |
| TP2 | A-6 |
| TP3 | A-6 |
| TP102 | D-7 |
| TP201 | F-1 |


DF BOARD WAVEFORMS




DF (1/3) BOARD




B-NSX1640-AEP>-DF

DF (2/3) BOARD


DF (3/3) BOARD




DF BOARD (1/3) IC3
CXA1470AS




DF BOARD (2/3) IC102, 105, 107
DF BOARD (3/3) IC201, 209, 212
MP7670AS




L BOARD



L -A SIDE-
SUFFIX: -11



L -B SIDE-
SUFFIX: -11



E BOARD


1

2

3

4


5



E -A SIDE-
SUFFIX: -11


E E

E BOARD




E -B SIDE-
SUFFIX: -11

E BOARD WAVEFORMS




E BOARD



ED BOARD (A SIDE)

- | | |
|--------|-----|
| D1001 | B-1 |
| D1002 | C-1 |
| D1003 | B-1 |
| D1004 | B-3 |
| D1005 | B-3 |
| D1006 | C-3 |
| D1007 | C-5 |
| D1008 | B-6 |
| D1009 | B-6 |
| D1010 | A-6 |
| D1011 | B-3 |
| D1012 | B-2 |
| D1013 | C-5 |
| D1014 | C-6 |
| D1015 | B-2 |
| D1016 | D-2 |
| D1017 | B-2 |
| D1018 | C-3 |
| IC1001 | B-2 |
| IC1002 | C-2 |
| Q1001 | A-2 |
| Q1003 | D-2 |
| Q1007 | A-4 |
| Q1009 | B-4 |
| Q1010 | A-5 |
| Q1011 | B-3 |
| Q1012 | A-4 |
| Q1013 | B-5 |
| Q1014 | C-3 |


ED BOARD



ED -A SIDE-
SUFFIX: -11


ED BOARD (B SIDE)

- | | |
|--------|-----|
| D1001 | B-6 |
| D1002 | C-6 |
| D1003 | B-6 |
| D1004 | A-5 |
| D1005 | B-5 |
| D1006 | B-4 |
| D1007 | B-3 |
| D1008 | B-2 |
| D1009 | B-2 |
| D1010 | A-2 |
| D1011 | B-4 |
| D1012 | B-5 |
| D1013 | C-3 |
| D1014 | B-2 |
| D1015 | B-6 |
| D1016 | C-5 |
| D1017 | B-5 |
| D1018 | C-5 |
| IC1001 | B-5 |
| IC1002 | C-5 |
| IC1010 | C-1 |
| IC1011 | B-1 |
| IC1013 | B-1 |
| IC1014 | D-1 |
| Q1001 | B-6 |
| Q1003 | D-5 |
| Q1007 | B-3 |
| Q1009 | B-3 |
| Q1010 | A-2 |
| Q1011 | A-4 |
| Q1012 | A-3 |
| Q1013 | B-2 |
| Q1014 | C-5 |




ED -B SIDE-
SUFFIX: -11


ED BOARD



EA BOARD



EA -A SIDE-
SUFFIX: -11




EA -B SIDE-
SUFFIX: -11

EA BOARD (A SIDE)

D6	A-3
D12	B-3
IC2	A-1
IC3	B-1
Q15	B-4
TP1	B-3
TP2	A-3
TP3	A-3
TP4	A-1
TP5	A-1


EA BOARD WAVEFORMS



EA BOARD (B SIDE)

D1	B-1
D4	A-2
D5	B-2
D6	A-4
D7	A-1
D8	A-1
D9	B-1
D10	B-2
D11	A-3
D12	A-4
D13	B-1
IC1	B-5
IC2	A-6
IC3	B-6
IC4	B-4
IC5	A-4
IC6	A-1
IC7	A-5
IC8	B-5
IC9	A-3
IC12	B-3
Q1	B-6
Q2	B-6
Q3	A-2
Q4	B-1
Q5	A-1
Q6	B-1
Q7	B-1
Q8	A-3
Q9	B-2
Q10	A-2
Q11	B-2
Q12	B-4
Q13	B-3
Q14	A-2
Q15	B-4
Q16	B-3
Q17	A-3
Q18	A-3
Q19	B-2
Q20	B-3
Q21	B-2
Q22	B-2
TP1	B-4
TP2	B-4
TP3	A-4
TP4	A-6
TP5	A-6

EA BOARD



PA PA

PA BOARD (A SIDE)

D1	H-8	TP102	I-10
D2	H-10	TP103	J-7
D3	H-8	TP150	I-6
D100	I-10	TP151	I-6
D101	I-9	TP152	H-6
D103	I-6	TP250	J-8
D105	I-8	TP251	J-9
D120	J-7	TP252	J-9
D140	J-6	TP253	J-9
D150	I-5	TP300	I-2
D151	H-6	TP600	F-10
D152	H-6	TP601	F-10


IC1	H-9
IC2	H-9
IC100	I-10
IC101	J-8
IC102	J-8
IC150	I-5
IC151	I-6
IC152	I-8
IC153	I-7
IC154	H-6
IC200	H-4
IC250	J-6
IC251	J-5
IC300	I-3
IC301	J-2
IC302	J-3
IC500	I-2

Q10	H-8
Q11	H-8
Q100	I-9
Q150	I-9
Q151	I-9
Q152	I-7
Q153	I-7
Q154	I-6
Q155	H-6
Q200	H-3
Q201	H-4
Q202	I-4
Q203	I-4
Q204	I-4
Q250	H-10
Q251	I-6
Q252	H-5
Q253	H-5
Q500	I-1
Q501	I-1
Q502	H-1
Q503	H-2
Q504	H-2
Q505	H-1
Q506	H-2
Q507	H-1
Q508	H-1
Q600	C-7
Q601	C-5
Q602	C-3

RV100	I-10
RV101	J-9
RV150	I-9
RV250	J-10

TP1	H-8
TP2	H-8
TP3	H-9
TP100	J-10
TP101	I-10


PA BOARD



PA -A SIDE-
SUFFIX: -11

PA PA

PA BOARD




PA BOARD (B SIDE)

D1	H-2	TP102	I-1
D2	H-1	TP103	J-4
D3	H-2	TP150	I-5
D100	I-1	TP151	I-5
D101	I-2	TP152	H-4
D102	J-4	TP250	J-3
D103	I-5	TP251	J-2
D104	J-5	TP252	J-2
D105	I-2	TP253	J-2
D150	I-6	TP300	I-9
D151	H-5	TP600	F-1
D152	H-5	TP601	F-1
D200	I-8		
D201	I-7		
D202	I-7		
D250	J-6		
D251	I-1		
D252	I-6		
D253	I-6		
D254	H-6		
D300	I-8		
D301	I-8		
D500	I-9		
D600	C-5		
D601	C-5		
D602	C-5		
D603	C-7		
D604	C-7		
D605	C-7		
D606	B-9		
D607	C-9		
D608	C-9		
D609	C-2		
D610	C-3		
IC1	H-1		
IC2	H-1		
IC100	I-1		
IC101	J-4		
IC102	I-2		
IC150	I-6		
IC151	I-5		
IC152	I-3		
IC153	H-4		
IC154	H-5		
IC200	H-7		
IC250	J-5		
IC251	J-6		
IC300	I-8		
IC301	J-8		
IC302	J-8		
IC500	H-9		
Q10	H-3		
Q11	H-3		
Q100	I-2		
Q150	I-2		
Q151	H-2		
Q152	I-4		
Q153	I-4		
Q154	I-5		
Q155	H-5		
Q200	I-7		
Q201	H-7		
Q202	I-7		
Q203	I-7		
Q204	I-6		
Q250	H-1		
Q251	I-5		
Q252	H-5		
Q253	H-6		
Q500	I-10		
Q501	I-10		
Q502	H-10		
Q503	H-9		
Q504	H-9		
Q505	H-9		
Q506	H-9		
Q507	H-10		
Q508	H-10		
Q600	C-4		
Q601	C-6		
Q602	C-9		
RV100	I-1		
RV101	I-2		
RV150	I-2		
RV250	J-1		
TP1	H-3		
TP2	H-3		
TP3	I-2		
TP100	J-1		
TP101	I-1		

PA -B SIDE-
SUFFIX: -11


PA (1/2) BOARD




PA (1/2)
(HV CONT)

B-SX1640-CAEP>-PA-1


PA (2/2) BOARD



PA BOARD WAVEFORMS




PB BOARD



PB -B SIDE-
SUFFIX: -11

PB PB



PD BOARD (A SIDE)




D500	E-2
D500	E-4
D501	F-4
D520	F-1
D521	G-1
D523	F-1
D527	A-3
D528	D-2
D529	E-2
D530	E-2
D531	G-2




PD, NB BOARD

PD, NB PD, NB




B-SX1640<AEP>-PD


PD BOARD IC502 MC14040BCP



PD BOARD WAVEFORMS




PE BOARD



PE BOARD (A SIDE)

D503	E-5	TP500	B-3
D501	A-4	TP501	B-3
D503	E-5	TP502	A-3
D504	E-5	TP503	B-4
D505	E-5	TP504	C-4
D506	D-6	TP505	E-6
D508	B-5		
D511	C-5		
D512	E-4		
D525	D-4		
D526	D-4		
IC2	B-2		
IC5	A-2		
IC500	A-3		
IC501	A-3		
Q3	A-2		
Q5	A-2		
Q500	C-5		
Q502	A-5		
Q504	B-4		
Q509	E-2		
Q513	E-3		
Q519	E-3		
Q524	D-4		

PE -A SIDE-
SUFFIX: -11




PE BOARD (B SIDE)


D500	E-2	IC6	A-5	Q522	C-5
D4	B-5	IC500	A-4	Q524	D-3
D6	A-5	IC501	A-4	Q525	A-3
D500	A-3	IC504	C-4		
D501	A-3	IC505	B-4	TP500	B-4
D502	A-4			TP501	B-4
D503	E-2	Q3	A-4	TP502	A-4
D504	E-2	Q5	A-5	TP503	B-3
D505	E-1	Q6	B-6	TP504	C-2
D506	D-1	Q7	B-6	TP505	E-1
D508	B-1	Q8	C-6		
D511	C-2	Q9	D-6		
D512	E-3	Q10	E-6		
D513	B-3	Q500	C-1		
D514	B-3	Q502	A-1		
D515	B-3	Q503	B-3		
D516	B-3	Q504	B-2		
D517	B-4	Q505	A-2		
D518	B-5	Q507	B-3		
D519	B-5	Q508	B-4		
D522	B-4	Q509	E-5		
D524	C-3	Q510	C-4		
D525	D-3	Q511	C-4		
D526	D-3	Q513	E-4		
D527	A-3	Q514	C-5		
		Q515	C-5		
IC2	B-4	Q516	C-3		
IC3	B-5	Q519	E-3		
IC5	A-5	Q521	B-6		

PE -B SIDE-
SUFFIX: -11

PE BOARD



PE BOARD WAVEFORMS



EBA BOARD

EBC BOARD


1

2


3

4


5




EBA -A SIDE-
SUFFIX: -11



EBA -B SIDE-
SUFFIX: -11




EBC -A SIDE-
SUFFIX: -11




EBC -B SIDE-
SUFFIX: -11


EBA BOARD



EBC BOARD



EBB BOARD




EBB BOARD (A SIDE)

D302 A-4
D303 A-4

IC350	C-5
IC351	C-6
IC353	A-5

Q302	A-4
Q303	A-5
Q304	C-1
Q305	C-2
Q306	A-2
Q307	A-3

EBB -A SIDE-
SUFFIX: -11



EBB BOARD (B SIDE)


D300	A-3
D301	A-2
D302	B-3
D303	B-2
D304	B-4
D305	B-5
D340	C-3
D341	C-2
D350	B-1
D351	C-1

IC350	C-1
IC351	C-1
IC352	B-1
IC353	A-2


Q302	A-3
Q303	A-3
Q304	B-5
Q305	B-5
Q306	A-5
Q307	A-4
Q340	C-3
Q341	C-2

EBB -B SIDE-
SUFFIX: -11

EBB BOARD



EBB BOARD WAVEFORMS



VPH-G90J/G90E/G90U/G90M

A

B

C

D

E

F


G

H

10-121

10-121

EBG BOARD




EBG BOARD (A SIDE)

D202	A-4
D203	A-4
IC250	C-5
IC251	C-6
IC253	A-5

Q202	A-4
Q203	A-5
Q204	C-1
Q205	C-2
Q206	A-2
Q207	A-3

EBG -A SIDE-
SUFFIX: -11



EBG BOARD (B SIDE)


D200	A-3
D201	A-2
D202	B-3
D203	B-2
D204	B-4
D205	B-5
D240	C-3
D241	C-2
D250	B-1
D251	C-1

IC250	C-1
IC251	C-1
IC252	B-1
IC253	A-2


Q202	A-3
Q203	A-3
Q204	B-5
Q205	B-5
Q206	A-5
Q207	A-4
Q240	C-3
Q241	C-2

EBG -B SIDE-
SUFFIX: -11

EBG BOARD



EBG BOARD WAVEFORMS



VPH-G90J/G90E/G90U/G90M

A

B

C

10-123
D


10-123
E

F

G

H


EBR BOARD



EBR BOARD (A SIDE)

- D102 A-2
- D103 A-3
- IC150 C-2
- IC151 C-1
- IC153 A-1
- Q102 A-2
- Q103 A-3
- Q104 C-5
- Q105 C-5
- Q106 A-5
- Q107 A-4

EBR -A SIDE-
SUFFIX: -11



EBR BOARD (B SIDE)


- D100 A-5
- D101 A-4
- D102 B-4
- D103 B-4
- D104 B-2
- D105 B-2
- D140 C-4
- D141 C-4
- D150 B-5
- D151 C-6
- IC150 C-5
- IC151 C-6
- IC152 B-5
- IC153 A-5
- Q102 A-4
- Q103 A-4
- Q104 C-1
- Q105 B-2
- Q106 A-1
- Q107 A-2
- Q140 C-4
- Q141 C-5

EBR -B SIDE-
SUFFIX: -11


EBR BOARD

EBR EBR

EBR (RED MG OUT)



EBR BOARD WAVEFORMS



VPH-G90J/G90E/G90U/G90M

A

B

C

D

E

F

G

H

10-125

10-125

EBH BOARD


1

2


3

4

5




EBH -A SIDE-
SUFFIX: -11




EBH -B SIDE-
SUFFIX: -11

EBH BOARD WAVEFORMS




EBH BOARD




EBQ BOARD

5




EBQ -A SIDE-
SUFFIX: -11




EBQ -B SIDE-
SUFFIX: -11

EBQ BOARD WAVEFORMS



EBQ BOARD



CAB BOARD (A SIDE)

D12 E-5
D13 D-4
D22 C-5
D24 C-4
D121 C-2
D155 C-2
D501 C-2
D511 B-2
D512 B-3
D581 C-3
D651 A-4
D652 A-4
D672 B-4
D726 A-1
D737 A-2
D738 A-2
D761 A-2


IC12 D-4
IC22 C-5
IC24 C-5
IC101 D-4
IC102 D-2
IC141 D-2
IC171 C-3
IC560 B-4
IC570 B-3
IC595 B-3
IC781 B-1
IC861 A-5

Q121 C-2
Q133 C-2
Q441 D-3
Q446 D-2
Q447 D-3
Q450 C-1
Q451 D-1
Q457 C-1
Q501 C-2
Q510 C-2
Q511 B-3
Q551 B-3
Q581 B-3
Q640 C-3
Q656 A-4
Q671 B-4
Q692 A-3
Q701 B-2
Q721 B-2
Q726 B-2
Q733 B-1
Q736 A-2
Q738 A-2
Q751 A-2
Q797 C-1

RV145 D-2
RV622 B-4
RV623 B-4
RV682 A-5
RV718 B-2
RV785 B-1
RV796 C-1

TP21 D-3
TP22 D-3
TP23 D-4
TP24 D-4
TP34 D-3
TP35 D-3
TP71 C-4
TP72 C-4
TP73 C-4
TP101 E-3
TP501 C-2
TP511 B-2
TP672 A-3
TP691 A-4
TP751 A-2

CAB BOARD



CAB -A SIDE-
SUFFIX: -11

CAB BOARD (B SIDE)


D525 C-3
D527 C-3
D611 C-2
D612 B-3
D615 B-2
D625 A-2
D650 B-1
D667 A-1
D691 A-2
D710 B-3
D726 A-4
D787 B-4

IC18 D-1

Q141 C-4
Q502 C-3
Q525 C-3
Q527 C-3
Q563 B-2
Q605 B-3
Q610 B-3
Q618 B-2
Q625 A-2
Q631 B-2
Q641 A-1
Q645 B-1
Q647 B-1
Q691 A-2
Q695 A-1
Q723 B-4
Q751 A-4
Q752 A-4
Q781 B-4


RV622 B-2
RV623 A-1
RV682 A-1
RV718 B-4
RV785 B-5

TP11 D-4
TP502 C-4
TP512 B-3
TP551 A-3
TP752 A-4




CAB -B SIDE-
SUFFIX: -11

CAB BOARD WAVEFORMS




CAB (1/3) BOARD



CAB (1/3)
(BLUE PRE AMP)


B-%SX1640<AEP>-CAB-1

CAB (2/3) BOARD




CAB (3/3)

CAB (3/3) BOARD




CAB BAORD (2/3) IC570
TC4W53FU




CAB (3/3)
(BLUE PRE AMP)

B-%SX1640<AEP>-CAB-3


CBB BOARD

CBB -B SIDE-
SUFFIX: -11



CDB BOARD (A SIDE)


RV965 C-4
RV1223 D-5



CDB -A SIDE-
SUFFIX: -11


CDB BOARD (B SIDE)

TP810	D-6
TP811	C-6
TP891	D-4
TP910	C-1
TP911	B-3
TP912	A-1
TP951	B-5
TP981	A-3
TP982	B-3
TP991	D-3
TP1201	D-2




CDB -B SIDE-
SUFFIX: -11

CDB BOARD WAVEFORMS




CDB BOARD




CDB
(BLUE VIDEO OUT)

CAG BOARD
CAG BOARD (A SIDE)

- | | |
|-------|-----|
| D12 | E-5 |
| D13 | D-4 |
| D22 | C-5 |
| D24 | C-4 |
| D121 | C-2 |
| D155 | C-2 |
| D501 | C-2 |
| D511 | B-2 |
| D512 | B-3 |
| D581 | C-3 |
| D651 | A-4 |
| D652 | A-4 |
| D672 | B-4 |
| D726 | A-1 |
| D737 | A-2 |
| D738 | A-2 |
| D761 | A-2 |
| IC12 | D-4 |
| IC22 | C-5 |
| IC24 | C-5 |
| IC101 | D-4 |
| IC102 | D-2 |
| IC141 | D-2 |
| IC171 | C-3 |
| IC560 | B-4 |
| IC570 | B-3 |
| IC595 | B-3 |
| IC781 | B-1 |
| IC861 | A-5 |
| Q121 | C-2 |
| Q133 | C-2 |
| Q441 | D-3 |
| Q446 | D-2 |
| Q447 | D-3 |
| Q450 | C-1 |
| Q451 | D-1 |
| Q457 | C-1 |
| Q501 | C-2 |
| Q510 | C-2 |
| Q511 | B-3 |
| Q551 | B-3 |
| Q581 | B-3 |
| Q640 | C-3 |
| Q656 | A-4 |
| Q671 | B-4 |
| Q692 | A-3 |
| Q701 | B-2 |
| Q721 | B-2 |
| Q726 | B-2 |
| Q733 | B-1 |
| Q736 | A-2 |
| Q738 | A-2 |
| Q751 | A-2 |
| Q797 | C-1 |
| RV145 | D-2 |
| RV622 | B-4 |
| RV623 | B-4 |
| RV682 | A-5 |
| RV718 | B-2 |
| RV785 | B-1 |
| RV796 | C-1 |
| TP21 | D-3 |
| TP22 | D-3 |
| TP23 | D-4 |
| TP24 | D-4 |
| TP34 | D-3 |
| TP35 | D-3 |
| TP71 | C-4 |
| TP72 | C-4 |
| TP73 | C-4 |
| TP101 | E-3 |
| TP501 | C-2 |
| TP511 | B-2 |
| TP672 | A-3 |
| TP691 | A-4 |
| TP751 | A-2 |



CAG -A SIDE-
SUFFIX: -11





CAG -B SIDE-
SUFFIX: -11

CAG BOARD (B SIDE)


- | | |
|-------|-----|
| D525 | C-3 |
| D527 | C-3 |
| D611 | C-2 |
| D612 | B-3 |
| D615 | B-2 |
| D625 | A-2 |
| D650 | B-1 |
| D667 | A-1 |
| D691 | A-2 |
| D710 | B-3 |
| D726 | A-4 |
| D787 | B-4 |
| IC18 | D-1 |
| Q141 | C-4 |
| Q502 | C-3 |
| Q525 | C-3 |
| Q527 | C-3 |
| Q563 | B-2 |
| Q605 | B-3 |
| Q610 | B-3 |
| Q618 | B-2 |
| Q625 | A-2 |
| Q631 | B-2 |
| Q641 | A-1 |
| Q645 | B-2 |
| Q647 | B-1 |
| Q691 | A-2 |
| Q695 | A-1 |
| Q723 | B-4 |
| Q751 | A-4 |
| Q752 | A-4 |
| Q781 | B-4 |
| RV622 | B-2 |
| RV623 | A-1 |
| RV682 | A-1 |
| RV718 | B-4 |
| RV785 | B-5 |
| TP11 | D-4 |
| TP502 | C-4 |
| TP512 | B-3 |
| TP551 | A-3 |
| TP752 | A-4 |

CAG BOARD WAVEFORMS




CAG (1/3) BOARD

CAG (2/3) BOARD




CAG (3/3) BOARD




CAG (3/3)
(GREEN PRE AMP)

B-SX1640-AEP-CAG-3


CAG BOARD (2/3) IC570
TC4W53FU




CBG BOARD



CBG -A SIDE-
SUFFIX: -11




CDG BOARD
CDG BOARD (A SIDE)




CDG -A SIDE-
SUFFIX: -11

CDG BOARD (B SIDE)




CDG -B SIDE-
SUFFIX: -11

CDG BOARD WAVEFORMS



CDG BOARD




CAR BOARD

CAR BOARD (A SIDE)


- 1
- 2
- 3
- 4
- 5

D12	E-5
D13	D-4
D22	C-5
D24	C-4
D121	C-2
D155	C-2
D501	C-2
D511	B-2
D512	B-3
D581	C-3
D651	A-4
D652	A-4
D672	B-4
D726	A-1
D737	A-2
D738	A-2
D761	A-2
IC12	D-4
IC22	C-5
IC24	C-4
IC101	D-4
IC102	D-2
IC141	D-2
IC171	C-3
IC560	B-4
IC570	B-3
IC595	B-3
IC781	B-1
IC861	A-5
Q121	C-2
Q133	C-2
Q441	D-3
Q446	D-2
Q447	D-3
Q450	C-1
Q451	D-1
Q457	C-1
Q501	C-2
Q510	C-2
Q511	B-3
Q551	B-3
Q581	B-3
Q640	C-3
Q656	A-4
Q671	B-4
Q692	A-3
Q701	B-2
Q721	B-2
Q726	B-2
Q733	B-1
Q736	A-2
Q738	A-2
Q751	A-2
Q797	C-1
RV145	D2
RV622	B-4
RV623	B-4
RV682	A-5
RV718	B-2
RV785	B-1
RV796	C-1
TP21	D-3
TP22	D-3
TP23	D-4
TP24	D-4
TP34	D-3
TP35	D-3
TP71	C-4
TP72	C-4
TP73	C-4
TP101	E-3
TP501	C-2
TP511	B-2
TP672	A-3
TP691	A-4
TP751	A-2



CAR -A SIDE-
SUFFIX: -11


CAR BOARD (B SIDE)




CAR -B SIDE-
SUFFIX: -11

D525	C-3
D527	C-3
D611	C-2
D612	B-3
D615	B-2
D625	A-2
D650	B-1
D667	A-1
D691	A-2
D710	B-3
D726	A-4
D787	B-4
IC18	D-1
Q141	C-4
Q502	C-3
Q525	C-3
Q527	C-3
Q563	B-2
Q605	B-3
Q610	B-3
Q618	B-2
Q625	A-2
Q631	B-2
Q641	A-1
Q645	B-2
Q647	B-1
Q691	A-2
Q695	A-1
Q723	B-4
Q751	A-4
Q752	A-4
Q781	B-4
RV622	B-2
RV623	A-1
RV682	A-1
RV718	B-4
RV785	B-5
TP11	D-4
TP502	C-4
TP512	B-3
TP551	A-3
TP752	A-4

CAR BOARD WAVEFORMS




CAR (1/3) BOARD


CAR (1/3)
(RED PRE AMP)

B-SX1640-AEP-CAR-1

CAR (2/3) BOARD



CAR (2/3) BOARD



CAR (3/3)
(RED PRE AMP)

B-56X1640<AEP>-CAR-3

10-150

10-150

VPH-G90J/G90E/G90U/G90M

A

B

C

D

E



F

G


H

CAR CBR

**CAR BOARD (2/3) IC570
TC4W53FU**


**CBR BOARD**

CBR -B SIDE-
SUFFIX: -11



CDR BOARD
CDR BOARD (A SIDE)


D811	B-2
D812	C-2
D832	D-2
D833	D-2
D841	D-2
D842	E-2
D851	B-3
D861	C-3
D941	C-5
D942	C-5
D961	D-4
D965	C-3
D1211	D-5
D1215	D-5
IC801	C-1
IC851	B-3
IC861	C-3
IC901	B-5
IC961	D-4
IC971	D-3
IC981	C-3
IC1211	D-5
Q819	D-1
Q821	E-1
Q948	D-4
Q961	D-3
Q1204	E-5
Q1210	E-6
RV965	C-4
RV1223	D-5



CDR -A SIDE-
SUFFIX: -11


CDR BOARD (B SIDE)


D801	A-4
D806	A-5
D811	B-5
D812	C-5
D820	C-5
D821	C-5
D831	E-5
D832	D-5
D833	D-5
D841	D-4
D842	E-4
D901	A-2
D906	A-2
D941	C-2
D942	C-2
D945	D-2
D955	B-2
D960	D-3
D981	C-3
D982	C-3
D1001	D-3
IC801	B-5
IC802	D-5
IC901	C-1
IC902	B-2
IC990	C-3
IC998	C-3
Q801	A-4
Q802	A-4
Q806	A-4
Q807	A-4
Q815	D-5
Q819	D-6
Q821	D-6
Q901	B-3
Q902	A-2
Q906	A-2
Q907	B-2
Q948	C-2
Q974	B-3
Q1204	D-1
Q1210	E-1
RV965	C-3
RV1223	D-2
TP810	D-6
TP811	C-6
TP891	D-4
TP910	C-1
TP911	B-3
TP912	A-1
TP951	B-5
TP981	A-3
TP982	B-3
TP991	D-3
TP1201	D-2



CDR -B SIDE-
SUFFIX: -11

CDR BOARD WAVEFORMS




CDR BOARD

CDR
(RED VIDEO OUT)


B-%SX1640<AEP>-COR

F F

F BOARD



F -A SIDE-
SUFFIX: -11




F -B SIDE-
SUFFIX: -11

10-154

10-154

F F



GA BOARD


1

2

3


4

5



GA -A SIDE-
SUFFIX: -11

GA BOARD



GA -B SIDE-
SUFFIX: -11

GA BOARD


1

2


3

4


5




GAA BOARD



GAA -A SIDE-
SUFFIX: -11




GAA -B SIDE-
SUFFIX: -11




GB BOARD

1
2
3
4
5



GB -A SIDE-
SUFFIX: -11

GB BOARD



GB -B SIDE-
SUFFIX: -11

GB (1/2) BOARD


1

2

3

4


5



GB(1/2)
(LOW B REG)

B-SX1640-CAEP>-GB-1

GB (2/2) BOARD



GBA BOARD


1

2


3

4


5



GBA -A SIDE-
SUFFIX: -11



GBA -B SIDE-
SUFFIX: -11

GBA BOARD

GBB BOARD


1

2


3

4

5




GBB -A SIDE-
SUFFIX: -11




GBB -B SIDE-
SUFFIX: -11

GBB BOARD



GC BOARD


1



GC -A SIDE-
SUFFIX: -11

2

3




GC -B SIDE-
SUFFIX: -11

4


5

GC BOARD



M M

M BOARD



M -A SIDE-
SUFFIX: -11

10-170

10-170

VPH-G9/J/G90E/G90U/G90M

A

B

C

D

E


F

G

H

M M

M BOARD



M -B SIDE-
SUFFIX: -11

VPH-G90J/G90E/G90U/G90M

10-171

10-171

A

B

C

D

E

F

G

H

1

2

3

4

5

M (1/3) BOARD


1

2


3

4

5




M (2/3) BOARD




M (2/3)


M (3/3) BOARD



MA BOARD



MA -A SIDE-
SUFFIX: -11



MA -B SIDE-
SUFFIX: -11

M (1/2) BOARD


1

2


3

4

5




MA (2/2) BOARD



MB BOARD

1




2

3

MB -A SIDE-
SUFFIX: -11


4

5




MB -B SIDE-
SUFFIX: -11

MB BOARD




MB
(INPUT B MOTHER)

MC BOARD



MC -A SIDE-
SUFFIX: -11



MC -B SIDE-
SUFFIX: -11

VPH-G90J/G90E/G90U/G90M

A


B

C

D

10-179

MC BOARD



MC
(INPUT C MOTHER)

10-179

E

F

G

H

MD BOARD


1

2


3

4


5




MD -A SIDE-
SUFFIX: -11




MD -B SIDE-
SUFFIX: -11




EC BOARD




EC -A SIDE-
SUFFIX: -11




EC -B SIDE-
SUFFIX: -11



ME BOARD



ME -A SIDE-
SUFFIX: -11



ME -B SIDE-
SUFFIX: -11

